


## Parts & Functions




- 1 Pressure Vent
- 2 Earpiece
- 3 Display
- 4 Light Sensor
- 5 Mic
- 6 External Device Port (with Port Cover)
- 7 Sub-display
- 8 Notification Lamp
- 9 Strap Eyelet
- 10 Charging Terminals
- 11 Internal Antenna Area
- 12 Infrared Port
- 13 Camera (Lens Cover)
- 14 Speaker
- 15 Mobile Light
- 16 Logo
- 17 Battery Cover

- Do not cover or place stickers, etc. over Light Sensor or Internal Antenna area.
- Close Port Cover after External Device Port use.
- Avoid metal Straps; may affect signal reception.

### Opening External Device Port Cover

- Pull at notch to open Port Cover.



### Handset Positions

#### Handset Closed

Keep handset closed when not in use.




#### Handset Open

Open handset to place or answer calls, enter text, etc.



## Handset Keys

- Keys are indicated in this guide as shown.
- Change assigned functions indicated \* with Set Key Shortcut.

**1 Multi Selector (right)**

Open Icon View. Long Press to access last opened Icon View page\*.

**2 Multi Selector (up)**

Open Mobile Widget window. Long Press to open PC Site Browser menu\*.

**3 Center Key**

Open Main Menu. Long Press to activate/cancel Keypad Lock.

**4 Multi Selector (left)**

Open Call Log (All). Long Press to enable/disable Bluetooth®.

**5 Mail Key**

Open Messaging menu. Long Press to open SI Mail Composition window\*.

**6 Shortcuts & A/a Key**

Open Shortcuts.

**7 Clear/Back Key**

Play Answer Phone messages. Long Press to activate/cancel Answer Phone.

**8 Start & Rakutomo Link Key**

Open Rakutomo Link. Long Press to open Double Number Mode menu.

**9 Dialpad**

Enter numbers to place calls or access functions. Long Press to open Phone Book.

**10 \* Key**

Enter \*, +, P, ? and -.

**11 Camera Key**

Activate Camera.

**12 Yahoo! Keitai Key**

Open Yahoo! Keitai portal. Long Press to open Bookmarks list\*.

**13 TV & Dictionary Key**

Activate TV. Long Press to open Dictionary.

**14 Multi Selector (down)**

Open Phone Book. Long Press to open Exchange Profile\*.

**15 Power On/Off & End Key**

Long Press to power off.

**16 # Key**

Enter #. Long Press to activate/cancel Manner mode.

**17 Multi Job & Manner Key**

Select handset mode. Long Press to activate/cancel Manner mode.

## Side Keys

**18 Volume Up Key**

**Handset Closed:** Long Press to illuminate Mobile Light.

**19 Volume Down Key**

**Handset Open:** Show/hide Softkeys. Long Press to enable/disable VeilView.

**20 Shutter Key**

**Handset Closed:** Toggle Clock view.  
**Handset Open:** Long Press to activate Video Camera.

## Multi Selector &amp; Side Keys

- In this guide, Multi Selector and Side Key operations are indicated as follows:

Press  or	
Press  or	
Press , ,  or	
Press  or	

## Battery & USIM Card Installation


Do not apply excessive force to Battery or USIM Card.

### Inserting

USIM Card must be inserted to use handset.


#### 1 Remove Battery Cover

Battery Cover




- Use notch to lift Battery Cover. Push up Battery Cover along edges to remove it.

#### 2 Use tab to pull out USIM Tray




#### 3 Slide in USIM Card with IC chip facing up



#### 4 Secure USIM Tray

#### 5 Insert Battery



- With logo side facing up, align Battery terminals with contacts.

#### 6 Replace Battery Cover




- Fit Battery Cover into slot, then firmly press down along edges.
- Close Battery Cover firmly. Debris trapped between gasket and base may expose handset to liquid/dust.

### Removing

Always power off first.

#### 1 Remove Battery Cover

#### 2 Remove Battery



- Lift Battery as shown.

#### 3 Pull out USIM Tray

#### 4 Lift and slide out USIM Card

- Secure USIM Tray, insert Battery and replace Battery Cover.
- Take care not to lose removed USIM Card.

#### After USIM Card Removal (Contract Termination, Handset Upgrade/ Replacement, Repairs, Etc.)

- Some files on handset and Memory Card may be inaccessible. Inserting another USIM Card may disable S! Appli and BookSurfing®.

## About Battery

- Charge Battery at least once every six months; uncharged Battery may die or affect files/settings.
- Depending on usage, bulges may appear near end of battery life; this does not affect safety.
- Replace Battery if operating time shortens noticeably.
- Clean Battery terminals and charging terminals with a dry cotton swab, etc.
- To maintain water/dust resistance, close Battery Cover properly. Debris trapped between gasket and base may expose handset to liquid/dust.
- If Battery Cover is damaged, replace it with a new one. Use of damaged Battery Cover may cause electric shock, battery corrosion, etc. due to water seepage.
- Battery is not water or dust proof.

### Lithium-ion Battery

- This product requires a lithium-ion battery. Lithium-ion batteries are recyclable.
  - To recycle a used lithium-ion battery, take it to any shop displaying the recycling symbol.
  - To avoid fire or electric shock, do not short circuit or disassemble Battery.



Li-ion00

## About USIM Card

USIM Card is an IC card containing customer and authentication information, including handset number. Save contacts on USIM Card Phone Book to use them on other SoftBank handsets. Depending on USIM Card in use, some entry items may not be supported, and some limits (character entry, etc.) may be lower.

### Precautions

- Do not insert USIM Card into any other IC card device. SoftBank Mobile is not liable for resulting damages.
- Keep USIM Card IC chip clean; debris may cause malfunction. Clean with a soft dry cloth.
- Do not attach labels to USIM Card. Malfunction may result.

### Important

- USIM Card is the property of SoftBank Mobile.
- USIM Card will be reissued for a fee if lost or damaged, etc.
- Return USIM Card to SoftBank Mobile upon contract termination.
- Returned USIM Cards are recycled.
- USIM Card specifications may change without prior notice.
- Keep a copy of information saved on USIM Card in a separate place. SoftBank Mobile is not liable for loss of information.
- If USIM Card or handset (with USIM Card inserted) is lost or stolen, suspend your service immediately. For details, contact SoftBank Customer Support, General Information (P.9-1).

## USIM PIN

**9999** by default; activate PIN Entry to restrict handset use.

### PIN Lock

- Entering incorrect PIN three consecutive times activates PIN Lock, limiting handset use.

### Canceling PIN Lock

- Contact SoftBank Customer Support, General Information (P.9-1) for your Personal Unblocking Key (PUK) and follow these steps:

Enter PUK →  → Enter new PIN →

→ Re-enter new PIN →

- Do not forget PUK; write it down if necessary.

### PUK Lock

- Entering incorrect PUK ten consecutive times activates PUK Lock, disabling handset. For recovery, USIM Card must be reissued at a SoftBank Shop (fees apply).

## Charging Battery (Desktop Holder)

Battery must be inserted in handset to charge it.

### Charging Battery Outside Japan

- SoftBank Mobile is not liable for problems resulting from charging Battery abroad.

### Important AC Charger Usage Note


- Retract blades after charging. Do not pull, bend or twist cord.

### When Notification Lamp is Flashing

- Battery is unchargeable; may be defective or simply at the end of its life; replace it.

Use Desktop Holder with AC Charger ZTDAA1 (optional accessory).

- In this guide, ZTDAA1 is referred to as "AC Charger."
- **AC Charger and Desktop Holder are not water or dust proof. Do not charge Battery while handset is wet.**
- Handset/AC Charger may become warm while charging.




### 1 Insert Charger connector into Desktop Holder

- Insert Charger connector in the correct orientation until it clicks.

### 2 Extend blades and plug AC Charger into AC outlet



### 3 Place handset into Desktop Holder



- Push down handset until it clicks into place.
- Notification Lamp illuminates red while charging.
- Notification Lamp goes out when Battery is full.

### 4 Remove handset from Desktop Holder

### 5 Unplug AC Charger

### 6 Disconnect Charger connector from Desktop Holder

- Squeeze release tabs and pull straight out.

### Important Desktop Holder Usage Notes

- Do not subject to force/pressure.
- Do not attempt to open handset.
- Do not get Straps caught between handset and Desktop Holder.

## Power On/Off

### Power On

Described for initial power on.


#### 1 (Long Press)

- After Power On Graphics, water/dust proofing information appears; follow these steps:

 →  →  →  →  → **設定**  
 →  → **Language** →  → **English**  
 →  →  (Long Press) →   
 (Long Press) → Change Menu opens

#### 2 Select option →

Guide descriptions are based on Standard Menu.




- After Change Menu guidance, My Details setup starts.

#### 3 Enter last name → →

Enter first name → 

- Change Menu display option appears.

#### 4 Yes or No →



Standby

- Choose **No** to enter Standby immediately after powering on.

#### When USIM Card is Not Installed

- **Insert USIM Card** appears; handset is unusable.

### Retrieving Network Information

A prompt appears when , , , or  is Pressed for the first time.



To use Network-related services:  
(Clock will be set automatically.)

#### 1 Yes → → Retrieval starts

#### 2


### Power Off

#### 1 (Long Press)

- After Power Off Graphics, handset shuts down.

# Display

## Standby




Hereafter, most screenshots omit Mobile Widgets and other icons.

## Indicator Descriptions

Check active indicators and their descriptions. (Status Icon List)


### 1 Tap indicator



- Active indicators are enlarged; description for selected indicator appears.
- After ❶, Touch & Hold other indicators to view their descriptions.
- After ❶, Tap indicator to access corresponding function (e.g., Battery Meter window from battery strength indicator); may be unavailable for some indicators.

## Information Window

Opens at the bottom for missed calls, new mail, etc.



Information Window

Information label (e.g., **Message**, etc.) and count appear. Select an item and Press to open it.

### Opening Information List Manually

**Phone** **Information**

### Clearing Information List

**Phone** **Information**

**Yes**

## Display Rotation

Motion Control sensor detects handset orientation. Display orientation changes with handset orientation in TV, Internet and some other functions.



Landscape Orientation

Portrait Orientation

## Softkeys

Function/operation labels appear at the bottom of Display; see key assignments below. Alternatively, Tap Touchscreen to execute the assigned function/operation.

### Portrait Orientation



### Landscape Orientation

Some key assignments may vary with window content.



## Display Saving

Display goes completely dark after set Display Saving time elapses. Press any key (except  during a call) to cancel Display Saving and reilluminate Display.

### Backlight

- Backlight turns off after Time Out time elapses. Press  -  to illuminate it (key press may affect active function).
- Display goes completely dark during a call. (Backlight does not turn off first.)

# Indicators

## Display Indicators

When Double Number is set to Dual Mode, line type appears at the bottom right of some indicators.

### Basic Status




		Within 3G Network
<b>1</b>		Within GSM Network
		Roaming
<b>2</b>		Signal Strength <sup>1</sup>
<b>3</b>		Battery Strength <sup>2</sup>

<sup>1</sup>More bars indicate stronger signal.

<sup>2</sup>Flashes while charging; battery strength % (appears when Display activates, etc.) is an approximation.


### Function Status



		S! Appli Active*
		S! Appli Paused*
<b>1</b>		Music Playback
		TV Recording (handset)
		TV Recording (Memory Card)
		Memory Card Inserted
<b>2</b>		Accessing Memory Card
		Reading Memory Card
		Formatting Memory Card
		TV Timer/TV Recording Timer Set
<b>3</b>		Compass Indicator
<b>4</b>		Music Playback (using Bluetooth®)
<b>5</b>		Multiple Functions (Multi Job) Active

\*Appears gold for some S! Appli.

### Notifications




<b>1</b>		Unread Mail
		Unread Delivery Report
<b>2</b>		Answer Phone Active & Message Recorded
		Answer Phone Canceled & Message Recorded
<b>3</b>		New Voicemail
<b>4</b>		Missed Call or New Mail on Idle Line
<b>5</b>		S! Appli Notification
<b>6</b>		Contents Key Received
<b>7</b>		Unread S! Information Channel info
		Software Update Result
		Unread S! Quick News info
<b>8</b>		Unread Urgent News

### Warnings



<b>1</b>		Mail Memory Low
<b>2</b>		Message Delivery Failure
<b>3</b>		Memory Card Unusable/Misinserted

■ Transmissions




1		SSL Browsing <sup>1</sup>
		Packet Transmission Active
2		Receiving Mail
		Sending Mail
3		Positioning <sup>2</sup>
4		Updating Software
5		RSS-compatible Site
6		Weather Indicator
		USB Cable Connected
		USB Transmission Active
		Infrared Transmission Active
		Infrared File Transfer
		Bluetooth® Active
		Bluetooth® Transmission Active
		Bluetooth® Transmission Active (for multiple connections)
		Bluetooth® Talk Active
		IC Transmission Active
7		S! Addressbook Back-up Transmission Active
		PC Site Browser in Use
		Infrared Active

<sup>1</sup>Hidden while Mobile Widget is in use.

<sup>2</sup>Flashes while sending location information.

■ Settings



1		Offline Mode
2		Answer Phone Active
3		Call Forwarding or Voicemail Active (forwarding condition: <b>Always</b> ) <sup>*</sup>
4		Calendar/Task (Alarm Set)
		Calendar/Task (Alarm Unset)
5		Alarm Set
6		Hour Minder Active
7		Manner Mode
		Drive Mode
		Original Mode
8		VeilView Active
		Keypad Lock Active
		IC Card Lock Active
9		Ringtone (Silent)
		Ringtone (Increasing Volume)
		Vibration for Incoming Voice/Video Calls Active

10		Auto Answer or Remote Monitor Active
11		Show Secret Data Active
		Function Lock (Once) Active
12		Wakeup TV Set

<sup>\*</sup>Indicator does not appear when Call Forwarding is set to Video Calls only, with Voicemail unset.

## Sub-display

View date/time and the following indicators with handset closed.

### Activating Sub-display



- Press  to toggle view.

### Indicators

#### Basic Status



<b>1</b>	Signal Strength <sup>1</sup>
<b>2</b>	Battery Strength <sup>2</sup>

<sup>1</sup>More bars indicate stronger signal.

<sup>2</sup>Flashes while charging.

#### Notifications

	Missed Call
	Answer Phone Message Recorded
	Missed Call Notification
	New Voicemail
	Unread Mail
	Unread Delivery Report
	Contents Key Received
	Unread S! Information Channel info
	Weather Indicator Update
	Location Information Request
	Pedometer Target Achieved
	S! Appli Notification
	Auto Backup Complete
	Auto Backup Canceled
	Unread Urgent News

#### Warnings

	Message Delivery Failure
	S! Information Channel Info Reception Failure
	Weather Indicator Update Failure
	Auto Backup Failure

#### Handset Status

	Alarm
	Calendar Alarm
	Task Alarm
	TV Alarm (Watch)
	TV Alarm (Record)

## Using Touchscreen

Touch Display to select menu items, open functions, scroll pages, etc.

### Basic Operations

#### Tap



Tap item or key to open or execute corresponding function/operation.

#### Double Tap

Tap Display twice in rapid succession (within approximately 0.6 seconds).

#### Touch & Hold



Touch item for 1+ seconds to move icon, open menu, etc.

#### Drag




Drag to move item or scribble/sketch.

#### Flick



Flick to scroll.

#### Pinch & Spread



Pinch or Spread to zoom in or out on images, etc.

## Important Touchscreen Usage Notes

- Touchscreen may not respond in these situations:
  - Use with gloves/long fingernails
  - Use of pens, pencils or sharp objects
  - Use with objects on/against Display
  - When Display is wet
- To prevent malfunctions, do not:
  - Touch Display with wet fingers
  - Use if Display is wet
  - Subject Display to force/pressure
  - Place labels or stickers over Display
- Calibrate Touchscreen (P.1-14) to improve response.

## Usage Examples

### Selection & Execution

Tap item to open or execute corresponding function/operation.



Tap **Data Folder**

- The result is the same as selecting an item with  and Pressing .

### Two Taps

When Tapping item only selects (highlights) it, Tap the item again to execute function/operation.




Tap **Music** twice



Music folder opens

## Screen Scroll

For hidden items, Flick/Drag in opposite direction.




Flick right



Left portion appears

### Zoom In & Zoom Out


Pinch or Spread to zoom in or out on images, etc.



- Double-Tapping images, etc. may also zoom in/out them.
- In Internet page or before saving captured photo, Touch & Hold area/portion to zoom it in.

### Open Menus

Touch & Hold Display to open menu.



### Calibrating Touchscreen

Calibrate Touchscreen to improve response. Hold handset normally during calibration.

- 1 → **Settings** → → **Phone/**
  - 2 **Touch Panel** →
  - 3 **Correct Touch Panel** →
- 
- 4 **Yes** →
    - Follow onscreen instructions.


#### Undo Calibration

- If calibration does not improve response, restore default setting as follows:

After 4,

# Main Menu

## Opening Main Menu



■ Touchscreen



■ Handset Key




### Menu Layout




### Main Menu Items

<b>Messaging</b>	Open/create messages, etc.
<b>Yahoo!</b>	Access the Internet.
<b>S! Appli</b>	Use S! Appli including games.
<b>Entertainment</b>	Read e-Books, receive news updates, etc.
<b>Camera</b>	Shoot photos or videos.
<b>Media</b>	Play/download media files.
<b>Tools</b>	Manage schedules, set Alarm, etc.
<b>Data Folder</b>	Open files saved to handset/Memory Card.
<b>Widget</b>	Use Mobile Widgets.
<b>TV</b>	Watch/record TV programs.
<b>Phone</b>	Add/search contacts, etc.
<b>Settings</b>	Customize handset interface, sounds, etc.

**Menu Navigation** To open *World Clock* using handset keys or Touchscreen:



**Escape/Return** Example: After opening *World Clock*



# Menu List

## Messaging

Received Msg.
Create Message
Retrieve New Msg.
Drafts
Templates
Sent Messages
Unsent Messages
Chat Folder
Server Mail Box
Create New SMS
Settings
Memory Status

## Yahoo!

Yahoo! Keitai
Menu List
Bookmarks
Saved Pages
Web Search
Enter URL
History
PC Site Browser
Browser Settings

## S! Appli

S! Appli Library
Osaifu-Keitai
Settings
Information

## Entertainment

S! Information Channel/Weather
S! Quick News
Urgent News
Free Contents
S! Contents Store
Blog Tool
BookSurfing
e-Book Viewer

## Camera

Easy Auto Camera
Pro Auto Camera
Quick Camera
Rapid Shooting Camera
Best Select Photo
Fish-eye Camera
Miniaturize Camera
HD Video Camera
Pro Auto Video Camera
Album
Scan Receipt
Barcode Reader

Scan Card
Kanji/English Grabber
Review
Set Camera Key

## Media

Music
Videos
MTP Mode

## Tools

### ■ PIM/Life

Calendar
Exchange Profile
Alarms
Wakeup TV
Relaxation Time
Tasks
Household Accounts
Calculator
Expenses Memo
Osaifu-Keitai
Simulated Call

### ■ Clock/Gauge

Stopwatch
Countdown Timer
World Clock
Hour Minder
Pedometer
Compass
S! GPS Navi
Battery Meter

### ■ Doc./Rec.

Dictionary
Search
Notepad
Scratch Pad
ASCII Art
Voice Recorder
Barcode/Scan
Phone Help

### ■ Connectivity

Bluetooth
Infrared
IC Transmission
USB Mode
USB Charge
Memory Card
Backup/Restore

## Data Folder

Pictures
DCIM
Ring Songs-Tones
S! Appli
Widget
Music
Videos
Lifestyle-Appli
Books
Customized Screen
Flash®
Other Documents
Memory Status

## Widget

Widget Store
Widget Contents
Settings

## TV

TV
TV Player
TV-Image Folder
TV Link
TV Listing
Reservation List
Recorder Contents
Settings

## Phone

Phone Book
Add New Entry
Information
Call Log
Play Messages
Play Voicemail
S! Addressbook Back-up
My Details
Set Category
Mail Groups
Rakutomo Link
Speed Dial/Mail
Touch-Tone Signal List
Settings/Manage

## Settings

## ■ Sound/Display

Mode Settings
Display
Customized Screen
Sounds & Alerts
Date & Time
言語選択 (Language)
Ringer Output
Earpiece Volume
Change Menu

## ■ Phone/☎

User Dictionary
Set Key Shortcut
Motion Control
Touch Panel
Set Key Light
Double Number
Memory Card
Backup/Restore
Locks
Software Update
Master Reset

## ■ Call

Call Time/Data Counter
Answer Phone
Voicemail/Call Forwarding
Video Call
Caller ID
<input type="checkbox"/> Missed Calls
Int'l Calling
Call Barring
Auto Answer
Call Waiting

## ■ Network

Select Network
Select Service
Re-search Signal
Offline Mode
Retrieve NW Info
Network Info
External Device
Technical Regulations
Conformity Certification

## Security Codes

These codes are required for handset use. (Save Handset Code and Administrator Code beforehand.)

- Guide descriptions are given assuming that Handset Code and Administrator Code are saved.
- Do not forget Security Codes.
- Do not reveal Security Codes. SoftBank Mobile is not liable for misuse or damages.

<b>Handset Code*</b>	Use or change some functions.
<b>Administrator Code*</b>	Required for Reset Settings, Reset All, etc.
<b>Center Access Code (Network Password)</b>	Four-digit code in contract; change contract details, access Optional Services from landlines, or set Call Barring.

\*Save/change on handset.

### If Security Code is Unsaved


- Code setup message/window opens whenever Security Code is required.
- #### Incorrect Code Entry
- Message appears for incorrect code entries; retry.
  - Call Barring settings will be locked if incorrect Center Access Code (Network Password) is entered three times consecutively when making a setting. To unlock, the code must be changed.
    - If Network Password has been previously changed on a mobile phone, enter the latest code to set Call Barring.

### Saving Handset Code

Enter four to eight digits.

1  ➔ **Settings** ➔  ➔ 

2 **Locks** ➔ 



Locks Menu

3 **Handset Code Settings** ➔ 

4 **Save Handset Code** ➔ 

5 **Enter Handset Code** ➔ 

6 **Re-enter Handset Code** ➔ 

### Changing Handset Code

After 5, enter current Handset Code ➔

 ➔ **Enter new Handset Code** ➔ 

➔ **Re-enter new Handset Code** ➔ 

**Saving Administrator Code**

Enter four to eight digits.

- 1 In Locks menu, Administrator Setting** ➔
- 2 Register Administrator Code** ➔
- 3 Enter Administrator Code** ➔
- 4 Re-enter Administrator Code** ➔

**Changing Administrator Code**

After **2**, enter current Administrator Code

- ➔  ➔ Enter new Administrator Code
- ➔  ➔ Re-enter new Administrator Code
- ➔

**Need/UnNeed Setting**

For enhanced security, set Need/UnNeed Setting to **Need**; then Handset Code will be required to delete all files/entries, etc.

- 1 In Locks menu, Handset Code Settings** ➔
- 2 Need/UnNeed Setting** ➔
- 3 Need** ➔  ➔ Enter Handset Code ➔

## Mobile Manners

Please use your handset responsibly. Take care not to disturb others when using your handset.

- Keep handset off in theaters, museums and other places where silence is the norm.
- Refrain from use in restaurants, hotel lobbies, elevators, etc.
- Observe signs and instructions regarding handset use aboard trains, buses, etc.
- Refrain from use that interrupts the flow of pedestrian or vehicle traffic.

### Manner Mode

Mutes most handset function sounds.

#### 1 (Long Press)



Indicator

- Manner mode activates.

### When Manner Mode is Active

- Ringtones and other sounds are muted.
- Handset vibrates for incoming transmissions, etc.
- Shutter click and Urgent News alert tones still sound at fixed volume.
- To unmute Speaker temporarily while playing music, etc.:

During playback,  ➔  ➔ Yes or No ➔  ➔ Adjust Volume

### Canceling Manner Mode

 (Long Press)


### Offline Mode

Suspend signal transmission and reception. Handset will be unable to place/receive calls, send/receive messages, access the Internet, etc.

#### 1 ➔ Settings ➔ ➔ Network

#### 2 Offline Mode ➔

#### 3 On ➔



- Offline Mode activates.

### Canceling Offline Mode

In , Off ➔ 

## My Details & Basic Settings

### Handset Number & Address

1  →  → 0\*\*



- Handset number, mail address (unsaved by default) and the name entered at initial setup appear.

### Editing My Details

After 1,  (select tab) → Select item →  → Select item →  → Edit →

### Date & Time

1  → *Settings* →  → In Sound/Display menu, *Date & Time* →

2 *Set Date/Time* →

3 Enter the year → Enter the month → Enter the day → Enter the time →

- If confirmation appears, choose *Yes* and Press .

### Language

1  → *Settings* →  → In Sound/Display menu, *Language* or *言語選択* →

2 *English* or *日本語* →

## Using World Clock

### Auto World Clock

Powering on outside Japan automatically sets World Clock; the local time for your current location appears in Standby. Powering on after arriving back to Japan restores original Clock setting and Clock view.

### Disabling Auto World Clock

- 1  → **Settings** →  → In **Sound/Display menu, Date & Time** → 
- 2 **Auto World Clock** → 
- 3 **Disabled** → 

### Setting World Clock Manually

- 1  → **Tools** →  →  → **Clock/Gauge** → **World Clock** → 



- 2 



Set Time Zone Window

- 3  → **Select city** → 

- 4  → **Standby returns**

### Advancing One Hour (Daylight Saving)

[Set Time Zone Window] 

- To cancel, Press .

### Adding Custom Time Zone

[Set Time Zone Window]  → Enter city name →  →  + or - →  → Enter time difference → 

### Showing World Clock in Standby Manually

- 1  → **Settings** →  → In **Sound/Display menu, Display** → 
- 2 **Standby Display** → 
- 3 **Clock/Calendar** → 
- 4 **World Clock (L), etc.** → 
- 5  → **Standby returns**

## Using Memory Card

### About Memory Card

Use microSD/microSDHC Memory Card to save and organize files for use on handset.


- Use recommended Memory Cards only. For details, contact SoftBank Customer Support, General Information (P.9-1).
- **If Memory Card is inserted, captured photos, downloads and other files are saved to Memory Card. (My Pictograms and Graphic Mail templates are saved to handset.)**

### Memory Card Cautions

- Do not force Memory Card into or out of handset.
- Keep Memory Card out of infants' reach; may cause choking if swallowed.
- Do not touch terminals or expose them to metal objects.
- SoftBank Mobile is not liable for any damages resulting from accidental loss/alteration of information. Keep a copy of contacts, etc. in a separate place.
- Never power off or remove Battery while files are being accessed.
- Be careful not to erase or overwrite files accidentally.

### Memory Card Slot Location

Memory Card Slot is located above USIM Card Slot. Do not insert Memory Card into USIM Card Slot.




## Inserting & Removing

Always power off first.

### 1 Remove Battery (P.1-3)

### 2 Insert Memory Card



- Insert Memory Card (terminals facing down) all the way until it clicks.
- Do not insert other objects.

### 3 Insert Battery, then replace Battery Cover (P.1-3)

#### If Appears after Power On

- Memory Card may not be inserted properly; reinsert it.

#### Removing Memory Card

- Gently push in Memory Card and release it; Memory Card pops out. Carefully remove Memory Card without bending it.



## Formatting Memory Card

When using a new Memory Card for the first time, format it on handset before trying to save files, etc. Formatting deletes all Memory Card files.

1  ➔ **Settings** ➔  ➔   
**Phone/** ➔ **Memory Card**  
 ➔ 

2 **Format Card** ➔  ➔ **Yes**  
 ➔ 

- Offline Mode activates; signal transmission and reception are suspended until formatting is complete.

3 **Yes** ➔   
 • To cancel, choose **No** and Press .

#### Precaution

- Never power off or remove Battery while formatting; may damage Memory Card or handset.