


Handset Parts	1-2
Parts & Functions	1-2
Charging Battery	1-4
Charging Battery (AC Charger)	1-4
Charging Battery (In-Car Charger)	1-5
Power On/Off	1-6
Handset Power On/Off	1-6
Display & Indicators	1-7
Display	1-7
Indicators	1-8
Accessing Functions	1-11
Main Menu	1-12
Shortcuts Menu & Key Shortcut	1-13
Toggling Active Functions (Multi Job)	1-14
Standby Shortcuts	1-15
Using Simplified Menus (Simple Menu)	1-16

Mobile Manners	1-17
Security Codes	1-18
Basic Tools	1-19
My Details & Basic Tools	1-19
Double Number	1-21
Using Double Number	1-21
Modes	1-22
Additional Functions	1-24
Troubleshooting	1-27

1

Getting Started

Parts & Functions



- 1 Earpiece
- 2 Display
- 3 TV Antenna Location
- 4 Microphone
- 5 External Device Port (with Port Cover)
- 6 External Display
- 7 Small Light
- 8 Strap Eyelet
- 9 Headphone Port (with Port Cover)
- 10 Charging Terminals
- 11 Memory Card Slot (with Slot Cover)
- 12 Internal Antenna Location
- 13 External Camera (lens cover)
- 14 Mobile Light
- 15 Infrared Port
- 16 Speaker
- 17 Battery Cover
- 18 Logo

- Do not cover or place stickers, etc. over Internal Antenna area.
- Replace Port/Slot Cover after Port/Slot use.
- Avoid metallic straps; Antenna sensitivity may be affected.

Handset Positions

Handset Closed



Keep handset closed when not in use.


Handset Open



Open handset to place or answer calls, enter text, etc.

Handset Keys

- Keys are indicated in this guide as shown.
- Change functions with * via Set Key Shortcut as needed.



- 1 Multi Selector (right)** Open Received Calls. Long Press to activate/cancel infrared.
- 2 Multi Selector (up)** Open Mobile Widget window. Long Press to open PC Site Browser menu.
- 3 Center Key** Open Main Menu. Long Press to activate/cancel Keypad Lock.

- 4 Multi Selector (left)** Open Dialed Numbers. Long Press to activate/cancel IC Card Lock.
- 5 Mail Key** Open Messaging menu. Long Press to open S! Mail Composition window.
- 6 A/a Key** Open Shortcuts menu. Long Press to show active indicators (Status Icon List).
- 7 Back Key** Play Answer Phone messages. Long Press to activate/cancel Answer Phone.
- 8 Start Key** Open All Calls. Long Press to open Double Number Mode menu.
- 9 Keypad** Enter numbers to place calls or access functions (Quick Operations). Long Press to open Phone Book.
- 10 * Key** Enter *, +, P, ? and -. Long Press to open S! Friend's Status member list.
- 11 Dictionary Key** Open Dictionary. Long Press to activate VeilView.
- 12 Yahoo! Keitai Key** Open Yahoo! Keitai portal. Long Press to open Yahoo! Keitai menu.
- 13 TV & Text Key** Activate TV. Long Press to open Change Menu window.
- 14 Multi Selector (down)** Open Phone Book. Long Press to create new Phone Book entries.

- 15 Power On/Off Key** Toggle Standby display. Long Press to turn handset power off.
- 16 # Key** Enter #. Long Press to activate/cancel Manner mode.
- 17 Multi Job & Manner Key** Select handset mode. Long Press to activate/cancel Manner mode.

Side Keys

- 18 S! Circle Talk Key** **Open:** Open S! Circle Talk member list. Long Press to activate mobile camera. **Closed:** Toggle Clock view. Long Press to illuminate Mobile Light.
- 19 Volume Up Key** **Closed:** Scroll External Display indicators. Long Press to check e-money balance.
- 20 Volume Down Key** Long Press to start Simulated Call. **Closed:** Scroll External Display indicators.

Multi Selector & Side Keys

- In this guide, Multi Selector and Side Key operations are indicated as follows:


Press or	
Press or	
Press , , or	
Press or	

1 Charging Battery (AC Charger)

Getting Started

Battery must be inserted in handset to charge it.

- Use specified AC Charger **ZTDAA1** (sold separately) only. In this guide, ZTDAA1 is referred to as "AC Charger."
- Handset and AC Charger may warm during charging.



Important AC Charger Usage Note

- Fold back blades after charging. Do not pull, bend or twist the cord.


1 Open Port Cover as shown



2 Connect AC Charger


- With arrows up, insert connector until it clicks.

3 Extend blades and plug AC Charger into AC outlet



- Small Light illuminates red while charging.
- Small Light goes out when battery is full.

4 Unplug AC Charger



- Pull AC Charger straight out.

5 Disconnect handset

- Squeeze release tabs to remove connector.

6 Fold back blades and replace Port Cover

When Small Light Flashes

- Battery is unchargeable; may be defective or simply at the end of its life; replace it.

USB Charge

- Connect handset (with power on) to PC via USB Cable to charge battery.

Charging Battery Overseas


- SoftBank is not liable for problems resulting from charging battery abroad.

Advanced

- Disabling USB Charge (P.1-24)

Charging Battery (In-Car Charger)

In-Car Charger may be purchased separately.



1 Open Port Cover as shown



2 Connect In-Car Charger

- With arrows up, insert connector until it clicks.

3 Plug Charger into cigarette lighter socket

4 Start car engine

- Small Light illuminates red while charging.
- Small Light goes out when battery is full.

5 Unplug Charger

6 Disconnect handset

- Squeeze release tabs to remove connector.

7 Replace Port Cover

Important In-Car Charger Usage Notes

- Disconnect Charger before leaving vehicle to prevent charging with engine off.
- Do not use In-Car Charger with Desktop Holder.
- Avoid charging battery inside extremely hot vehicles.

Handset Power On/Off

Power On

Follow these steps when powering on 831SH s for the first time:

1 (Long)

- After Power On Graphic, follow the steps below.

→ → → → → **設定**
 → → **Language** → → **English**
 → (Long) → (Long) →
 Change Menu window opens

2 Select option →

Guide descriptions are based on Large Font Menu.



- My Details setup starts.

3 Enter last name → → Enter first name →

- Change Menu display option confirmation appears.

4 Yes or No →



Standby


- Choose **No** to enter Standby immediately after powering on.

When USIM Card is Not Installed

- Insert USIM Card** appears; insert the card to use handset.

Retrieving Network Information

Handset initiates Network Information retrieval when , , or is pressed for the first time.



Follow these steps to retrieve Network Information to use Network-related services and TV; retrieval automatically sets Clock:

1 Yes → → Retrieval starts

2

Power Off

1 (Long)

- After Power Off Graphic, handset shuts down.

Display

Standby

Indicators

Indicators (signal strength, battery strength, active functions, etc.) appear.




Major Indicators

	Signal strength		Memory Card inserted
	Unread mail		Alarm set
	Manner mode active		Battery strength

Information

Information window opens at the bottom for Missed Calls, new mail, etc.




Information Window

Information label (e.g., **Message**, etc.) and count appear in Information window. Select an item and press to open it.

Softkeys

Functions/operations assigned to , , and appear at the bottom.



Display Saving

- Display goes dark after Display Saving time elapses. Press any key to activate it.

Backlight




- Backlight turns off after Time Out time elapses. Press - to illuminate it (key press may affect active function).

Advanced


- Handling Information list (P.1-24)








Indicators

Display Indicators

Descriptions based on Standard Menu.
,  and  indicate line type in Dual Mode (**P.1-21**).

Basic Status












1		International roaming in progress
2		Signal strength ¹
3		Battery strength (% ² appears in turn)
4		Packet transmission protocol ready (3G)
		Packet transmission protocol ready (GSM)
		Within 3G range
		Within GSM range

¹The more bars the better.


²Battery strength % is an approximation.

Function Status



1		Active S! Application
		Paused S! Application
		Music playback in progress
		TV recording in progress
2		Memory Card in use
		Memory Card formatting
		TV Timer/TV Recording Timer set
3		Multiple functions (Multi Job) active

■ Notifications




1	✉	Unread mail
2	✉	Unread Delivery Report
3	☎	Answer Phone active & message recorded
	☎	Answer Phone canceled & message recorded
4	☎	New Voicemail
5	➡	Missed Call or new mail on idle line
6	🎮	S! Appli/Mobile Widget Notification
7	🔑	Contents Key received
	📄	Unread S! Information Channel info
8	📄	Software Update result
	📄	Unread S! Quick News info
9	📄	Unread S! Friend's Status notification or unanswered registration request

■ Warnings



1	✉	Mail memory low
2	✉	Message delivery failure
3	💳	Memory Card unusable/misinserted

■ Transmissions




	🔒	SSL browsing in progress ¹
1	📶	Waiting packet transmission (3G)
	📶	Waiting packet transmission (GSM)
2	✉	Receiving mail
	✉	Sending mail
3	📄	S! Friend's Status online
4	📶	Positioning in progress ²
	📶	Software Update in progress
5	🔌	USB Cable connected
	📶	USB transmission in progress
	📶	Infrared transmission in progress
	📶	Infrared file transfer in progress
	🔄	S! Addressbook Back-up transmission in progress
6	💻	PC Site Browser in use
	📶	RSS-compatible site
7	☀	Weather Indicator
8	📶	Infrared transmission ready

¹Hidden while Mobile Widget is in use.

²Flashes while positioning.

■ Settings



1	📱	Offline Mode active
2	☎	Answer Phone active
3	📞	Call Forwarding or Voicemail active (forwarding condition: Always) [*]
4	🕒	Schedule/Task (Alarm set)
	🕒	Schedule/Task (Alarm unset)
5	🕒	Hour Minder active
6	🔔	Alarm set
	📺	Wakeup TV set
7	👤	Manner mode active
	🚗	Drive mode active
	👤	Original mode active
	📄	VeilView active
8	🔑	Keypad Lock active
	📶	IC Card Lock active
9	📞	Auto Answer or Remote Monitor active
10	🔔	Ringtone (Silent)
	🔔	Ringtone (Increasing Volume)
11	🔔	Vibration active
	🔔	Show Secret Data active
	🔒	Function Lock active

^{*}Indicator does not appear when Call Forwarding is set to Video Calls only, with Voicemail unset.

External Display Indicators

Basic Status



1		Signal strength ¹
2		Battery strength ²

¹The more bars the better.

²Battery strength % is an approximation.

Notifications



1		Missed Calls
2		Answer Phone message recorded
3		Missed Call Notification
4		New Voicemail
5		Unread mail
6		Unread Delivery Report
7		Contents Key received
8		Unread S! Information Channel info
9		Weather Indicator update
10		Weather Indicator

Warnings



1		Message delivery failure
2		S! Information Channel info reception failure
3		Decoration Call transmission failure
4		IP Service connection failure
5		Weather Indicator update failure

Handset Status



1		Alarm
2		Schedule Alarm
3		Task Alarm
4		S! Appli/Mobile Widget Notification
5		Unread S! Friend's Status notification
6		TV Alarm (watch)
7		TV Alarm (record)

External Display Date & Time

- Press to toggle Clock view.

Accessing Functions

Use the following methods as needed.

Main Menu



Repeat menu item selection.


Select menu items



Enter numbers


Use shortcuts

Quick Operations




Enter numbers to access functions.
To activate functions, press the corresponding key.

Shortcuts




Access assigned functions (changeable).

Key Shortcut



Long Press or to access assigned functions (changeable).

Standby Shortcuts



Save functions to Standby.

Access a function in Shortcuts menu while another is active, then toggle function windows as needed.

Main Menu

Menu Item Selection



1 




- Main Menu opens.


2 Use  to select menu item



- Menu/window opens.
- If Sub Menu opens, use  to select an item and press .


Tabs

- Menus/lists in a single window appear in separate tabs; use  to toggle tabs.




Tab

Reverse Navigation

- Press . If a confirmation appears, follow onscreen prompts.

Returning to Standby

- Press . If a confirmation appears, follow onscreen prompts.

Simple Menu

- Simplify menus; ideal for users who use only basic handset functions.

Main Menu Items


Messaging	Open/create messages, etc.
Yahoo! Keitai	Browse the Internet
S! Appli	Use S! Applications including games
TV	Watch/record TV programs
Camera	Capture images or record video
Entertainment	Read e-Books, receive news updates, etc.
Tools	Manage schedules, set Alarm, scan QR Codes, etc.
Data Folder	Open files saved on handset/Memory Card
Media Player	Play/download media files
Communication	Communicate with other users in various ways
Phone	Search contacts, add entries, etc.
Settings	Customize handset interface, sounds, etc.

Shortcuts Menu & Key Shortcut

Shortcuts Menu

Access assigned functions via Shortcuts menu.

1



Shortcuts Menu

2 **Select function** ➔

- Menu/window opens.

Changing Default Shortcuts

In 2, select numbered function ➔
 ➔ **Assign Function** ➔ ➔ Select menu item ➔ ➔ Select new item ➔

- To assign menu items, select one and press .

Assigning Files & Folders

In 2, select numbered function ➔
 ➔ **Assign Data** ➔ ➔ Select file/folder ➔
 ■ For folders, select **Set this folder** and press .

Key Shortcut

In Standby, Long Press , or to access assigned functions.

	Open S! Mail Composition window
	Open Yahoo! Keitai menu
	Open PC Site Browser menu
	Create new Phone Book entries
	Activate/cancel IC Card Lock
	Activate/cancel Infrared

Changing Assigned Functions

Follow these steps to assign Calculator to .


1 ➔ **Settings** ➔

2 **In Phone menu, Set Key Shortcut** ➔



Key Shortcut Menu

3 **Long press** ➔



4 **From Appli** ➔

5 **Tools** ➔ ➔ **In PIM/Lifestyle menu, Calculator** ➔

Bookmark

In 4, **From Bookmark** ➔ ➔

Select title ➔ ➔ Yes ➔

Infrared or Show Secret Data On/Off

In 4, **From Other** ➔ ➔ Select item ➔

Canceling Assigned Function

In 4, **Off** ➔

Advanced

Changing item order Restoring default shortcuts (P.1-24)

1 Toggling Active Functions (Multi Job)

Multi Job Feature

Access a function in Shortcuts menu while another is active.


While browsing the Internet



Multi Job may not activate from some menus/windows (e.g., ringtone/ringvideo selection, etc.).

Using Multi Job

- 1** In a function window, In text entry/dial windows, Long Press .





- 2** Select function ➡



- Menu/window opens.

- 3** To toggle active windows, マナー




- 4** ➡ Multi Job ends

- If a confirmation appears, follow onscreen prompts.

Standby Shortcuts

Paste shortcuts to functions, files, folders, etc. to Standby for easy access.

Saving Shortcuts to Standby

- 1
 - Pointer () appears.
- 2 Use to select (OPEN)
 - ➔
 - Press to toggle selection.
 - Alternatively, use to point to (OPEN) and press .
- 3 **Shortcut**

- 4 **Select item** ➔
 - Corresponding icon appears in Standby.
 - >> appears when more items are available.

Advanced

- Reversing icon selection order with ● Editing sheet names ● Locking sheets (P.1-24)

5 Use to specify target location ➔

Saving from Menu/Window

- In Options menu, select **SetAsStbyShortcut** (may not appear for some items); select sheet as needed.

Removing Shortcuts from Standby

- ➔ Use to select icon ➔ ➔ **Operation** ➔ ➔ **Remove** ➔ ➔ **Yes** ➔

Moving Icons

- ➔ Use to select icon ➔ ➔ **Operation** ➔ ➔ **Change Layout** ➔ ➔ **Specify target location** ➔

Moving Icons to Front/Back

- ➔ Use to select icon ➔ ➔ **Operation** ➔ ➔ **To Front or To Back** ➔


Using Shortcuts

- 1 ➔ Use to select icon
 - ➔
 - Menu/window opens or command is executed.

Toggling Sheets

Toggle sheets to use Standby shortcuts and widgets pasted on each sheet.

1 ➔ (Long)



- To toggle further, Long Press or press repeatedly.
- Sheet name appears at the top, then disappears.
- Save Standby shortcuts as needed; corresponding icons appear on the current sheet.

Using Locked Sheets


- ➔ **Select** ➔ ➔ **Enter**
Handset Code ➔

1 Using Simplified Menus (Simple Menu)

Getting Started

Simple Menu Features

Activate Simple Menu to reduce available handset functions and simplify menus.




Menu Items

Messaging	Received Msg., Create Msg., Drafts, Templates, Sent Messages, Unsent Msg., Create SMS
Phone	Phone Book, Add New Entry, Play Messages, Answer Phone, Call VM, My Details, Speed Dial/Mail
Camera	Photo Camera, Video Camera, Scan Barcode, Scan Card, Scan Text, Review, Camera Settings, Video Settings
Convenient Tool	Calendar, Alarms, Calculator, Assignment, Dictionary, Notepad, S! Friend's Status, S! Circle Talk, Double Number, Change Menu
Data Folder	-
TV	-

Key assignments are largely the same as those in Large Font/Standard Menu.

Activating Simple Menu

1 (Long)



2 Simple Menu ➔

While Using an Incompatible Function

- End the function before activating Simple Menu.

Canceling Simple Menu

(Long) ➔ Large Font Menu ➔

Mobile Manners

Please use your handset responsibly. Use these basic tips as a guide. Inappropriate handset use can be both dangerous and bothersome. Please take care not to disturb others when using your handset. Adjust handset use according to your surroundings.

- Turn it off in theaters, museums and other places where silence is the norm.
- Refrain from using it in restaurants, hotel lobbies, elevators, etc.
- Observe signs and instructions regarding handset use aboard trains, etc.
- Refrain from use that interrupts the flow of pedestrian or vehicle traffic.

Manner Mode

Mutes most handset function sounds.

1 マナー (Long)



- Manner mode is set.

When Manner Mode is Active

- Ringtones and other sounds are muted.
- 831SH s vibrates for transmissions/alerts.
- Shutter click still sounds at fixed volume.

Canceling Manner Mode

マナー (Long)


Offline Mode

Temporarily suspends all transmissions.

1 ➔ Settings ➔ ➔ Network

2 Offline Mode ➔

3 On ➔



- Offline Mode is set.

Canceling Offline Mode

In , Off ➔

Advanced

- Changing handset modes ● Creating a custom mode ● Resetting Mode Settings (P.1-25)

Security Codes

These codes are required for handset use.

- Write down Security Codes.
- Do not reveal Security Codes. SoftBank is not liable for misuse or damages.

Handset Code	9999 by default; use or change some functions
Center Access Code	4-digit code selected at contract; access Optional Services via landlines or change contract details
Network Password*	4-digit code selected at contract; restrict incoming/outgoing calls (Call Barring)

*Change as needed.


Incorrect Code Entry

- **Handset code is incorrect!** appears; try again.
- If Network Password is incorrectly entered three times consecutively, Call Barring settings are locked. To resolve, Network Password and Center Access Code must be changed.


Changing Handset Code

Enter four to eight digits for new Handset Code.


1 → **Settings** →




2 **Locks** →




3 **Change Code** →



4 **Enter current Handset Code** →




5 **Enter new Handset Code** →



6 **Re-enter new Handset Code** →

My Details & Basic Tools

My Number



- Handset phone number and the name entered at initial setup appear.

Editing My Details


After ①, [Select] (select tab) → Select item → [Edit] → Select item → [Done] → Edit → [Done]

VeilView

Activate VeilView to prevent peeking.



Canceling VeilView



Keypad Lock

Lock handset keys and prevent accidental operation/function activation.



- Keypad Lock activates.
- [Power] does not turn off handset power.

Incoming Calls while Keypad Lock is Active

- Keypad Lock is temporarily canceled; press [Call] to answer calls. Keypad Lock reactivates after the call.

Canceling Keypad Lock



Pen Light



- Mobile Light illuminates.



Important Pen Light Usage Note

- Do not point Pen Light at people or look at it directly.

Advanced

- Clearing My Details ● Toggling My Details in Dual Mode ● Changing battery strength indicator pattern ● Changing VeilView pattern/density (P.1-25)

Battery Meter

1 ➔ **Tools** ➔ ➔ **Clocks/Gauges**

2 **Battery Meter** ➔

- Approximate battery strength appears.

Changing Battery Strength Indicator Pattern

After , ➔ **Select pattern** ➔

- Remaining time is approximated for current handset usage pattern.

Phone Help

Access this handy guide to handset settings and key functions/shortcuts.

1 ➔ **Tools** ➔ ➔ **Doc./Rec.**

2 **Phone Help** ➔


3 **Select item** ➔

- For **Indicators**, select category and press .

Indicator Descriptions

Check active indicators and their descriptions. (Status Icon List)

1 (Long)




- Active indicators are enlarged; description for selected indicator appears.
- Use to select indicators to view their descriptions.
- Press to open menu/window (e.g., Battery Meter window from battery strength indicator). May be unavailable for some indicators.

Using Double Number

Manage two accounts (Line A and Line B, with separate phone numbers and mail addresses) on one handset.

- Double Number requires a separate contract and basic monthly fee.
- While abroad, any Line B messaging charges are applied to Line A.
- For more information, contact SoftBank Mobile Customer Center, General Information (P.15-39).

Two Phone Numbers & Two Mail Addresses



Activating Double Number

Make sure signal is stable.

- 1 ➔ **Settings** ➔
- 2 In Phone menu, **Double Number** ➔
- 3 **Switch On/Off** ➔
- 4 **On** ➔
- 5 **Enter Handset Code** ➔ ➔ **Yes** ➔

Canceling Double Number

- In 4, **Off** ➔ ➔ 5
- When Double Number is canceled:
 - Line B calls and SMS messages are redirected to Line A Phone Number.
 - Initial portion of Line B S! Mail is redirected to Line A. (Full messages are irretrievable.)
 - Double Number account is not affected.

Modes

Activate **A Mode** to use Line A only, **B Mode** to use Line B only, or **Dual Mode** to use both accounts.

A Mode

Receive Calls to Line A Only

- Place calls or send messages via Line A.

A Mode & B Mode Precautions

- Line indicators do not appear in Phone Book entries, message lists, Call Log records, etc.
- When an operation affects information on the other line, a confirmation appears. Follow onscreen prompt(s).

B Mode

Receive Calls to Line B Only

- Place calls or send messages via Line B.

B Mode Restrictions

- Handset connects to the Internet via Line A. (During Internet connections, place/receive calls via Line B.)
- S! Friend's Status, S! Circle Talk and Decoration Call are unavailable.

Advanced

- Omitting Handset Code entry when switching modes
- Renaming Double Number modes
- Showing indicator for calls missed or new mail on idle line
- Hiding Internet connection confirmation (P.1-26)

Dual Mode

Receive Calls to Both Accounts

- Place calls or send messages via Line A (or the account of record for Phone Book entries or Call Log records) by default; toggle accounts as required.

Phone Book Entries

Specify A, B or Dual.

Messaging


Select Line A or Line B.
Sender Address changes accordingly.

Calling






Select Line A or Line B.
Caller ID changes accordingly.

- , **B** and  indicate line type in Phone Book entries, message lists, Call Log records, etc.

Switching Modes

-  (Long)
- Enter Handset Code ➔ 
- Select mode ➔ 
 - For *B Mode* confirmation appears.
- Yes ➔ 

Saving Modes to Phone Book Entries

-  ➔ **Phone** ➔  ➔ **Add New Entry** ➔ 
- Mode:** ➔  ➔ **Select mode** ➔ 

Entries Saved with Double Number Off

- Dual* is set automatically.

Advanced

-   Rejecting calls to either line in Dual Mode
-  Setting main line for Dual Mode (P.1-26)

USB Charge

Disabling USB Charge: [•] → *Settings* → [•] → [📶] *Connectivity* → *USB Charge* → [•] → *Disable* → [•]

Information

Handling Information list: [Start Here] [•] → *Phone* → [•] → See below

Opening List Manually Information → [•]

Clearing List Information → [•] → [🔄] → *Yes* → [•]

Shortcuts

Changing item order: [🔄] → Select numbered function → [📄] → *Move* → [•] → Select target location → [•]

Restoring default shortcuts: [🔄] → Select numbered function → [📄] → *Set to Default* → [•] → *Yes* → [•]

Standby Shortcut

Reversing icon selection order with [🔄]: [🔄] → [📄] → *Move Focus(Reverse)* → [•]
 • To cancel, select *Move Focus(Order)*.

Editing sheet names: [Start Here] [🔄] → [📄] → *Sheet Settings* → [•] → *ChangeSheetName* → [•] → See below

Renaming
 Select sheet → [•] → Enter name → [•]

Resetting All Sheet Names
 [📄] → *Yes* → [•]

Locking sheets: [Start Here] [🔄] → [📄] → *Sheet Settings* → [•] → *Set Sheet Lock* → [•] → Enter Handset Code → [•] → See below

Activating Lock
 Select sheet → [•] → *On* → [•]

Changing Method for Temporary Access
Unlock Method → [•] → *No Password* → [•]
 • Press [🔄], then select [📄] and press [•] to unlock sheet temporarily.

Mode	
Changing handset modes	<p>Start Here → Settings → In Phone menu, Mode Settings → See below</p> <p>Selecting a Handset Mode</p> <p>Select mode →</p> <p>Customizing Handset Modes</p> <p>Select mode → Select item → Adjust settings</p> <ul style="list-style-type: none"> Not available for Normal mode.
Creating a custom mode	<p>Settings → In Phone menu, Mode Settings → Original → Select item → Adjust settings</p>
Resetting Mode Settings	<p>Settings → In Phone menu, Mode Settings → Select mode → Enter Handset Code → Yes →</p>
My Details	
Clearing My Details	<p>0% → Reset My Details → Yes →</p>
Toggling My Details in Dual Mode	<p>0% → Switch to B or Switch to A →</p>

Battery Meter

Changing battery strength indicator pattern	<p>Settings → In Phone menu, Display → Mini Battery → Select pattern →</p> <ul style="list-style-type: none"> For patterns other than Clock & Battery, indicators appear in turn. To change interval, press . For Battery level (or Level), approximate battery strength appears as a percentage. Remaining time is approximated for current handset usage pattern. <ul style="list-style-type: none"> Remaining time is hidden while charging.
---	--

VeilView

Changing VeilView pattern/density	<p>Start Here → Settings → In Phone menu, Display → VeilView → See below</p> <p>Pattern</p> <p>Pattern Setting → Select pattern →</p> <p>Scale</p> <p>Scale Setting → Select scale or Animation →</p> <p>Color</p> <p>Color Setting → Select color →</p> <p>Density</p> <p>Density Setting → Adjust density →</p> <ul style="list-style-type: none"> For Density:2 or Density:3, use before pressing to adjust the pattern appearance for straight view.
-----------------------------------	--

Double Number

■ All Modes

Omitting Handset Code entry when switching modes	<input type="checkbox"/> → <i>Settings</i> → <input type="checkbox"/> → In Phone menu, <i>Double Number</i> → <input type="checkbox"/> → <i>Password Entry</i> → <input type="checkbox"/> → <i>Off</i> → <input type="checkbox"/> → Enter Handset Code → <input type="checkbox"/>
Renaming Double Number modes	<input type="checkbox"/> → <i>Settings</i> → <input type="checkbox"/> → In Phone menu, <i>Double Number</i> → <input type="checkbox"/> → <i>Mode Name</i> → <input type="checkbox"/> → Select mode → <input type="checkbox"/> → Enter name → <input type="checkbox"/> → Select icon → <input type="checkbox"/>

■ A Mode & B Mode

Showing indicator for calls missed or new mail on idle line	<input type="checkbox"/> → <i>Settings</i> → <input type="checkbox"/> → In Phone menu, <i>Double Number</i> → <input type="checkbox"/> → <i>Show Missed</i> → <input type="checkbox"/> → <i>On</i> → <input type="checkbox"/>
Hiding Internet connection confirmation	<input type="checkbox"/> → <i>Settings</i> → <input type="checkbox"/> → In Phone menu, <i>Double Number</i> → <input type="checkbox"/> → <i>Packet Warning</i> → <input type="checkbox"/> → <i>Off</i> → <input type="checkbox"/> • Available for B Mode.

■ Dual Mode

Rejecting calls to either line in Dual Mode	<input type="checkbox"/> → <i>Settings</i> → <input type="checkbox"/> → In Phone menu, <i>Double Number</i> → <input type="checkbox"/> → <i>Reject By Line</i> → <input type="checkbox"/> → Select line → <input type="checkbox"/> → <i>On</i> → <input type="checkbox"/>
Setting main line for Dual Mode	<input type="checkbox"/> → <i>Settings</i> → <input type="checkbox"/> → In Phone menu, <i>Double Number</i> → <input type="checkbox"/> → <i>Send Priority</i> → <input type="checkbox"/> → Select option → <input type="checkbox"/>

Battery Meter



--- appears

- Calculating time; not a malfunction.



100% does not appear

- This is by design; not a malfunction.



Battery runs out faster

- A low ambient temperature reduces battery time.
- An older battery may run out faster.



Remaining time changes suddenly

- Time estimated by handset status; estimate may take time to appear.