





<b>Handset Parts</b> .....	<b>1-2</b>
Parts & Functions .....	1-2
<b>Charging Battery</b> .....	<b>1-4</b>
Charging Battery (AC Charger) .....	1-4
Charging Battery (In-Car Charger) ...	1-5
<b>Power On/Off</b> .....	<b>1-6</b>
Handset Power On/Off.....	1-6
<b>Display</b> .....	<b>1-7</b>
Display & Indicators .....	1-7
<b>Accessing Functions</b> .....	<b>1-10</b>
Handset Menus .....	1-10
Key Shortcut .....	1-11
Using Simplified Menus (Simple Menu)	..... 1-12
Toggling Active Functions (Multi Job)	..... 1-13

<b>Motion Control</b> .....	<b>1-14</b>
<b>Mobile Manners</b> .....	<b>1-16</b>
<b>Security Codes</b> .....	<b>1-17</b>
<b>Basic Tools</b> .....	<b>1-18</b>
My Details & Basic Tools .....	1-18
<b>Double Number</b> .....	<b>1-19</b>
Using Double Number .....	1-19
Modes.....	1-20
<b>Additional Functions</b> .....	<b>1-22</b>
<b>Troubleshooting</b> .....	<b>1-24</b>

# 1

## Getting Started

## Parts & Functions




- 1** Light Sensor
- 2** Earpiece
- 3** Display
- 4** Internal Camera
- 5** Microphone
- 6** Strap Eyelet
- 7** Headphone Port (with Port Cover)
- 8** Charging Terminals
- 9** Memory Card Slot (with Slot Cover)
- 10** External Device Port (with Port Cover)
- 11** External Display
- 12** Small Light
- 13** External Camera (lens cover)
- 14** Internal Antenna Location
- 15** Mobile Light
- 16** Infrared Port
- 17** Speaker
- 18** Logo
- 19** Battery Cover

- Do not cover or place stickers, etc. over Light Sensor or Internal Antenna area.
- Replace Port/Slot Cover after Port/Slot use.
- Avoid metallic straps; Antenna sensitivity may be affected.

### Handset Positions

#### Handset Closed



Keep handset closed when not in use.


#### Handset Open



Open handset to place or answer calls, enter text, etc.

## Handset Keys

Keys are indicated in this guide as shown.



- 1 Multi Selector (right)** Open Received Calls. Long Press to activate/cancel infrared.
- 2 Multi Selector (up)** Open Standby Window. Long Press to open PC Site Browser menu.
- 3 Center Key** Open Main Menu. Long Press to activate/cancel Keypad Lock.
- 4 Multi Selector (left)** Open Dialed Numbers. Long Press to activate/cancel Bluetooth®.

- 5 Mail Key** Open Messaging menu. Long Press to open S! Mail Composition window.
- 6 Shortcuts & A/A Key** Open Shortcuts menu.
- 7 Clear/Back Key** Play Answer Phone messages. Long Press to activate/cancel Answer Phone.
- 8 Start Key** Open All Calls. Long Press to open Double Number Mode menu.
- 9 Keypad** Enter numbers to place calls or access functions (Quick Operations). Long Press to open Phone Book.
- 10 \* Key** Enter \*, +, P, ? and -. Long Press to open S! Friend's Status member list.
- 11 Dictionary Key** Open Dictionary. Long Press to activate VeilView.
- 12 Multi Job & Manner Key** Select handset mode. Long Press to activate/cancel Manner mode.
- 13 Yahoo! Keitai Key** Open Yahoo! Keitai portal. Long Press to activate Familink Remote.
- 14 TV & Text Key** Activate TV. Long Press to open Change Menu window.
- 15 Multi Selector (down)** Open Phone Book. Long Press to create new Phone Book entries.
- 16 Power On/Off Key** Toggle Standby display. Long Press to turn handset power off.

- 17 # Key** Enter #. Long Press to activate/cancel Manner mode.
- 18 Camera Key** Activate mobile camera. Long press to activate Review.

## Side Keys

- 19 S! Circle Talk Key** Long Press to illuminate Mobile Light. Open: Open S! Circle Talk member list.
- 20 Volume Up Key** Closed: Scroll External Display indicators. Long Press to check e-money balance.
- 21 Volume Down Key** Long Press to start Pretense Call. Closed: Scroll External Display indicators.
- 22 Shutter Key** Open: Long press to activate mobile camera. Closed: Toggle Clock view.

## Multi Selector &amp; Side Keys

- In this guide, Multi Selector and Side Key operations are indicated as follows:


Press  or	
Press  or	
Press , ,  or	
Press  or	

## 1 Getting Started Charging Battery (AC Charger)

Getting Started

Battery must be inserted in handset to charge it.


- Use specified AC Charger ZTDAA1 (sold separately) only. In this guide, ZTDAA1 is referred to as "AC Charger."
- Handset and AC Charger may warm during charging.



### Important AC Charger Usage Note

- Fold back blades after charging. Do not pull, bend or twist the cord.


### 1 Open Port Cover as shown



### 2 Connect AC Charger


- With arrows up, insert connector until it clicks.

### 3 Extend blades and plug AC Charger into AC outlet



- Small Light illuminates red while charging.
- Small Light goes out when battery is full.

### 4 Unplug AC Charger



- Pull AC Charger straight out.

### 5 Disconnect handset

- Squeeze release tabs to remove connector.

### 6 Fold back blades and replace Port Cover

#### When Small Light Flashes

- Battery is unchargeable; may be defective or simply at the end of its life; replace it.

#### USB Charge

- Connect handset (with power on) to PC via USB Cable to charge battery.

#### Charging Battery Overseas


- SoftBank is not liable for problems resulting from charging battery abroad.

### Advanced


- Disabling USB Charge (P.1-22)

## Charging Battery (In-Car Charger)

In-Car Charger may be purchased separately.



### 1 Open Port Cover as shown



### 2 Connect In-Car Charger

- With arrows up, insert connector until it clicks.

### 3 Plug Charger into cigarette lighter socket

### 4 Start car engine

- Small Light illuminates red while charging.
- Small Light goes out when battery is full.

### 5 Unplug Charger

### 6 Disconnect handset

- Squeeze release tabs to remove connector.

### 7 Replace Port Cover

#### Important In-Car Charger Usage Notes

- Disconnect Charger before leaving vehicle to prevent charging with engine off.
- Do not use In-Car Charger with Desktop Holder.
- Avoid charging battery inside extremely hot vehicles.

# Handset Power On/Off

## Power On

Follow these steps when powering on 930SH for the first time:


### 1 (Long)

- After Power On Graphic, follow the steps below.

→ → → → → → **設定**  
 → → **Language** → → **English**  
 → → (Long) → (Long) →  
 Change Menu window opens

### 2 Select option →

Guide descriptions are based on Standard Menu.



- My Details setup starts.

### 3 Enter last name → → Enter first name → →

- Change Menu display option confirmation appears.

### 4 Yes or No →



Standby

- Choose **No** to enter Standby immediately after powering on.

#### When USIM Card is Not Installed

- Insert USIM Card** appears; insert the card to use handset.

## Retrieving Network Information

Handset initiates Network Information retrieval when , or is pressed for the first time.



- Choose **Yes** and press . When confirmation appears, press .
- Retrieve Network Information to use Network-related services and TV; retrieval automatically sets Clock.

## Power Off

### 1 (Long)

- After Power Off Graphic, handset shuts down.


# Display & Indicators

## Viewing Display

### ■ Standby



- Indicators (signal strength, battery strength, etc.) appear.
- Information window opens at the bottom for Missed Calls, new mail, etc.




Information Window

- Information label (e.g., **Message**, etc.) and count appear in Information window. Select an item and press to open it.

### ■ Softkeys

Functions/operations assigned to , , and appear at the bottom.



### Display Saving

- Display goes dark after Display Saving time elapses. Press any key to activate it.

### Backlight

- Backlight turns off after Time Out time elapses. Press - to illuminate it (key press may affect active function).

## Indicators

, and indicate line type in Dual Mode (P.1-19).

### ■ Basic Status



1		International roaming in progress
2		Signal strength <sup>1</sup>
3		Packet transmission protocol ready (3G)
		Packet transmission protocol ready (GSM)
		Packet transmission available (3G)
4		Packet transmission available (GSM)
		Battery strength (% <sup>2</sup> appears in turn)
5		IP Service enabled <sup>3</sup>

<sup>1</sup>The more bars the better.

<sup>2</sup>Battery strength % is an approximation.

<sup>3</sup>Appears when Decoration Call or S! Appli Communication is enabled.

accompanies even if packet transmission is not in progress. Both indicators disappear when Decoration Call and S! Appli Communication are **Off**.

## Advanced


- Handling Information list (P.1-22)

■ Function Status



1		Active S! Application
		Paused S! Application
		Music playback in progress
		TV recording in progress (handset)
2		TV recording in progress (Memory Card)
		Memory Card in use
		Memory Card formatting
3		TV Timer/TV Recording Timer set
		Music playback in progress (via Bluetooth®)
4		Multiple functions (Multi Job) active

■ Notifications




1		Unread mail
		Unread Delivery Report
2		Answer Phone active & message recorded
		Answer Phone canceled & message recorded
3		New Voicemail
4		Missed Call or new mail on idle line
5		S! Appli Notification
6		Contents Key received
7		Unread S! Information Channel info
		Software Update result
8		Unread S! Quick News info
		Unread S! Friend's Status notification or unanswered registration request

■ Warnings



1		Mail memory low
2		Message delivery failure
3		Memory Card unusable/misinserted

■ Transmissions



1		SSL browsing in progress
		Waiting packet transmission (3G)
		Waiting packet transmission (GSM)
2		Receiving mail
		Sending mail
3		S! Friend's Status online
4		Positioning in progress*
		Software Update in progress
5		USB Cable connected
		USB transmission in progress
		Infrared transmission in progress
		Infrared file transfer in progress
		Bluetooth® transmission ready
		Bluetooth® transmission in progress
		Bluetooth® talk in progress
6		S! Addressbook Back-up transmission in progress
		PC Site Browser in use
7		RSS-compatible site
8		Weather Indicator
		Infrared transmission ready

\*Flashes while positioning.



## Settings

1		Offline Mode active
2		Answer Phone active
3		Call Forwarding or Voicemail active (forwarding condition: <b>Always</b> ) <sup>*</sup>
4		Schedule/Task (Alarm set)
5		Schedule/Task (Alarm unset)
6		Hour Minder active
7		Alarm set
8		Manner mode active
9		Drive mode active
10		Original mode active
11		VeilView active
12		Keypad Lock active
13		IC Card Lock active
14		Auto Answer or Remote Monitor active
15		Ringtone (Silent)
16		Ringtone (Increasing Volume)
17		Vibration active
18		Show Secret Data active
19		Function Lock active

<sup>\*</sup>Indicator does not appear when Call Forwarding is set to Video Calls only, with Voicemail unset.

## External Display Indicators

### Basic Status

1		Signal strength <sup>*</sup>
2		Battery strength

<sup>\*</sup>The more bars the better.

### Notifications

1		Missed Calls
2		Answer Phone message recorded
3		Missed Call Notification
4		New Voicemail
5		New mail
6		New Delivery Report
7		Contents Key received
8		Unread S! Information Channel info
9		Weather Indicator update

## Warnings

1		Message delivery failure
2		S! Information Channel info reception failure
3		Decoration Call transmission failure
4		IP Service connection failure
5		Weather Indicator update failure

### Handset Status


1		Alarm
2		Schedule Alarm
3		Task Alarm
4		S! Appli Notification
5		Unread S! Friend's Status notification
6		TV Alarm (watch)
7		TV Alarm (record)

### External Display Date & Time

- Press to toggle Clock view.

## 1 Handset Menus


Getting Started



- Press to return to Standby from function windows, menus, etc.

### Main Menu opens.


- Select an item and press to open Sub Menus/function window.



### Shortcuts menu opens.


- Select a function and press to access it.

Shortcuts



### Enter numbers to access functions.

- To activate functions, press the corresponding key.



### Advanced

- Customizing shortcuts
- Restoring default shortcuts (P.1-22)

## Key Shortcut

Long Press , or to access assigned functions.

	Open S! Mail Composition window
	Activate Famalink Remote
	Open PC Site Browser menu
	Create new Phone Book entries
	Activate/cancel Bluetooth®
	Activate/cancel Infrared


### Changing Assigned Functions

Follow these steps to assign Calculator to

- **Settings** → → In Phone Settings menu, **Set Key Shortcut** →



- 2 Long press** →



- 3 From Appli** →

- 4 Tools** → → In PIM/Lifestyle menu, **Calculator** →

#### Bookmark

In , **From Bookmark** → →

Select title → → **Yes** →

#### Bluetooth® or Infrared On/Off

In , **From Other** → → Select item →

#### Show Secret Data Setting Window

In , **From Other** → → **Secret Mode** →

#### IC Card Lock On/Off

In , **From Other** → → **IC CardLock On/Off** →


#### Canceling Assigned Function

In , **Off** →

# 1 Using Simplified Menus (Simple Menu)

## Simple Menu Features

Activate Simple Menu to reduce available handset functions and simplify menus.



- Fonts are enlarged and appear in bold.
- Clock is enlarged (Calendar is hidden).
- Only Display Change is available for Motion Control.

## Menu Items

<b>Messaging</b>	Received Msg., Create Msg., Drafts, Templates, Sent Messages, Unsent Msg., Create SMS
<b>Phone</b>	Phone Book, Add New Entry, Play Messages, Answer Phone, Call VM, My Details, Speed Dial/Mail
<b>Camera</b>	Photo Camera, Video Camera, Barcode/Scan, Review, Photo Camera Settings, Video Camera Settings
<b>Convenient Tool</b>	Calendar, Alarms, Calculator, Assignment, Dictionary, Notepad, S! Friend's Status, S! Circle Talk, Double Number Settings, Change Menu
<b>Data Folder</b>	-
<b>TV</b>	-

Key assignments are largely the same as in Standard Menu.

## Activating Simple Menu

### 1 (Long)



### 2 **Simple Menu** ➔

#### While Using an Incompatible Function

- End the function before activating Simple Menu.

## Canceling Simple Menu

### 1 (Long)


### 2 **Standard Menu** ➔

# toggling Active Functions (Multi Job)

## Multi Job Feature

Access a function in Shortcuts menu while another is active.

While browsing the Internet




Jot down information


Multi Job may not be activated from some menus/windows (e.g., when selecting ringtone/ringvideo, etc.).

## Using Multi Job

- In a function window,**  In text entry/dial windows, Long Press .





- Select function**  



- Menu/window opens.

- To toggle active windows,** 



- Multi Job ends** 


- When a confirmation appears, follow onscreen prompts.

## Motion Control

Sensor detects handset orientation or movement. Move handset to navigate pages, mute ringer, etc.

- Activate Display first.
- Activate Motion Control by function beforehand.

### Change Orientation




#### Display Change

Rotate handset 90 degrees counterclockwise and return. Display orientation changes accordingly.

#### Display Rotation

Digital TV  
PC Site Browser  
Document Viewer  
Image Viewer  
Video Viewfinder

### Turn Over



#### Activate Quick Silent

Turn handset over to instantly mute ringer and stop vibration.

#### Ringer

Incoming Calls,  
Alarms, etc.

#### Vibration

Incoming Calls,  
Alarms, etc.

- Some tones may not be silenced.

### Shake Left/Right



#### Navigate Functions

Shake to the left to navigate back, or right to navigate forward.

#### Music

Music Player

#### Channels

TV


#### Images

Data Folder  
(Pictures)

#### Pages

Document  
Viewer

## Shake Forward or Backward



## Zoom In/Zoom Out

Shake forward to enlarge, or backward to reduce.

## Fonts

Message Window  
Yahoo! Keitai

## Zoom Image

Data Folder  
(Pictures)

## Zoom Page


PC Site Browser  
Document Viewer

## Disabling Display Rotation

Video Viewfinder always rotates with handset orientation.

1  → **Settings** →

2 In Phone Settings menu,  
**Motion Control** →



Motion Control Menu

3 **Display Change** →  →

**Select function** →

4 **Off** →

## Activating Motion Control by Function

1 In Motion Control menu,  
**Action Settings** →

2 **Select function** →

3 **On** →

## Activating Show Secret Data Temporarily

**Enter Handset Code** → **Shake handset left or right**

- Close handset in Standby to cancel Show Secret Data.

## Important Motion Control Usage Notes

- Hold/shake handset correctly to avoid unintended results.
- Motion Control may be unavailable while handset is ringing/vibrating.
- Confirm there is ample space for Motion Control use; hold handset firmly and shake it gently to avoid injury/breakage. Do not shake handset roughly; handset may slip, resulting in injury or damage.

## Advanced

Practicing Motion Control actions (P.1-22)

# Mobile Manners

Please use your handset responsibly. Use these basic tips as a guide. Inappropriate handset use can be both dangerous and bothersome. Please take care not to disturb others when using your handset. Adjust handset use according to your surroundings.

- Turn it off in theaters, museums and other places where silence is the norm.
- Refrain from using it in restaurants, hotel lobbies, elevators, etc.
- Observe signs and instructions regarding handset use aboard trains, etc.
- Refrain from use that interrupts the flow of pedestrian or vehicle traffic.

## Manner Mode

Mutes most handset function sounds.

1  (Long)




- Manner mode is set.

### When Manner Mode is Active

- Ringtones and other sounds are muted.
- 930SH vibrates for transmissions/alerts.
- Shutter click still sounds at fixed volume.

### Canceling Manner Mode

 (Long)


## Offline Mode

Temporarily suspends all transmissions.

1  → **Settings** →  →   
**NW Settings**



2 **Offline Mode** → 

3 **On** → 




- Offline Mode is set.

### Canceling Offline Mode

In , **Off** → 

## Advanced

-   Changing handset modes  Creating a custom mode  Resetting Mode Settings (P.1-22)



## Security Codes

These codes are required for handset use.

- Write down Security Codes.
- Do not reveal Security Codes. SoftBank is not liable for misuse or damages.

<b>Handset Code</b>	9999 by default; use or change some functions
<b>Center Access Code</b>	4-digit code selected at contract; access Optional Services via landlines or change contract details
<b>Network Password</b>	4-digit code selected at contract; restrict incoming/outgoing calls (Call Barring)

Change Network Password as needed.


### Incorrect Code Entry

- **Handset code is incorrect!** appears; try again.
- If Network Password is incorrectly entered three times consecutively, Call Barring settings are locked. To resolve, Network Password and Center Access Code must be changed.

### Changing Handset Code


Enter four to eight digits for new Handset Code.

1  → **Settings** → 




Phone Settings Menu


2 **Locks** → 




3 **Chg. Handset Code** → 



4 **Enter current Handset Code** → 



5 **Enter new Handset Code** → 



6 **Re-enter new Handset Code** → 

## 1 My Details & Basic Tools

### My Number

1 → →



- Handset phone number and the name entered at initial setup appear.

### Keypad Lock

Lock handset keys and prevent accidental operation/function activation.

1 (Long)

- Keypad Lock activates.
- does not turn off handset power.

### Incoming Calls while Keypad Lock is Active

- Keypad Lock is temporarily canceled; press to answer calls. Keypad Lock reactivates after the call.

### Canceling Keypad Lock

(Long)

### Pen Light

1 (Long)

- Mobile Light illuminates.

2 → Mobile Light goes out

### Important Pen Light Usage Note

- Do not point Pen Light at people or look at it directly.

### Battery Meter

1 → *Tools* → →

*Timer/Clock* → *Battery Meter* →

- Approximate battery strength appears.

### Phone Help

Access this handy guide to handset settings and key functions/shortcuts.

1 → *Tools* → → *Doc./Rec.*

2 *Phone Help* →

3 *Select item* → • Toggle guides as needed.

### VeilView

Activate VeilView to prevent peeking.

1 (Long)

### Canceling VeilView

(Long)

### Advanced


- Editing/clearing My Details
- Toggling My Details in Dual Mode (P.1-22)
- Changing battery strength indicator pattern
- Changing VeilView pattern/density (P.1-23)

## Using Double Number

Manage two accounts (Line A and Line B, with separate phone numbers and mail addresses) on one handset.

- Double Number requires a separate contract and basic monthly fee.
- For more information, see SOFTBANK MOBILE Corp. Website (P.14-22).

### Two Phone Numbers & Two Mail Addresses



### Activating Double Number

Make sure signal is stable.

- 1 → **Settings** →
- 2 In Phone Settings menu, **Double Number Settings** →
- 3 **Switch On/Off** →
- 4 **On** →
- 5 **Enter Handset Code** → → **Yes** →

### Canceling Double Number

In 4, **Off** → → 5

- When Double Number is canceled:
  - Line B calls and SMS messages are redirected to Line A Phone Number.
  - Initial portion of Line B S! Mail is redirected to Line A. (Full messages are irretrievable.)
  - Double Number account is not affected.

### Advanced

- Omitting Handset Code entry when switching modes
- Renaming Double Number modes (P.1-23)

# Modes

Activate **A Mode** to use Line A only, **B Mode** to use Line B only, or **Dual Mode** to use both accounts. While abroad, any Line B messaging charges are applied to Line A.

## A Mode

### Receive Calls to Line A Only

- Place calls or send messages via Line A.

#### A Mode & B Mode Precautions

- Line indicators do not appear in Phone Book entries, message lists, Call Log records, etc.
- When an operation affects information on the other line, a confirmation appears. Follow onscreen prompt(s).

## B Mode

### Receive Calls to Line B Only

- Place calls or send messages via Line B.

#### B Mode Restrictions

- Handset connects to the Internet via Line A. (During Internet connections, place/receive calls via Line B.)
- S! Friend's Status, S! Circle Talk and Decoration Call are unavailable.

## Advanced

- Showing indicator for calls missed or new mail on idle line
- Hiding Internet connection confirmation (P.1-23)

## Dual Mode

## Receive Calls to Both Accounts

- Place calls or send messages via Line A (or the account of record for Phone Book entries or Call Log records) by default; toggle accounts as required.

## Phone Book Entries

Specify A, B or Dual.

## Messaging


Select Line A or Line B.  
Sender Address changes accordingly.

## Calling

Select Line A or Line B.  
Caller ID changes accordingly.

-  **B** and  indicate line type in Phone Book entries, message lists, Call Log records, etc.

## Switching Modes

-  (Long)
- Enter Handset Code → ●
- Select mode → ●
  - For *B Mode* confirmation appears.
- Yes → ●

## Saving Modes to Phone Book Entries

- → *Phone* → ● → *Add New Entry* → ●
- Mode:* → ● → *Select mode* → ●

## Entries Saved with Double Number Off

- Dual* is set automatically.

## Advanced


-  ● Rejecting calls to either line in Dual Mode
- Setting main line for Dual Mode (P.1-23)

USB Charge	
Disabling USB Charge	● → Settings → ● → Connectivity → USB Charge → ● → Disable → ●
Information	
Handling Information list	Start Here ● → Phone → ● → See below
	Opening List Manually Information → ●
	Clearing List Information → ● → Yes → ●
Shortcuts	
Customizing shortcuts	Start Here ● → Select numbered function → ● → See below
	Changing Default Shortcuts Assign → ● → Select menu item → ● → Select new item → ●
	Changing Item Order Move → ● → Select target location → ●
Restoring default shortcuts	● → Select numbered function → ● → Set to Default → ● → Yes → ●
Motion Control	
Practicing Motion Control actions	● → Settings → ● → In Phone Settings menu, Motion Control → ● → Action Test → ● ● → Select item → ● • Follow onscreen instructions.

Mode	
Changing handset modes	Start Here ● → Settings → ● → In Phone Settings menu, Mode Settings → ● → See below
	Selecting a Handset Mode Select mode → ●
	Customizing Handset Modes Select mode → ● → Select item → ● → Adjust settings • Not available for Normal mode.
Creating a custom mode	● → Settings → ● → In Phone Settings menu, Mode Settings → ● → Original → ● → Select item → ● → Adjust settings
Resetting Mode Settings	● → Settings → ● → In Phone Settings menu, Mode Settings → ● → Select mode → ● → Enter Handset Code → ● → Yes → ●
My Details	
Editing/clearing My Details	Start Here ● → ● → See below
	Editing My Details Select tab → Select item → Select item → ● → Edit → ●
	Clearing My Details Select My Details → ● → Yes → ●
toggling My Details in Dual Mode	● → ● → Switch to B or Switch to A → ●

## Battery Meter

## Changing battery strength indicator pattern

- → **Settings** → ● → In Phone Settings menu, **Display** → ● → **Mini Battery** → ● → **Select pattern** → ●
- For patterns other than **Clock & Battery**, indicators appear in turn. To change interval, press .
- For **Battery level** (or **level**), approximate battery strength appears as a percentage.
- **Remaining time** is approximated for current handset usage pattern.
  - Remaining time is hidden while charging.

## VeilView

## Changing VeilView pattern/density

- Start Here** ● → **Settings** → ● → In Phone Settings menu, **Display** → ● → **VeilView** → ●
- See below
- Pattern**
- Pattern Setting** → ● → **Select pattern** → ● → **Select scale or animation** → ●
- Density**
- Density Setting** → ● → **Select density** → ●

## Double Number

## All Modes

- Omitting Handset Code entry when switching modes**
  - → **Settings** → ● → In Phone Settings menu, **Double Number Settings** → ● → **Password Entry** → ● → **Off** → ● → Enter Handset Code → ●
- Renaming Double Number modes**
  - → **Settings** → ● → In Phone Settings menu, **Double Number Settings** → ● → **Mode Name** → ● → **Select mode** → ● → Enter name → ● → **Select icon** → ●

## A Mode &amp; B Mode

- Showing indicator for calls missed or new mail on idle line**
  - → **Settings** → ● → In Phone Settings menu, **Double Number Settings** → ● → **Show Missed** → ● → **On** → ●
- Hiding Internet connection confirmation**
  - → **Settings** → ● → In Phone Settings menu, **Double Number Settings** → ● → **Packet Warning** → ● → **Off** → ●
  - Available for B Mode.

## Dual Mode

- Rejecting calls to either line in Dual Mode**
  - → **Settings** → ● → In Phone Settings menu, **Double Number Settings** → ● → **Reject By Line** → ● → **Select line** → ● → **On** → ●
- Setting main line for Dual Mode**
  - → **Settings** → ● → In Phone Settings menu, **Double Number Settings** → ● → **Send Priority** → ● → **Select option** → ●

## Battery Meter



### --- appears

- Calculating time; not a malfunction.



### 100% does not appear

- This is by design; not a malfunction.



### Battery runs out faster

- A low ambient temperature reduces battery time.
- An older battery may run out faster.



### Remaining time changes suddenly

- Time estimated by handset status; estimate may take time to appear.