Internet Services	5-2
Service Basics	5-2
Yahoo! Keitai	5-3
Using Yahoo! Keitai	5-3
PC Site Browser	5-4
Using PC Site Browser	5-4
Browsing	5-5
Basic Operations	

Bookmarks & Saved Pages	5-7
Using Bookmarks & Saved Pages	5-7
RSS Feeds	5-8
Updating Blogs & News	5-8
Additional Functions	. 5-9
Troubleshooting	5-16

5

Yahoo! Keitai & PC Site Browser



Service Basics

Access the Mobile Internet via Yahoo! Keitai, or view PC Internet sites via PC Site Browser.

- Service requires a separate contract; retrieve Network Information to use these services.
- For more about Yahoo! Keitai, see SoftBank Mobile Website (P.15-22).

Transmission/Information Fees

Some page content may automatically activate Internet connection incurring transmission fees. Information fees may also apply.

Security

Electronic certificates are saved on handset to support SSL (encryption protocol for Internet transmissions of important/sensitive information).

Secure Pages

- A confirmation appears before entering and exiting secure pages.
- When a security notice appears, subscribers must decide for themselves whether or not to open the page. Opening secure pages constitutes agreement to the terms of usage. SoftBank, VeriSign Japan, Cybertrust, Entrust Japan, GlobalSign, RSA Security and SECOM Trust Systems cannot be held liable for any damages associated with the use of SSL.

Advanced



Clearing cache (temporarily saved information) Clearing authentication information (And more on P.5-9)

Disabling manufacture number auto send for authentication Resetting browser settings and stored information (Bookmarks, Saved Pages, etc.) (And more on **P.5-15**)

Using Yahoo! Keitai

Opening Main Menu

Internet pages may not open depending on connection/Server status, etc.





Internet Page

- Yahoo! Keitai Main Menu appears.
- To disconnect, press 🗹.
- Highlight menu item
 - Corresponding page opens.
 - Repeat to open additional links.
- ③ → Yes → Page closes

Returning to Previous Pages [Internet Page] Previous page

[Internet Page]

→ Previous page opens

Follow these steps to return to the initial page:

[Internet Page]

Personal Provides Pr

Enter user ID or password ▶ ● ▶ ☑

Playing Media Streams (Streaming)

[Internet Page] Select file ▶ ●

- Downloaded content cannot be saved.
- Packet transmission fees apply even while stream is paused.

Using History





- Select record

 Connection starts
 - Corresponding page opens.





Entering URLs Directly





- Enter URL → → Connection starts
 - Corresponding page opens.





Customizing streaming settings Streaming from Media Player (P.5-12)



Using PC Site Browser

Open PC sites from Yahoo! JAPAN (preset home page).

- Internet pages may not open depending on connection/Server status, etc.
- Browsing PC sites may incur higher charges depending on subscribed price plan.






Homepage **→** • **→** Connection starts



Internet Page

- Yahoo! JAPAN Home opens.
- When a message appears, follow onscreen prompts.
- To disconnect, press [2].
- Highlight menu item **→** Corresponding page opens.

 - Repeat € to open additional links.









Basic Operations

Page Browsing

Scrolling Pages

If page content continues beyond view, use : to scroll pages. Long Press it to scroll continuously.



Switching Frames

On framed pages, Long Press et to select other frames.



When pointer navigation is active, point to a frame and press • to select it.

Viewing Single Frame


Select frame

□ □ Convenient


Tabbed Browsing

Open another page in a new tab and switch between tabs.

Opening a New Tab








Switching Tabs



 When pointer navigation is active. point to a tab and press of to open it.







Selecting Text

Activate pointer navigation to enable text selection (Drag Mode). Select text to copy or look up words in dictionaries.

- Text may not be selectable or linked page may open depending on the site or page.
- Follow these steps to use a dictionary:
- On a page, point to first
 - Drag Mode is activated.
- Highlight text range



- - Text range remains unchanged even when pointer is moved.
- Select dictionary
 Select dictionary
 - Dictionary opens with text inserted.



Starting Over

After ⓒ, point to first character ▶ • From @


Additional Page Operations

Enter text or select/execute items.



- **Text Entry**
- On a page, select text entry field

 ●
- Enter text **→** •
- Internet page returns.



- **Pull-down Menu Item Selection**
- On a page, select menu list field

 ●

When Multiple Selection is Supported

- Select items as needed and press
- Page Item Indicators
- Selection Items Buttons ○ or boxes □ appear.
- On a page, select button or box **⇒** | • |



- ○/□ changes to ⊙/☑
- Execution Items

Execute the assigned command.

On a page, select command •




Using Bookmarks & Saved Pages

Bookmarks

Bookmark sites for quick access.

- Saving Bookmarks
- On a page, □ → Bookmarks→ → Save →
 - Save appears only for savable pages.
- Enter/edit title ⇒ •
- 💽 Save 🖈 💽







- Select title ▶
 - Corresponding page opens.



→ Open List → ● Select title→ ●

Saved Pages

Save page content; handset opens saved pages without connecting to the Internet.

- Saving Pages
- On a page, □ → Saved

 Pages → □ → Save → □
 - Save appears only for savable pages.
- Enter/edit title ⇒
 - Opening Saved Pages
- Yahoo! Keitai → ●Saved Pages → ●




- Select page →
 - Corresponding page opens.

Opening Saved Pages Online
[Internet Page]

→ Saved Pages →

→ Open List → → Select page

▶ ●





Updating Blogs & News

Register RSS-compatible sites: view content updates without opening source sites. Transmission fees apply.

Subscribing to RSS Feeds

appears for RSS-compatible sites.

<u>□</u> 15:05 □ - RSS Indicator Available for PC Site Browser.

On a compatible page, | >

Select feed **▶** • (□/☑) **▶** Complete selection **→** [v]

Save **▶** •

• Choose Yes to update immediately or *No* and press .

Via RSS Icons

Use RSS icons to subscribe to RSS feeds from sites that are not RSS-compatible. Available for PC Site Browser.

On a page, select icon >

Checking Updates

Follow these steps to update all feeds:

Yahoo! Keitai

RSS Feed **▶** •



RSS Feed List

- Yes or No **→**
- Select feed **→** •



Title List

Select title **→** Information appears.

Updating Single RSS Feeds [RSS Feed List] Select feed ▶ 🖃 ▶ Reload ⇒ • • • Yes or No • • **Accessing Source Sites** [Title List] Select title ▶ • ▶ Select linked title **→** Yes **→** • **→** Yes

or *No* **▶** •





Connecting/Browsing

General

	Switching browsers	On a page, Change to PC Browser or Change to Y! Keitai This Page or Linked Page Yes or No Yes or No
	Using previously entered URLs	Start Here ● → Yahoo! Keitai → ● → See below
		Yahoo! Keitai Enter URL
		PC Site Browser PC Site Browser PC Site Brow

History

	Start Here ● → Yahoo! Keitai → ● → History → ● → □ → Change to PC Browser or Change to Y! Keitai → ● → See below
Deleting History	One Record
,	
records	Select record ⇒ □ ⇒ Delete ⇒ • Yes ⇒ •
	All Records
	Delete All ■ Enter Handset Code ■
	● → Yes → ●
Opening History	→ Yahoo! Keitai → → History → →
properties	Select record ⇒ □ → Details → ●
0	
Sorting History	● → Yahoo! Keitai → ● → History → ● → 🗈
records	Sort ⇒ ● ⇒ By Domain or By Date ⇒ ●

Sending History records via mail	Select record Se

■ Memory Operation

For PC Site Browser, perform the following sequence instead of Browser Settings ▶ •.

PC Site Browser ▶ ● PC Site Browser Settings ▶ ●

Clearing cache	Pahoo! Keitai Teitai Browser Settings
(temporarily saved	→ Memory Operation → ● Delete
information)	Cache ⇒ • Yes ⇒ •
Clearing cookies	● → Yahoo! Keitai → ● → Browser Settings → ● → Memory Operation → ● → Delete Cookies → ● → Yes → ●
Clearing	Yahoo! Keitai Browser Settings
authentication	→ Memory Operation →
information	Auth Info ⇒ ● → Yes ⇒ ●



Additional Functions Page Operations Yahoo! Keitai & PC Site Browser Using Web Search → Web Search → ● → Enter search text → ● On a page, → Convenient Functions → ● Searching current ⇒ Search ⇒ • ⇒ Enter search text ⇒ • page Press to jump to next search result, if any.

Looking up copied words in dictionaries	On a page, □ Convenient Functions ● Copy & Search Dict. ● Select first character ● Highlight text range ● Select dictionary ● Search ● Select word, etc. ●
Saving files to Data Folder	Start Here On a page,
	Files on Page Select file ⇒ ● ⇒ Save ⇒ ● Enter name ⇒ ● ⇒ Save here ⇒ ● • Some files are saved automatically. • Confirm signal is strong, battery is adequately charged and that there is enough free memory beforehand.
	Background Images Save Background Image Save ⇒ Save ⇒ Enter name ⇒ Save here ⇒ ●
Using linked info	Dialing Numbers On a page, highlight number Call or Video Call
	Sending Messages On a page, highlight number or mail address → ○ → Create Message → ○ → S! Mail or SMS → ○ → Complete message → □

Copying text	On a page, → Copy Text → → Select first character → → Highlight text range → ●
Sending URLs via mail	On a page, → Convenient Functions → → Send URL → → S! Mail or SMS → → Complete message → → S! Mail Composition window opens automatically depending on character count.
Jumping to page top/bottom	On a page, → Convenient Functions → → Jump In Page → → Page Top or Page Bottom → ●
Opening function shortcuts	On a page, → Help → ●
Opening page properties	On a page, → Convenient Functions → → Details → → Select item → ●
Changing encoding to read garbled text	On a page,
	Start Here On a page, → Convenient Functions → → Flash®Menu → ● → See below
Handling Flash® files	Pausing/Playing Pause, Resume or Replay
	Selecting Image Quality Quality
Updating page content	On a page,
Yahoo! Keitai	·
Changing Font	On a page, [3] (Long) to enlarge or [1] (Long)

Changing Font	On a page, [3] (Long) to enlarge or [1] (Long)
Size	to reduce



■ PC Site Browser

Switching view	On a page, PC Screen or Small Screen In Small Screen view, PC sites are redesigned to fit Display.
Zooming on pages (Zoom Factor)	On a page, [3] (Long) to enlarge or [1] (Long) to reduce
Jumping to specific locations	On a page, 55 (Long) → Quick Movement map appears → Select location → ●
Zooming specific areas	On a page, point to area

Internet Page Settings

■ Yahoo! Keitai & PC Site Browser

For PC Site Browser, perform the following sequence instead of $Browser\ Settings \Rightarrow \bullet$.

PC Site Browser ▶ • PC Site Browser Settings ▶ •

Disabling automatic image display/sound playback	Start Here ● ⇒ Yahoo! Keitai ⇒ ● ⇒ Browser Settings ⇒ ● ⇒ Downloads ⇒ ● ⇒ See below
	Image Display Images ⇒ • Do not Show ⇒ •
piaybaok	Sound Playback Sounds
Changing Font Size	→ Yahoo! Keitai → Browser Settings → Font Size → Select size →

_		
		Start Here ● ≯ Yahoo! Keitai ≯ ● ≯ Browser Settings ≯ ● ≯ Cursor Settings ≯ ● ≯ See below
	Using pointer navigation	Activating Cursor Mode Settings Normal Mode Normal Mode
		Changing Pointer Speed Speed Settings
(Using Memory Card as primary download storage	● Yahoo! Keitai ● ● Browser Settings ● ● Download to ● ● Prefer Card ● ● Some files may be saved to handset regardless of this setting.
	■ Yahoo! Keitai	
	Changing scroll unit	→ Yahoo! Keitai → Browser Settings → Scroll Unit → Select unit →
	PC Site Browse	r
1	Hiding navigation map for continuous scroll	● Yahoo! Keitai ● PC Site Browser ● PC Site Browser Settings ● Scroll Settings ● Page Navigation ● Off ●
	Changing scroll unit	● Yahoo! Keital ● PC Site Browser ● PC Site Browser Settings ● Scroll Settings ● Scroll Unit ● Select unit ●
	Hiding PC Site Browser messages	Yahoo! Keitai PC Site Browser PC Site Browser Settings Warning Message PC Site Browser or

Yahoo! Keitai ⇒ ● → Off ⇒ ●



Streaming

Bookmarks	
	Start Here ● ≯ Yahoo! Keitai ≯ ● ≯
	Bookmarks ⇒ • See below
	One Title
Deleting titles	Select title ▶ □ ▶ Delete ▶ ● ≯ Yes ▶ ●
	All Titles
	Delete All ■ Enter Handset Code ■
	● → Yes → ●
	▶ Yahoo! Keitai ▶ ● ▶ Bookmarks ▶ ●
Editing titles	Select title ⇒ □ ⇒ Edit ⇒ • Title: ⇒ •
_	⇒ Enter title ⇒ • □
Edition	Yahoo! Keitai Bookmarks
Editing bookmarked URLs	⇒ Select title ⇒ □ ⇒ Edit ⇒ • ⇒ URL: ⇒ •
	⇒ Edit ⇒ • ⇒ v
	▶ Yahoo! Keitai ▶ ● ▶ Bookmarks ▶ ●
Sending	Select title ⇒ □ ⇒ Send ⇒ • → As
bookmarked URLs via mail	Message → ● → S! Mail or SMS → ● →
	Complete message 🗼 🗹
	S! Mail Composition window opens automatically
	depending on character count.
Changing title order	● → Yahoo! Keitai → ● → Bookmarks → ●
	Select title ⇒ □ ⇒ Change Order ⇒ •
	Select target location
Opening title	▶ Yahoo! Keitai ▶ ● ▶ Bookmarks ▶ ●
properties	Select title ⇒ □ → Details ⇒ ●

Sorting titles into folders	Start Here ● ⇒ Yahoo! Keitai ⇒ ● ⇒ Bookmarks ⇒ ● ⇒ See below
	Creating Folders □ → Create Folder → ● → Enter name → ●
	Moving to Folders Select title ⇒ □ → Move → ● Select folder ⇒ ● → Move ⇒ ●
	Moving from Folders Select folder → ● → Select title → □ → Move → ● → Move → ●
	Renaming Folders Select folder ⇒ □ ⇒ Rename ⇒ ● Enter name ⇒ ●
	Deleting All Titles within a Folder Select folder
	Deleting Folders Select folder ⇒ □ ⇒ Delete ⇒ ● ⇒ Enter Handset Code ⇒ ● ⇒ Yes ⇒ ●

Saved Pages	
Deleting pages	Start Here ● → Yahoo! Keitai → ● → Saved Pages → ● → See below
	One Page Select page
	All Pages
Editing page titles	● → Yahoo! Keitai → ● → Saved Pages → ● → Select page → □ → Rename → ● → Enter title → ●
Changing page order	● ❤ Yahoo! Keitai ◆ ● ❖ Saved Pages ◆ ● ❖ Select page ❖ ② ❖ Change Order ❖ ● ❖ Select target location ❖ ●
Opening page properties	→ Yahoo! Keitai → ● → Saved Pages → ● → Select page → ● → Details → ●
Switching page list view	● → Yahoo! Keitai → ● → Saved Pages → ● → Select page → □ → List View or Preview View → ●



RSS Feeds	
Disabling feed updates	● Yahoo! Keitai → ● PC Site Browser → RSS Feed → ● Select feed → ● Manage RSS Feed → ● Restrict Update → ●
Sorting feeds into folders	Start Here ● → Yahoo! Keitai → ● → PC Site Browser → ● → RSS Feed → ● → See below
	Creating Folders
	Moving to Folders Select feed → Manage RSS Feed → Move → → Select folder → Move
	Renaming Folders Select folder Manage RSS Feed Rename Enter name
	Deleting Folders Select folder
Deleting feeds	Start Here ● → Yahoo! Keitai → ● → PC Site Browser → ● → RSS Feed → ● → See below
	One Entry Select feed ⇒ □ → Delete → • → Yes → •
	All Entries Manage RSS Feed Delete All Del

Sorting feeds	● ▶ Yahoo! Keitai ▶ ● ▶ PC Site Browser ▶ ● ▶ RSS Feed ▶ ● ▶ □ ▶ Manage RSS Feed ▶ ● ▶ Sort ▶ ● ▶ Select option ▶ ●
Opening feed properties	● Yahoo! Keitai → PC Site Browser ● → RSS Feed → → Select feed → → Manage RSS Feed → ● Details → ●
Exchanging feeds with other devices	Start Here ● → Yahoo! Keitai → ● → PC Site Browser → ● → RSS Feed → ● → □ → Manage RSS Feed → ● → See below
	Exporting All Feeds Export All
	Importing (Adding Feeds) Import ⇒ ● ⇒ Select file ⇒ ● ⇒ As New Items ⇒ ● ⇒ Yes or No ⇒ ● ⇒ Yes or No ⇒ ●
	Importing (Overwriting Existing Feeds) Import → ● → Select file → ● Delete All → ● → Enter Handset Code → ● → Yes ● → Yes or No → ● → Yes or No → ●
Sending feeds via mail	● ◆ Yahoo! Keitai ◆ ● PC Site Browser ● ◆ RSS Feed ◆ ● Select feed ◆ ● Manage RSS Feed ◆ ● As Message ◆ ● Complete message ◆ ♥



Security Settings

For PC Site Browser, perform the following sequence instead of $Browser\ Settings \Rightarrow \bullet$.

PC Site Browser ▶ ● PC Site Browser Settings ▶ ●

Disabling manufacture number auto send for authentication	● → Yahoo! Keitai → ● → Browser Settings → ● → Security Settings → ● → Manufacture Number → ● → Off → ●
Disabling referer information delivery to the Server	● → Yahoo! Keitai → ● → Browser Settings → ● → Security Settings → ● → Send Referer → ● → Not Send → ●
Enabling/disabling cookies	● Yahoo! Keitai ● ● Browser Settings ● ● Security Settings ● ● Cookies ● ● Select option ● ●
Selecting script execution option	● ◆ Yahoo! Keitai ◆ ● ◆ Browser Settings ◆ ● ◆ Security Settings ◆ ● ◆ Script Settings ◆ ● ◆ Select option ◆ ●
Hiding confirmations before entering/ exiting secure pages	● → Yahoo! Keitai → ● → Browser Settings → ● → Security Settings → ● → Secure Prompt → ● → Do not Show → ●
Opening electronic certificates saved on handset	● Yahoo! Keital ● Browser Settings ● Security Settings ● Root Certificates ● Select certificate ●

Changing validity of entered user ID/ password	● Yahoo! Keitai ● Browser Settings ● Security Settings ● Keep Auth Info ● Select option ● ● Per Browsing retains entered user ID/password during browsing sessions. On retains such authentication information even after turning handset off. ● Authentication information may not be retained depending on the site.
Enabling/disabling Ajax (for asynchronous communication)	● → Yahoo! Keitai → ● → Browser Settings → ● → Security Settings → ● → Restrict Ajax → ● → Select option → ●

Resetting

For PC Site Browser, perform the following sequence instead of Browser Settings → •.

PC Site Browser → • PC Site Browser Settings → •

Resetting browser settings and stored information (Bookmarks, Saved Pages, etc.)	Yahoo! Keitai Browser Settings Initialized Browser Enter Handset Code Yes
Restoring default handset settings	● → Yahoo! Keitai → ● → Browser Settings → ● → Reset Settings → ● → Enter Handset Code → ● → Yes → ●



Connecting/Browsing



What is the bar at Display bottom?

• This is a data progress bar; the number beside it indicates transmitted (green) or received (red) data.

Page Operations



Internet page does not open completely

• Portions of page content may not appear in tabbed browsing; close other tabs.



Text overlaps

- The site may be designed for browsing on PCs; try Tiny font size.
- Text may overlap when Zoom Factor is used; adjust scale.



Cannot access other functions while browsing the Internet

• When switching between Yahoo! Keitai and PC Site Browser (appears), additional function activation is disabled; close either browser and retry.

