



Specifications	6-2
Warranty & Service	6-2
Customer Service	6-3

● Wi-Fi router

Model Name	SoftBank 1015B
Dimensions	105 mm (D) × 62.5 mm (W) × 15.2 mm (H)
Weight ¹	130 g (including Battery)
Interface	Compatible with USB 2.0
Power Consumption ¹	4 W (maximum) Power consumption varies by usage.
Operating Environment	Operating Temperature: 0°C to +40°C Operating Humidity: 0% to 85%
Frequency	W-CDMA: 1500 Mhz, 1700 Mhz
Compatible Networks	WAN (Wi-Fi router): 3G (W-CDMA); 3G High Speed (HSPA/HSDPA, HSPA+, DC-HSDPA); IEEE802.11b/g/n WAN (Cradle): IEEE802.3u (10BASE-TX); IEEE802.3i (10BASE-T) WLAN: IEEE802.11b/g/n
Charging Time ²	140 minutes (with AC Charger, power off)
Continuous Operating Time ³	330 hours
Continuous Communication Time ³	2.6 hours

¹ Approximate value² Varies by ambient temperature, battery usage, etc.³ Varies by environment, signal conditions, etc.

● Cradle

Dimensions	58.8 mm (D) × 81 mm (W) × 29 mm (H)
Weight ¹	50 g
Interface	USB 2.0 RJ45

¹ Approximate value

Wi-Fi router purchase includes Warranty.

- Confirm shop name and purchase date.
 - Read contents of Warranty and keep it in a safe place.
 - The warranty period can be found in the Warranty.
 - Before submitting Wi-Fi router for repairs, contact SoftBank Customer Support (P.6-3) or SoftBank Shop; be prepared to describe problem in detail.
 - During the warranty period, repairs will be made under the terms and conditions described in the warranty.
 - After the warranty period, repairs will be upon request; if said repairs can be made, you will be charged for them.
- SoftBank Mobile is not liable for any damages resulting from the use of this Wi-Fi router.
 - Files and settings may be lost or altered due to accidents or repairs. Keep a copy of important files, etc.
SoftBank Mobile is not liable for damages resulting from accidental loss or alteration of files or settings.
 - Disassembling or modifying this Wi-Fi router may be a violation of the Radio Law. Note that SoftBank Mobile does not accept repair requests for disassembled or modified products.
 - For more information, contact SoftBank Shop or SoftBank Customer Support (P.6-3).

Customer Service

For information about SoftBank Mobile devices or services, call General Information.
For repairs, call Customer Assistance.

SoftBank Customer Support

General Information

- From a SoftBank handset, dial toll free at 157
- From a landline/IP phone, dial toll free at 0800-919-0157

Customer Assistance

- From a SoftBank handset, dial toll free at 113
- From a landline/IP phone, dial toll free at 0800-919-0113

If you cannot reach a toll free number, use the number (charges apply) below for your service area:

Hokkaido Area Tohoku Area Hokuriku Area Kanto, Koshinetsu Area	022-380-4380	Tokai Area	052-388-2002
Kansai Area	06-7669-0180	Chugoku, Shikoku Area Kyushu, Okinawa Area	092-687-0010

SoftBank Technical Support Center (Setup, Operations & Technical Issues)*

Service Hours 9:00-20:00

From a SoftBank handset, dial toll free at 5525

From a landline/IP phone, dial toll free at 0088-21-5525

*These numbers cannot be dialed from outside Japan.

SoftBank Mobile Global Call Center

From outside Japan, dial +81-3-5351-3491 (toll free from SoftBank handsets)

If 101SB is lost/stolen, call this number immediately (international charges apply)