Calendar & Tasks	9-2
Calendar	9-2
Tasks	9-5
Alarms	9-7
Using Alarms	9-7
Wakeup TV	9-9
Using Wakeup TV	
Calculator	9-11
Using Calculator	9-11
Expenses Memo	9-12
Adding Expenses	9-12
Osaifu-Keitai®	9-13
Osaifu-Keitai® (Japanese)	9-13
Locking IC Card	9-14
Simulated Call	9-17
Faking Incoming Calls	9-17
Stopwatch	9-18
Using Stopwatch	9-18
Countdown Timer	9-19
Using Countdown Timer	9-19
World Clock	9-20
Opening World Clock	9-20

Hour Minder	9-21
Using Hour Minder	9-21
Document Viewer	9-22
Opening PC Documents	9-22
Notepad	9-23
Saving Text	
ASCII Art	9-24
Using ASCII Art	9-24
Voice Recorder	9-25
Recording/Playing Voice	9-25
Scan Barcode	9-26
Scanning Barcodes	9-26
Create QR Code	9-27
Creating QR Codes	9-27
Scan Card	9-28
Scanning Business Cards	9-28
Text Scanner	9-29
Scanning Text	9-29
Additional Functions	9-30
Troubleshooting	9-42
3	

9

Handy Extras





Calendar Window

Opening Help [Calendar Window] 0%

Toggling View

Press repeatedly to toggle Calendar window.



2Month View

Month View



Week View

Key Assignments

All Views

Open Previous Page	¥****
Open Next Page	#72
Go to Current Date	5 ts
Open Help	0 ⁵⁸

Month/2Month View

|--|

Week View

Select Date	•••
Select Time Block	•

Advanced



Handy

Extras

🖖 Changing default view Jumping to specified date JChanging date color JSelecting task view option Adding stamps (Month View) Hiding schedules Saving additional holidays Removing/restoring holidays (P.9-30)

Saving Schedules

Follow these steps to save subject, start/ end date/time, Alarm and schedule details. Either Subject or Description must be saved per entry.

In Calendar window, select date


olimits

olimits



- ∠ <Add New Entry>

 ●
- 🔁 Enter subject 🖈 💽



Enter start date/time → ■



- End: ▶ ▶ Enter end date/time ▶ ●
- 🔁 Alarm: 🖈 💽
- Alarm Time:

 ◆ ◆ Select time ◆ ◆ \frac{\pi}{2}
- Saved



At Alarm Time

Alarm activates; sounds/vibrates by related settings.



Stopping Alarm to Return to Standby

Stopping Alarm to Open Schedule


 While Alarm sounds/vibrates, press a key other than ●, ♠ or ➡.

When Another Function is Active

 Alarm may not activate until handset returns to Standby.

Incoming Calls

 Active Alarm stops for incoming calls.
 Information window opens after handset returns to Standby.





Schedule List

- 🔁 Select schedule or task 🖈 💽
- 🛐 🗈 ➡ Standby returns

Opening Task List
In ∅, select task ▶ ⋈ ♣ Go to Tasks
▶ ●

Accessing Secret Entries
[Calendar Window] ⋈ ♣ Unlock
Temp. ♦ ● ▶ Enter Handset Code

Opening Related Message

Open schedule-related messages saved from Messaging message list.

- In schedule list, select schedule ▶ ●
- 🔁 🖹 🖈 Related Mail 🖈 💽
 - Related message opens.

Deleting Message from Schedule
After ①, ● → Related Mail: → ● →
Yes → ● →

Deleting Schedules

- One Entry
- In schedule list, select schedule ▶
- Delete → → This Data →

 → Yes → ●
- All Entries of the Day
- In Calendar window, select date ▶ №
- Delete

 → All This Day

 → → Yes → •

Advanced


▶ •



Tasks

Saving Tasks


Follow these steps to save subject, due date/time, Alarm and task details: Either Subject or Description must be saved per entry.

























Handy Extras



At Ala

At Alarm Time

Alarm activates; sounds/vibrates by related settings.



Stopping Alarm to Return to Standby

Stopping Alarm to Open Task


When Another Function is Active

 Alarm may not activate until handset returns to Standby.

Incoming Calls

 Active Alarm stops for incoming calls.
 Information window opens after handset returns to Standby.

Opening Tasks





Task List

- Use to open completed or uncompleted task list.
- 🕗 Select task 🖈 💽



📵 🕯 ➡ Standby returns

Accessing Secret Entries

After ①, ← → Unlock Temp. → ● → Enter Handset Code → ●

Marking Tasks as Completed
After ①, select task ▶ ☑

Deleting Tasks

- One Entry
 - \rceil In task list, select task 🖈 🕾
- 🔎 Delete 🖈 💽
- 🚯 This Task 🕈 💿 🖈 Yes 🕈 💿
- All Completed Tasks
- 📗 In task list, 🔄
- Delete → •
- All Comp. Tasks ⇒ ⇒
 Yes ⇒ ●




Using Alarms

Setting Alarm

Follow these steps to set Alarm to sound at a specific time on a specific day of the week:

Set Snooze (Alarm repeats at set interval), Alarm Volume and Duration.





Alarm List

2 --:-- → ● → Enter hour (24-hour format) → Enter minutes → ●







































Stopping Alarm

• Press a key.

When Another Function is Active

 Alarm may not activate until handset returns to Standby.

Incoming Calls

 Active Alarm stops for incoming calls.
 Information window opens after handset returns to Standby.

When Snooze is Set

Alarm repeats at the set interval. Other Alarms do not activate while handset is Snoozing.

Canceling Snooze

While Snoozing, ● → Yes → ●

 Snooze is automatically canceled after a period of time.

Canceling Alarm

In Alarm list, select entry ▶ ⊡



 Reactivate entry to use the same settings.

Reactivating Entry

In ②, Switch On ▶ •

Deleting Alarm

One Entry

🕦 In Alarm list, select entry 🖈 🕾

Reset Alarm 🕈 💽

Yes ⇒ •

■ All Entries

በ In Alarm list, select entry 🕈 🕾

Clear All → •

Using Wakeup TV

Setting Wakeup TV

Follow these steps to activate TV at a specific time on a specific day of the week:

- Complete TV Area Setup beforehand.
- TV may not activate in poor signal conditions.
- **→** Tools **→ →** In PIM/ Lifestyle menu, Wakeup TV




Wakeup TV List





Wakeup TV Menu







- Select day **▶ ●** (□/☑) **▶** Complete selection **→** 🖾
- Select channel **→** •
- Saved • For more settings, repeat @ - 3.
- Wakeup TV setting ends




Canceling Alarm

 Alarm activates at Wakeup TV time. To cancel Alarm, follow these steps:

[Wakeup TV Menu] Alarm On/Off: ▶ • **→** Off **→** • **From** ③

Adjusting Alarm Volume

[Wakeup TV Menu] Alarm Volume: >







TV activates after Alarm.



Stopping Alarm Instantly

- While Alarm sounds/vibrates, press a key. When Another Function is Active
- TV may not activate depending on the function.

After TV is On for a Period of Time

• Confirmation appears. Choose Yes and press • to exit TV.

Canceling Wakeup TV

- In Wakeup TV list, select entry **→** □
- · Reactivate entry to use the same settings.

Reactivating Entry

In ②, Wakeup TV On ▶ •

Deleting Wakeup TV

- One Entry
 - In Wakeup TV list, select entry **→** 🕾

 - Yes **▶** •
- All Entries
- In Wakeup TV list, select entry **→** 🕾
- - Enter Handset Code **→** Yes ⇒ •

Using Calculator

● → Tools → ● In PIM/ Lifestyle menu, Calculator




Calculator Window

- Use Keypad to enter digits
 - Calculate







Memory Calculation

- Clear Memory before starting new Memory calculations.
- Numbers saved in Memory remain until handset power is turned off.

Incoming Calls

 Calculations are not affected. End the call to return to Calculator.

Using % Function

Use by to find definite percentage of a known value.

Example: Calculate 30% of 800,000


Enter $800,000 \Rightarrow x \Rightarrow 30 \Rightarrow \%$

240,000 appears.



Entering Expenses

🚹 Enter amount 🕈 😧







Saving under Custom Category
In ③, Other ▶ ● ▶ Enter name ▶ ●

Checking Entries



🕖 Totals 🖈 💽



Expenses Memo List


Saving Entries to Notepad

[Expenses Memo List] → Save to Notepad → •

All expense details are saved as a single entry.

Deleting Entries

One Entry



🔎 Delete Item 🖈 💽

Yes ⇒ •

All Entries

🕦 In Expenses Memo list, 🕾

🗩 Delete All 🕈 💽



Osaifu-Keitai® (Japanese)

Osaifu-Keitai® describes IC Card-equipped handsets that support e-money or credit functions/services. Osaifu-Keitai® encompasses a range of IC Card-based services on FeliCa-compatible SoftBank handsets. 831SH s supports Osaifu-Keitai®. To use e-money, e-ticketing and reward points, etc., hold handset over a compatible reader/writer at shops, restaurants, and other retail outlets, etc.

Basics

Before using Osaifu-Keitai®, activate Lifestyle-Appli, complete registration, customize settings and charge accounts.

Starting Lifestyle-Appli

● → Tools → ● In PIM/Lifestyle menu, Osaifu-Keitai → ● → Lifestyle-Appli → ● → Select application → ●

Lifestyle-Appli Precautions


- Contact Osaifu-Keitai[®] service providers for Lifestyle-Appli registration and usage details.
- Keep service passwords/customer service contact information, etc. in a separate place.

Using Osaifu-Keitai®

Follow these steps to conduct a transaction: Example: Making an electronic payment

- Lifestyle-Appli activation is not necessary.
- Transactions are possible even when handset power is off (if battery is adequately charged).
- Calls/Internet transmissions do not affect transactions.





Align handset parallel to reader/writer.


Important Osaifu-Keitai® Usage Note

 SoftBank is not liable for damages resulting from accidental loss/alteration of IC Card data/settings.

When Placed Over Sensor

- If recognition is slow, move handset around slightly.
- Handset may respond automatically for some services.

ep service passwords/customer





IC Card Lock

Use this function to restrict access to/prevent unauthorized use of Osaifu-Keitai® on handset.









IC Card Lock → ● ◆ On → ●

Canceling IC Card Lock
In ⑤, IC Card Lock ▶ ● → Off ▶ ●

Enter Handset Code ▶ ●



Handy Extras

Remote Lock

Disable Osaifu-Keitai® remotely by mail or phone.

Lock	Send mail to activate Remote Lock
Call Remote Lock	Call from a specified phone to activate Remote Lock

Mail Remote Lock

- Preparation on Handset
- → Tools → In PIM/ Lifestyle menu, Osaifu-Keitai → ●
- Settings →
- Remote Lock → ► Enter Handset Code → •







Mail Lock Menu

- 🕞 Remote Lock PW 🖈 💽
- 🖺 Enter password 🕈 💽
- Switch On/Off → •
- ② On **→ →** 🗹

Canceling Mail Remote Lock In ③, *Off* ▶ ● ▶ ☑

Activating Remote Lock via Mail
If handset cannot receive mail IC Card
Lock is not set.

- Send S! Mail or e-mail to handset with password as subject
 - After handset receives message, IC Card Lock is set and notice is sent as a reply.

- → Tools → In PIM/ Lifestyle menu, Osaifu-Keitai
- Settings →
- Remote Lock → → Enter Handset Code → ●



Call Lock → •



Call Lock Menu

Ph.No. to Lck1 or Ph.No. to Lck2 ▶ •



- Phone Book

 Select entry

 Select phone number

 Phone Book

 Select phone
 - Select Phone Number to enter directly.
- Switch On/Off ▶ •
- On → > □

Enabling Activation via Public Phone
In ⑤, Set Public Ph ➡ ● ➡ On ➡
● ➡ From ②

Canceling Call Remote Lock
In ⑤, Off ➡ ● ➡ ☞

■ Activating Remote Lock via Phone
If handset cannot receive calls IC Card
Lock is not set

- Using one of the specified phones, call handset

 Send Caller ID.
 - Seria Caller ID.
 - Handset receives call
 End the call
- The call is recorded as a Missed Call.
- Within three minutes, repeat

 O ② twice



 After the third Missed Call, IC Card Lock is set; a message announces Remote Lock activation. Confirm the message and end the call.

If Series is Interrupted by Another Call

• Missed Call count is reset. Start over from the beginning.

Handy Extras

Faking Incoming Calls

Handset rings to emulate an incoming call.

- Save name and phone number to show as Caller ID.
- Ringer may be muted by handset settings. To override Silent setting, see P.9-36.

Setting Simulated Call









- Name: ▶ Enter name
- Phone Number:

 ▶

 ¥7
- Assign Tone → Select tone/file **→** •
- PIM/Lifestyle menu returns

When Name and Phone Number are Unset Handset rings with Caller ID "Withheld." Canceling Simulated Call [Simulated Call Menu] Switch On/Off

→ ○ → Off → ○ → □

Setting Wait Time

[Simulated Call Menu] Receive Timing

Select time
▶ □
▶ □

Using Simulated Call

- Long)
 - Available regardless of handset position.
 - Handset rings and incoming Voice Call window opens.
 - Ringtone stops after a period of time.
- In incoming Voice Call window, press
 - Voice Call window opens. (Softkeys are dummies.)
- Simulated Call ends

When Receive Timing is Not Immediately


- cancel Simulated Call activation.
- Simulated Call activation is canceled by incoming calls, Alarms, etc. during wait time.

Handy Extras

Using Stopwatch

Stopwatch stops when battery runs low.





Stopwatch Window

- Stopwatch starts
- Stopwatch stops
 Press to resume.

Stopwatch ends

 Records are deleted when Stopwatch ends.





Using Countdown Timer



Timer Entry Window


Enter minutes → Enter seconds → •



Countdown Timer Window

 \bullet Press \boxdot to change time.

- Countdown starts
 - Press to stop/resume countdown.
- Set time elapses → Tone sounds



Using Timer Records

After ①, ☐ → Select record → • → → From ⓒ

Resetting Countdown Timer Stop countdown and Incoming Calls

 Countdown is not affected by incoming calls. End the call to return.

When Set Time Elapses


Tone sounds.



Stopping Tone Instantly

- Press or a Side Key. (Tone stops automatically after a period of time.)
- When Timer Time Elapsed during a Call
- Tone sounds after the call.





- Select area → •
- **▶** World Clock ends

Advancing One Hour (Daylight Saving) [Set Time Zone Window] 2 ■ To cancel, press 🗹. **Adding Custom Time Zone** [Set Time Zone Window] ← → Enter

Enter time difference ▶ •

Opening World Clock in Standby

- **Settings ●** In Phone menu, *Display* **▶** •
- Standby Display **▶** •





Set Time Zone Window

Handy Extras

Using Hour Minder

Setting Hour Minder

Follow these steps to activate the hourly time signal at selected hours:





Hour Minder Menu







Select hour **→** • (□/☑) **→** Complete selection **▶** 🗹



Saved





In (4), A Check All or Uncheck All

At Hour Minder Time

Hour Minder activates: sounds/vibrates by related settings.



Stopping Tone Instantly


• Press a key.

When Another Function is Active

- Hour Minder does not activate. Incoming Calls
- Active Hour Minder stops for incoming calls.

Canceling Hour Minder







Opening PC Documents

Supported File Formats:

PDF (.pdf)

Microsoft® Excel® (.xls)

Microsoft® Word (.doc)

Microsoft® PowerPoint® (.ppt)

- Some files may not appear correctly.
- Download files via the Internet.
- When transferring files from PCs, save to corresponding Memory Card folder (P.15-23).






Select file 🖈 💽

Zooming In/Out with Loupe (Magnifier)
In open file, ⊞ (Long) ➡ Specify
portion ➡ ↩ ➡ Zoom Out or Zoom
In ➡ ■

Key Assignments	
View Whole Page	•
Scroll	⊹
View Upper Left	1 %
Toggle Full Screen View On/Off	2 %
View Upper Right	3 %
Zoom Out	4 t / ▶
Continuous Zoom Out	(Long) (Long)
View Center	5 to
Zoom In	6 ta
Continuous Zoom In	6 (Long) (Long)
View Lower Left	7 s
Jump to Page	8 [⇔]
View Lower Right	9 5 wmz
Open Help	0 to the
Next Page	#75
Previous Page	¥
Fit Width	<u> </u>
Rotate 90°	\$27

Saving Text

New Notepad Entry





Notepad List





- Enter text ▶ •
- Select Category → → Saved

Sorting Entries Temporarily

[Notepad List]

■ Press repeatedly to toggle sort options (Modified, Created, Category and Accessed).

Opening Notepad



🤰 🗭 🕨 List returns

Deleting Entries

One Entry



- Delete Item → Yes → •
- All Entries
- In Notepad list, select entry →

 Manage →

 Setting/Manage →

 ■

Using ASCII Art

Inserting ASCII Art



Select entry ▶ •



Previewing ASCII Art

In ②, select entry ▶ ☐

■ Press • to insert ASCII Art.

Editing Entries





ASCII Art List



Deleting Entries

- In ASCII Art list, select entry

 → → Delete → •
- Yes ⇒ •



Recording/Playing Voice

Recording

- If battery runs low while recording, Voice Recorder shuts off.
- Record conversations during calls via Rec Caller Voice.





Recording Window



- Recording starts



 For Extended Voice, recording is saved automatically.




Play Before Saving
In ②, Playback → ● → Playback
starts → ⋈ → Playback stops
Starting Over
In ②, ⋈ → From ②











Playback Operations


Adjust Volume	·
Pause/Resume	•
Stop	戻る



Scanning Barcodes


Scan UPC/JAN (1D barcodes) or QR Codes (2D barcodes).

- Membership file or password may be required when scanning barcodes.
- Some barcodes may not be scanned.











Scan Window

 Use Focus Adjustment Bar as a guide (better focus in darker blue).



Scan starts

- If recognition takes time, slowly adjust the distance between handset and barcode.
- Press 🗹 to stop scan.

Tone sounds → Scan results appear



Split Data

- After scanning, confirmation appears.
 Follow onscreen prompt(s).
- Scan results do not appear until all split data is scanned.

Starting Over

After \bigcirc , \bowtie \Rightarrow Yes \Rightarrow \bigcirc \Rightarrow From \bigcirc

Key Assignments in Scan Window

Toggle Focus Mode	1 8
Switch to Photo Viewfinder	3 &
Focus Lock	7
Mobile Light On/Off	#3%
Adjust Brightness	••
Open Help	0**


Advanced



Scanning during text entry Scanning continuously Reading saved barcode images Saving scan results Saving to Notepad Saving linked info to Phone Book Opening saved scan results Using linked info Using images as Wallpaper Saving images & melodies Copying text (And more on P.9-38 - 9-39)

Creating QR Codes

Create QR Codes from these items on handset:



Large items are divided into multiple QR Codes.

Procedure

Follow these steps to create QR Codes from Data Folder files:











- Select folder **→ →** Select file or entry **→**
 - QR Code is created.



 QR Code is saved to Data Folder (Pictures).




Scanning Business Cards

Scan business cards and save names. addresses, etc. to Phone Book.

- English business cards may not be scanned correctly.
- Some cards may not be scanned.







Frame card on Display




Scan Window

- Scan starts • Press 🗹 to stop scan.
- Scan results appear





New Phone Book entry is saved.




Key Assignments in Scan Window

Toggle Focus Mode	1 8
Switch to Photo Viewfinder	3 8
Focus Lock	c
Mobile Light On/Off	#%5
Adjust Brightness	•
Open Help	0**



Some text cannot be scanned.





Scan Text ▶ •

Frame text in center of Display



- Adjust to frame text in [].
- Use Focus Adjustment Bar as a guide (better focus in darker blue).
- Press v to stop scan.
 - Select line **▶ ▶** Scan results appear







Key Assignments	in	Scan	Window
-----------------	----	------	--------

Toggle Focus Mode	1 *
Switch to Photo Viewfinder	3 ☆
Focus Lock	c
Mobile Light On/Off	# 70
Adjust Brightness	•
Open Help	0 ⁵⁻⁶

[🕾] Scanning during text entry Scanning more text Saving scan results Saving linked info to Phone Book Saving to Notepad Opening saved scan results Using linked info Pasting to message text Copying text (P.9-40 - 9-41)



Calendar		
■ View Settings	View Settings	
Changing default view	■ Tools ■ In PIM/Lifestyle menu, Calendar ■ □ □ Calendar Settings ■ Default View ■ Select type ■	
Jumping to specified date	→ Tools → ● → In PIM/Lifestyle menu, Calendar → ● → 83 → Enter date → ●	
	Start Here ● → Tools → ● In PIM/Lifestyle menu, Calendar → ● → See below	
Changing date	By Days of the Week → Calendar Settings → ● Set Color → ● By Week → ● Select day → ● Select color → ●	
color	By Date Select date ⇒ 45 ⇒ Select color ⇒ •	
	Resetting "By Date" Colors → Calendar Settings → ● Set Color → ● Reset Color → ● Select option → ● → Yes → ●	
Selecting task view option	■ * Tools * ■ In PIM/Lifestyle menu, Calendar * ■ * A Calendar Settings * ■ * Tasks View * ■ * Select option * ■	
Adding stamps (Month View)	● → Tools → ● In PIM/Lifestyle menu, Calendar → ● → Select date → ②② → Select stamp → ● • Available in Month View only.	
Hiding schedules	■ * Tools * ■ In PIM/Lifestyle menu, Calendar * ■ * Select date * ■ * Select entry * ■ * ■ * Secret: * ■ * On * ■ ** ** ** ** ** ** ** ** **	

Saving additional holidays	Simrt Here ● → Tools → ● → In PIM/Lifestyle menu, Calendar → ● → → Calendar Settings → ● → Set Holiday → ● → ○ Private → See below Adding Holidays <empty> ● ● Enter name → ● Enter date → ● → Select frequency → ● → ✓ Editing Added Holidays Select holiday → Edit ● → Name: → ● ● Enter date → ● → Select frequency → ● → Enter date → ● → Select frequency → ● → Enter date → ● → Select frequency → ● → ✓</empty>	
Removing/restoring holidays	● * Tools * • In PIM/Lifestyle menu, Calendar * • * A Calendar Settings * • Set Holiday * • A Private or Public Select holiday * • (□/√)	
Saving/Editing Schedules		
Setting Category/	Start Here ● → Tools → ● → In PIM/Lifestyle menu, Calendar → ● → Select date → ● → Select entry → ● → ● > See below	
Location	Category Category: Select Category ■ Select Category	
	Location Location: ▶ ■ Enter location ▶ □	
Saving repetitive schedules	■ Tools ■ In PIM/Lifestyle menu, Calendar ■ Select date ■ Select entry ■ ■ Repeat: ■ Select frequency ■ Enter repeat time ■ ■ Repeat time is not available for Every Year.	



Sounding Alarm tone even in Manner mode	Calendar • • Alarm Settings • For Manner Mode: • Ring • Yes
■ Managing Sche	dules
	Start Here ● → Tools → ● In PIM/Lifestyle menu, Calendar → ● → See below
Searching entries	By Subject 6.□ → Enter subject → ●
	By Category S Select Category ■
Checking memory status	● → Tools → ● → In PIM/Lifestyle menu, Calendar → ● → Select date → → Memory Status → ●
Deleting all entries	 Tools In PIM/Lifestyle menu, Calendar Delete All Data Enter Handset Code Yes
Deleting entries by specifying week (Week View)	Start Here ● → Tools → ● In PIM/Lifestyle menu, Calendar → ● → See below
	Within One Week Select date ⇒ → Delete ⇒ ● → All This Week ⇒ ● → Yes ⇒ ●
	Up to the End of Previous Week Select date ⇒ → Delete ⇒ ● UpTo Last Week ⇒ ● ≯ Yes ⇒ ●

Toole > In DIM/Lifectule menu

		<u> </u>
	Deleting entries by specifying month (Month View)	Start Here ● → Tools → ● In PIM/Lifestyle menu, Calendar → ● → See below
		Within One Month Select date → → Delete → → All This Month → ● → Yes → ●
		Up to the End of Previous Month Select date → → Delete → ● → By Last Month → ● → Yes → ●
	Deleting entries in	→ Tools →
	two months	Calendar ⇒ • ⇒ All
	(2Month View)	2 months ⇒ • Yes ⇒ •

Tasks

■ Task List

Secret: Don	Hiding tasks	● * Tools * • In PIM/Lifestyle menu, Tasks * • * Select task * * Dedit * • Secret: * • On * • *
---	--------------	--

■ Saving/Editing Tasks

Editing tasks	■ ** Tools ** • In PIM/Lifestyle menu, Tasks ** • Select task ** A** Edit ** • * Select item ** • Edit in the same manner as saving tasks ** A**
Setting priority	■ Tools ■ In PIM/Lifestyle menu, Tasks ■ Select task ■ Edit ■ ■ Priority: ■ Select option ■ ■

Changing Alarm tone/video & duration	Start Here ● → Tools → ● → In PIM/Lifestyle menu, Tasks → ● → Select task → → → Edit → ● → Alarm: → ● → See below
	Alarm Tone/Video Assign Tone/Video: Select folder Select tone/file Select start point if required.
	Duration Duration: Select time Duration: Durat
Changing Alarm volume	■ Tools ■ In PIM/Lifestyle menu, Tasks ■ Alarm Settings ■ Alarm Volume: ■ Adjust level ■ ■
Selecting Vibration option	▼ Tools ▼ ▼ In PIM/Lifestyle menu, Tasks ▼ ▼ △ → Alarm Settings ▼ ▼ ▼ Vibration: ▼ ▼ Select option ▼ ▼
Sounding Alarm tone even in Manner mode	■ * Tools * ■ In PIM/Lifestyle menu, Tasks * ■ * Alarm Settings * ■ * For Manner Mode: * Ring * ■ Yes ■

■ Managing Tasks

	Start Here		
Searching tasks	By Subject		
	By Subject ⇒ ● Denter subject ⇒ ●		
	By Due Date		
	By Due Date ⇒ ● ⇒ Enter date ⇒ ●		
Sorting tasks by	→ Tools →		
priority	Tasks → • → B → Sort → • Priority → •		
Checking memory	→ Tools →		
status	Tasks → Memory Status → Memory Status		
Deleting all tasks	■ Tools ■ In PIM/Lifestyle menu, Tasks ■ Delete ■ All Tasks ■ Enter Handset Code ■ Yes ■		

Alarms	
Editing entries	● → Tools → ● → In PIM/Lifestyle menu, Alarms → ● → Select entry → ● → Select item → ● → Edit in the same manner as saving entries → ✓
Saving entry name	■ → Tools → ■ In PIM/Lifestyle menu, Alarms → ■ → Select entry → ■ → Subject: ■ ● Enter name → ■ → 🖂
	Start Here ● → Tools → ● → In PIM/Lifestyle menu, Alarms → ● → Select entry → ● → Tone/Video: → ● → See below
Changing Alarm tone/video	Using Preset Tone or Data Folder File Select folder ■ Select tone/file ■ □ Select start point if required.
	Using Customized Screen Tone/Video Customized Screen
Setting handset to vibrate at Alarm Time	■ Tools ■ In PIM/Lifestyle menu, Alarms ■ Select entry ■ Vibration: ■ On or Link to Sound ■ ▼ Select Link to Sound to allow compatible SMAF files to control vibration.
Sounding Alarm tone even in Manner mode	■ * Tools * • In PIM/Lifestyle menu, Alarms * • * Settings * • * For Manner Mode * • * Ring * • * Yes * •
Activating Alarm based on World Clock time	● ▼ Tools ▼ ● ▼ In PIM/Lifestyle menu, Alarms ▼ ● ▼ Settings ▼ ● ▼ Link to World Clk ▼ ● ▼ On ▼ ●

Wakeup TV

-	
Editing entries	● * Tools * • In PIM/Lifestyle menu, Wakeup TV * • Select entry * • * Select item * • Edit in the same manner as saving entries * *
	Start Here
Changing Alarm tone/video	Using Preset Tone or Data Folder File Select folder ■ Select tone/file ■ Select start point if required.
	Using Customized Screen Tone/Video Customized Screen
Sounding Alarm tone even in Manner mode	● ▼ Tools ▼ ● In PIM/Lifestyle menu, Wakeup TV ▼ ● ▼ For Manner Mode ▼ ● ▼ Ring ▼ ● ▼ Yes ▼ ●

Calculator

Copying calculation results	While result appears,
Changing exchange rate for currency conversion	● → Tools → ● → In PIM/Lifestyle menu, Calculator → ● → → Money Converter → ● → Exchange Rate → ● → Domestic or Foreign → ● → Enter rate → ●
Converting currencies	● → Tools → ● → In PIM/Lifestyle menu, Calculator → ● → Enter amount of money → → Money Converter → ● → To Domestic or To Foreign → ● • Set Exchange Rate first.

Expenses Memo

Changing Category of saved entry	● → Tools → ● In PIM/Lifestyle menu, Expenses Memo → ● → Totals → ● → Select entry → ● → Select Category → ●
Changing amount	● → Tools → ● In PIM/Lifestyle menu, Expenses Memo → ● → Totals → ● → Select entry → △ → Change Amount → ● → Edit → ●
Renaming Categories	● * Tools * • In PIM/Lifestyle menu, Expenses Memo * • Edit Category * • Select Category * • Enter name * •

Osaifu-Keitai [®]	
Enabling to view e-money balances	■ Tools ■ In PIM/Lifestyle menu, Osaifu-Keitai ■ Settings ■ Balance Info ■ Enter Handset Code ■ <empty> ■ SI Appli or Lifestyle-Appli ■ ■ Select application ■ ■ ● For use with compatible Lifestyle-Applications. ■ Start Lifestyle-Appli once before adding it to Balance Info list.</empty>
Checking e-money balance on External Display Moving applications up/down Balance Info list	With handset closed,
Removing applications from Balance Info list	Tools
Customizing handset response to reader/writer commands	● Tools ● In PIM/Lifestyle menu, Osaifu-Keitai ● Settings ● V/F Settings ● Enter Handset Code ● Select item ● Off ●
Opening IC Card properties	● ➤ Tools → ● In PIM/Lifestyle menu, Osaifu-Keitai → ● → Settings → ● → IC Card Status → ●

	Start Here
Changing IC Card	Changing Recipient
Lock notice	To Set Recipient ⇒ ● ⇒ Set Recipient ⇒ ●
recipient	⇒ Select method ⇒ ● ⇒ Select/enter
	number/address
	Omit step of pressing Rs when selecting Phone Book as setting method.
	Disabling Notice
	Off → ● →
Changing required Missed Call count for Call Remote Lock	■ Tools ■ In PIM/Lifestyle menu, Osaifu-Keitai ■ Settings ■ Remote Lock ■ Enter Handset Code ■ Call Lock ■ Count for Lock ■ Enter Missed Call count ■ ■
Restoring default Osaifu-Keitai® settings	● ▶ Tools ▶ ● In PIM/Lifestyle menu, Osaifu-Keitai ▶ ● ▶ Settings ▶ ● ▶ Set to Default ▶ ● ▶ Enter Handset Code ▶ ● Yes ▶ ●



Simulated Call

	● → Tools → ● → In PIM/Lifestyle menu,
	Simulated Call
Starting via	→ Yes → •
Simulated Call menu	 Simulated Call starts immediately regardless of
Siliulated Call Illellu	Receive Timing setting.
	Settings remain even after starting Simulated Call
	during setup.
Clearing caller information	→ Tools →
	Simulated Call
	→ Yes → • → □ → □
Overriding Silent volume setting	→ Tools →
	Simulated Call ⇒ • For Silent Mode ⇒ •
	⇒ Ring ⇒ • Yes ⇒ • □

Hour Minder

Changing Hour Minder tone/video	Start Here ● → Tools → ● → Clocks/Gauges → Hour Minder → ● → Advanced → ● Tone/Video: → ● → See below
	Using Preset Tone or Data Folder File Select folder → ● Select tone/file → ● → → → → Select start point if required.
	<u> </u>
	Using Customized Screen Tone/Video Customized Screen
Setting handset to vibrate at Hour Minder Time	● Tools ● Clocks/Gauges Hour Minder ● Advanced ● Vibration: ● On or Link to Sound ● Select Link to Sound to allow compatible SMAF files to control vibration.
Sounding Hour Minder tone even in Manner mode	● Tools → ● Clocks/Gauges → Hour Minder → ● Advanced → ● For Manner Mode: ● PRing → Yes → ●
Activating Hour Minder based on World Clock time	■ Tools ■ Clocks/Gauges ■ Hour Minder ■ Advanced ■ Link to World Clk: ■ On ■ P

Notepad	
Editing Notepad	Start Here ● → Tools → ● → Doc./Rec. → Notepad → ● → Select entry → → See below Editing Text Edit Text → ● → Edit → ●
	Changing Category Change Category Select Category ■
Searching text within all entries	● → Tools → ● → O Doc./Rec. → Notepad • ● → Select entry → → Search → ● Enter text → ●
Inserting Notepad text into message text	■ Tools ■ Doc./Rec. Notepad ■ Select entry Bend ■ As Msg. Text ■ S! Mail or SMS ■ Complete message ■ S! Mail Composition window opens automatically depending on character count.
Sending entries via S! Mail	● → Tools → ● → O Doc./Rec. → Notepad → ● → Select entry → → Send → ● → Via Message → ● → Complete message → ✓
Creating text files	■ Tools ■ Doc./Rec. Notepad ■ Select entry Bright Setting/Manage ■ Create Text File ■ Enter name ■ Save here ■
Importing text files	▶ Tools
Checking memory status	■ Tools ■ Doc./Rec. Notepad ■ Select entry B Setting/Manage ■ Memory Status ■

Opening properties	
Voice Recorder	
Saving longer recordings	■ Tools ■ Doc./Rec. Voice Recorder ■ Record Time ■ Recording Extended Voice ■ Recording starts ■ Recording ends Insert Memory Card to record in Extended Voice mode. (Recording is saved automatically.)
Sending Voice files via S! Mail	■ Tools ■ Doc./Rec. Voice Recorder ■ ■ Recording starts ■ Recording ends Save and Send ■ Complete message ■ Available in For Message mode.
Switching storage media	● → Tools → ● → Doc./Rec. → Voice Recorder → ● → Save Recording to → ● Select option → ● ● Available in For Message mode. ● Set to Ask Each Time to select media after every recording.
	-

Scan Barcode	
	Start Here In a text entry window, ☐ ♦ Scan ♦ ● ♦ Scan Code ♦ ● ♦ Frame barcode in center of Display ♦ ● ♦ See below
Scanning during text entry	Pasting All Scan Results •
	Pasting a Part of Scan Results → Select first character → → Highlight text range → ●
Scanning continuously	■ Tools ■ Doc./Rec. Barcode/ Scan ■ Scan Barcode ■ → Continuous Scan ■ On ■ Frame barcode in center of Display ■ Choose Yes to continue scanning or No and press to view scan results.
Reading saved barcode images	● ★ Tools ★ ● ★ O Doc./Rec. ★ Barcode/ Scan ★ ● ★ Open Barcode ★ ● ★ Select file ★ ●
Saving scan results	■ * Tools * • * Doc./Rec. * Barcode/ Scan * • * Scan Barcode * • * Frame barcode in center of Display * • * A Save * •
Saving to Notepad	● → Tools → ● → O Doc./Rec. → Barcode/ Scan → ● → Scan Barcode → ● → Frame barcode in center of Display → ● → → Notepad → ●

Saving linked info to Phone Book	■ Tools ■ Doc./Rec. ■ Barcode/ Scan ■ Scan Barcode ■ Frame barcode in center of Display ■ Select number or mail address □ Save to Ph.Book ■ As New Entry ■ ■ Complete other fields ■ To add to an existing entry, select As New Detail. When MEMORY: appears in scan results, press ■ to enter the items underlined with a dotted line automatically in Phone Book entry window.
Opening saved scan results	■ Tools ■ Doc./Rec. ■ Barcode/ Scan ■ Scanned Results ■ Select file ■ Select a file and press to rename files, open properties or delete files. ■ Some files may not open.
	Start Here ● → Tools → ● → Doc./Rec. → Barcode/Scan → ● → Scan Barcode → ● → Frame barcode in center of Display → ● → See below Dialing Numbers Select phone number → ● →
Using linked info	Sending Messages Select mail address → ● Complete message → № • When MAILTO: appears in scan results, press • to enter the items underlined with a dotted line automatically in Composition window.
	Accessing Internet Sites Select URL

Using images as Wallpaper	■ * Tools * • • Doc./Rec. * Barcode/ Scan * • * Scan Barcode * • * Frame barcode in center of Display * • Select image * * Set as Wallpaper * • • • • For images smaller or larger than Display, Wallpaper Display options appear; follow onscreen prompts.
Saving images & melodies	■ Tools ■ Doc./Rec. ■ Barcode/ Scan ■ Scan Barcode ■ Frame barcode in center of Display ■ Select file ■ To Data Folder ■ ■
Opening or playing files	■ Tools Doc./Rec. Barcode/ Scan Scan Scan Barcode Frame barcode in center of Display Select file
Using images for System Graphics	■ Tools ■ Doc./Rec. ■ Barcode/ Scan ■ Scan Barcode ■ Frame barcode in center of Display ■ Select image As System ■ Select item ■ Specify display area ■ ■ Some images may be usable without specifying display area.

Pasting to message text	Start Here ● → Tools → ● → Doc./Rec. → Barcode/Scan → ● → Scan Barcode → ● → Frame barcode in center of Display → ● → → Send Message → ● → See below
	All Text ■
	Selected Text → Select first character → ● → Highlight text range → ● → S! Mail or SMS → ● Complete message → → ● S! Mail Composition window opens automatically depending on character count.
Copying text	Start Here ● → Tools → ● → Doc./Rec. → Barcode/Scan → ● → Scan Barcode → ● → Frame barcode in center of Display → ● → See below
	Text
	Number, Address or URL Select number, mail address or URL Copy Telephone, Copy Address or Copy URL ■


Scan Card

Saving to Notepad	● * Tools * • * Doc./Rec. * Barcode/ Scan * • * Scan Card * • * Frame card in center of Display * • * • * A Notepad * •
Pasting to message text	Start Here ● → Tools → ● → Doc./Rec. → Barcode/Scan → ● → Scan Card → ● → Frame card in center of Display → ● → ● → → Send Message → ● → See below
	All Text ■ S! Mail or SMS ■ Complete message □ • S! Mail Composition window opens automatically depending on character count.
	Selected Text → Select first character → • → Highlight text range → • → S! Mail or SMS → • → Complete message → ✓ • S! Mail Composition window opens automatically depending on character count.
Copying text	Start Here $\blacksquare \Rightarrow Tools \Rightarrow \blacksquare \Rightarrow \triangle Doc./Rec. \Rightarrow Barcode/Scan \Rightarrow \blacksquare \Rightarrow Scan Card \Rightarrow \blacksquare \Rightarrow$ Frame card in center of Display $\Rightarrow \blacksquare \Rightarrow \blacksquare \Rightarrow$ See below
	Text

Scan Text

Scanning during text entry	In a text entry window, Scan Frame text in center of Display Select line Select line Select line Select line Select line Select line
Scanning more text	■ Tools ■ Doc./Rec. Barcode/ Scan ■ Scan Text ■ Frame text in center of Display ■ Select line ■ ■ Continue Part or Scan More ■ Select Continue Part to enter additional text or Scan More to enter text after a line break.
Saving scan results	■ Tools ■ Doc./Rec. Barcode/ Scan ■ Scan Text ■ Frame text in center of Display ■ Select line ■ ■ ■ Save ■ ■
Saving linked info to Phone Book	■ Tools ■ Doc./Rec. Barcode/ Scan ■ Scan Text ■ Frame text in center of Display ■ Select line ■ ■ Select number or mail address □ Save to Ph.Book ■ As New Entry ■ Complete other fields □ ■ To add to an existing entry, select As New Detail.
Saving to Notepad	■ Tools Doc./Rec. Barcode/ Scan ■ Scan Text ■ Frame text in center of Display ■ Select line ■ Notepad ■
Opening saved scan results	■ Tools Doc./Rec. Barcode/ Scan Doc./Rec. Barcode/ Scan Doc./Rec. Barcode/ Scan Doc./Rec. Barcode/ Select afle and press to rename files, open properties or delete files. Some files may not open.

Using linked info	Start Here ● → Tools → ● → Doc./Rec. → Barcode/Scan → ● → Scan Text → ● → Frame text in center of Display → ● → Select line → ● → ● → See below Dialing Numbers
	Select phone number Sending Messages Select mail address Complete message
	Accessing Internet Sites Select URL ●
Pasting to message text	Start Here ● → Tools → ● → Doc./Rec. → Barcode/Scan → ● → Scan Text → ● → Frame text in center of Display → ● → Select line → ● → ● → Send Message → ● See below
	All Text ■ S! Mail or SMS ■ Complete message ■ □ ■ S! Mail Composition window opens automatically depending on character count.
	Selected Text → Select first character → → Highlight text range → → S! Mail or SMS → → Complete message → → • S! Mail Composition window opens automatically depending on character count.



Osaifu-Keitai®



Cannot use Osaifu-Keitai® (S! FeliCa)

• Battery may be low. Charge battery or install a charged battery.



Recognition via reader/writer takes time

• Check logo area. Foreign articles can block/hamper recognition.



Call Remote Lock does not activate even after specified number of Missed Calls

- . Missed Call count is reset by calls from other numbers. If series is interrupted, start over from the beginning.
- When Call Forwarding is active, Missed Calls may not be recorded.

Wakeup TV



TV does not activate with specified channel

• If Wakeup TV Time arrives while TV is active, channel does not switch to the specified one.

Voice Recorder



Cannot record properly

• If incompatible microphone is connected, recording may fail.



Noise/skipping occurs

 Avoid shocks to handset while recording; may cause noise or skipping.



Recording takes time to start

• Recording window may take longer to open as more Voice files are saved on Memory Card.

Scanning Barcode/Card/Text



Cannot read barcodes properly

- · Scan may fail if barcode is dirty or unclear.
- · Scan may fail if barcode is scanned under inadequate light.
- · Scan may fail if multiple barcodes are captured at one time.



Cannot read barcodes during text entry

· Scanning is not available during calls or when mobile camera is active.



Cannot read barcode images in **Data Folder automatically**

· When scan fails, follow onscreen instructions and select next barcode image manually.



Cannot scan business cards properly

- Scan fails if business card is printed in light-colored text on a dark background, handwritten or printed in casual/decorative fonts, decorated with a background pattern, or designed with both vertical and horizontal text.
- · Scan may fail if business card is printed in light-colored text on a light background, printed in italics or extremely small fonts, decorated with a logo or logo-like text, printed on a glossy paper or other material, or dirty/folded.



Cannot scan text properly

- Scanning over 35 characters at one time may yield poor results.
- · Adjust to frame text in []. Letters at the ends may be distorted.

