# 9

**Entertainment &
Communication**

Customizing Standby Display (Japanese)

Paste various widgets (applications) to Standby to access/activate information/ functions immediately from Standby.

S! Quick News & S! Friend's Status Widget

Widgets

Obtaining Widgets

1 ● ➜ *Entertainment* ➜ ●
➜ *Mobile Widget* ➜ ●

Mobile Widget Menu

2 *Widget Contents* ➜ ●

Widget List

3 *Download* ➜ ●
● Follow onscreen instructions.

Installing Widgets
● Some widgets may need to be installed manually; follow these steps:
[Widget List] Select widget ➜ ㊂ ➜ *Install* ➜ ● ➜ *Yes* ➜ ●
Activating Single Widgets
[Widget List] Select widget ➜ ● ➜ ●

Advanced

◦ ●Opening properties ●Opening widget notification history ●Canceling automatic updates ●Receiving updates automatically while abroad ●Disabling widget notifications ●Disabling cookies ●Deleting cookies (**P.9-15**)

Saving Widgets to Standby

1 ⃞

• Pointer (✎) appears.

2 Use ⊡ to select 🔲 (OPEN) ➜ ⚫

Widget Tab

Standby Shortcut Tab

• Press ⊡ to toggle selection.
• Alternatively, use 💠 to point to 🔲 (OPEN) and press ⚫.

3 Select widget ➜ ⚫

• Corresponding icon appears in Standby.

4 Use 💠 to specify target location ➜ ⚫

Removing Widgets from Standby
⃞ ➜ Use ⊡ to select widget ➜ ⊠ ➜ *Operation* ➜ ⚫ ➜ *Remove* ➜ ⚫ ➜ *Yes* ➜ ⚫

Moving Widgets
⃞ ➜ Use ⊡ to select widget ➜ ⊠ ➜ *Operation* ➜ ⚫ ➜ *Change Layout* ➜ ⚫ ➜ Specify target location ➜ ⚫

Moving Widgets to Front/Back
⃞ ➜ Use ⊡ to select widget ➜ ⊠ ➜ *Operation* ➜ ⚫ ➜ *To Front* or *To Back* ➜ ⚫

Updating View
⃞ ➜ Use ⊡ to select widget ➜ ⊠ ➜ *Operation* ➜ ⚫ ➜ *Update View* ➜ ⚫

Using Widgets

1 ⃞ ➜ Use ⊡ to select widget ➜ ⚫

2 ⚫

• Widget activates; follow onscreen instructions.

Using Sheets

Paste widgets and Standby Shortcuts on each sheet; toggle sheets to use them.

Saving Widgets on Other Sheets

1 **In Widget list, select widget** ➜ ⊠

2 *Set as StbyShortcut* ➜ ⚫

Set as StbyShortcut
シート1
Unregistered X/5
シート2
Unregistered X/5
シート3
Unregistered X/5
シート4
Unregistered X/5

3 Select sheet ➜ ⚫

4 Specify target location ➜ ⚫

Entertainment & Communication

9

Advanced

🖐 ●Logging in to Yahoo!JAPAN ●Viewing widget-related information (Japanese) ●Reversing icon selection order with ⊡ ●Slowing pointer speed ●Editing sheet names ●Locking sheets (**P.9-15** - **9-16**)

Toggling Sheets

1. ⓒ ➜ ⸬ **(Long)**

Ⓣⓘⓛ🅼 〔　　　〕◀▥▥▥

↓ ⸬ (Long)

Ⓣⓘⓛ 〔ｼｰﾄ2〕◀▥▥▥

● To toggle further, Long Press ⸬ or press ⌨.
● Sheet name appears at the top, then disappears.
● Save widgets as needed; corresponding icons appear on the current sheet.

Using Locked Sheets
ⓒ ➜ Select 🅐 ➜ ● ➜ Enter Handset Code ➜ ●

Deleting Widgets

■ **One Entry**

1. **In Widget list, select widget ➜** ✉

● *S!速報ニュース/S!ともだち状況* cannot be deleted.

2. *Delete* ➜ ● ➜ *Yes* ➜ ●

■ **All Entries**

1. **In Widget list,** ✉

● When an item other than *Download* or *S!速報ニュース/S!ともだち状況* is selected, press ✉ then select *Manage Items* and press ●.

2. *Delete All* ➜ ● ➜ Enter Handset Code ➜ ●

3. *Yes* ➜ ●

● If there is widget saved in Standby, a confirmation appears.

Using S! Quick News & S! Friend's Status Widget

832SH is preloaded with *S!速報ニュース/S!とも だち状況* (S! Quick News & S! Friend's Status widget) that shows S! Quick News and S! Friend's Status information in Standby.

〔😊▯▯▯▯▯▯〕 ─── S! Friend's Status
〔【S!速報ニュースとは?】〕 ─── S! Quick News

View Settings

■ **Setting View Pattern**

1. ⓒ ➜ Use ⸬ to select S! Quick News/S! Friend's Status widget ➜ ✉

2. *Operation* ➜ ● ➜ *Pattern Setting* ➜ ●

3. Select item ➜ ● (☑) ➜ ⸬

■ **Switching View**

1. ⓒ ➜ Use ⸬ to select S! Quick News/S! Friend's Status widget ➜ ✉

2. *Operation* ➜ ● ➜ *Switch Pattern* ➜ ●

● Repeat the above steps to switch the view.

Advanced

🔧 ●Adding news items ●Changing news scroll speed ●Showing unread news only ●Showing news images ●Assigning members ●Managing members (**P.9-16**)

Receiving Content Updates (Japanese)

View content updates or breaking news. Transmission fees apply.

Registering S! Quick News Items

1. ● ➔ *Entertainment* ➔ ● ➔ *S! Quick News* ➔ ●

   Title🎮   15:05📶
   S! Quick News
   S! Quick News List
   Settings

   S! Quick News Menu

2. *S! Quick News List* ➔ ●

   Title🎮   15:05📶
   📰 登録はこちら   📋
   📰 S!速報ニュースとは ▶ 📋
   - <未登録>
   - <未登録>

   S! Quick News List

3. *登録はこちら* ➔ ● ➔ *Yes* ➔ ●

   ● Handset connects to the Internet.

4. Select item ➔ ●

   ● Follow onscreen instructions.

Opening Information

1. In S! Quick News List, select item ➔ ●

   ● Title list appears.

2. Select title ➔ ●

   Title🎮   15:05📶
   📰 ニュース通報
   台風7号接近
   今年最大の台風7号が九州地
   方に接近中。今夜にも上陸のお
   それ。河川の増水などに、警戒
   が必要

   ● Press 🔲 to return to title list, or 🔽 to open next title.

Updating Items Manually
[S! Quick News List] Select item ➔ 🔽 ➔ *更新* ➔ ● ➔ *一件* or *全件* ➔ ●

	Indicators		
📰	Unread Special news	📋	Unread General news
📰	Read Special news	📋	Read General news
📰	Unread News Flash	☒	Auto update disabled
📰	Read News Flash		

Advanced

🖱 ●Updating S! Quick News list automatically ●Checking update schedule ●Deleting S! Quick News items ●Resetting S! Quick News List ●Changing background image ●Accessing source sites ●Disabling image download (**P.9-17**)

S! Information Channel & Weather Indicator (Japanese)

Subscribe to Japanese mobile periodicals that download to handset automatically; use Weather Indicator as needed. Transmission fees apply.

Service Registration & Content Subscription

1 **●** ➡ *Entertainment* ➡ **●** ➡ *S! Information Channel/ Weather* ➡ **●**

```
Title                15:05
     S!Info. Channel
What's New

Back Issue

Registration/Cancel

Get Latest Contents
```
S! Information Channel Menu

2 *Registration/Cancel* ➡ **●**
● Handset connects to the Internet. Follow onscreen instructions.

New Received Information

Information window opens for new S! Information Channel info delivery.

1 **While Information window appears,** *S! Info. Channel* ➡ **●**
● S! Information Channel page opens. Follow onscreen instructions.
● S! Information Channel page handling is similar to that of Yahoo! Keitai.

2 **☎** ➡ **Page closes**

Opening Unread Latest Issue
[S! Information Channel Menu]
What's New ➡ **●**
Opening Back Issues
[S! Information Channel Menu]
Back Issue ➡ **●** ➡ Select date ➡ **●**

Using Weather Indicator

After S! Information Channel registration, local area weather indicator appears in Standby.

☀	Clear skies (day)	☃	Snow
☽	Clear skies (night)	⚡	Thunder showers
☁	Cloudy	▷	Then
☔	Rain	╱	Partly/chance of

Example: ☁/☔ ➡ Partly cloudy with a chance of rain
Indicators other than the above also appear for more information.

Manual Update
[S! Information Channel Menu]
Weather Indicator ➡ **●** ➡ *Manual Update* ➡ **●** ➡ *Yes* ➡ **●**

Reading e-Books (Japanese)

Downloading e-Books

1. ⌨ ➡ **メニューリスト** ➡ ●

2. **書籍・コミック・写真集** ➡ ●
 - Follow onscreen instructions.
 - Downloaded e-Books are saved to Data Folder (Books).

Note
 - Alternatively, go to SH-web Mobile Internet site (*シャープメーカーサイトSH-web* in Bookmarks; see **P.5-7**) for e-Books.

e-Book Viewer

Read XMDF books and dictionary files. Some files may not be supported.

1. ● ➡ *Entertainment* ➡ ●

 | Till🗺 15:05📶
 | Entertainment
 | 🌐 Mobile Widget
 | 📰 S! Quick News
 | 📡 S! Information Cha…
 | 📖 BookSurfing
 | 📖 e-Book Viewer

 Entertainment Menu

2. *e-Book Viewer* ➡ ●
 - e-Book Viewer starts. Refer to the e-Book Viewer help menu for operational instructions.

BookSurfing®

Download Contents Keys and read CCF files. Some files may not be supported.

1. **In Entertainment menu, *BookSurfing* ➡ ●**
 - BookSurfing® S! Application starts. Refer to the BookSurfing® help menu for operational instructions.

Moving CCF Files via Memory Card
 - When purchasing a new handset, move CCF files and retrieve Contents Keys to open the files. Some files may need to be re-downloaded.

Advanced

👆 ●Copying text ●Opening non-832SH e-Books (Library) ●Using Library (**P.9-19**)

9-7

Using S! Friend's Status

Exchange current usage status, mood, etc. with compatible handsets.

- Save and organize members in Groups.
- S! Friend's Status requires a separate contract and basic monthly fee.
- Set Connection status to *Online* first.

First S! Friend's Status Use

Follow these steps to register a number saved in Phone Book; Status, Availability and Comment are sent to the members.

⠿⠿ ⠿ ⠿ 15:05⠿
● Yamada Takako
私の状況
⚠ Online
☺ ごきげん
⚙ Answer Status
📷 Answer OK
📧 Reply OK
👥 Join OK
💬 <Add Comment>

1 ⌨ **(Long)**

Change My Status
to Online?
Yes
No

2 *Yes* ➜ ●

A member is not
registered.
Register a member?
Yes
No

3 *Yes* ➜ ●

4 *Phone Book* ➜ ●

5 **Select entry ➜ ● ➜ Select phone number ➜ ●**

Send a member
registration
request to Ueda
Mikio?
Yes
No

- Omit number selection step if only one number is saved.

6 *Yes* ➜ ●

- Registration request is sent to the number.

When Request is Accepted
- An acceptance notice arrives; My Status is sent and member's status appears on handset.

Direct Entry
  In 4, *Add New Entry* ➜ ● ➜ **Enter phone number** ➜ ● ➜ 6

Advanced

📇 ●Adding members ●Deleting members ●Moving members ●Renaming Groups ●Rejecting requests ●Updating manually ●Opening notices
●Sending My Details image (And more on **P.9-19** - **9-20**)

Opening Member Status

1. ⚹ **(Long)** ➜ ⊙ **Select Group**

My Status
Member Status

2. **Select member** ➜ ●

When Cancellation Notice Arrives
● Member is deleted from S! Friend's Status member list.

Changing My Status

Follow these steps to change Status, Availability and Comment; new status is sent to the members.

1. ⚹ **(Long)** ➜ *私の状況* ➜ ●

Connection Status

My Status Window

2. **Select Status, e.g., *ごきげん*** ➜ ●

Status Template Window

3. **Select new Status** ➜ ●

4. **Select Availability, e.g., *Answer OK*** ➜ ● ➜ **Select new Availability** ➜ ●

5. *<Add Comment>* ➜ ● ➜ **Enter text** ➜ ●

6. ⊠ ➜ **Update starts**

Changing Connection Status
[My Status Window] *Online* (or *Offline*) ➜ ● ➜ Select status ➜ ●
Changing Status Icon/Label
[Status Template Window] Select Status ➜ ⊠ ➜ *Status Icon* or *Status Label* ➜ ● ➜ Select Pictogram or enter text ➜ ● ➜ ⊠
Changing Availability Settings at Once
In 4, *Answer Status* ➜ ● ➜ Select new Answer Status ➜ ● ➜ From 5
Editing My Status Name
[My Status Window] ⊠ ➜ *Edit Name* ➜ ● ➜ Edit ➜ ●

Entertainment & Communication

9

9-9

Entertainment & Communication

9

Receiving Request from Unsaved Numbers

When a registration request arrives, a confirmation appears.

```
Accept the
registration
request from Kondo
Koichi?
   Yes
   No
ConfirmLater
```

1 *Yes* ➡ ●

● Acceptance notice is sent; the number is registered.

Rejecting
In ❶, *No* ➡ ● ➡ *Yes* ➡ ●
■ Rejection notice is sent; the number cannot be registered for 24 hours.
■ For *ConfirmLater*, Information window opens.

Creating Status Templates

Save custom combinations of Status Icon and Status Label to each template.

```
          15:05
状況テンプレート
  1   2   3   4
☺ごきげん
☻ハッピー
㊙ひま～
♨あそぼ～
㊙やばっ
```

1 In Status Template window, ☑ ➡ *New Entry* ➡ ●

2 Enter name ➡ ●

3 *<未定>* ➡ ●

```
          15:05
Status Setting
Status Icon

Status Label
```

4 *Status Icon* ➡ ● ➡ Select Pictogram ➡ ●

5 *Status Label* ➡ ● ➡ Enter text ➡ ● ➡ ☒

6 Repeat ❸ - ❺ ➡ ☒ ➡ Saved

Saving to Data Folder
[Status Template Window] ◌ Select template ➡ ☑ ➡ *Save to DF* ➡ ● ➡ *Save here* ➡ ●
Loading Templates via Data Folder
[Status Template Window] ☑ ➡ *Add Template* ➡ ● ➡ Select template ➡ ●
Renaming Templates
[Status Template Window] ◌ Select template ➡ ☑ ➡ *Edit Temp. Name* ➡ ● ➡ Enter name ➡ ●

Advanced

Using S! Circle Talk

Use handset like a walkie-talkie to speak to multiple parties simultaneously.

- A subscription to S! Friend's Status is required.
- Transmission fees apply during S! Circle Talk.

Registering Members

Follow these steps to register a number saved in Phone Book:

1 📷
- When registering a member for the first time, a confirmation appears. Choose *Yes* and press ●, then skip ahead to ❸.

2 *<Add New Entry>* ➡ ●

```
Til      15:05
    New Entry
Individual
Group
```

3 *Group* ➡ ● ➡ *Group Name:* ➡ ● ➡ Enter name ➡ ●

```
Til      15:05
NewGroup 0 People
Group Name:
Friend
No.1:

No.2:
```

4 Select number, e.g., *No.1:* ➡ ●

5 *Phone Book* ➡ ●

6 Select entry ➡ ● ➡ Select phone number ➡ ●

```
Til      15:05
NewGroup 1 People
Group Name:
Friend
No.1:
Ueda Mikio
No.2:
```

- Omit number selection step if only one number is saved.
- Repeat ❹ - ❻ to add members.

7 🔳 ➡ **Saved**

Saving as Individuals
In ❸, *Individual* ➡ ● ➡ ❻ - ❻

Saving from S! Friend's Status Member List
In ❺, *Members List* ➡ ● ➡ Select member ➡ ● ➡ ❼
- Omit ❼ when *Individual* is selected in ❸.

Advanced

Editing individual members *Editing Groups* (**P.9-20**)

Initiating S! Circle Talk

Follow these steps to send S! Circle Talk requests to members:
(First, set Connection status to *Online* (**P.9-9**).)

[●] 1 🔲

```
Till📶  🔋        15:05📋
S! C/T Member List
⇨<Add New Entry>
👤 Natsuyama Sora
👤 Friend
```

2 **Select member or Group ➡ ●**

3 **● ➡ Transmission starts**
   ● S! Circle Talk starts when request is accepted by a receiver.
   ● Loudspeaker activates automatically.

Direct Entry
   Enter phone number ➡ 🔲 ➡ ● ➡ Transmission starts

S! Circle Talk Operations

■ **Speaking**

1 **Press and hold 🔲 when *Press and Hold* 🔘 appears ➡ You have the floor**

```
Till📶  🔋        🔊 15:05📋
S! Circle Talk  2
Ueda Mikio        🔘
```

```
Press and Hold  🔘
Add            🔇
```

   ● 🔘*:My Turn* appears when you have the floor.

2 **Keep holding 🔲 to speak ➡ Release 🔲 ➡ Floor is released**
   ● Warning tone sounds before time limit.

Incoming Calls during S! Circle Talk
● Incoming calls are rejected. Set handset to exit S! Circle Talk to answer incoming calls as needed.
Canceling Loudspeaker
   During S! Circle Talk, ●
   ■ To reactivate, follow these steps:
      ● ➡ While message appears, ●

■ **Exiting S! Circle Talk**

1 **🔚 ➡ Connection ends**
   ● S! Circle Talk ends automatically when there is only one participant left, including yourself.

Rejoining S! Circle Talk
   🔄/◁ ➡ Select most recent S! Circle Talk record ➡ 🖃 ➡ *Rejoin Circle Talk* ➡ ●
   ■ Not available when S! Circle Talk has ended or maximum number of participants are already engaged.

Accepting S! Circle Talk Request

1 **While handset is ringing/ vibrating, 🔄 ➡ S! Circle Talk starts**
   ● Alternatively, press 🔲.
   ● S! Circle Talk Operations: left

Blogging

Save blog details to view or update blogs easily on handset.

Saving Blog Details

Setup for Posting via Mail

Follow these steps to save blog name and address for posting:

1. ● ➡ *Communication* ➡ ●
   ➡ *Blog Tool* ➡ ●

   > Blog Tool
   > ① Add New Entry
   > ② Add New Entry
   >
   > Blog Tool Window

2. *Add New Entry* ➡ ●

   > Blog Setting
   > Blog Menu
   > Blog by send Mail
   > Refer/Send by Yahoo! …
   > Refer/Send by PCSiteB…
   >
   > Blog Setting Menu

3. *Blog Menu* ➡ ● ➡ Enter name ➡ ●

4. *Blog by send Mail* ➡ ●

   > Blog Setting
   > Blog's Email Address
   > Blog's Title
   > Blog's Text
   > Picture Size
   > M(640x640)
   >
   > Blog Setting Menu (Mail)

5. *Blog's Email Address* ➡ ●
   ➡ Enter mail address ➡ ●

6. CLEAR/BACK ➡ Y!

Saving Title/Text for Posts
After ❺, *Blog's Title* or *Blog's Text*
➡ ● ➡ Enter title or text ➡ ● ➡ ❻
■ Saved title/text is entered automatically when posting.

Setting Image Size for Posting
After ❺, *Picture Size* ➡ ● ➡ Select size ➡ ● ➡ ❻

Setup for Posting via the Internet

Save URL for Yahoo! Keitai or PC Site Browser, or both.

1. **In Blog Setting menu, *Refer/ Send by Yahoo! Keitai* or *Refer/Send by PCSiteBrowser* ➡ ●**

   > Blog Setting
   > Blog's URL
   > Refer Blog's URL

2. *Blog's URL* ➡ ● ➡ Enter URL ➡ ●

3. *Refer Blog's URL* ➡ ● ➡ Enter URL ➡ ●

4. CLEAR/BACK ➡ Y!

Advanced

🔧 ●Editing entries ●Deleting entries (**P.9-21**)

Posting to Blogs

Complete setup for posting via mail/ Internet beforehand.

Posting via Mail

1 **In Blog Tool window, select entry** ➜ ●

2 *Blog by send Mail* ➜ ●
 ● S! Mail Composition window opens with address entered.
 ● Omit ❷ if no URL is saved for posting.

3 **Complete message** ➜ ✉

Posting via the Internet

1 **In Blog Tool window, select entry** ➜ ●

2 *Blog by send Browser* ➜ ●
 ● Page of URL saved in *Blog's URL* opens.
 ● Omit ❷ if no address is saved for posting.
 ● If PC Site Browser message appears, follow onscreen prompts.

When URL is Saved for Yahoo! Keitai & PC Site Browser
 After ❷, select browser ➜ ●

Opening Blog Page

1 **In Blog Tool window, select entry** ➜ ✉
 ● Page of URL saved in *Refer Blog's URL* opens.
 ● If PC Site Browser message appears, follow onscreen prompts.

When URL is Saved for Yahoo! Keitai & PC Site Browser
 After ❶, select browser ➜ ●

Mobile Widget

■ Managing

Opening properties	● ➡ *Entertainment* ➡ ● ➡ *Mobile Widget* ➡ ● ➡ *Widget Contents* ➡ ● ➡ Select widget ➡ ✉ ➡ *Details* ➡ ● ● Select widget other than *S!速報ニュース/S!ともだち状況*.

■ Widget History

Opening widget notification history	Start Here ● ➡ *Entertainment* ➡ ● ➡ *Mobile Widget* ➡ ● ➡ *Widget History* ➡ ● ➡ See below **Showing All Text** Select record ➡ ✉ ➡ *View full text* ➡ ● **Deleting a Record** Select record ➡ ✉ ➡ *Delete* ➡ ● ➡ *Yes* ➡ ● **Deleting All Records** Select record ➡ ✉ ➡ *Delete All* ➡ ● ➡ Enter Handset Code ➡ ● ➡ *Yes* ➡ ●

■ Settings

Canceling automatic updates	● ➡ *Entertainment* ➡ ● ➡ *Mobile Widget* ➡ ● ➡ *Settings* ➡ ● ➡ *Auto Refresh* ➡ ● ➡ *Off* ➡ ●
Receiving updates automatically while abroad	● ➡ *Entertainment* ➡ ● ➡ *Mobile Widget* ➡ ● ➡ *Settings* ➡ ● ➡ *AutoConnect Abroad* ➡ ● ➡ *On* ➡ ●
Disabling widget notifications	● ➡ *Entertainment* ➡ ● ➡ *Mobile Widget* ➡ ● ➡ *Settings* ➡ ● ➡ *Notification Setting* ➡ ● ➡ *Off* ➡ ●

Disabling cookies	● ➡ *Entertainment* ➡ ● ➡ *Mobile Widget* ➡ ● ➡ *Settings* ➡ ● ➡ *Cookies* ➡ ● ➡ *Disabled* ➡ ●
Deleting cookies	● ➡ *Entertainment* ➡ ● ➡ *Mobile Widget* ➡ ● ➡ *Settings* ➡ ● ➡ *Delete Cookies* ➡ ● ➡ *Yes* ➡ ●

■ Operations in Standby

Logging in to Yahoo!JAPAN	⬡ ➡ ✉ ➡ *Yahoo!JAPAN log in* ➡ ● ● Follow onscreen instructions. ● To log out, select *Yahoo!JAPAN log out* in the above steps.
Viewing widget-related information (Japanese)	⬡ ➡ ✉ ➡ *Information* ➡ ● ● Follow onscreen instructions.
Reversing icon selection order with ⬢	⬡ ➡ ✉ ➡ *Move Focus(Reverse)* ➡ ● ● To cancel, select *Move Focus(Order)*.
Slowing pointer speed	⬡ ➡ ✉ ➡ *Cursor Speed* ➡ ● ➡ *Slow* ➡ ●

■ **Sheets**

Editing sheet names	Start Here ⑤ ➡ ▣ ➡ *Sheet Settings* ➡ ● ➡ *Change Sheet Name* ➡ ● ➡ See below
	Renaming Select sheet ➡ ● ➡ Enter name ➡ ●
	Resetting All Sheet Names ▣ ➡ *Yes* ➡ ●
Locking sheets	Start Here ⑤ ➡ ▣ ➡ *Sheet Settings* ➡ ● ➡ *Set Sheet Lock* ➡ ● ➡ Enter Handset Code ➡ ● ➡ See below
	Activating Lock Select sheet ➡ ● ➡ *On* ➡ ●
	Changing Method for Temporary Access *Unlock Method* ➡ ● ➡ *No Password* ➡ ● ● Press ⑤, then select 🔒 and press ● to unlock sheet temporarily.

■ **S! Quick News & S! Friend's Status Widget (S! Quick News)**

Adding news items	⑤ ➡ Use ⊻ to select S! Quick News/ S! Friend's Status widget ➡ ▣ ➡ *Operation* ➡ ● ➡ *Contents Menu* ➡ ● ➡ *Add News* ➡ ● ➡ *S! Quick News List* ➡ ● ➡ 登録はこちら ➡ ● ➡ *Yes* ➡ ● ➡ Select genre ➡ ● ➡ Select item ➡ ● ● Follow onscreen instructions.
Changing news scroll speed	⑤ ➡ Use ⊻ to select S! Quick News/ S! Friend's Status widget ➡ ▣ ➡ *Operation* ➡ ● ➡ *Contents Menu* ➡ ● ➡ *News Display* ➡ ● ➡ *News Speed* ➡ ● ➡ Select speed ➡ ●
Showing unread news only	⑤ ➡ Use ⊻ to select S! Quick News/ S! Friend's Status widget ➡ ▣ ➡ *Operation* ➡ ● ➡ *Contents Menu* ➡ ● ➡ *News Display* ➡ ● ➡ *Target News* ➡ ● ➡ *Unread Only* ➡ ●

Showing news images	⑤ ➡ Use ⊻ to select S! Quick News/ S! Friend's Status widget ➡ ▣ ➡ *Operation* ➡ ● ➡ *Contents Menu* ➡ ● ➡ *News Display* ➡ ● ➡ *Display Image* ➡ ● ➡ *On* ➡ ● ● Available when only S! Quick News area is set to appear on the Panel.

■ **S! Quick News & S! Friend's Status Widget (S! Friend's Status)**

Assigning members	**When Pattern Setting is Not *Friend's Status(List)*** ⑤ ➡ Use 🔀 to select member field ➡ ▣ ➡ *Operation* ➡ ● ➡ *Contents Menu* ➡ ● ➡ *Assign Member* ➡ ● ➡ Select category ➡ ● ➡ Select entry/member ➡ ● **When Pattern Setting is *Friend's Status(List)*** ⑤ ➡ Use ⊻ to select S! Quick News/ S! Friend's Status widget ➡ ▣ ➡ *Operation* ➡ ● ➡ *Contents Menu* ➡ ● ➡ *Assign Member* ➡ ● ➡ Select category ➡ ● ➡ Select entry/ member ➡ ● ➡ *(Empty)* ➡ ●
Managing members	Start Here ⑤ ➡ Use 🔀 to select member ➡ ▣ ➡ *Operation* ➡ ● ➡ *Contents Menu* ➡ ● ➡ See below
	Deleting Members *Delete* ➡ ● ➡ *Yes* ➡ ●
	Changing Member Order *Move* ➡ ● ➡ ▣ (Up) or ⊻ (Down) ➡ ●
	Changing Member Icons *Change Icon* ➡ ● ➡ Select Pictogram ➡ ●

S! Quick News

■ Opening/Updating Items

<table>
<tr>
<td rowspan="8">Updating S! Quick News list automatically</td>
<td>● ➡ <i>Entertainment</i> ➡ ● ➡ <i>S! Quick News</i> ➡ ● ➡ <i>Settings</i> ➡ ● ➡ <i>Automatic Update</i> ➡ ● ➡ Select item ➡ ● ➡ ● ➡ Select interval or choose <i>On</i> ➡ ●</td>
</tr>
<tr><td>● If a confirmation appears, press ●.</td></tr>
<tr><td>● When Special is set to <i>On</i>, items are updated every four hours.</td></tr>
<tr><td>● When General is set to <i>On</i>, items are updated once a day.</td></tr>
<tr><td>● To cancel automatic update, choose <i>Off</i> and press ●.</td></tr>
<tr><td>● Updating items may incur high charges.</td></tr>
<tr><td>● Only available in Japan.</td></tr>
<tr><td></td></tr>
<tr>
<td>Checking update schedule</td>
<td>● ➡ <i>Entertainment</i> ➡ ● ➡ <i>S! Quick News</i> ➡ ● ➡ <i>Settings</i> ➡ ● ➡ <i>Check Schedule</i> ➡ ●</td>
</tr>
<tr>
<td rowspan="4">Deleting S! Quick News items</td>
<td>[Start Here] ● ➡ <i>Entertainment</i> ➡ ● ➡ <i>S! Quick News</i> ➡ ● ➡ <i>S! Quick News List</i> ➡ ● ➡ Select item ➡ ⌫ ➡ See below</td>
</tr>
<tr><td>**One Entry**
一件 ➡ ● ➡ <i>Yes</i> ➡ ●</td></tr>
<tr><td>**All Entries**
全件 ➡ ● ➡ Enter Handset Code ➡ ● ➡ <i>Yes</i> ➡ ●</td></tr>
<tr><td></td></tr>
<tr>
<td>Resetting S! Quick News List</td>
<td>● ➡ <i>Entertainment</i> ➡ ● ➡ <i>S! Quick News</i> ➡ ● ➡ <i>Settings</i> ➡ ● ➡ <i>Delete S! Quick News Lists</i> ➡ ● ➡ Enter Handset Code ➡ ● ➡ <i>Yes</i> ➡ ●

● Not available during automatic updates.</td>
</tr>
</table>

■ Other

<table>
<tr>
<td>Changing background image</td>
<td>● ➡ <i>Entertainment</i> ➡ ● ➡ <i>S! Quick News</i> ➡ ● ➡ <i>Settings</i> ➡ ● ➡ <i>Change Skin</i> ➡ ● ➡ Select pattern ➡ ●</td>
</tr>
<tr>
<td>Accessing source sites</td>
<td>● ➡ <i>Entertainment</i> ➡ ● ➡ <i>S! Quick News</i> ➡ ● ➡ <i>S! Quick News List</i> ➡ ● ➡ Select item ➡ ● ➡ Select title ➡ ● ➡ Select title ➡ ● ➡ <i>Yes</i> ➡ ●</td>
</tr>
<tr>
<td>Disabling image download</td>
<td>● ➡ <i>Entertainment</i> ➡ ● ➡ <i>S! Quick News</i> ➡ ● ➡ <i>Settings</i> ➡ ● ➡ <i>Show Image</i> ➡ ● ➡ <i>Off</i> ➡ ●</td>
</tr>
</table>

S! Information Channel

■ **Receiving Information**

| Hiding Information window for new received info | ● ➡ *Entertainment* ➡ ● ➡ *S! Information Channel/Weather* ➡ ● ➡ *Notification* ➡ ● ➡ *Off* ➡ ● |
| Requesting re-delivery | ● ➡ *Entertainment* ➡ ● ➡ *S! Information Channel/Weather* ➡ ● ➡ *Get Latest Contents* ➡ ● ➡ *Yes* ➡ ● |

■ **Information Pages**

Changing Display Size	On a page, □ ➡ *Settings* ➡ ● ➡ *Display Size* ➡ ● ➡ Select size ➡ ●
Changing scroll unit	On a page, □ ➡ *Settings* ➡ ● ➡ *Scroll Unit* ➡ ● ➡ Select unit ➡ ●
Copying text	On a page, □ ➡ *Copy Text* ➡ ● ➡ Select first character ➡ ● ➡ Highlight text range ➡ ●
Saving files to Data Folder	On a page, □ ➡ *Save Items* ➡ ● ➡ Select file ➡ ● ➡ *Save* ➡ ● ➡ Enter name ➡ ● ➡ *Save here* ➡ ● ● Some files are saved automatically.
Opening page properties	On a page, □ ➡ *Page Information* ➡ ●

■ **Weather Indicators**

Checking weather forecast	● ➡ *Entertainment* ➡ ● ➡ *S! Information Channel/Weather* ➡ ● ➡ *Weather Indicator* ➡ ● ➡ *Weather* ➡ ●
Changing weather forecast page font size	On a page, □ ➡ *Settings* ➡ ● ➡ *Font Size* ➡ ● ➡ Select size ➡ ●
Hiding Weather Indicator in Standby	● ➡ *Entertainment* ➡ ● ➡ *S! Information Channel/Weather* ➡ ● ➡ *Weather Indicator* ➡ ● ➡ *Settings* ➡ ● ➡ *Standby Setting* ➡ ● ➡ *Off* ➡ ●
Canceling Weather Indicator automatic updates	● ➡ *Entertainment* ➡ ● ➡ *S! Information Channel/Weather* ➡ ● ➡ *Weather Indicator* ➡ ● ➡ *Settings* ➡ ● ➡ *Icon Update* ➡ ● ➡ *Off* ➡ ●
Hiding Information window for weather updates	● ➡ *Entertainment* ➡ ● ➡ *S! Information Channel/Weather* ➡ ● ➡ *Weather Indicator* ➡ ● ➡ *Settings* ➡ ● ➡ *Weather Notif.* ➡ ● ➡ *Off* ➡ ●

e-Books

Copying text	In open page, `Y` ➜ *文字列をコピー* ➜ `●` ➜ Select first character ➜ `●` ➜ Highlight text range ➜ `●`
Opening non-832SH e-Books (Library)	`●` ➜ *Entertainment* ➜ `●` ➜ *e-Book Viewer* ➜ `回` ➜ Select file ➜ `●` ● Some files may not open.

Using Library	[Start Here] `●` ➜ *Entertainment* ➜ `●` ➜ *e-Book Viewer* ➜ `回` ➜ See below
	
	Adding Folders
	`回` ➜ *New Folder* ➜ `●` ➜ Enter name ➜ `●`
	
	Switching Folders
	`回` ➜ *Switch Folders* ➜ `●` ➜ Select folder ➜ `●`
	
	Renaming Folders/Files
	Select folder/file ➜ `回` ➜ *Change Name* ➜ `●` ➜ Enter name ➜ `●`
	
	Moving Files
	Select file ➜ `回` ➜ *Move* ➜ `●` ➜ Select folder ➜ `●` ➜ *Move here* ➜ `●`
	
	Deleting Folders/Files
	Select folder/file ➜ `回` ➜ *Delete* ➜ `●` ➜ *Yes* ➜ `●`
	
	Opening File Properties
	Select file ➜ `回` ➜ *Details* ➜ `●`

S! Friend's Status

■ Members & Groups

Adding members	`※` (Long) ➜ `◁` Select Group ➜ `回` *Add Member* ➜ `●` ➜ Select method ➜ `●` ➜ Select entry or enter phone number ➜ `●` ➜ *Yes* ➜ `●`
Deleting members	`※` (Long) ➜ `◁` Select Group ➜ Select member ➜ `回` ➜ *Registration Release* ➜ `●` ➜ *Yes* ➜ `●` ➜ *Yes* ➜ `●` ● Cancellation notice is sent; deleted members cannot be re-registered for 24 hours.
Moving members	`※` (Long) ➜ `◁` Select Group ➜ Select member ➜ `回` ➜ *Change Group* ➜ `●` ➜ Select target Group ➜ `●`
Renaming Groups	`※` (Long) ➜ `◁` Select Group ➜ `回` ➜ *Edit Group Name* ➜ `●` ➜ Enter name ➜ `●`
Rejecting requests	[Start Here] `※` (Long) ➜ `回` ➜ *Settings* ➜ `●` ➜ *Request Reply* ➜ `●` ➜ See below **Rejecting Requests from Unsaved Numbers** *Confirm if Registered* ➜ `●` ● Rejection notice is sent to rejected numbers automatically. **Rejecting All Requests** *Always Ignore* ➜ `●` ● Rejection notice is sent to all requesters automatically.

■ **Status & Availability**

Saving custom Availability combinations	$⁑$ (Long) ➡ $⊡$ ➡ *Settings* ➡ $●$ ➡ *Answer Status* ➡ $●$ ➡ *User Setting* ➡ $●$ ➡ Select type ➡ $●$ ➡ Select Availability ➡ $●$ ➡ $⨯$
Changing Status Icon Pictogram or Status Label description	$⁑$ (Long) ➡ $⊡$ ➡ *Settings* ➡ $●$ ➡ *Status Setting* ➡ $●$ ➡ $⊡$ Select template ➡ Select Status ➡ $●$ ➡ *Status Icon* ➡ $●$ ➡ Select Pictogram ➡ $●$ ➡ *Status Label* ➡ $●$ ➡ Enter text ➡ $●$ ➡ $⨯$

■ **Status Templates**

Resetting templates	Start Here $⁑$ (Long) ➡ *私の状況* ➡ $●$ ➡ Select Status ➡ $●$
	One Template $⊡$ Select template ➡ $⊡$ ➡ *Reset* ➡ $●$ ➡ *Yes* ➡ $●$
	All Templates $⊡$ ➡ *Reset All* ➡ $●$ ➡ *Yes* ➡ $●$

■ **Member Status & Notices**

Updating manually	$⁑$ (Long) ➡ $⊡$ ➡ *Settings* ➡ $●$ ➡ *Status Update* ➡ $●$
Opening notices	$⁑$ (Long) ➡ $⊡$ ➡ *Status Notif. List* ➡ $●$ ➡ Select notice ➡ $●$

■ **My Details**

Sending My Details image	$⁑$ (Long) ➡ $⊡$ Select Group ➡ Select member ➡ $⊡$ ➡ *Send Image* ➡ $●$ ➡ *Yes* ➡ $●$

S! Circle Talk

■ **Member List**

Editing individual members	Start Here $⊡$ ➡ Select member ➡ $⊡$ ➡ See below
	Replacing Members *Edit* ➡ $●$ ➡ $●$ ➡ Select method ➡ $●$ ➡ Select entry ➡ $●$
	Deleting Members *Delete* ➡ $●$ ➡ *Yes* ➡ $●$
Editing Groups	Start Here $⊡$ ➡ Select Group ➡ $⊡$ ➡ See below
	Editing Group Name/Members *Edit* ➡ $●$ ➡ Select target ➡ $●$ ➡ Edit/enter ➡ $●$ ➡ $⨯$
	Deleting Group Members *Edit* ➡ $●$ ➡ Select member ➡ $⊡$ ➡ *Delete* ➡ $●$ ➡ *Yes* ➡ $●$ ➡ $⨯$
	Deleting Groups *Delete* ➡ $●$ ➡ *Yes* ➡ $●$

■ **Settings**

Disabling Loudspeaker	$⊡$ ➡ $⊡$ ➡ *Loudspeaker* ➡ $●$ ➡ *Off* ➡ $●$
Exiting S! Circle Talk for incoming calls	$⊡$ ➡ $⊡$ ➡ *Incoming Calls* ➡ $●$ ➡ *Voice Calls* or *Video Calls* ➡ $●$ ➡ *Accept Calls* ➡ $●$

Blog Tool

Editing entries	● ➡ *Communication* ➡ ● ➡ *Blog Tool* ➡ ● ➡ Select entry ➡ 🙂 ➡ *Edit* ➡ ● ➡ Select item ➡ ● ➡ Edit ➡ ▦ ➡ ⓨ ● For *Blog Menu*, omit step of pressing ▦ after editing.
Deleting entries	● ➡ *Communication* ➡ ● ➡ *Blog Tool* ➡ ● ➡ Select entry ➡ 🙂 ➡ *Delete* ➡ ● ➡ *Yes* ➡ ●

S! Friend's Status

? Cannot use S! Friend's Status

- Set IP Service Setting to *On*.

? Handset rejected a registration request automatically

- Rejection notice is sent automatically when 30 members are already registered or handset fails to respond within two hours.

? Registration request arrived from a deleted member

- Registration request arrives when a member fails to receive cancellation notice within 24 hours.

? Registration request was sent to a member automatically

- Registration request is sent automatically when handset fails to receive rejection/cancellation notice within 24 hours.

? Cannot create Status Templates

- Three templates may already be added; reset one and retry.

S! Circle Talk

? Cannot use S! Circle Talk

- Set IP Service Setting to *On*.

? S! Circle Talk starts automatically

- Check My Status; handset accepts S! Circle Talk requests automatically if S! Circle Talk Availability is set to *Auto Join*.

? Cannot accept S! Circle Talk requests

- Check My Status; handset rejects S! Circle Talk requests automatically if S! Circle Talk Availability is set to *Join NG*.

S! Quick News

? Cannot receive content updates

- Update may fail out-of-range or in poor signal conditions.
- Automatic Update does not affect S! Quick News List News Flash update items overnight.
- USIM Card replacement cancels Automatic Update.