

Tools

Calendar	12-2
Opening Calendar	12-2
Creating Schedule Events.....	12-2
Setting Day Off.....	12-4
Viewing/Editing Schedule Events.....	12-4
Calendar Functions.....	12-5
Alarms	12-6
Setting Alarm	12-6
Calculator	12-7
Notepad	12-8
Notepad Functions	12-8
Count Down Timer	12-9
Voice Recorder	12-9
Bar Code Reader	12-10
Scanning Barcodes	12-10
Viewing/Editing Scanned Data	12-11
Using Barcode Data.....	12-11
One Touch Guide	12-12




Calendar

View by day, week or month; set Alarms for events.

Opening Calendar

1 (Side Key)

Current month appears.

- When a date with schedule events is selected, up to four events appear.
- Press  or  to show previous/next month calendar.
- To switch Monthly/Weekly view:
 P.12-5



One Month Window

Note


- Alternatively, **Main Menu** ► **Tools** ► **Calendar**.


Creating Schedule Events

Save up to 100 entries.

1 (Side Key)

2 to highlight a date

→  [Menu] → **New Entry**



3 Select an item (See below)

Item	Operation/Description
Summary	> Enter title or content
Category	Select an event type; icon appears in Standby > Select a category
Start	> Enter date and time the schedule event starts
End	> Enter date and time the schedule event ends
Description	> Enter event description
Repetition	> Select a repeat type (→ Enter repeating time)

Item	Operation/Description
Reminder	> Select an alarm type
Location	> Enter location
Schedule Tone	> Select an item <ul style="list-style-type: none"> · Default Tone · Ring Songs-Tones or Music → Highlight a file → [Set]
Schedule Volume	> to adjust volume
Notification Light	Set schedule alarm notification light color > Select a color or OFF

4 [Save]

Schedule Icon

Selected icon in Category appears in Standby.

Example: (Meeting), (Anniversary), (Birthday)

- If nothing selected, appears.
- Icon disappears after scheduled event has passed.

Note

- Schedule events between 00:00 on 2000/01/01 and 23:59 on 2099/12/31 can be saved on handset.

At Reminder Time

Schedule Tone sounds and Notification Light flashes.

- 1 When Schedule Tone sounds, Schedule Tone stops and Schedule Event List appears.
- 2 to view details

Canceling Schedule Tone

- Press to return to Standby.
- Press [Stop] to return to previous menu.
- Press any key except for , [Stop], [View] or to cancel Schedule Tone without returning to Standby. Press to view detailed schedule.

Note

- Schedule Tone does not sound in the following cases:
 - During a call (Notification appears and handset vibrates)
 - In Manner Mode (Manner Mode settings take priority)
 - When handset power is turned off
 - For entries invalidated by Time Correction

Setting Day Off

- Day Off dates appear in red.

- (Side Key)
- (Highlight a date →) ☑[Menu] → **Set Day Off**
- Select an item (See below)

Item	Operation/Description
Weekly	> Check dates → ☑[OK]
Today*	> Once or Yearly
Reset All	Reset all Day off dates > ○

* To cancel selection: **Reset Holiday**

Viewing/Editing Schedule Events

- (Side Key) → Select a date



Schedule Event List

- Select a schedule event

Detailed schedule appears.

- Press ☑ to switch Schedule tab and Contents tab.
- To edit: ○[Edit] → Edit selected items
(☞ From Step 3 on P.12-2)



Schedule Event Details

Calendar Functions

From ▶ □ (Side Key)

Switch Calendar View

<Default> One Month

> [Menu] → *View Format* → *One Month* or *One Week*

- Select *One Week* view to see daily schedules.

Search Specific Day

> [Menu] → *Go to Date* → Enter date

Set Week Start Day

> [Menu] → *Start Week From* → Select a day

Delete Schedule Events

> Follow the steps below

Item	Operation/Description
One	> Select a date → Highlight an event → [Menu] → <i>Delete</i> → [●]
Scheduled Events*	> Highlight a date → [Menu] → <i>Delete</i> → <i>Day</i> → [●] → [●]
Past Events*	> Highlight a date → [Menu] → <i>Delete</i> → <i>Past</i> → [●] → [●]
All	> [Menu] → <i>Delete</i> → <i>All</i> → [Menu] → [YES] → Enter Phone Password

* Repetitive entries cannot be deleted.

Calendar Memory Status

> [Menu] → *Memory Status*

Tip

- Send Schedule Data via Infrared (☞ P.10-3)

Alarms

When scheduled time arrives, alarm tone sounds and animation appears on Display. Notification Light illuminates.


Setting Alarm

Set up to five alarms. Alarm tone sounds at the specified time once, everyday or weekly as set.

-  appears in Standby when Alarm is set.





Main Menu ▶ Tools ▶ Alarms

1 Select an Alarm



2 Select an item (See below)

Item	Operation/Description
Alarm ON/OFF	Activate or cancel Alarm > ON or OFF
Time	> Enter time

Item	Operation/Description
Repetition	> Select a repeat type (→ For Weekly , check days →  [OK])
Alarm Tone	> Select an item · Default Tone · Ring Songs-Tones or Music → Highlight a file* →  [Set]
Set Alarm Snooze	Alarm Tone sounds for 60 seconds, repeating up to five times at specified intervals > ON or OFF (→ For ON , enter interval)
Alarm Volume	>  to adjust volume
Picture	Select image to appear > Select an item · Default Picture · Pictures → Highlight a still image →  [Set]
Set Alarm Vibration	Select Vibration type > Select pattern or OFF
Notification Light	Select Notification Light color > Select a color or OFF
Set Alarm Priority	Set Manner Mode or Alarm priority > Manner Mode Prioritized or Alarm Prioritized

* When selecting an SMC file, highlight a Play Point → [Set]

3 [Save]

At Alarm Time

Alarm Tone sounds, Notification Light flashes and image appears on Display.



1 Press any key

Alarm stops and confirmation window appears.
(When pressing , confirmation does not appear.)



- Alarm stops automatically after 60 seconds of inactivity, and confirmation window appears.


■ Cancel/Reactivate Alarm

> **Main Menu** ► **Tools** ► **Alarms** ► Highlight an alarm ►  **[Menu]**
► **Alarm ON** or **Alarm OFF**

- Activate a canceled Alarm to apply previous settings.
-  appears for set alarms;  for unset/canceled ones.

Snooze Function

If **ON**, press any key except ; confirmation appears. To cancel Alarm, press  **[Stop]**.

- When pressing  to stop alarm, confirmation does not appear.
(Snooze function is still active.)













Note

- Alarm Tone does not sound in the following cases:
 - During a call (Notification appears and handset vibrates)
 - In **Manner Mode Prioritized** (Manner Mode settings take priority)
 - When handset power is turned off
 - For entries invalidated by Time Correction

Calculator

Calculates up to 10 digits.

Main Menu ► **Tools** ► **Calculator**

Operation	Assigned key
Number (0 - 9)	 - 
+	
-	
x	
÷	
=	
Decimal point	
Clear	 or 
Toggle + and -	
%	









■ Enter Negative Numbers

- > Enter number, then 
- Press  to toggle negative/positive value.

Example:

-17+28.5=11.5

Notepad


Main Menu ► Tools ► Notepad

1 [Menu] → *New*

2 Enter text

New note is added to the top of the list.

- Up to 64 characters can be entered.



Notepads Window

Notepad Functions

From ► Main Menu ► Tools ► Notepad

Edit Notes

- > Select a note → [Edit] → Edit text
- Edited note is overwritten.

Delete Notes

- > Highlight a note → [Menu] → *Delete* → *One* or *All* → [YES] (→ For *All*, enter Phone Password)

Note Property

- > Highlight a note → [Menu] → *Property*



Insert Notes into Message Text

- > Highlight a note → [Menu] → *Send* → *Send via S! Mail* or *Send via SMS* → Enter mail address, etc. (S! Mail: From Step 2 on P.13-4/SMS: From Step 2 on P.13-8) → [Send]

Count Down Timer

Alarm Tone sounds, handset vibrates and Notification Light flashes when specified time elapses.

Main Menu ► Tools ► Count Down Timer


- 1 Enter time
- 2  [Start]
 - To cancel:  [Stop]

■ Stop Alarm Tone

> When Alarm tone sounds, 


- Alarm stops automatically after 30 seconds.

Note





- Incoming calls/other alarms do not interfere with timer operation. However, if timer reaches 00:00 while other functions are active, alarm does not sound.
- Alarm tone volume and vibration pattern follow Assign Ringtone ( P.16-2).


Voice Recorder

Record voice memos.

- Record for up to 60 seconds each.
- Recording conversation during a call:  P.2-9

Main Menu ► Tools ► Voice Recorder

- 1 
Recording starts.
- 2  to stop recording
 - To playback: 
- 3  [Save]
Recorded sounds are saved in Ring Songs-Tones folder.



Note

- Sounds recorded by Voice Recorder cannot be set as Alarm, Ringtone or Schedule Tones.

Bar Code Reader

Scan barcodes (JAN) or QR Codes with built-in camera.
Access websites, send messages, etc. from QR Codes.

JAN Codes

JAN Code is a one-dimensional bar code denoting numerals with bars and spaces of different widths.

QR Codes

QR Code is a two-dimensional bar code containing information.

Example: SoftBank mobile phones



Scanning Barcodes

- Up to ten items can be saved.
- For split data, up to 16 QR Codes can be scanned at a time and saved as one item.

Main Menu ► Tools ► Bar Code Reader ► Scan Barcodes

1 Frame barcode in the center of Display

- To adjust Display brightness: or
- To zoom:
- To use Focus Lock:

2

Scanning starts, and scanned results appear when completed.

- For split data, → Repeat Step 1 and 2

3 [Save]

- To start over: → → Go to Step 2

Note

- Handset cannot read barcodes or two-dimensional codes other than JAN/QR Codes.
- Some barcodes may be unreadable.
- Barcode recognition may be slow. Hold handset steady while scanning.
- Brightness can be adjusted while scanning; however, zoom level cannot be changed.
- Saved items are automatically named "yyymmdd_hhmmss" unless changed. (yy: year, mm: month, dd: day, hh: hour, mm: minute, ss: second)
- Barcodes may not be correctly read owing to scratch, dirt, damage, quality of printed material, light reflection, or QR code version.

Viewing/Editing Scanned Data

Main Menu ► Tools ► Bar Code Reader
► Saved Data List

1 View Saved Data

Select an item

Edit Title

Highlight an item →  [Menu] → **Rename** → Edit title

Delete Saved Data







> In Step 1, highlight an item →  [Menu] → **Delete One** → 

Using Barcode Data

From ► Main Menu ► Tools ► Bar Code Reader
► Saved Data List

■ Use URLs/Mail Addresses/Phone Numbers

> Select an item → Follow the steps below

Item	Operation/Description
URL (http:// or https://)	Connect to websites; add to Bookmarks ( P.14-8)
URL (rtsp://)	Streaming; add to Bookmarks
Mail Address	Create S! Mail ( P.13-4); save to Phone Book ( P.4-3)
Phone Number	Make calls; create messages* (S! Mail:  P.13-4/SMS:  P.13-8); save to Phone Book ( P.4-3)
Phone Book Data (MEMORY: text)	Save to Phone Book <ul style="list-style-type: none">● Save MEMORY: text only● Saved to Phone regardless of Save Settings selection

* SoftBank handset numbers only

■ Insert Scanned Text into Messages

- > Select an item → [Menu] → *Paste Data & Create Mail*
 → *S! Mail* or *SMS* → Create message (S! Mail: From Step 2 on P.13-4/SMS: From Step 2 on P.13-8)

■ Copy Text from Scanned Results

- > Select an item → [Menu] → *Copy* → Follow the steps below

Item	Operation/Description
All Text	> [All] →
Selected Text	> Place cursor before (or after) text to copy →
	Place cursor after (or before) text to copy →

One Touch Guide

Access One Touch Guide for instructions to key operations.

Main Menu ► Tools ► One Touch Guide

1 Select a function

Instructions appear.

- Press or to view previous or next information.



Example:
Magnifying Loupe

Note

- Alternatively, view from Shortcuts (P.1-20) or Private Menu (P.1-22).