



Tools

Osaifu-Keitai®	11-2	Alarm	11-14
About Osaifu-Keitai®	11-2	Setting Alarm.....	11-14
Using Osaifu-Keitai®	11-3	Canceling Alarm	11-15
Activating IC Card Lock.....	11-4	Bar Code Reader	11-16
Schedule	11-6	Scanning Bar Codes	11-16
Schedule Window	11-6	Checking Scanned Data.....	11-17
Saving Events to Schedule	11-6	Text Reader	11-18
Checking Saved Events	11-7	Scanning Text.....	11-19
To Do List	11-9	Checking Scanned Text	11-20
Saving Tasks.....	11-9	Advanced Features	11-21
Checking Saved Tasks	11-10	Osaifu-Keitai®	11-21
Deleting Tasks	11-10	Schedule	11-21
Text Memo	11-11	To Do List	11-22
Saving Text Memos	11-11	Text Memo	11-23
Deleting Text Memos.....	11-11	Alarm.....	11-23
Voice Memo	11-12	Bar Code Reader & Text Reader	11-23
Recording the Other Party's Voice	11-12		
Recording Your Voice	11-12		
Calculator	11-13		



About Osaifu-Keitai®

"Osaifu-Keitai®" is a range of IC Card-based services used by Osaifu-Keitai® compatible handsets.

Make purchases using e-money or e-ticketing. Hold handset up to a reader/writer to pay for your purchase.

©Osaifu-Keitai® Terms

Osaifu-Keitai®	Cellular phone equipped with "FeliCa" contactless IC card technology for reading and writing data by holding phone up to a reader/writer.
IC Card	An IC chip embedded in Osaifu-Keitai®-compatible handsets.
Lifestyle-Appli	SI Applications to use Osaifu-Keitai®. Some applications are preinstalled.

Tip

- Data saved in IC Card varies by service content and usage history. Procedures to delete IC Card data vary by Lifestyle-Appli. Contact Osaifu-Keitai® service providers for details.
- Softbank is not liable for damage from accidental loss or alteration of IC Card data or settings.
- IC Card data can be misused if your Osaifu-Keitai® compatible handset is lost or stolen. Softbank is not liable for any resulting damages.

Getting Started

Downloading Lifestyle-Appli

Download Lifestyle-Appli via Internet website.

- Lifestyle-Appli is saved to Data Folder.



Registrations/Settings

Activate Lifestyle-Appli to complete registration or customize settings.

- Make deposit into account, check payment records or balance, etc.

Note

- Keep a copy of service passwords, customer service contact, etc. in a separate place.



Downloading Lifestyle-Appli

1 [OK] >> Tools >> [OK] >> Osaifu-Keitai >> [OK] >> Lifestyle-Appli >> [OK] >> Download LifeApp >> [OK] >> YES >> [OK]

2 Select a Lifestyle-Appli >> [OK] (twice)

■ To Activate Lifestyle-Appli Right Away

>> YES >> [OK] >> Select a Lifestyle-Appli >> [OK]

■ To Activate Lifestyle-Appli Later

>> NO >> [OK]

Note

- Check the battery level before downloading Lifestyle-Appli. If the battery level is low, download may fail.
- If you replace USIM Card due to damage or loss, downloaded Lifestyle-Appli are no longer available.

Activating Lifestyle-Appli

1 [OK] >> Tools >> [OK] >> Osaifu-Keitai >> [OK] >> Lifestyle-Appli >> [OK]



Lifestyle-Appli List Window

2 Select a Lifestyle-Appli >> [OK]

■ To End Lifestyle-Appli

>> [Back] >> End >> [OK]

Note

- Keep a copy of service passwords, customer service contact, etc. in a separate place.

Tip


- Lifestyle-Appli is paused when a call arrives. Lifestyle-Appli resumes when the call ends.

Using Osaifu-Keitai®

Reader/Writer Transactions

- There is no need to activate a Lifestyle-Appli during transaction.
- Make sure battery is adequately charged.
- Transactions are possible even when handset power is off or during calls or Internet transmissions.

1 Hold [F] logo up to a reader/writer >> Check scan result on reader/writer display




Place this part over reader/writer

- Hold handset parallel to the reader/writer. Try moving handset around if recognition is slow.

**Note**

- Softbank is not liable for damages from accidental loss or alteration of IC Card data or settings.

Tip


- Data may be unreadable if a metal object, etc. is between  logo and reader/writer.

Activating IC Card Lock

Use this function to restrict access to and prevent unauthorized use of Osaifu-Keitai®.


- 1**  **Tools**  **Osaifu-Keitai**  **IC Card Lock Set.** 

2 Enter Security Code



IC Card Lock Setting Window

3 IC Card Lock **ON**

-  appears in Standby.
- Alternatively, set IC Card Lock by: Press and hold **3** in Standby.

■ To Set Operation of IC Card Lock after Power Off

- IC Lock(Power-off)**  **Maintain or IC Card Lock ON** 

■ To Cancel IC Card Lock

- Press and hold 3 in Standby**
Enter Security Code 

Remote Lock

Call from a specified phone to activate Call Remote Lock.


◎ Saving Numbers to Activate Call Remote Lock

- 1**  **Tools**  **Osaifu-Keitai**  **Call Remote Lock** 

2 Enter Security Code

3 ON

- To Cancel Call Remote Lock
OFF 



Call Remote Lock Setting Window



4 <Not Recorded> >> [] >>

Enter Phone Numbers >> []

- To save numbers from Phone Book, Redial or Received calls >> [] >> **Look-up Address** >> [] >> **Phone Book, Redial or Received Calls** >> [] >> Select a number >> []

- To save a Payphone number >> [] >> **Payphone** >> []

5 []

◎ Activating Call Remote Lock

1 Using one of the specified phones, call handset

- Send Caller ID.

2 Hang up after handset receives the call

3 Within three minutes, repeat 1 - 2 twice

- After the third Missed Call, IC Card Lock is set; a message announces IC Card Lock activation.

Note

- If series is interrupted by another call, Missed Call count is reset. Start over from the beginning.

More Features

Advanced

Osaifu-Keitai®

- ❖ Check Lifestyle-Appli Properties
- ❖ Check Memory Status
- ❖ Delete a Lifestyle-Appli
- ❖ Edit Call Remote Lock Numbers
- ❖ Delete Call Remote Lock Numbers

(P. 11-21)

Customize

Osaifu-Keitai®

- ❖ Set illumination for IC Card
- ❖ Delete all Lifestyle-Appli
- ❖ Set Whether to Enable Opening from Browser


(P. 14-40)




Schedule

Save future events to Schedule. Set the alarm to be activated at a specified time with message and animation appearing to remind you of the event. Saved events can be checked from Schedule window.

Schedule Window



Schedule Window




Saving Events to Schedule

- **Schedule** is assigned to by default. See P. 14-39 for how to change the assigned function.

1 **Tools** **Schedule**

2 **Schedule**



Event Edit Window

3 **Enter subject** **Select an icon**

Entered content appears when alarm sounds or vibrates.



Schedule

4 Enter start/end date and time

5 **1 Time, Daily** (), **Weekly** (), **Monthly** () or **Annually** ()

■ To Specify Days of the Week
Weekly () Put checkmarks to days of the week

6 Select an alarm notification option

■ To Activate Alarm Prior to Event
ON/Set Time Enter time

7 Select an alarm tone type (Select a folder Select an alarm tone)

Folders are unavailable when **Clock Alarm Tone** or **OFF** is selected.

8 Enter place

9 Enter details

Entered content appears when alarm sounds or vibrates.

Alarm Notification Operations

When the set time arrives, alarm sounds and animation appears on Display for approximately five minutes.
 Press any key to stop the alarm tone.
 Press any key again to end notification message.

Tip

- If the set alarm time arrives during a call, alarm tone sounds through earpiece.
- If a call arrives while the alarm is sounding, the alarm stops.

Adding Holidays

1 [Schedule] window **Holiday**

2 Enter year, month and date

3 **1 Time or Annually** ()

4 Enter content

5

Checking Saved Events

1 **Tools** **Schedule**


2009/ 4/16(Thu)						
S	M	T	W	T	F	S
			1	2	3	4
5	6	7	8	9	10	11
12	13	14	15	16	17	18
19	20	21	22	23	24	25
26	27	28	29	30		
16(T)	13:00		Meeting			
16(T)	14:30		Guest			
16(T)	15:30		Going out			
16(T)	19:30		drinking			

Schedule Window

■ To Toggle between Weekly View and Monthly View




- 2** to select a date with events



Event List Window

- 3** Select an event



Event Details Window

Deleting Events

○To Delete One Event

- 1** [Event List] window
Select an event

- 2** Delete **Delete This**
 YES

○To Delete Multiple Events

- 1** [Event List] window

- 2** Delete **Delete selected**

- 3** Select an event

Repeat this step to specify other events.

- 4** **YES**

○To Delete All Events Prior to a Specified Date

- 1** In [Schedule] window, select date, [Event List] window or [Event Details] window

- 2** Delete **Delete Past**
 Select an item
 YES

More Features

Advanced

Schedule

- ❖ Sort Events by Icon
- ❖ Check Number of Saved Events
- ❖ Edit an Event
- ❖ Copy an Event
- ❖ Make/Cancel Secret Setting of an Event
- ❖ Delete All Events
- ❖ Reset Holidays

(P. 11-21)

Customize

Alarm

- ❖ Set Priority at Alarm Notification Time
- ❖ Change Alarm Tone

(P. 14-3)




To Do List

Save tasks to To Do List. Set Alarm to remind you of deadlines.

Saving Tasks

- 1 **Tools** **To Do List** **New**

- **To Edit a Saved Task**
 ► Select a task ►



Task Edit Window

- 2 **Enter task**

Task appears when alarm time arrives.

- 3 **Enter Date** **Enter due date and time**

- **To Enter Due Date from Calendar**
 ► **Choose Date** ► ► Select a date on Calendar ► ► Enter date/time ►

- **To Cancel a Due Date**
 ► **No Date** ►

- 4 **Select a priority level**

- 5 **Select a category**

- 6 **Select an alarm notification option**

- **To Activate Alarm Prior to Due Time**
 ► **ON/Set Time** ► ► Enter time

- 7 **Select an alarm tone type** (**Select a folder** **Select an alarm tone**)

Folders are unavailable when **Clock Alarm Tone** or **OFF** is selected.

Alarm Notification Operations

When the set time arrives, alarm sounds and animation appears on Display for approximately five minutes. Press any key to stop the alarm tone. Press any key again to end notification message.


Tip

- If the set alarm time arrives during a call, alarm tone sounds through earpiece.
- If a call arrives while the alarm is sounding, the alarm stops.




Checking Saved Tasks

- 1 **Tools** **To Do List**



Task List Window

- 2 Select a task



Task Details Window

Tip

- Overdue tasks are indicated by red status icons (e.g.).

Deleting Tasks

To Delete One Task

- 1 [Task List] window Select a task
- 2 **Delete** **Delete This** **YES**

To Delete Multiple Tasks

- 1 [Task List] window
- 2 **Delete** **Delete selected**
- 3 Select a task Repeat this step to specify other tasks.
- 4 **YES**

More Features

Advanced

- To Do List
- ❖ Sort Tasks by Category
 - ❖ Change Order of Tasks
 - ❖ Set Task Status
 - ❖ Delete All Tasks

(P. 11-22)

Customize

- Alarm
- ❖ Set Priority at Alarm Notification Time
 - ❖ Change Alarm Tone

(P. 14-3)




Text Memo

Save short notes or messages as text memos.

- Saved text memos can be inserted in Schedule or in messages.

Saving Text Memos

- 1** **Tools** **Text Memo**



Text Memo List Window

- 2** **<Not Recorded>**
Enter content

- To Edit a Saved Text Memo**
 Select a text memo
Edit content

Deleting Text Memos

◎ To Delete One Text Memo

- 1** [Text Memo List] window
Select a text memo
- 2** **Delete** **Delete This**
 YES

◎ To Delete Multiple Text Memos

- 1** [Text Memo List] window
- 2** **Delete** **Delete selected**
- 3** Select a text memo
Repeat this step to specify other text memos.
- 4** **YES**

More Features

Advanced

Text Memo

- ❖ Save a Text Memo to Schedule
- ❖ Sort Text Memos by Category
- ❖ Check Text Memo Information
- ❖ Delete All Text Memos

(P. 11-23)



The following two types of voice memos can be recorded with Voice Memo:

“Voice memo during a call” to record the other party’s voice during a call; and “Voice memo in Standby” to record your voice in Standby.

- Only one entry, either a voice memo during a call or a voice memo in Standby, can be saved on handset. When a new voice memo is recorded, the previously saved entry is overwritten.
- The available recording time is 20 seconds for both types of voice memos.
- See P. 3-5 and P. 3-18 for playing and deleting a recorded voice memo.

Recording the Other Party’s Voice

1 Press during a call **Voice Memo**

A short beep sounds through the earpiece, and recording starts. When remaining recording time reaches five seconds, a short beep sounds. When recording is finished, two short beeps sound.

■ To Stop Recording



Recording Your Voice

1 **Tools** **Voice Memo**

2 **YES** **Record your voice**

Speak into microphone after short beep sounds through earpiece. When remaining recording time reaches five seconds, a short beep sounds. When recording is finished, two short beeps sound.

■ To Stop Recording



Tip

- Recording stops automatically when a call arrives, alarm goes off or another function is activated.



1 **Tools** **Calculator**

2 Enter numbers with Keypad
 ▶ Enter +, -, × or ÷ with Multi Selector

■ To Calculate Negative Numbers
 ▶ ▶ Enter numbers with keypad ▶ Enter +, -, × or ÷ with Multi Selector

3
 Result appears.

Available Functions

Enter Number	0 - 9
+ (Add)	
- (Subtract)	
× (Multiply)	
÷ (Divide)	
= (Equal)	
Decimal Point	
Cancel Calculation	クリア (AC)
Clear Number	クリア (C)

Tip

- If the calculation result exceeds 10 digits, .E appears.



Setting Alarm

- 1 **Tools** **Alarm**

Alarm 1/2	
1 Alarm1	ON
2 Alarm2	OFF
3 Alarm3	OFF
4 Alarm4	OFF
5 Alarm5	OFF

Alarm List

To View Alarm Entries

- Select an entry

Alarm	
Alarm1	
6:30	
SuMoTuWeThFrSa	
Clock Alarm Tone	
Level 4	
Snooze 5times/5min	
Auto Power OFF	

Alarm Details Window

- 2 Select an alarm

Edit Alarm	
Alarm2	
Time	
Clock Alarm Tone	
Level 4	
Snooze 5times/5min	
Auto Power OFF	

Alarm Setting Window

- 3 Enter title

Title appears in Alarm message.

- 4 Enter time

- 5 **1 Time, Daily**
() or **Select Day ()**

To Specify Days of the Week

- Select Day ()** Put checkmarks to days of the week

- 6 Select an alarm tone type (Select a folder Select an alarm tone)

Folders are unavailable when **Clock Alarm Tone** or **OFF** is selected.

- 7 to adjust volume

- 8 **ON** Enter number of activation times
 Enter time interval

To Cancel Snooze


- OFF** Enter ringing duration

- 9 **ON or OFF**



◎ Alarm Activation Operations

When the set time arrives, alarm is activated and animation appears on Display. When the auto power-on function is set to **ON** in Alarm Setting window, handset is automatically turned on, if it has been off, to activate the alarm.


Press any key to stop the alarm tone. When Snooze is set to **OFF**, press any key again to cancel the alarm with two short beeps, and return to the window before the alarm activation. When Snooze is set to **ON**, the alarm sounds repeatedly in the set time interval. Press  to cancel Snooze with two short beeps.

Note

- The alarm and snooze cancellation beeps do not sound when **Keypad Sound** is set to **OFF**.
- Set the auto power-on function to **OFF** in Alarm Setting window and turn off handset, when you are near high-precision electronic devices or devices using weak signals, on an aircraft or in a hospital where handset use is prohibited.
- If a call arrives while the alarm is sounding, the alarm stops.
- If the alarm activation time comes during a call, Snooze does not work even if it is set to **ON**.

Canceling Alarm

- 1 [Alarm List] ►► Select an alarm ►► 

Each time you press , the alarm toggles between ON and OFF.

Tip

- Alarm settings are retained even if the alarm is canceled.

More Features

Advanced

Alarm

- ❖ Cancel All Alarms
- ❖ Edit Alarm Settings

(👉 P. 11-23)

Customize

Alarm

- ❖ Set Priority at Alarm Notification Time
- ❖ Change Alarm Tone

(👉 P. 14-3)



JAN codes and QR codes can be scanned by Bar Code Reader using handset camera.

About JAN & QR Codes

① JAN Code

A bar code made of vertical lines (bars) with different widths and spaces in between, representing numbers. Handset can scan 8-digit (JAN8) and 13-digit (JAN13) bar codes.

② QR Code

A two-dimensional code representing alphanumerics, kanji, kana, or pictographs. Some QR codes are made up of several data areas that are scanned as individual QR codes and then automatically combined as one QR code.

Scanning Bar Codes

- Position handset camera at a distance of 6 to 8 cm from the bar code.

1 **Tools** **Bar Code Reader**

2 Frame the bar code in the recognition field



Bar Code Scanning Window

Scanning starts automatically.

┐, ┘, └ and ┌ indicate the corners of the recognition field.

■ To Cancel Scanning

OK

■ To Adjust Zoom

(Zoom out) or (Zoom in)

■ To Scan a QR Code Made of Several Data Areas (QR Codes)

OK (twice) Scan a QR code
Repeat this step to scan other QR codes.

All component QR codes must be scanned in order to access or save scanned data on handset.

3 Check scanned data

■ To Discard Scanned Data

クリア **YES**

4 **Store** **YES**
 OK

Tip

- A JAN code/QR code must be accurately focused and be enlarged to fill the recognition field.
- Scanning may take a while.
- Some bar codes may not be scanned depending on the size, version or print quality, or due to scratches, stains, damage or the reflection of light.



Checking Scanned Data

1 [Bar Code Scanning]
window >>  >> **Reading**
Data List >> 

Bar Code Reader	
1	20090416_1010_0000
2	20090415_2035_0000
3	20090415_1218_0000

Scanned Bar Code Data List Window

2 Select an entry >> 

Bar Code Reader	
http://www.XXXX.co.jp	

Scanned Bar Code Data Details Window

Tip

- Characters that are not supported by Bar Code Reader are replaced with spaces (blanks).

More Features

Advanced

Using Scanned Data

- ❖ Make a Call
- ❖ Compose a Message
- ❖ Access the Internet
- ❖ Save to Phone Book
- ❖ Save a Bookmark
- ❖ Copy Text
- ❖ Edit Title of Scanned Data
- ❖ Delete Scanned Data

( P. 11-24)




Use Text Reader to scan printed text.

Scan Modes

Card read	Scan name, phone number, e-mail address, postal code, address and memo printed on business cards, and save all scanned data collectively as a Phone Book entry.
Compose message	Scan address, subject or message text, and open Composition (S! Mail) window with the address, subject or message text entered.
URL	Scan URL, and access the page or save the URL to Bookmark.
Mail address	Scan e-mail address, and compose an S! Mail to the address.
Phone number	Scan phone number, and make a call to the number.

Free memo	Scan Japanese or English text, and save the text to Text Memo.
-----------	--

Text Scanning Window



①	Recognition Frame
②	Scan Item Icons <div> Name Phone number E-mail address Postal code Address Memo Address Subject Message text </div>
③	Recognized Text Field
④	Recognition Mode
⑤	Key Guidance
⑥	Negative Mode <i>Nega</i> appears when <i>NEGA/POSI Mode</i> is set to <i>Negative Fix</i> .
⑦	Remaining Number of Characters That Can be Scanned




Scanning Text

- Position handset camera at a distance of 6 to 8 cm from the text.

<Example> Scanning in *Card Read* mode

1 **Tools** **Text Reader**

2 **New** **Select a scan mode**



Text Scanning Window

3 **to select a scan item icon**
 ▶ **Frame text in the recognition frame**

■ To Adjust Zoom

▶ (Zoom in) or (Zoom out)

4

The text is scanned.
 The recognized text appears.

■ To Rescan the Same Text

▶ **YES** ▶

■ When Scanned Text Overflows Recognized Text Field

▶ to scroll the field

■ To Save Scanned Text without Correcting It

▶

■ To Scan Following Text

▶ ▶ **Frame text in the recognition frame (include several scanned characters of the preceding text)** ▶

■ To Scan Another Item

▶ ▶ **to select a scan item icon** ▶ **Frame text in the recognition frame** ▶

5 ▶ **Store** ▶


Tip

- Text must be accurately focused and be enlarged to fill the recognition frame.
- When **Processing** appears, do not move handset.
- Handwritten text is not recognized.
- Text may not be recognized correctly when:
 - Faxed or copied text is scanned.
 - Decorated characters are scanned.
 - Spaces between characters are uneven.
 - Text is indistinguishable from the background.
 - Ambient lighting is inappropriate.




Checking Scanned Text

1 **Tools** **Text Reader** **Reading Data List**



Scanned Text List Window

2 **Select an entry**



Scanned Text Details Window

More Features

Advanced

Scanning Text

- ❖ Correct Scanned Text
- ❖ Edit Scanned Text
- ❖ Set Printing Status of Text
- ❖ Set Guidance OFF/ON
- ❖ Set Vertical/Lateral Scan

(P. 11-23)

Using Scanned Data

- ❖ Make a Call
- ❖ Compose a Message
- ❖ Access the Internet
- ❖ Save to Phone Book
- ❖ Save a Bookmark
- ❖ Search Phone Book
- ❖ Save a Text Memo
- ❖ Copy Text
- ❖ Delete Scanned Data

(P. 11-24)



Osaifu-Keitai®

Start Here

[Lifestyle-Appli List] window P. 11-3
 [Call Remote Lock Setting] window P. 11-4

Check Lifestyle-Appli Properties

[Lifestyle-Appli List] window >>
 Select a Lifestyle-Appli >> [F] >>
Properties >> [F]

Check Memory Status

[Lifestyle-Appli List] window >> [F]
 >> **Memory Info** >> [F]

Delete a Lifestyle-Appli

[Lifestyle-Appli List] window >>
 Select a Lifestyle-Appli >> [F] >>
Delete >> [F] >> **YES** >> [F]

Edit Call Remote Lock Numbers

[Call Remote Lock Setting] window >> Select phone number
 >> [F] >> Change phone number >>
 [F] >> **YES** >> [F] >> [F]

Delete Call Remote Lock Numbers

[Call Remote Lock Setting] window >> Select phone number
 >> [F]
 ● To select *Delete this*
 >> *Delete this* >> [F] >> **YES** >> [F]
 ● To select *Delete All*
 >> *Delete All* >> [F] >> **YES** >> [F]

Schedule

Start Here

[Schedule] window P. 11-6
 [Event Edit] window P. 11-6
 [Event List] window P. 11-8
 [Event Details] window P. 11-8

Sort Events by Icon

[Schedule] window, [Event List] window or [Event Details] window >> [F] >> **Icon Display** >>
 [F] >> Select an icon >> [F]

Check Number of Saved Events

[Schedule] window >> [F] >> **No. of Schedules** >> [F]

Edit an Event

[Event List] window/ [Event Details] window (>> Select an event) >> [F] >> **Edit** >> [F] >> Edit each item >> [F]



Copy an Event

[Event List] window/ [Event Details] window >> [P] >> **Copy** >> [■] >> Edit each item >> [✉]

[💡] Repetition setting of an event is canceled when it is copied.

Make/Cancel Secret Setting of an Event

- To Make Secret Setting

[Event Edit] window >> Enter each item >> [✉]

- To Cancel Secret Setting

[Event List] window/ [Event Details] window >> [P] >> **Release Secret** >> [■] >> **YES** >> [■]

[💡] Before making/canceling secret setting, set handset to Secret Mode or Secret Data Only Mode (P. 4-9).

Delete All Events

[Schedule] window, [Event List] window or [Event Details] window >> [P] >> **Delete** >> [■] >> **Delete All** >> [■] >> Enter Security Code >> [■] >> Select an item >> [■] >> **YES** >> [■]

Reset Holidays

[Schedule] window >> [P] >> **Reset Holiday** >> [■] >> **YES** >> [■]

To Do List

Start Here

[Task List] window P. 11-10

[Task Details] window P. 11-10

Sort Tasks by Category

[Task List] window >> [P] >> **Category Display** >> [■] >> Select a category >> [■]

Change Order of Tasks

[Task List] window >> [P] >> **Sort/Filter** >> [■] >> Select a criterion >> [■]

Set Task Status

[Task List] window/ [Task Details] window (>> Select a task) >> [P] >> **Change Status** >> [■] >> Select a status >> [■]

[💡] The set status is indicated by the status icon in Task List window and in Task Details window.

[💡] When **Completion** is set as status, enter the completion date.

Delete All Tasks

[Task List] window >> [P] >> **Delete** >> [■] >> **Delete All** >> [■] >> Enter Security Code >> [■] >> **YES** >> [■]



Text Memo

Start Here

[Text Memo List] window..... P. 11-11

Save a Text Memo to Schedule

[Text Memo List] window >> Select a text memo >> >> **Edit Schedule** >> >> Enter each item >>

Event Edit window opens with the text memo details set as event content.

Sort Text Memos by Category

[Text Memo List] window >> Select a text memo >> >> **Category** >> >> Select a category >>

Check Text Memo Information

[Text Memo List] window >> Select a text memo >> >> **Text Memo Info** >>

Delete All Text Memos

[Text Memo List] window >> >> **Delete** >> >> **Delete All** >> >> Enter Security Code >> >> **YES** >>

Alarm

Start Here

[Alarm List] P. 11-14

[Alarm Details] window P. 11-14

Cancel All Alarms

[Alarm List] / [Alarm Details] window >> >> **Release All** >> >> **YES** >>

Edit Alarm Settings

[Alarm List] / [Alarm Details] window (>> Select an alarm) >> >> Edit each item >>

Bar Code Reader & Text Reader

Start Here

[Scanned Bar Code Data List] window P. 11-17

[Scanned Bar Code Data Details] window P. 11-17

[Text Scanning] window P. 11-19

[Scanned Text List] window P. 11-20

[Scanned Text Details] window P. 11-20

Scanning Text

Correct Scanned Text

[Text Scanning] window >> Scan text >> to move cursor to the character you want to correct >> Press the number key corresponding to the correct character on the suggestion list
 Press to toggle between upper case and lower case.



Edit Scanned Text

[Text Scanning] window >> Scan text >> >> **Edit** >> >> Edit text using keypad

To cancel editing and return to scanned text, press , select **Select Recog. Data** and then press .

Set Printing Status of Text

[Text Scanning] window >> >> **NEGA/POSI Mode** >> >> **Auto setting, Positive Fix** or **Negative Fix** >>

Set to **Positive Fix** when dark-colored text is printed on a light-colored background.

Set to **Negative Fix** when light-colored text is printed on a dark-colored background.

Set Guidance OFF/ON

[Text Scanning] window >> >> **Guidance OFF** or **Guidance ON** >>

Set Vertical/Lateral Scan

[Text Scanning] window >> >> **Vertical Writing** or **Lateral Writing** >>

Using Scanned Data

Make a Call

[Scanned Bar Code Data Details] window/ [Scanned Text Details] window >> Select a phone number >> >> **Dialing** >> >> **Voice Phone** or **Video Call** >> >> **Dial** >> >> Talk >> to end call

Compose a Message

[Scanned Bar Code Data Details] window/ [Scanned Text Details] window >> Select an e-mail address >> >> **Create S! Mail** >> >> Compose and send S! Mail

Access the Internet

[Scanned Bar Code Data Details] window/ [Scanned Text Details] window >> Select a URL >> >> **Internet** >> >> **YES** >>

Save to Phone Book




[Scanned Bar Code Data Details] window/ [Scanned Text Details] window >> Select an item >> >> **Add to Phone Book** >>

- To select **Phone**
>> **Phone** >> >> **New** or **Add** >> (>> Search Phone Book >> Select an entry >> (twice)) >> Edit each item >> (>> **YES** >>)
- To select **USIM**
>> **USIM** >> >> **New** or **Overwrite** >> (>> Search Phone Book >> Select an entry >> (twice)) >> Edit each item >> (>> **Overwrite*** or **Add** >>)



* To select **Overwrite**, press , select **YES**, then press .



Save a Bookmark

[Scanned Bar Code Data Details] window/ [Scanned Text Details] window ➤ Select a URL ➤  ➤ **Add Bookmark** ➤  (twice) ➤ Select a folder ➤ 





Search Phone Book

[Scanned Text Details] window ➤ Select an item ➤  ➤ **Search Phone Book** ➤  ➤ Search Phone Book




Save a Text Memo

[Scanned Text Details] window ➤ Select an item ➤  ➤ **Add to Memo** ➤ 






Copy Text

[Scanned Bar Code Data Details] window/ [Scanned Text Details] window ➤  ➤ **Copy** ➤  ➤ Select beginning of characters ➤  ➤ Select end of characters ➤ 

Edit Title of Scanned Data

[Scanned Bar Code Data List] window ➤ Select an entry ➤  ➤ **Edit Title** ➤  ➤ Edit title ➤ 

Delete Scanned Data

[Scanned Bar Code Data List] window/ [Scanned Text List] window ➤ Select an entry ➤ 
 ● To select *Delete This*
 ➤ *Delete This* ➤  ➤ **YES** ➤ 
 ● To select *Delete All*
 ➤ *Delete All* ➤  ➤ Enter Security Code ➤  ➤ **YES** ➤ 