Internet Services	5-2
Service Basics	5-2
Yahoo! Keitai	5-3
Using Yahoo! Keitai	5-3
PC Site Browser	5-4
Using PC Site Browser	5-4
Using PC Site Browser Browsing	
•	5-5

Bookmarks & Saved Pages	5-7
Using Bookmarks & Saved Pages.	5-7
RSS Feeds	5-8
Updating Blogs & News	5-8
Additional Functions	5-9
Troubleshooting	5-16

5

Yahoo! Keitai & PC Site Browser



Service Basics

Access the Mobile Internet via Yahoo! Keitai, or view PC Internet sites via PC Site Browser.

- Service requires a separate contract; retrieve Network Information to use these services.
- For more about Yahoo! Keitai, see SOFTBANK MOBILE Corp. Website (P.14-22).

Transmission/Information Fees

Some page content may automatically activate Internet connection incurring transmission fees. Information fees may also apply.

Security

Electronic certificates are saved on handset to support SSL (encryption protocol for Internet transmissions of important/sensitive information).

Secure Pages

- A confirmation appears before entering and exiting secure pages.
- When a security notice appears, subscribers must decide for themselves whether or not to open the page.
 Opening secure pages constitutes agreement to the terms of usage.
 SoftBank, VeriSign Japan, Cybertrust, Entrust Japan, GlobalSign, RSA Security and SECOM Trust Systems cannot be held liable for any damages associated with the use of SSL.

Advanced



© Clearing cache (temporarily saved information) Disabling manufacture number auto send for authentication Resetting browser settings and stored information (Bookmarks, Saved Pages, etc.) (And more on P.5-14 - 5-15)

Using Yahoo! Keitai

Opening Main Menu

Internet pages may not open depending on connection/Server status, etc.





Internet Page

- Yahoo! Keitai Main Menu appears.
- To disconnect, press \(\sqrt{y} \).
- Highlight menu item **→** (●)
 - Corresponding page opens.
 - Repeat to open additional links.
- ি **♦** *Yes* **♦ ♦** Page

closes

Returning to Previous Pages [Internet Page] → Previous page opens

■ Follow these steps to return to the initial page:

Returning to Yahoo! Keitai Main Menu

User Authentication

Enter user ID or password ▶ ● ▼

Streaming

- Enjoy audiovisual media while it downloads.
- Packet transmission fees apply even while stream is paused.

Using History





Select record **→ ●** Connection starts

• Corresponding page opens.





Entering URLs Directly





- Enter URL → → Connection starts
 - Corresponding page opens.
- Yes → Page closes








Using PC Site Browser

Open PC sites from Yahoo! JAPAN (preset home page).

- Internet pages may not open depending on connection/Server status. etc.
- Browsing PC sites may incur higher charges.










Internet Page

- Yahoo! JAPAN Home opens.
- When a message appears, follow onscreen prompts.
- To disconnect, press \\\^\mathbb{Y}\).
- Highlight menu item **→**
 - Corresponding page opens.
 - Repeat (a) to open additional links.



Returning to Previous Pages [Internet Page] → Previous page opens ■ Follow these steps to return to the

initial page:

Returning to Yahoo! JAPAN Home [Internet Page]

→ Homepage → ●

User Authentication Enter user ID or password ▶ ● ▼

Using History In ②, History → ③ → Select record

 \rightarrow \bigcirc

Entering URLs Directly

In ②, Enter URL → ● Enter URL **▶** (**●**)

Hiding Softkeys

() → Off → ()

Browsing in Wideview

[Internet Page] Rotate handset 90 degrees counterclockwise



- 🐡 Switching browsers 🖲 Using previously entered URLs 🕒 Deleting History records 🖲 Opening History properties 🔘 Sorting History records 🕒 Sending History records via mail (P.5-9)
 - Showing navigation map for continuous scroll Changing scroll unit (PC Site Browser) Hiding PC Site Browser messages (P.5-14)

Basic Operations

Page Browsing

Scrolling Pages

If page content continues beyond view, use � to scroll pages.

Long Press � to scroll continuously.

Switching Frames

On framed pages, Long Press et to select other frames.

When pointer navigation is active, point to a frame and press
to select it.

Viewing Single Frame

Select frame $\Rightarrow \boxtimes f$ \Rightarrow Convenient Functions $\Rightarrow f$ $\Rightarrow f$ Frame In $\Rightarrow f$

Tabbed Browsing

Open another page in a new tab and switch between tabs.

Opening a New Tab


On a page, select menu item

→ ☑ → Tab Menu → ●

Open in New Tab → ●



Switching Tabs



• When pointer navigation is active, point to a tab and press • to open it.

Closing Tabs

(Long) → Select tab → ● →

→ Tab Menu → ● → Close Tab

or Close All Other Tabs → ●

- 🖑 🌑 Using Web Search 🜑 Searching current page 🖫 Looking up copied words in dictionaries 🜑 Saving files to Data Folder 🖫 Jumping to page top/bottom
 - Changing character size Zooming specific areas (And more on P.5-9 5-10)
 - Changing scroll unit Disabling automatic image display/sound playback (And more on P.5-14)



Selecting Text

Activate pointer navigation and Long Press
to enable text selection (Drag Mode). Select text to copy or look up words in dictionaries.

Follow these steps to use a dictionary:

- On a page, select first character → (Long)
 Drag Mode is activated.
- ∠ Highlight text range → ●
- Select dictionary

 Dictionary opens with text inserted.
- Search → Select word

Text Entry

- On a page, select text entry field ▶ ●
- Enter text

 Internet page returns.

Using Entered Text (Input Memory)

[Internet page] Select text entry field

→ ● → ☑ → Insert/Font Size → ●

→ Input Memory → ● → Select text

→ ●

Pull-down Menu Item Selection



Select item → ●


When Multiple Selection is Supported

• Select items as needed and press

Page Item Indicators

Selection Items

Buttons \bigcirc or boxes \square appear.



Execution Items

Execute the assigned command.

On a page, select command



Bookmarks

Bookmark sites for quick access.


- Saving Bookmarks
- On a page,

 → Bookmarks

 → Save →

 O
 - Save appears only for savable pages.
- Enter/edit title → ●
- Opening Bookmarks





Corresponding page opens.

Opening Bookmarks Online [Internet Page] → Bookmarks → → Open List → → ↔ Select type → Select title → ●

Saved Pages

Save page content; handset opens saved pages without connecting to the Internet.

- Saving Pages
- On a page, ⇒ Saved Pages ⇒ Save ⇒
 - Save appears only for savable pages.
- Enter/edit title ▶ ●

Opening Saved Pages





Select page

● Corresponding page opens.


Opening Saved Pages Online

[Internet Page]

→ Saved Pages

→
→ Open List
→
→ Select

page
→
●



Updating Blogs & News

Register RSS-compatible sites; view content updates without opening source sites. Transmission fees apply.

Subscribing to RSS Feeds

Available for PC Site Browser only.

- Via RSS-Compatible Sites
- appears for RSS-compatible sites.



- - Save

 Choose Yes to update immediately or No and press ●.

Via RSS Icons

Use RSS/RDF/XML icons on RSS-compatible sites.

- On a page, select icon ▶ ●
- Yes → Save → ●

Checking Updates

Follow these steps to update all feeds:

- PC Site Browser → → RSS Feed → ●



RSS Feed List

- Reload All → → ●
- Yes or No → ●
- 🕞 Select feed 🕈 💿



- Select title

 Information appears.
- Updating Single RSS Feeds

 [RSS Feed List] Select feed ▶ ♥ ▶

 Reload ▶ ▶ Yes or No ▶ ●

 Disabling/Enabling Updates

 [RSS Feed List] Select feed ▶ ♥ ▶

 Manage RSS Feed ▶ ▶ Restrict
- Manage RSS Feed → Restrict
 Update or Accept Update → ●
 Accessing Source Sites
 - [Title List] Select title → → Select linked title → → Yes → →
 - → Yes or No → ●



Connecting/Browsing

General

Switching browsers	On a page, Convenient Functions Change to PC Browser or Switch Browser This Page or Linked Page Yes or No Yes
Using previously entered URLs	Start Here ● → Yahoo! Keitai → ● See below Yahoo! Keitai
	Enter URL → ● → □ → URL Entry Log → ● Select URL → ● → ●
	PC Site Browser PC Site Browser ● → Enter URL ● → ⑤ URL Entry Log ● → Select URL ● → ●

■ History

	Start Here ● → Yahoo! Keitai → ● → History → ● → ⊖ Select type → See below
Deleting History records	One Record Select record ⇒ ☑ ⇒ Delete ⇒ ● ➤ Yes ⇒ ●
records	All Records
Opening History properties	● → Yahoo! Keitai → ● → History → ● → Select record → ☑ → Details → ●
Sorting History records	→ Yahoo! Keitai → ● → History → ● → → Sort → ● → By Domain or By Date → ●

● Yahoo! Keitai ● ● History ● ● S! Mail or SMS ● ● Complete message ● ☑ ● S! Mail Composition window opens automatically depending on character count.

Page Operations

■ Vahool Kaitai & DC Site Browser

Yanoo! Keitai & PC Site Browser	
Using Web Search	On a page, Convenient Functions Web Search Enter search text
Searching current page	On a page, Convenient Functions Search Enter search text Press to jump to next search result, if any.
Looking up copied words in dictionaries	On a page, Convenient Functions Copy & Search Dict. Highlight text range Select dictionary Search Search Search
	Start Here On a page, See below See Save Items Save
Saving files to Data Folder	Files on Page Select file → ● → Save → ● → Enter name → ● → Save here → ● • Some files are saved automatically. • End memory-consuming operations (TV recording, etc.) beforehand. • Confirm signal is strong, battery is adequately charged and that there is enough free memory beforehand.
	Background Images Save Background Image



Using linked info	Dialing Numbers On a page, highlight number → ● → Call or Video Call → ●
	Sending Messages On a page, highlight number or mail address → ● Create Message → ● > S! Mail or SMS → ● Complete message → ☑
Copying text	On a page,
Sending URLs via mail	On a page, Convenient Functions Send URL S! Mail or SMS S! Mail or SMS S! Mail Composition window opens automatically depending on character count.
Jumping to page top/bottom	On a page, → Convenient Functions → ● → Jump In Page → ● → Page Top or Page Bottom → ●
Opening function shortcuts	On a page, ☑ → Help → ●
Opening page properties	On a page, → Convenient Functions → → Details → → Select item → →
Changing encoding to read garbled text	On a page, ☑ → Settings → ● Char-code → ● → Select option → ●

	Start Here On a page, → Convenient Functions → → Flash®Menu → → See below
Handling Flash® files	Pausing/Playing Pause, Resume or Replay ●
	Setting Image Quality Quality
Updating page content	On a page, → Reload → ● To update content in Saved Pages, open a page and follow the steps above.
■ Yahoo! Keitai	
Changing character size	On a page, (enlarge) or (reduce)
■ PC Site Browser	
Switching view	On a page, → PC Screen or Small Screen → ● In Small Screen view, PC sites are redesigned to fit Display.
Zooming on pages (Zoom Factor)	On a page, (enlarge) or (reduce)
Jumping to specific locations	On a page, ^{∞5} ! (Long) → Quick Movement map appears → Select location → ●
Zooming specific areas	On a page, point to area • 7] (Long) • Pointed area is enlarged and shown in the lower half of Display. Long Press 7] to toggle Zoom Area options (Small, Large and Off).



Streaming

Playing media streams	On a page, select file On a page, select fil
Customizing streaming settings	Start Here While streaming,
	Changing Playback Size Display Size → ● Select size → ●
	Setting Backlight Status Backlight
	Adjusting Sound Effects Sound Effects Select effect Playback size may not change depending on file/stream. Selecting Normal Settings applies Display Backlight setting.
Streaming from Media Player	Start Here ● → Media Player → ● → Streaming → ● → See below
	Resuming from Stopped Point Last Played
	Using Bookmarks Bookmarks
	Using History History Select record Packet transmission fees apply even while stream is paused. Streaming sound is heard from Speaker/ Headphones regardless of Sound Output setting.

Bookmarks & Saved Pages

■ Bookmarks

Deleting titles	Start Here
	One Title Select title
	All Titles
Editing titles	● Yahoo! Keitai ● Bookmarks ● Select type ■ Select title ■ Abdit ■ Title: ● ■ Enter title ■ ■ ▼
Editing bookmarked URLs	● Yahoo! Keitai ● Bookmarks ● ● Select type ● Select title ● ● Edit ● ● URL: ● ■ Edit ● ● ∑
Sending bookmarked URLs via mail	● Yahoo! Keitai ● Bookmarks ● Select type Select title ☑ Send ● As Message ● S! Mail or SMS ● Complete message ☑ ● SI Mail Composition window opens automatically depending on character count.
Changing title order	● Yahoo! Keital ● Bookmarks ● Select type Select title ● Move ● Select target location ● ●
Opening title properties	Yahoo! Keitai Bookmarks Select type Select title Details




Sorting titles into folders	Start Here ● → Yahoo! Keitai → ● → Bookmarks → ● → ⊖ Select type → See below
	Creating Folders ☑ → Create Folder → ● Enter name → ●
	Moving to Folders Select title $\Rightarrow \boxtimes \Rightarrow$ Move $\Rightarrow \bullet \boxtimes \Rightarrow$ Select folder $\Rightarrow \bullet \Rightarrow \bullet \bigcirc$
	Moving from Folders Select folder → ● → Select title → □ → Move → ● → □ → ●
	Renaming Folders Select folder ⇒ ☑ ⇒ Rename ⇒ ● ⇒ Enter name ⇒ ●
	Deleting Folders Select folder ⇒ ☑ → Delete ⇒ ● Yes → ●

■ Saved Pages

■ Saved Fages	
Deleting pages	Start Here → Yahoo! Keitai → → Saved Pages → → See below
	One Page Select page
	All Pages
Editing page titles	● Yahoo! Keitai ● Saved Pages ● Select page ● Mename ● Enter title ●
Changing page order	● Yahoo! Keitai ● Saved Pages ● Select page ● Move ● Select target location ● ●
Opening page properties	 Yahoo! Keitai Select page Details O
Switching page list view	● Yahoo! Keitai ● Saved Pages ● Select page ● ☑ List View or Preview View ● ●

RSS Feeds	
Deleting feeds	Start Here
	One Entry Select feed ⇒ ☑ ⇒ Delete ⇒ ● → Yes ⇒ ●
	All Entries
Sorting feeds	● Yahoo! Keital ● PC Site Browser ● RSS Feed ● Manage RSS Feed ● Sort ● Select option ●
Opening feed properties	● Yahoo! Keital ● PC Site Browser ● RSS Feed ● Select feed Manage RSS Feed ● Details ●
Sorting feeds into folders	Start Here ● → Yahoo! Keitai → ● → PC Site Browser → ● → RSS Feed → ● → See below
	Creating Folders
	Moving to Folders Select feed ⇒ ☑ → Manage RSS Feed ⇒ ● → Move → ● → Select folder → ● → Move → ●
	Renaming Folders Select folder
	Deleting Folders Select folder → ☑ → Delete → ● → Enter Handset Code → ● → Yes → ●





Settings

Unless noted otherwise, settings are available for Yahoo! Keitai and PC Site Browser. (Operations described for Yahoo! Keitai.)

■ Internet Page

Changing scroll unit	● → Yahoo! Keitai → ● → Browser Settings → ● → Scroll Unit → ● → Select unit → ●
Disabling automatic image display/sound playback	Start Here
	Image Display Images ⇒ ● Do not Show ⇒ ●
	Sound Playback Sounds ⇒ ● Do not Play ⇒ ●
Changing character size	● Yahoo! Keitai → ● Browser Settings → ● Font Size → ● Select size → ●
Using pointer navigation	Start Here
	Activating Cursor Mode Settings → ● Normal Mode → ●
	Changing Pointer Speed Speed Settings
Using Memory Card as primary download storage	● Yahoo! Keitai ● ● Browser Settings ● Download to ● ● Prefer Card ● ● • Some files may be saved to handset regardless of this setting.

■ PC Site Browser

Showing navigation map for continuous scroll	● Yahoo! Keitai ● PC Site Browser ● PC Site Browser Settings ● Scroll Settings ● Page Navigation ● On ● Page Navigation
Changing scroll unit (PC Site Browser)	● Yahoo! Keitai ● PC Site Browser ● PC Site Browser Settings ● Scroll Settings ● Scroll Unit ● Select unit ●
Hiding PC Site Browser messages	● Yahoo! Keitai ● PC Site Browser ● PC Site Browser Settings ● Warning Message ● PC Site Browser or Yahoo! Keitai ● Off ●

■ Memory Operation	
Clearing cache (temporarily saved information)	Yahoo! Keital
Clearing cookies	● Yahoo! Keital ● Browser Settings ● Memory Op. ● Delete Cookies ● Yes ●
Clearing authentication information	● Yahoo! Keital ● Browser Settings ● Memory Op. ● Delete Auth Info ● Yes ●
Deleting all RSS feeds	● Yahoo! Keital ● PC Site Browser ● PC Site Browser Settings ● Memory Op. ● Delete RSS Feed List ● Enter Handset Code ● Yes ● Available for PC Site Browser.



■ Security Settings

Disabling manufacture number auto send for authentication	● Yahoo! Keitai • ● → Browser Settings • ● → Security Settings • ● → Manufacture Number • ● → Off • ●
Disabling referer information delivery to the Server	● Yahoo! Keitai ● Browser Settings ● Security Settings ● Send Referer ● Not Send ●
Enabling/disabling cookies	● Yahoo! Keitai ● Browser Settings ● Security Settings ● Cookies ● ● Select option ●
Selecting script execution option	● Yahoo! Keitai ● Browser Settings ● Security Settings ● Script Settings ● Select option ●
Hiding confirmations before entering/exiting secure pages	● Yahoo! Keitai • ● → Browser Settings • ● → Security Settings • ● → Secure Prompt • ● → Do not Show • ●
Opening electronic certificates saved on handset	● Yahoo! Keitai ● Browser Settings ● Security Settings ● Root Certificates ● Select certificate ●
Changing validity of entered user ID/ password	● Yahoo! Keitai ● Browser Settings ● Security Settings ● Keep Auth Info ● ● Select option ● ● • Per Browsing retains entered user ID/password during browsing sessions. On retains such authentication information even after turning handset off. • Authentication information may not be retained depending on the site.

Enabling/disabling Ajax (for asynchronous communication)	● Yahoo! Keitai ● ● Browser Settings ● ● Security Settings ● ● Restrict Ajax ● ● Select option ● ●	
Resetting		
Resetting browser		
settings and	Yahoo! Keitai Browser Settings	
stored information	→	
(Bookmarks,	Handset Code ⇒ ● <i>Yes</i> ⇒ ●	
Saved Pages, etc.)		
Restoring default	Yahoo! Keitai Beact Settings Beact Settings Beact Settings	

Code ⇒ ● → Yes ⇒ ●

handset settings

→ ● → Reset Settings → ● → Enter Handset



Connecting/Browsing



What is the bar at Display bottom?

• This is a data progress bar; the number beside it indicates transmitted (green) or received (red) data.

Page Operations



Internet page does not open completely

• Portions of page content may not appear in tabbed browsing; close other tabs.



Text overlaps

• The site may be designed for browsing on PCs; try Tiny font size.



Cannot access other functions while browsing the Internet

• When switching between Yahoo! Keitai and PC Site Browser (appears), additional function activation may be disabled; close either browser and retry.

