

Entertainment

Mobile Widget (Japanese)	7-2
Pasting Widgets to Standby	7-2
Using Widgets	7-2
Downloading Widgets	7-3
Arranging Widgets in Standby.....	7-3
S! Quick News (Japanese)	7-4
Registering S! Quick News Items	7-4
Opening New Information	7-4
S! Information Channel/Weather (Japanese)	7-6
Registering/Canceling.....	7-6
Using S! Information Channel.....	7-6
Using Weather Indicator	7-7
Option Menu Items.....	7-8
E-Books (Japanese)	7-8

Mobile Widget (Japanese)

Paste widgets to Standby to access information or tools from Standby.

Network Widget

Some widgets may periodically connect to network, incurring packet transmission fees.

- During transmission, other functions (e.g. Video Calls) may be disabled.

View Mobile Widget Overview

> **Main Menu** ▶ Entertainment ▶ Mobile Widget ▶ Information

Show/Hide Widget

> **Main Menu** ▶ Entertainment ▶ Mobile Widget ▶ Information

> In Standby, 

Pasting Widgets to Standby

Paste up to five widgets per sheet. Select from four sheets and organize sheets by theme.

- 1  Widget List appears.
- 2 Select a widget →  [Menu] → **Paste on Stand-by** → Select a sheet
- 3  to move to target location → 

Toggle Sheets






> In Standby,  →  [Back] or  [Forward]


Note

- Alternatively, **Main Menu** ▶ Entertainment ▶ Mobile Widget ▶ **Widget Contents** or **Main Menu** ▶ Data Folder ▶ **Widget** to select widgets
- When saving widgets from microSD to Standby, do not remove microSD Card.

Using Widgets

Selecting Widgets in Standby

- 1 In Standby,  Pointer () appears.
 - To disable pointer:  or 
- 2  to move pointer → Select a widget
Follow onscreen instructions.



Selecting Widgets from Widget List

- 1  Widget List appears.
- 2 Select a widget



Widget List

Move Widgets in List

- >  → Highlight a widget →  [Move] →  to determine a target location →  [OK]

Tip

-  ● Mobile Widget (P.18-15)

Downloading Widgets

Main Menu ► Entertainment ► Mobile Widget
► Widget Contents

- 1 **Download Widget** → YES
931P connects to the Network, and download site appears.
Follow onscreen instructions.

Installing Widgets




Some widgets may require you install them manually; follow steps below:



- > In download completion window,  [Menu] → **Install**
- Once installation is completed, widgets appear in Widget List. Widget folder in Data Folder includes widgets that are not yet installed.

Note

- Alternatively, **Main Menu** ► **Data Folder** ► **Widget**
► **Download Widget** ► **YES** to download

Arranging Widgets in Standby

- 1 In Standby,  →  to move pointer → Highlight a widget →  [Operate]
- 2 Select an item (See below)

Item	Operation/Description
Move	>  to move to a target location → 
Delete frm Standby	> YES
Forward	Move overlapping widget to foreground
Rear	Move overlapping widget to background
Reload	Update widget

S! Quick News (Japanese)

Add news headlines, weather forecasts, etc. via S! Quick News List to scroll across Standby Window.

- Registering or viewing S! Quick News incurs transmission fees. No fees apply for viewing ticker information. For more information, visit SOFTBANK MOBILE Corp. Website (<http://www.softbank.jp>).

Registering S! Quick News Items

- Register one **Quick** news, up to four **General** news and one **Special** news.

Main Menu ▶ Entertainment ▶ S! Quick News
▶ S! Quick News List

1 Add News → YES

Yahoo! Keitai connects and contents list appears.



2 Select an item

Follow onscreen instructions.

Opening New Information

Viewing New Information in Standby

When new information is received,  appears in Standby.

1 In Standby,  →  to move pointer → Select ticker

2  [Select]

Content list appears.

3 Select information

Details appear.

Tip

Settings

- Turn Back Light Off after All S! Quick News Viewed (☞P.18-6)
- Show Only Unread Items in Standby ● Change Marquee Speed
- Hide S! Quick News ● Show Image Data (☞P.18-16)

Opening S! Quick News List

Icons



Main Menu ► Entertainment ► S! Quick News ► S! Quick News List

- 1 Select an item
Content list appears.
- 2 Select information
Detailed information appears.
- 3 To connect to the Network, select a title → **YES**

■ Update Manually

> In Step 1, [Menu] → **Update** or **All Update** → **YES**

■ View Summary

> In Step 1, highlight information → [Menu] → **Summary Display**

■ Delete Registered Items

> In Step 1, (highlight information →) [Menu] → **Delete** or **All Delete** → **YES** (→ For **All Delete**, enter Phone Password)

Note

- Alternatively, **Main Menu** ► **Entertainment** ► **S! Quick News**
► **Settings** ► **Del S! Quick News List** ► **YES** to delete all information

Tip

Settings

- Automatically Update S! Quick News List
- Delete S! Quick News Information (P.18-16)

S! Information Channel/Weather (Japanese)

Subscribe to content and periodically receive updates. Set Weather Indicator to appear on Standby.

- Transmission fees apply for updates.

Registering/Canceling

Main Menu ► Entertainment ► S! Info Ch./Weather

1 Register/Cancel → YES

931P connects to the Network.
Follow onscreen instructions.

Using S! Information Channel

- Up to seven updates are saved.

Viewing New Information


When information arrives,  and Event Indicator appear in Standby.

1 In Standby,  →  to move pointer → Select Event Indicator

2  [Select]

Follow onscreen instructions.

- Option Menu Items (P.7-8)



Manually Retrieve Information

Select Event Indicator "Failed to download"

- Alternatively, Main Menu ► Entertainment ► S! Info Ch./Weather ► Get Latest Contents ► YES

Delete Information

> Main Menu ► Entertainment ► S! Info Ch./Weather ► Highlight What's New? ►  [Menu] ► Delete ► YES

Note

- Alternatively, Main Menu ► Entertainment ► S! Info Ch./Weather ► What's New? to retrieve information
- If there is unread information in both S! Quick News and S! Information Channel,  does not appear. Only Event Indicator appears.


Viewing Previously Received Information

Main Menu ► Entertainment ► S! Info Ch./Weather

1 History → Select a date

 for unread news and  for read news appear.

Delete History

> Main Menu ► Entertainment ► S! Info Ch./Weather ► History ► (Highlight a History) ►  [Menu] ► Delete or Delete all ► YES
(► For Delete all, enter Phone Password)

Using Weather Indicator

Weather Indicator for current forecast area appears in Standby.

Viewing New Information

Event Indicator and Weather Indicator appear for weather updates.

1 In Standby,  →  to move pointer → Select Event Indicator or Weather Indicator

2  [Select]

Information appears.

Follow onscreen instructions.

- Option Menu Items (➡P.7-8)

Weather Indicator

Indicators are updated periodically.

Example:  Clear,  Rain later thunderstorm,

 Cloudy with occasional snow, etc.

- See Weather Indicator List (➡P.19-24) for a complete list of indicators.

Manually Update Weather Indicator

Select Event Indicator "*Failed to download*"

- Alternatively, **Main Menu** ▶ Entertainment
▶ S! Info Ch./Weather ▶ Weather Indicator ▶ Manual Update
▶ YES

Hide Event Indicator

- > **Main Menu** ▶ Entertainment ▶ S! Info Ch./Weather
▶ Weather Indicator ▶ Missed Event Settings ▶ OFF

Note

- Alternatively, view forecast details from **Main Menu**
▶ Entertainment ▶ S! Info Ch./Weather ▶ Weather Indicator
▶ Weather

Hiding Weather Indicator


Main Menu ▶ Entertainment ▶ S! Info Ch./Weather
▶ Weather Indicator ▶ Display Settings

1 **OFF**

- When Display Settings is set to **OFF**, update is also deactivated.

Option Menu Items


While viewing a content, press  [Menu] for these options.

Item	Operation/Description
Forward	Go to next page
Text Copy	Copy page text
Select File	View, play or save file to Data Folder (From Step 2 in Downloading Image/Sound Files:  P.14-11)
Jump in this page	Jump to top/end of page
Yahoo! Keitai	View top menu
Font Size	Change character size* or character conversion method
Exit viewing this	Exit content

* Linked with Font Size setting in Internet option menu.

E-Books (Japanese)

Use **BookSurfing®** to acquire/view e-books, comics, photo books, etc. or **e-Book Viewer** to view XMDF files on 931P.

- BookSurfing® and e-Book Viewer are S! Appli.
- Download Content Keys ( P.9-5) to read CCF/XMDF files.
- Some copy protected files have extensions different from the ones below.

Application	File Format
BookSurfing®	CCF (.ccf)
e-Book Viewer	XMDF (.zbf, .zbf, .zbf)

- Some PC content may not be viewable via e-Book Viewer.

Main Menu ► Entertainment

1 **BookSurfing** or **e-Book Viewer**

- See application Help menu for usage information.

Note

- Launch BookSurfing®/e-Book Viewer via S! Appli, or select a file from Books in Data Folder.