12

Tools

Calendar	12-2
Opening Calendar	12-2
Creating Calendar Events	12-2
Saving Holidays/Memorial Days	12-3
Viewing/Editing Calendar Event Details	12-4
Calendar Functions	12-4
Tasks	12-5
Saving a Task	
Using Tasks	12-6
Alarms	12-6
Alarm Tone	12-6
Setting Alarm	12-7
Calculator	12-8
Notepad	12-8
Saving a Note	12-8
Notepad Functions	12-9
Dictionary (Japanese)	12-9
Sound Recorders	<mark>12-1</mark> 0
Voice Recorder	12-10
Voice Announce	12-10
Bar Code Reader	12-11
Scanning Barcodes	12-11
Viewing/Editing Scanned Data	
Using Scanned Data	12-12

Calendar

View by day, week or month; set Alarms for events.

Opening Calendar

Main Menu ► Tools ► Calendar

Current month appears.

- When a date with Calendar events is selected, number of AM and PM events and up to three contents appear.
- (Prev.) or (Next) to show previous/next month calendar.
- To switch Monthly/Weekly view: ☐ P.12-4



Monthly View

Creating Calendar Events

Save up to 1000 entries.

Main Menu ► Tools ► Calendar



Select an item (See below)

Item	Operation/Description			
Select icon/	> Select an icon → Edit subject			
Edit summary				
Whole day > OFF or ON				
setting	 When ON is set, Alarm goes off at 0:00 a.m. 			
Date (from)	> Enter start date and time			
Date (to)	>Enter end date and time			
Repeat	> Select a repetition → (For <i>Select day</i> , check days → (Finish))			
Alarm	> Select an Alarm type (→ For <i>ON/Set time</i> , enter time) • Alarm Tone: ☐ P.12-6			
Alarm tone	> Select an Alarm tone type → Select a folder → Select an Alarm tone			
Contents	> Enter event description			

3 ⊠[Finish]

Calendar Event Indicators

Following indicators appear in Calendar Window.

(Blue): Morning event

(Orange): Afternoon event

__ (Underscore): Event that lasts for two days or longer

• Following indicators appear on Display.

② : Alarm
D : Daily

M : Monthly
Y : Yearly

w : Weekly

Y : Yeari

Note

- Calendar events between 00:00 on 2000/01/01 and 23:59 on 2037/12/31 can be saved on 931P.
- Alarm tone does not sound when Privacy Key Lock or Personal Data Lock is set. However, settings can be changed even while Personal Data Lock is set (△P.11-5).

Saving Holidays/Memorial Days

Save up to 100 entries (one entry a day) each for Holidays or Memorial days.

Main Menu ▶ Tools ▶ Calendar

- ¶ Highlight a date → ☑ [New] → Holidays or Memorial days
- 2 Select an item (See below)

Item	Operation/Description
Date setting	> Enter a date
Repeat	 Select a repetition type 1 time does not repeat Holidays/Memorial days events.
Edit holiday/ anniversary	> Enter description

3 ⊠[Finish]

Indicators

Holidays appear in red.

Memorial days are marked with a red circle.

Following indicators appear in Calendar/Calendar Event List Window:

 [★] : Holidays : Memorial days : Yearly repeat

Viewing/Editing Calendar Event Details

Main Menu ► Tools ► Calendar

1 to select a date

Select an event

 To edit: ○ [Edit] → Edit selected item (Schedule: ☐From Step 2 on P.12-2/ Holiday, Anniversary: ☐From Step 2 on P.12-3)

2009/ 6/ 6(Sat)	
1 11:35~11:35	
◆ Scheduled	
2 11:40~12:00	
3 12:30~13:00	
⊪ Mea I	

Calendar Event List

ß	Scl	hedu l	е		
⊗ Summar					
Schedu	ıle	d			
∰Whole	day	y			0FF
<pre>②Date(1</pre>					
2009/		6(Sa	t)	11:	35
①Date(t)					
2009/	6/	6(Sa	t)	11:	35
					0FF
⊘ Alarm					0FF
 ■Conter	ıts				
Schedu	ıle	d			

Calendar Event Details

Calendar Functions

From ► Main Menu ► Tools ► Calendar

Functions Available in Calendar Window

> Highlight a date → [Y] [Menu] → Select an item (See below)

Item	Operation/Description
New	Create a new entry (☐FP.12-2, P.12-3)
iicii	create a new entry (231.12 2,1.12 3)

Item	Operation/Description
Weekly display/ 1 Month	Toggle Monthly/Weekly view
Icon display	Entries in category of selected icon appear > Select an icon
No. of schedules	Display number of saved Schedule, Holiday or Anniversary entries
Add shortcut icon	Create a shortcut (⊈ P.1-22)
Send all Ir data	(□ P.10-3)
AllIC transmission	(<u>r</u> P.10-5)
Delete past	Delete past entries/items, prior to highlighted date > Select a category to delete → YES
Delete all	> Enter Phone Password → Select an item → YES
Reset holidays	Restore deleted Holidays > YES

Functions Available in Calendar Events List/Details

> Select a date (→ Select a Schedule, Holiday or Anniversary) → [**Y**/[**Menu**] → Select an item (See below)

Item	Operation/Description
New	Create a new entry (☐FP.12-2, P.12-3)
Edit	Edit selected item (Left)
Сору	Copy an entry to another day Enter date and time to copy an entry to
Calendar display	Switch from Icon display to Calendar display

Item	Operation/Description
Icon display	Entries in category of selected icon appear
	> Select an icon
Set secret	Activate/deactivate Secret Mode
mode/	> YES (→ For Set secret mode, enter Phone Password)
Release	 Secret entries appear only in Secret Mode or
secret	Secret Data Only (⊈P.11-9).
Compose	Create S! Mail by copying event date and content to
S! Mail	message text (∠From Step 2 on P.13-4)
Send Ir data	(<u>r</u> F.10-3)
Send all Ir	(□ P.10-3)
data	
IC	(□ P.10-5)
transmission	
AlliC	(<u>r</u> P.10-5)
transmission	
Copy to	Copy an entry to microSD Card
microSD	> YES
	To display data on microSD Card: ☐ P.9-18
Delete this	> YES
Delete past	Delete past entries/items, prior to highlighted date
	> Select a category to delete → YES
Delete select	> Check entries to delete → [Finish] → YES

Tasks

Make quick notes of task to manage in Task list.

Saving a Task

Main Menu ► Tools ► Tasks

- [New] → Select an item (See below)
 - To check saved Tasks, select a Task. To edit, press [Edit] in detail window.

Item	Operation/Description
Edit Tasks	>Enter content
Due date > Select how to enter due date → Enter due dat • Select <i>No date</i> to enter none.	
Priority	> Select a priority level
Category	> Select a category
Alarm	> Select an Alarm type (→ For <i>ON/Set time</i> , enter time) • Alarm Tone: ☐ P.12-6
Alarm tone	> Select an Alarm tone type → Select a folder → Select an Alarm tone

□[Finish]

• When content is not entered, Tasks cannot be saved.

Note

• Alarm tone does not sound when Privacy Key Lock or Personal Data Lock is set. However, settings can be changed even while Personal Data Lock is set (⊈P.11-5).

Using Tasks

In Tasks window press [XV] [Menu] for following operations

in tasks window, press 🛂 [wenu] for following operations.				
Item	Item Operation/Description			
New	Create a new entry (⊈₹P.12-5)			
Edit	Edit an entry (△→P.12-5)			
Change	Change status indicator shown in Tasks list			
status	> Select a status (→ For <i>Completion</i> , select an item →			
	Enter Completion date)			
	 Overdue status indicator turns red. 			
Show by	> Select a category			
category				
Sort/Filter	Sort list by due date, entry order, status, etc.			
	> Select a condition			
Add shortcut	Create a shortcut (☐FP.1-22)			
icon				
Send Ir data	(□ P.10-3)			
Send all Ir	(⊈ P.10-3)			
data				
IC transmission	(□ P.10-5)			
AlliC	(⊆ F.10-5)			
transmission				
Copy to	Copy a Task to microSD Card			
microSD	> YES			
	To display data on microSD Card: ☐ P.9-18			
Delete this	> YES			
Delete select	> Check entries → ☑[Finish] → YES			
Delete	Delete an entry in <i>Completion</i> status			
completed	> YES			
Delete all	> Enter Phone Password → YES			

Alarms

Alarm Tone

When scheduled time arrives, alarm tone sounds and Notification Light illuminates.

• For Calendar events and Tasks, alarm message and animation corresponding to selected icon appear on Display.

To Stop Alarm Tone for Calendar Events, Tasks or Alarm Press any key.

Missed Alarm

"Missed Alarm" Event Indicator appears in Standby for alarms missed during Privacy Key Lock, Personal Data Lock or Infrared transmission once locks are canceled or transmission ends. Select indicator to view content.

Note

• When one or more Alarms are set to the same time, alarm sounds in the order of : "Alarm" → "Timer Recording" → "Tasks" → "Calendar" → "Timer Watching" For Tasks, "Missed Alarm" indicator appears.

Setting Alarm

Set up to 12 alarms. Alarm tone sounds at the specified time once, everyday or weekly as set.

Main Menu ► Tools ► Alarms

Highlight an Alarm $\rightarrow \square$ [Edit]



Select an item (See below)

Item	Operation/Description
,	Activate or cancel Alarm
on/off)	>ON or OFF
Time setting	> Set Alarm time
Repeat	> Select a repetition (→ For <i>Select day</i> , check days → <a> [Finish])
Alarm tone	> Select an Alarm tone type → Select a folder → Select an Alarm tone
Alarms (Alarm volume)	> 🖸 to set Alarm tone volume
Snooze	>ON or OFF (→ For OFF, enter time)
setting	 When Snooze is set to ON, Alarm tone sounds for 60
	seconds, repeating up to six times at five minute intervals.
Prefer	>ON or OFF
manner mode	 Set Manner Mode or Alarm priority.

[Finish]

appears.

Alarm Indicators

- Following indicators appear:
 - D: Repeats daily W: Repeats weekly

Cancel & Reactivate Alarm

- > In Alarms list, press [Y7] [Menu] → Select set this or Release this → YES
- Cancel or reactivate an alarm entry as required.
- Highlight an entry → □ to reactivate/cancel Alarm.

Cancel Snooze

> Press any key → <a>

Note

- Copy protected files may not be set as Alarm tone.
- Alarm tone does not sound when Privacy Key Lock or Personal Data Lock is set. However, settings can be changed even while Personal Data Lock is set (⊈P.11-5).

Calculator

Main Menu ► Tools ► Calculator

Operation	Assigned key
Number (0 - 9)	0 - 9
+	
_	D
х	o
÷	
=	•
Decimal point	
%	Y 7
Clear	(7U79)XE)



12 Tools

Example:

-17+28.5=11.5











Notepad

Save up to 20 notes.

Saving a Note

Main Menu ► Tools ► Notepad

- <Not Recorded>
 - Select a saved note to view content. [Edit] to edit.
- Enter text
 - Up to 256 double-byte or 512 single-byte characters can be entered.



Notepads Window

Notepad Functions

In Notenad list window press [VIMenu] for following operations

<u> </u>	indow, press [interial for following operations.
Item	Operation/Description
Edit	Edit a saved note
Compose S! Mail	Create S! Mail by copying content to message text (13 From Step 2 on P.13-4)
Edit schedule	Copy a note to Schedule to create a Calendar event > Schedule → Save a new note (☐From Step 2 on P.12-2)
Add shortcut icon	Create a shortcut (⊈₹P.1-22)
Send Ir data	(⊆ F.10-3)
Send all Ir data	(1 P .10-3)
IC transmission	(1 P .10-5)
AllIC transmission	(1 P .10-5)
Copy to microSD	Copy a note to microSD Card > YES ■ To display data on microSD Card: 🗲 P.9-18
Notepad Info	Display entry date, latest modified date and category of note
Category	> Select a category ● When no category applies, select <i>None</i> .
Delete this	> YES
Delete selected	> Check notes → [Finish] → YES
Delete all	> Enter Phone Password → YES

Dictionary (Japanese)

Use ケータイTOOL<辞書> to access dictionaries (学研 辞スパ 英和·和英辞書 and 学研 国語辞書).

● ケータイTOOL<辞書> is an S! Appli.

Main Menu ► Tools ► Dictionary

Read 免責 (disclaimer) → OK

ケータイTOOL<辞書> activates.

● To disable 免責: Uncheck アプリ起動時に常に表示する。(Always show disclaimer when accessing dictionaries)

Search results appear.

- To scroll pages: [○]/[○]
- To switch dictionaries: 1/3
- To search again: [∑7][再検索]

Select a word Details appear.

To end, \frown \rightarrow **Stopped**

Note

● While Dictionary application is active, press [□][メニュー] for useful functions.

• Record for about 60 seconds each.

Main Menu ► Tools ► Sound Recorders ► Voice Recorder

- 1 YES

12 ਰ

Voice Announce

Set recorded sound for on hold tone/holding tone, Alarm, Calendar event alarm, Tasks alarm, ringtones, Answer Phone message, Timer Watching (Digital TV), Ring Songs&Tones Play List.

- Record only one item for about 15 seconds.
- Select Voice Announce in individual window to set Voice Announce as specific tone.

Main Menu ► Tools ► Sound Recorders ► Voice Announce

1 Record

Recording starts.

Tone beeps five seconds before recording ends.

2 • [Stop] to end recording

Tone beeps twice and previous screen returns.

- To play back: *Play*
- To delete: Erase → YES

Bar Code Reader

Scan barcodes (JAN) or QR Codes with built-in camera. Access websites, send messages, etc. from QR Codes.

JAN Codes

JAN Code is a one-dimensional bar code denoting numerals with bars and spaces of different widths.

OR Codes

QR Code is a two-dimensional bar code containing information.



Scanning Barcodes

Up to five items can be saved. For split data, scan up to 16 divided QR Codes.

Main Menu ► Tools ► Bar Code Reader ► Scan Barcodes

- 1 Frame barcode in the center of Display
 - To adjust Display brightness: ∑[Menu] → Brightness →
 Adjust to -3 (dark) +3 (light)
 - To zoom: 🔯
 - To use Focus Lock:

[Start]

Scanning starts, and scanned results appear when completed.

- For split data, OK → Repeat Step 1 and 2
- To use scanned data: 🖙 Step 2 on P.12-12

Bar Code Reader SoftBank mobile phones

Example: Scanned Results Window (QR Code: 🖆 Left)

3 (Σ) [Menu] → Save result → OK

Note

- 931P cannot read barcodes or two-dimensional codes other than JAN/ QR Codes.
- Some barcodes cannot be read depending on code type or size.
- Barcode recognition may be slow. Hold handset steady while scanning.
- Barcodes may not be correctly read owing to scratch, dirt, damage, quality of printed material, light reflection, or QR code version.

12

Tools

Viewing/Editing Scanned Data

Main Menu ► Tools ► Bar Code Reader ► Saved Data List

1 View

Select an item

Edit Title

Highlight an item \rightarrow Y? [Menu] \rightarrow Edit title \rightarrow Edit

Delete Saved Data

> In Step 1, (highlight an item →) [Y] [Menu] → Delete → Delete this or Delete all (→ For Delete all, enter Phone Password) → YES

Using Scanned Data

Main Menu ► Tools ► Bar Code Reader ► Saved Data List

- Select an item
- **7 Y**/**[Menu]** → Select an item (See below)

Item	Oneration/Description
item	Operation/Description
Save result	Save scanned results
Display list	Display Saved Data List
Internet	Connect to URL
	> Yahoo! Keitai or PC Site Browser → YES
	Alternatively, select URL to connect to Internet.
Compose	Create S! Mail to selected address (☐From Step 4 on
S! Mail	P.13-4)
	 Alternatively, select address to create S! Mail.
Dialing	Call selected phone number
	> Select a dialing method → <i>Dial</i>
	Alternatively, select phone number to dial.
Add to	Save scanned results to Phone Book (☐From Step 2 on
Phone Book	P. 4-5)
Add	Save URL to Bookmark
bookmark	> YES → • [OK]
Сору	Copy selected characters to another place (☐From Step 2
	on P.3-9)
bookmark	> YES →