

S! GPS Navi

About S! GPS Navi	17-2
Using S! GPS Navi	17-2
Checking Your Current Position	17-2
Activating Navi Appli	17-3
Using Location Navi (Japanese).....	17-3
Using Location Log.....	17-3

About S! GPS Navi

S! GPS Navi provides location information by communicating with base stations and by GPS satellite. Check your position on map, area information or route to your destination using a Navi Appli.

Note

- Location information may be inaccurate due to location or signal conditions.
- SoftBank is not liable for any resulting damages.
- Position cannot be determined while Positioning Lock is active (☞P.18-22).
- For more information, visit SOFTBANK MOBILE Corp. Website (<http://www.softbank.jp>).

Using S! GPS Navi

Checking Your Current Position

Activate Navi Appli to check your position.

Main Menu ▶ Tools ▶ S! GPS Navi

1 *Current Location* → YES

Positioning starts.

- To check your current position during positioning: When [Use] appears at lower right, (S!) → OK

2 When positioning is complete, (M)[Map] → YES

931P connects to the Network and web page opens.

- To reposition: (R)[Retry]

Save to Phone Book

Save obtained location information to Phone Book.

- > Positioning is complete → (S!)[Menu] → *Add to Phone Book* → YES
→ Follow the steps for saving to Phone Book (☞From Step 2 on P.4-5)

Indicating Positioning Accuracy Level

Accuracy Level 🌀🌀🌀 ... Fairly accurate

Accuracy Level 🌀🌀🌀 ... Relatively accurate

Accuracy Level 🌀🌀🌀 ... No accurate location information retrieved
Retrieve location information again.

Activating Navi Appli

Search for current area information or route to your destination.

- End all applications including suspended applications.

Main Menu ► Tools ► S! GPS Navi ► Navi Appli

Using Location Navi (Japanese)

Use Location Navi to locate a person via a SoftBank 3G handset or PC.

For more information, visit SOFTBANK MOBILE Corp. Website (<http://www.softbank.jp>).

Main Menu ► Tools ► S! GPS Navi ► Location Navi

Note

- Event Indicator appears when location information is automatically provided or location information request is rejected. Select indicator to show location log.

Using Location Log

Up to 50 latest location info are saved. Delete as required.

Main Menu ► Tools ► S! GPS Navi ► Location Logs

1 Show Details

Select a record to view details

- ☒ appears if positioning fails.

Delete a Record

Highlight a record → ☒ [Menu] → *Delete* → *Delete this* → *YES*

Delete All

☒ [Menu] → *Delete* → *Delete all* → Enter Phone Password → *YES*

Note

- When 50 records are saved, oldest is deleted first.
- When positioning is requested while viewing a record, a message appears and log window returns.

Tip

Settings ● S! GPS Navi Settings (P.18-22)

