

Handset Security	11-2
Operations Security	11-2
Information Security.....	11-3

Face Recognition	11-4
Using Face Recognition	11-4
Additional Functions	11-6

11

Handset Security




Operations Security

Function Lock

Restrict access to handset functions.

Auto	Lock when Display turns off or handset is closed
Once	Lock immediately; setting is canceled once handset is unlocked
At Power On	Lock when handset is turned on; Handset Code entry window opens

- 1 → **Settings** → → **In Phone menu, Locks** →



Locks Menu

- 2 **Function Lock** →
- 3 **Select item** → → **Enter Handset Code** →

Unlocking Temporarily

While handset is locked, enter **Handset Code** →

When Function Lock is Active

- Press corresponding key to turn handset on/off, answer calls, place callers on hold, end calls, etc.

PIN Entry

Activate PIN Entry to require PIN entry each time handset is turned on.

- 1 **In Locks menu, PIN Entry** → → **Switch On/Off** →
- 2 **On** → → **Enter PIN** →

Secure Remote Lock

Lock a lost handset remotely via PC or another handset. Secure Remote Lock disables all operations except turning handset on, and activates IC Card Lock. For more about Secure Remote Lock, see SOFTBANK MOBILE Corp. Website (P.15-23) or contact SoftBank Mobile Customer Center, General Information (P.15-41).



Advanced

- Changing PINs ● Setting Secure Remote Lock activation message to appear (P.11-6)

Information Security

Application Lock

Restrict access to these functions:

Phone Book


Calendar/Tasks

Yahoo! Keitai

Mail


Notepad

- 1 → **Settings** → → In Phone menu, **Locks** →



Locks Menu

- 2 **Application Lock** →



- 3 **Select item** → (✓)
 - For Phone Book, select **No Refer** or **Refer** and press .

- 4 → **Enter Handset Code** →

Temporary Access to Functions

- When accessing functions, enter Handset Code and press .

History Lock

Restrict access to Call Log and sent/received mail records.

- 1 In Locks menu, **History Lock** →



- 2 **Select item** → (✓)

- 3 → **Enter Handset Code** →

Temporary Access to Records

- When accessing records, enter Handset Code and press .

Show Secret Data

Activate Show Secret Data to access Secret entries.

- 1 In Locks menu, **Show Secret Data** →
- 2 **On** → → **Enter Handset Code** →

When Show Secret Data is Active

- Predictive is not available for text entry.

Activating Temporarily with Motion Control

- 1 **Enter Handset Code** → **Shake handset left or right**
 - Show Secret Data is canceled when handset is closed or Display goes dark in Standby.



Using Face Recognition

Capture portraits with mobile camera then match live image to saved ones to unlock handset or access functions/files. If Face Recognition fails, Function Lock activates.

Precautions

- Identification accuracy is not guaranteed. SoftBank cannot be held liable for misuse or any damages associated with the use of Face Recognition.
- Handset Code is required to cancel Face Recognition. Changing the code helps enhance security.
- Osaifu-Keita[®] is available even when Face Recognition is active.
- When capturing/scanning face, remember these points:
 - Make sure your face is clearly visible.
 - Face should be lit evenly and brightly.

Precautions for Portrait Capture

- Look straight into lens and frame whole face with no expression.
- Do not wear a mask when capturing portraits, even for use with **Low(Mask)**.


Saving User Information

- 1 → **Settings** → → **In Phone menu, Locks** →
- 2 **Face Recognition** →



Face Recognition Menu

- 3 **User Registration** → → **Enter Handset Code** →



- 4 **Select from User 1 to User 5** →



- 5 **User Name:** → → **Enter name** →

- 6 **Register Riddle:** → → **Enter question** →

- 7 **Register Answer:** → → **Enter answer** →

- 8 **Face Image:** →



- 9 **Select from Image 1 to Image 5** →

- Mobile camera activates.

- 10 **Frame your face on Display** → → →

- 11 **Yes** →
 - To save more, repeat 9 - 10.

- 12 → → **Saved**



Advanced

- Editing/deleting user information
- Changing/deleting portraits
- Changing accuracy level (P.11-6)

Scanning Face

Face Recognition window opens when handset is turned on or opened, or whenever Display is refreshed after Display Saving time.


1 Face the Display → Recognition starts



2 If face matches a saved portrait, handset unlocks

When Matching Portrait is Found

Saved question appears.



1 [] → Enter answer → []


Advanced

● Changing recognition guide option ● Opening contact information when recognition fails (P.11-6)

If You Cannot Remember the Answer
 In 1, [] → Enter Handset Code → []
When No Question or Answer is Saved
 In 1, Enter Handset Code → []

When Recognition Fails

Function Lock activates.



Retrying Face Recognition

1 []

Unlocking with Handset Code

1 Enter Handset Code → []

Activating & Canceling

- 1 In Face Recognition menu, **Switch On/Off** → []
- 2 **On or Off** → [] → Enter Handset Code → []





PIN Entry

Changing PINs

Start Here [] → **Settings** [] → In Phone menu, **Locks** [] → See below

Changing PIN

PIN Entry [] → **Change PIN** [] → Enter current PIN [] → Enter new PIN [] → Re-enter new PIN []

- Activate PIN Entry first.

Changing PIN2

Change PIN2 [] → Enter current PIN2 [] → Enter new PIN2 [] → Re-enter new PIN2 []

Secure Remote Lock

Setting Secure Remote Lock activation message to appear

Start Here [] → **Settings** [] → In Phone menu, **Locks** [] → **Set Lock Message** [] → See below

Saving Message

Message [] → Enter Handset Code [] → Enter message [] → Yes []

Checking Message

Check Message []

Face Recognition

Editing/deleting user information

Start Here [] → **Settings** [] → In Phone menu, **Locks** [] → **Face Recognition** [] → **User Registration** [] → Enter Handset Code [] → Select from **User 1 to User 5** [] → See below

Editing

[] → Select item [] → Change portrait or enter information [] → []

- Edit items in the same way as saving entries.

Deleting

[] → Yes []

Changing/deleting portraits

Start Here [] → **Settings** [] → In Phone menu, **Locks** [] → **Face Recognition** [] → **User Registration** [] → Enter Handset Code [] → Select from **User 1 to User 5** [] → **Face Image:** [] → Select from **Image 1 to Image 5** [] → See below

Changing

[] → [] → Yes [] → [] → [] → []

Deleting

[] → Yes []

Changing accuracy level

[] → **Settings** [] → In Phone menu, **Locks** [] → **Face Recognition** [] → **Security Level** [] → Select level []

- When set to **Low(Mask)**, handset recognizes faces with masks.

Changing recognition guide option

[] → **Settings** [] → In Phone menu, **Locks** [] → **Face Recognition** [] → **Conductor Setting** [] → Select option []

Opening contact information when recognition fails

[] → **Settings** [] → In Phone menu, **Locks** [] → **Face Recognition** [] → **Report** [] → Enter Handset Code [] → Enter contact information []