Mobile Widget	10-2
Customizing Standby Display	
(Japanese)	10-2
S! Quick News	10-5
Receiving Content Updates (Japan	ese)
	10-5
S! Information Channel	10-6
S! Information Channel & Weather	
O: IIIIOIIII GIIGIII GIIGIII GI WOGAII GI	
Indicator (Japanese)	10-6

S! Friend's Status	10-8
Using S! Friend's Status	10-8
S! Circle Talk	. 10-11
Using S! Circle Talk	10-11
Near Chat	. 10-13
Using Near Chat (Japanese)	10-13
Blog Tool	. 10-14
Blogging	10-14
Additional Functions	. 10-16
Troubleshooting	. 10-23

Entertainment & Communication




Customizing Standby Display (Japanese)

Paste various widgets (applications) to Standby to access/activate information/functions immediately from Standby.



Obtaining Widgets





Mobile Widget Menu





Widget List



Installing Widgets

 Some widgets may need to be installed manually; follow these steps:

[Widget List] Select widget ⇒ ③ ⇒

Install ⇒ ⑥ ⇒ Yes ⇒ ⑥

Activating Single Widgets

Deleting Widgets

- In Widget list, select widget

 → □
 - *S!速報ニュース/S!ともだち状況* cannot be deleted.



Deleting All Widgets

In Widget list, Download → ③ →

Delete All → ⑥ → Enter Handset

Code → ⑥ → Yes → ⑥

If there is a widget saved in Standby, a confirmation appears; follow onscreen prompt.



Saving Widgets to Standby





- Select widget

 Orresponding icon appears in
- Use � to specify target location ▶ ●

Using Pointer (₨)

Standby.

- After ①, Long Press ② to activate pointer navigation; select widgets, etc.
- To cancel pointer navigation, Long Press (*).

Using Widgets

① ♦ Use ۞ to select widget ♦ ●



20

Widget activates; follow onscreen instructions.

Using Sheets


Paste widgets and Standby Shortcuts on each sheet; toggle sheets to use them.

Toggling Sheets





- To toggle further, press ♥ or
- Sheet name appears at the top, then disappears.
- Save widgets as needed; corresponding icons appear on the current sheet.



- Saving Widgets on Other Sheets
- In Widget list, select widget





Select sheet ▶ ●



Specify target location → ●

Removing Widgets from Standby

- ① → Use ۞ to select widget → ⑤
- 🔁 Operation 🕈 💿



- Remove **→** ●
- Yes → ●

Using S! Quick News & S! Friend's Status Widget

935SH is preloaded with *SI速報ニーパSIともだち状況* (S! Quick News & S! Friend's Status widget) that shows S! Quick News and S! Friend's Status information in Standby.




- View Settings
- Setting View Pattern
- ① → Use ﴿ to select S! Quick News/S! Friend's Status widget → ②
- Settings → Pattern
 Setting →
 - Select item → (☑) → ☞
- Switching View
- ① ◆ Use ۞ to select S! Quick News/S! Friend's Status widget ◆ ②
- ② Operation → → Switch Pattern → ●
 - Repeat the above steps to switch the view.



Receiving Content Updates (Japanese)

View content updates or breaking news. Transmission fees apply.

Registering S! Quick News Items






S! Quick News Menu





S! Quick News List




Handset connects to the Internet.



Opening Information

- In S! Quick News List, select item

 ◆
 - Title list appears.





• Press (22) to return to title list, or (22) to open next title.

Updating Items Manually

[S! Quick News List] Select item ▶



Indicators Unread Special news Read Special news Read General news Unread News Auto update disabled

S! Information Channel & Weather Indicator (Japanese)

Subscribe to Japanese mobile periodicals that download to handset automatically; use Weather Indicator as needed.


Transmission fees apply.

Service Registration & Content Subscription





S! Information Channel Menu



Handset connects to the Internet.
 Follow onscreen instructions.

New Received Information

Information window opens for new S! Information Channel info delivery.

While Information window appears, *S! Info. Channel*

- S! Information Channel page opens.
 Follow onscreen instructions.
- S! Information Channel page handling is similar to that of Yahoo! Keitai.



Opening Unread Latest Issue
[S! Information Channel Menu]

What's New

●

Opening Back Issues

[S! Information Channel Menu] Back
Issue → ● Select date → ●

Using Weather Indicator

After S! Information Channel registration, local area weather indicator appears in Standby.



Example: □/* ► Partly cloudy with a chance of rain
Indicators other than the above also appear for more information.

Manual Update

[S! Information Channel Menu]


Weather Indicator → ● → Manual


Update → ● → Yes → ●



Reading e-Books (Japanese)

Downloading e-Books





- Follow onscreen instructions.
- Downloaded e-Books are saved to Data Folder (Books).

Note

 Alternatively, go to SH-web Mobile Internet site (シャープ・メーカーサイトSH-web in Bookmarks; see P.5-7) for e-Books.

e-Book Viewer

Read XMDF books and dictionary files. Some files may not be supported.





Entertainment Menu



 e-Book Viewer starts. Refer to the e-Book Viewer help menu for operational instructions.

BookSurfing®

Download Contents Kevs and read CCF files. Some files may not be supported.

- In Entertainment menu, BookSurfing **→** (●)
 - BookSurfing[®] S! Application starts. Refer to the BookSurfing® help menu for operational instructions.

Moving CCF Files via Memory Card

 When purchasing a new handset, move CCF files and retrieve Contents Keys to open the files. Some files may need to be re-downloaded.

Using S! Friend's Status

Exchange current usage status, mood, etc. with compatible handsets.

- Save and organize members in Groups.
- S! Friend's Status requires a separate contract and basic monthly fee.
- Set Connection status to Online first.

First S! Friend's Status Use

Follow these steps to register a number saved in Phone Book; Status, Availability and Comment are sent to the members.







Yes → ●



- Yes → ●
- Phone Book ⇒ ●





- Omit number selection step if only one number is saved.
- Yes → ●
 Registration request is sent to the number.
- When Request is Accepted

 An acceptance notice arrives; My Status is sent and member's status appears on handset.

Direct Entry

In \bigcirc , Add New Entry \Rightarrow \bigcirc \Rightarrow Enter phone number \Rightarrow \bigcirc \Rightarrow \bigcirc



Opening Member Status

(Long) **→** Select Group



Select member → ●




When Cancellation Notice Arrives

 Member is deleted from S! Friend's Status member list.

Changing My Status

Follow these steps to change Status, Availability and Comment; new status is sent to the members.





My Status Window

② Select Status, e.g., ごきげん



Status Template Window

- 👔 Select new Status 🕈 💿
- Select Availability, e.g.,

 Answer OK → → Select

 new Availability → ●







Receiving Request from Unsaved Numbers

When a registration request arrives, a confirmation appears.





 Acceptance notice is sent: the number is registered.

Rejecting

In \bigcirc , No \Rightarrow \bigcirc \Rightarrow Yes \Rightarrow \bigcirc

- Rejection notice is sent: the number cannot be registered for 24 hours.
- For *ConfirmLater*. Information window opens.

Creating Status Templates

Save custom combinations of Status Icon and Status Label to each template.



- In Status Template window,
- Enter name **→** (●)
- <未定> ▶ ●



Status Icon

◆

● Select Pictogram **→** (●)



Repeat € - 5 → 🕏 → Saved

Saving to Data Folder

[Status Template Window] Select template

Save to DF

Output

Description: Save here → ●

Loading Templates via Data Folder [Status Template Window]

→ Add Template

◆

Select template **▶ (•)**

Renaming Templates

[Status Template Window] Select **→** • **→** Enter name **→** •



Using S! Circle Talk


Use handset like a walkie-talkie to speak to multiple parties simultaneously.


- A subscription to S! Friend's Status is required.
- Transmission fees apply during S! Circle Talk.

Registering Members

Follow these steps to register a number saved in Phone Book:







• When registering a member for the first time, a confirmation appears. Choose **Yes** and press (•), then skip ahead to 69.



<Add New Entry> ▶ ●

Group







- Select number, e.g., No.1:
- Phone Book **▶** (●)
- Select entry **→ ● →** Select phone number **→** (●)



- Omit number selection step if only one number is saved.
- Repeat 4 5 to add members.



Saving as Individuals

In ③, Individual → ④ → 🖯 - 🕞

Saving from S! Friend's Status Member List In ⑤. Members List → ⑥ → Select member **→ () → ()**

■ Omit when Individual is selected in .





Initiating S! Circle Talk


Follow these steps to send S! Circle Talk requests to members:

(First, set Connection status to *Online* (P.10-9).)





Select member or Group ▶ ●



- S! Circle Talk starts when request is accepted by a receiver.
- Loudspeaker activates automatically.

Direct Entry

Enter phone number $\Rightarrow \bigcirc \Rightarrow Call$ S! Circle Talk $\Rightarrow \bigcirc \Rightarrow \bigcirc$

S! Circle Talk Operations

- Speaking
- Press and hold when Press and Hold a appears
 - You have the floor



- :My Turn appears when you have the floor.
- Keep holding → to speak

 Release → Floor is
 released
 - Warning tone sounds before time limit.


Incoming Calls during S! Circle Talk

 Incoming calls are rejected. Set handset to exit S! Circle Talk to answer incoming calls as needed.

Canceling Loudspeaker During S! Circle Talk,

- To reactivate, follow these steps:
 - While message appears, ●

Exiting S! Circle Talk



 S! Circle Talk ends automatically when there is only one participant left, including yourself.

Rejoining S! Circle Talk

- ②/⊙ → Select most recent S! Circle
 Talk record → ◎ → Rejoin Circle
 Talk → ●
- Not available when S! Circle Talk has ended or maximum number of participants are already engaged.

Accepting S! Circle Talk Request

- While handset is ringing/ vibrating, ● → S! Circle Talk starts
 - Alternatively, press
 - S! Circle Talk Operations: left



Using Near Chat (Japanese)

Exchange real-time text messages wirelessly with compatible Bluetooth® devices within ten meters. (Available even when handset is out-of-range.) Because this application employs Bluetooth® wireless technology transmission/connection fees do not apply.

Access Restriction

• In the event that this handset may be used by a minor, access to this application may be password restricted by a supervising adult. In this case. Handset Code access must also be managed to prevent the execution of Memory All Clear that may be used to reset the application password.

Sending Near Chat Request















- Near Chat S! Application starts.
- A confirmation appears. Read the message and press (はい) or ∞ (いいえ).
- For more, see Near Chat S! Application instructions.

Receiving Near Chat Request

When a Near Chat request arrives, a tone sounds and S! Appli Notification appears.



After a period of inactivity, Information window opens, tone sounds and notification appears.







- Near Chat S! Application starts.
- A confirmation appears. Read the message and press (はい) or ∞ (いいえ).
- For more, see Near Chat S! Application instructions.

Rejecting Request In ①, No **→** ⊙



Blogging

Save blog details to view or update blogs easily on handset.

Saving Blog Details


Setup for Posting via Mail

Follow these steps to save blog name and address for posting:






Blog Tool Window





Blog Setting Menu







Blog Setting Menu (Mail)

- Blog's Email Address →
 - → Enter mail address → ●



Saving Title/Text for Posts

After ⑤, Blog's Title or Blog's Text

→ ⑥ → Enter title or text → ⑥ → ⑥

- Saved title/text is entered automatically when posting.
- Setting Image Size for Posting

 After ⑤, Picture Size ♦ ⑥ ♦ Select

size **→** ① **→** ③

Setup for Posting via the Internet

Save URL for Yahoo! Keitai or PC Site Browser, or both.

In Blog Setting menu, Refer/ Send by Yahoo! Keitai or Refer/Send by PCSiteBrowser ▶ ●



- Blog's URL → ► Enter URL → ●
- Refer Blog's URL → → Enter URL → ●
- CLEAR ES

 CLEAR ES

 YEACK ES




Posting to Blogs


Complete setup for posting via mail/ Internet beforehand.







- S! Mail Composition window opens with address entered.
- Omit @ if no URL is saved for posting.



Posting via the Internet





- Page of URL saved in Blog's URL opens.
- Omit @ if no address is saved for postina.
- If PC Site Browser message appears, follow onscreen prompts.

When URL is Saved for Yahoo! Keitai & PC Site Browser

After ②. select browser ▶ ●

Opening Blog Page



- Page of URL saved in Refer Blog's URL opens.
- If PC Site Browser message appears, follow onscreen prompts.

When URL is Saved for Yahoo! Keitai & PC Site Browser

After ①, select browser ▶ ⊙





abroad

abroad

Hiding confirmation

Mobile Widget Managing Description Descripti Opening ● Widget Contents → ● Select widget properties → □ → Details → ● • Select widget other than S!速報ニュース/S!ともだち状況. Widget History Start Here ● **Entertainment Mobile** Widget ⇒ ● Widget History ⇒ ● See below **Showing All Text** Select record ⇒ © ⇒ View full text ⇒ ● Opening widget **Deleting a Record** notification history Select record ⇒ © ⇒ Delete ⇒ • Yes ⇒ • **Deleting All Records** Select record → 🖾 → Delete All → • ► Enter Settings Description Descripti Canceling SettingsAuto Refresh→ automatic updates Receiving updates Entertainment Mobile Widget automatically while Settings AutoConnect Abroad

→ Off *→* •

● Settings → ● Set Use Abroad → ●

Disabling widget notifications	● Entertainment → ● → Mobile Widget → ● Settings → ● → Notification Setting →	
Disabling cookies	Off Mobile Widget Settings Cookies Disabled	
Deleting cookies	Settings Delete Cookies Pyes But Principle Mobile Widget Delete Cookies Pyes Pyes Pyes Delete Cookies Pyes Py	
■ Operations in Standby		
Logging in to Yahoo!JAPAN	 ③ → ② → Yahoo!JAPAN log in → ● Follow onscreen instructions. To log out, select Yahoo!JAPAN log out in the above steps. 	
Moving widgets	⑤ → Use ὧ to select widget → ⊚ → Operation → ⑥ → Change Layout → ⑥ → Specify target location → ⑥	
Moving widgets to front/back	⑤ → Use � to select widget → ⑤ → Operation → ⑥ → To Front or To Back → ⑥	
Updating view	③ → Use ﴿ to select widget → ⑤ → Operation → ⑥ → Update View → ⑥	

Removing widgets at once by sheet	Start Here (5) → (22) → Operate from List → (4) → Remove → (4) → See below
	All Widgets Remove All → ● Select sheet → ⊙ → Yes → ●
	Selected Widgets Select also Remove → ● Select widget → ● (□/☑) → Complete selection → ♡ → Yes → ●
Viewing widget-related information (Japanese)	(§) ⇒ (a) ⇒ Information ⇒ •
Slowing pointer speed	(§) → (S) → Settings → (O) → Cursor Speed → (O) → Slow → (O)

■ Sheets

Editing sheet names	Start Here ♦
	Renaming Select sheet
	Resetting All Sheet Names
	Start Here (5) → (a) → Settings → (b) → Sheet Settings → (c) → Set Sheet Lock → (c) → Enter Handset Code → (c) → See below
Locking sheets	Activating Lock Select sheet → ● On → ●
	Changing Method for Temporary Access Unlock Method → ● → No Password → ● • Press ⑤, then select ■ and press ● to unlock sheet temporarily.

S! Quick News & S! Friend's Status Widget (S! Quick News)

2. Guick Hens & C. I Helia S Charles Widger (C. Guick News)	
Adding news items	③ Select S! Quick News/S! Friend's Status widget * ⑤ Operation * ⑥ Contents Menu * ⑥ * Add News * ⑥ S! Quick News List * ⑥ * 登録はこちら * ⑥ Yes * ⑥ Select genre * ⑥ Select item * ⑥ Follow onscreen instructions.
Changing news scroll speed	③ Select S! Quick News/S! Friend's Status widget → ⑤ Operation → ⑥ Contents Menu → ⑥ News Display → News Speed → ⑥ Select speed → ⑥
Showing unread news only	Select S! Quick News/S! Friend's Status widget
Showing news images	Select S! Quick News/S! Friend's Status widget



S! Quick News & S! Friend's Status Widget (S! Friend's Status)

	5
Assigning members	When Pattern Setting is Not Friend's Status(List) ③ Select S! Quick News/S! Friend's Status widget → ⑤ Use ﴿ to select member field → ② → Operation → ⑥ → Contents Menu → ⑥ → Assign Member → ⑥ → Select category → ⑥ Select entry/member → ⑥
	When Pattern Setting is Friend's Status(List) ③ ◆ Select S! Quick News/S! Friend's Status widget ◆ ⑤ ◆ Operation ◆ ⑥ ◆ Contents Menu ◆ ⑥ ◆ Assign Member ◆ ⑥ ◆ Select category ◆ ⑥ ◆ Select entry/member ◆ ⑥ ◆ (Empty) ◆ ⑥
Managing members	Start Here (*) → Select S! Quick News/S! Friend's Status widget → (*) → Use (*) to select member field → (*) → Operation → (*) → Contents Menu → (*) → See below
	Deleting Members Delete → ● → Yes → ●
	Changing Member Order Move → ● ⇒ ⊕ (Up) or ⊕ (Down) → ●

Changing Member Icons

Change Icon → ● Select Pictogram → ●

S! Quick News

Opening/Undating Items

Opening/opdating items	
Updating S! Quick News list automatically	● Entertainment ● S! Quick News ● Settings ● Automatic Update ● Select item ● ● Select interval or choose On ● ● If a confirmation appears, press ●. ● When Special is set to On, items are updated every four hours. ● When General is set to On, items are updated once a day. ■ To cancel automatic update, choose Off and press ●. ● Updating items may incur high charges. ● Only available in Japan.
Checking update schedule	 ♠ Entertainment ♦ ♠ ♦ S! Quick News ♦ ♠ Settings ♦ ♠ ♦ Check Schedule ♦ ♠
	Start Here
Deleting S! Quick News items	One Entry —# ● ● ¥ Yes ●
	All Entries 全件 ◆ ● → Enter Handset Code → ● → Yes → ●
Resetting S! Quick News List	Entertainment S! Quick News Settings Delete S! Quick News Lists Enter Handset Code Yes Not available during automatic updates.

Other

Changing background image	Entertainment
Accessing source sites	● Entertainment ● S! Quick News ● ● S! Quick News List ● Select item ● Select title ● Select title ● Select title ● Select title
Disabling image download	● Entertainment ● ● S! Quick News ● Settings ● ● Show Image ● ● ●

S! Information Channel

■ Receiving Information

Hiding Information window for new received info	● ★ Entertainment ★ ● ★ S! Information Channel/Weather ★ ● ★ Notification ★ ● ★ Off ★ ●
Requesting re-delivery	● Entertainment ● ● SI Information Channel/Weather ● ● Get Latest Contents ● ● Yes ●

■ Information Pages

On a page,
On a page,
On a page, Copy Text Select first character Highlight text range Output
On a page, Save Items Save Save Enter name Save here Some files are saved automatically.
On a page, ⊚ <i>→ Details →</i> •

■ Weather Indicators

Checking weather forecast	Entertainment	
Changing weather forecast page font size	On a page, ⓐ → Settings → ● → Font Size → ● → Select size → ●	
Hiding Weather Indicator in Standby	● Entertainment ● S! Information Channel/Weather ● Weather Indicator ● Settings ● Standby Setting ● ● Off ●	
Canceling Weather Indicator automatic updates	● Entertainment ● ● S! Information Channel/Weather ● ● Weather Indicator ● Settings ● ● Icon Update ● ● Off ● ●	
Hiding Information window for weather updates	● Entertainment ● ● S! Information Channel/Weather ● ● Weather Indicator ● ● Settings ● ● Weather Notif. ● ● Off ●	

e-Books	
Copying text	In open page, ② ◆ 文字列を北´- ◆ ⑥ ◆ Select first character ◆ ⑥ ◆ Highlight text range ◆ ⑥
Opening non-935SH e-Books (Library)	Description Descripti
	Start Here ● → Entertainment → ● → e-Book Viewer → □ → See below
	Adding Folders
	Switching Folders ② → Switch Folders → ● Select folder → ●
Using Library	Renaming Folders/Files Select folder/file → ② → Rename → ● → Enter name → ●
	Moving Files Select file ⇒ ② ⇒ Move ⇒ ● ⇒ Select folder ⇒ ● → Move here ⇒ ●
	Deleting Folders/Files Select folder/file ⇒ ② ⇒ Delete ⇒ ● Yes ⇒ ●
	Opening File Properties Select file

S! Friend's Status


■ Members & Groups

Adding members	(Long)
Deleting members	(Long) → Select Group → Select member → ② → Registration Release → → Yes → ● Cancellation notice is sent; deleted members cannot be re-registered for 24 hours.
Moving members	(Long) → Select Group → Select member → ③ → Change Group → ● → Select target Group → ●
Renaming Groups	(Long) → Select Group → (a) → Edit
nelialiling Groups	Group Name ⇒ ● Denter name ⇒ ●
nenaming Groups	Group Name
Rejecting requests	Start Here ★ (Long) → ② → Settings → ● →

■ Status & Availability

	-
Saving custom	X (Long) → □ → Settings → ● → Answer
Availability	Status → ● → User Setting → ● → Select
combinations	type → ● → Select Availability → ● → 💬
Changing Status Icon Pictogram or Status Label description	Status Settings Status Settings Status Settings Status Select Status Stat

■ Status Templates



■ Member Status & Notices

Updating manually	(Long) → ⊗ → Settings → ● → Status Update → ●
Opening notices	X (Long) → ② → Status Notif. List → ● → Select notice → ●

■ My Details

Sending My Details	(Long) → Select Group → Select member
image	⇒ Send Image Yes O



S! Circle Talk

■ Member List

	Start Here
Editing individual members	Replacing Members Edit → ● → ● → Select method → ● → Select entry → ●
	Deleting Members Delete → ● → Yes → ●
	Start Here
Editing Groups	Editing Group Name/Members Edit → ● → Select target → ● Edit/enter → ● → ⊙
	Deleting Group Members Edit → ● → Select member → ◎ → Delete → ● → Yes → ● → ⊙
	Deleting Groups Delete → ● Yes → ●

Settings

Disabling	● Communication > ● S! Circle Talk
Loudspeaker	● Description ● Des
Exiting S! Circle Talk for incoming calls	Communication S! Circle Talk Incoming Calls Voice Calls Video Calls Accept Calls

Blog Tool

•	Editing entries	● Communication ● Blog Tool ● Select entry ● Didt ● Select item ● Edit ● Select For Blog Title, omit step of pressing after editing.
	Deleting entries	● → Communication → ● → Blog Tool → ● → Select entry → ② → Delete → ● → Yes → ●



S! Friend's Status



Cannot use S! Friend's Status

• Set IP Service Setting to On.



Handset rejected a registration request automatically

· Rejection notice is sent automatically when 30 members are already registered or handset fails to respond within two hours.



Registration request arrived from a deleted member

• Registration request arrives when a member fails to receive cancellation. notice within 24 hours.



Registration request was sent to a member automatically

 Registration request is sent automatically when handset fails to receive rejection/cancellation notice within 24 hours.



Cannot create Status Templates

• Three templates may already be added; reset one and retry.

S! Circle Talk



Cannot use S! Circle Talk

• Set IP Service Setting to On.



S! Circle Talk starts automatically

· Check My Status; handset accepts S! Circle Talk requests automatically if S! Circle Talk Availability is set to Auto Join.



Cannot accept S! Circle Talk requests

· Check My Status; handset rejects S! Circle Talk requests automatically if S! Circle Talk Availability is set to Join NG.

Near Chat



Cannot receive Near Chat requests

• S! Appli Request may be set to Off.

S! Quick News



Cannot receive content updates

- Update may fail out-of-range or in poor signal conditions.
- Automatic Update does not affect S! Quick News List News Flash update items overnight.
- USIM Card replacement cancels Automatic Update.

