

<b>Handset Security</b> .....	11-2
Operations Security .....	11-2
Information Security.....	11-3

<b>Function Control</b> .....	11-4
Using Function Control.....	11-4
<b>Additional Functions</b> .....	11-5

# 11

## Handset Security




## Operations Security

### Function Lock

Restrict access to handset functions.

<b>Auto</b>	Lock when Display turns off or handset is closed
<b>Once</b>	Lock immediately; setting is canceled once handset is unlocked
<b>At Power On</b>	Lock when handset is turned on; Handset Code entry window opens

- 1 **Settings** **In Phone menu, Locks** **In**



Locks Menu

- 2 **Function Lock** **In**
- 3 **Select option** **Enter Handset Code** **Enter**

#### Unlocking Temporarily

While handset is locked, enter Handset Code **Enter**

#### When Function Lock is Active

- Press corresponding key to turn handset on/off, answer calls, place callers on hold, end calls, etc.

### PIN Entry

Activate PIN Entry to require PIN entry each time handset is turned on.

- 1 **In Locks menu, PIN Entry** **Switch On/Off** **In**
- 2 **On** **Enter PIN** **Enter**

### Secure Remote Lock

Lock a lost handset remotely via PC or another handset. Secure Remote Lock disables all operations except turning handset on, and activates IC Card Lock. For more about Secure Remote Lock, see SoftBank Mobile Website (P.15-23) or contact SoftBank Mobile Customer Center, General Information (P.15-41).



### Advanced

- Changing PIN** **Setting Secure Remote Lock activation message to appear (P.11-5)**

# Information Security

## Application Lock

Restrict access to these functions:

Phone Book


Calendar/Tasks

Yahoo! Keitai

Mail


Notepad

- 1 → **Settings** → → **In Phone menu, Locks** →



Locks Menu

- 2 **Application Lock** →



- 3 **Select item** → (✓)

For Phone Book, select **No Refer** or **Refer** and press .

- 4 → **Enter Handset Code**  
→


### Temporary Access to Functions

- When accessing functions, enter Handset Code and press .

## History Lock

Restrict access to Call Log and sent/received mail records.

- 1 **In Locks menu, History Lock** →



- 2 **Select item** → (✓)

- 3 → **Enter Handset Code**  
→

### Temporary Access to Records

- When accessing records, enter Handset Code and press .

## Show Secret Data

Activate Show Secret Data to access Secret entries.

- 1 **In Locks menu, Show Secret Data** →

- 2 **On** → → **Enter Handset Code** →

### When Show Secret Data is Active

- Predictive is not available for text entry.

## Activating Temporarily with Motion Control

- 1 **Enter Handset Code** → **Shake handset left or right** →

- Show Secret Data is canceled when handset is closed or Display goes dark in Standby.



## Using Function Control

Restrict access to the following functions remotely. (Available for administrators.)

Camera	Infrared
Bluetooth	Memory Card
USB	Digital TV
Messaging	S! Mail
PC Mail	Attach File
Voice Call (placing)	Video Call (placing)
USIM (writing)	Flash®
Yahoo! Keitai	PC Site Browser
Streaming	IP Service
S! Appli	Osaifu-Keitai
Mobile Widget	

- A message appears while Function Control is in progress.
- May be unavailable depending on subscription. For details, contact the nearest SoftBank Shop or SoftBank Mobile Customer Center, General Information (P.15-41).

### ■ When Accessing Restricted Functions

A message (example shown below) appears; the function is inaccessible.




Message may not appear for some functions.

### Checking Restriction Status

1 ➔ **Settings** ➔ ➔ **In Phone menu, Locks** ➔

2 **Function Control** ➔



- Restriction status appears for each function.



## PIN Entry

## Changing PIN

- → *Settings* → ● → In Phone menu, *Locks*
- ● → *PIN Entry* → ● → *Change PIN* → ●
- Enter current PIN → ● → Enter new PIN →
- → Re-enter new PIN → ●
- Activate PIN Entry first.

## Secure Remote Lock

## Setting Secure Remote Lock activation message to appear

- Start Here ● → *Settings* → ● → In Phone menu, *Locks* → ● → *Set Lock Message* → ● → See below
- Saving Message**
- Message* → ● → Enter Handset Code → ● →
- Enter message → ● → Yes → ●
- Checking Message**
- Check Message* → ●

