

News/Entertainment

S! Information Channel/Weather (Japanese)	8-2
Registering/Canceling.....	8-2
Using S! Information Channel.....	8-2
Using Weather Indicator.....	8-3
Option Menu Items.....	8-4
S! Quick News (Japanese)	8-4
Registering S! Quick News Items	8-4
Opening New Information	8-5
E-Books (Japanese)	8-6
Blogging	8-7
Saving Blog Details.....	8-7
Posting to Blogs	8-7
Blogging Functions.....	8-8

S! Information Channel/Weather (Japanese)

Subscribe to content and periodically receive updates. Set Weather Indicator to appear on Standby.

- Transmission fees apply for updates.
- Auto download is not available overseas.

Registering/Canceling

Main Menu ► News/Entertainment ► S! Info Ch./Weather

1 Register/Cancel → YES

Handset connects to the Network.
Follow onscreen instructions.

Using S! Information Channel

- Up to seven updates are saved.

Viewing New Information

When information arrives,  and Event Indicator appear in Standby.

1 In Standby,  →  to move pointer → Select Event Indicator

2  [Select]

Follow onscreen instructions.

- Option Menu Items (☞P.8-4)



Manually Retrieve Information

Select Event Indicator "Failed to download"

- Alternatively, Main Menu ► News/Entertainment ► S! Info Ch./Weather ► Get Latest Contents ► YES

Delete Information

- > Main Menu ► News/Entertainment ► S! Info Ch./Weather ► Highlight What's New? ►  [Menu] ► Delete ► YES

Note

- Alternatively, Main Menu ► News/Entertainment ► S! Info Ch./Weather ► What's New? to retrieve information
- If there is unread information in both S! Quick News and S! Information Channel,  does not appear. Only Event Indicator appears.


Viewing Previously Received Information

Main Menu ► News/Entertainment ► S! Info Ch./Weather

1 History → Select a date

 for unread news and  for read news appear.

Delete History

- > Main Menu ► News/Entertainment ► S! Info Ch./Weather ► History ► (Highlight a History) ►  [Menu] ► Delete or Delete all ► YES
(► For Delete all, enter Phone Password)

Using Weather Indicator

Weather Indicator for current forecast area appears in Standby.

Viewing New Information

Event Indicator and Weather Indicator appear for weather updates.

1 In Standby,  →  to move pointer → Select Event Indicator or Weather Indicator

2  [Select]

Information appears.

Follow onscreen instructions.

- Option Menu Items (➔P.8-4)



Weather Indicator

Indicators are updated periodically.

Example:  Clear,  Rain later thunderstorm,

 Cloudy with occasional snow, etc.

- See Weather Indicator List (➔P.19-24) for a complete list of indicators.

Manually Update Weather Indicator

Select Event Indicator "*Failed to download*"

- Alternatively, **Main Menu** ▶ News/Entertainment
▶ S! Info Ch./Weather ▶ Weather Indicator ▶ Manual Update
▶ YES

Hide Event Indicator

- > **Main Menu** ▶ News/Entertainment ▶ S! Info Ch./Weather
▶ Weather Indicator ▶ Missed Event Settings ▶ OFF

Note

- Alternatively, view forecast details from **Main Menu**
▶ News/Entertainment ▶ S! Info Ch./Weather
▶ Weather Indicator ▶ Weather

Hiding Weather Indicator


Main Menu ▶ News/Entertainment ▶ S! Info Ch./Weather
▶ Weather Indicator ▶ Display Settings

1 OFF

- When Display Settings is set to **OFF**, update is also deactivated.

Option Menu Items

Open information and press  [Menu] for these options.

Item	Operation/Description
Forward	Go to next page
Text Copy	Copy page text
Select File	View, play or save file to Data Folder (From Step 2 in Downloading Image/Sound Files:  P.15-11)
Jump in this page	Jump to top/end of page
Yahoo! Keitai	View top menu
Font Size*	Change character size
Exit viewing this	Exit content

* Linked with Font Size setting in Internet option menu.

S! Quick News (Japanese)

Add news headlines, weather forecasts, etc. via S! Quick News List to scroll across Standby Window.

- Registering or viewing S! Quick News incurs transmission fees. No fees apply for viewing ticker information. For more information, visit SOFTBANK MOBILE Corp. Website (<http://www.softbank.jp>).
- Auto download is not available overseas.

Registering S! Quick News Items

- Register one *Quick* news, up to four *General* news and one *Special* news.




Main Menu ► **News/Entertainment** ► **S! Quick News**
 ► **S! Quick News List**

- 1 Add News → YES**
Yahoo! Keitai connects and contents list appears.
- 2 Select an item**
Follow onscreen instructions.

Opening New Information

Viewing New Information in Standby

When new information is received,  appears in Standby.

- 1 In Standby,  →  to move pointer → Select ticker
- 2  [Select]
Content list appears.
- 3 Select information
Details appear.

Tip

Settings

- Show Only Unread Items in Standby
- Change Marquee Speed
- Hide S! Quick News
- Image Download (☞P.18-18)

Opening S! Quick News List


Main Menu ► News/Entertainment ► S! Quick News
► S! Quick News List

- 1 Select an item
Content list appears.
- 2 Select information
Detailed information appears.
- 3 To connect to the Network, select a title → **YES**


Update Manually

> In Step 1,  [Menu] → **Update** or **All Update** → **YES**

View Summary

> In Step 1, highlight information →  [Menu] → **Summary Display**

Delete Registered Items

> In Step 1, (highlight information →)  [Menu] → **Delete** or **All Delete** → **YES** (→ For **All Delete**, enter Phone Password)

Note

- Alternatively, **Main Menu ► News/Entertainment ► S! Quick News ► Settings ► Del S! Quick News List ► YES** to delete all information

Tip

Settings

- Automatically Update S! Quick News List
- Delete S! Quick News Information (☞P.18-19)

E-Books (Japanese)

Use **BookSurfing®** to acquire/view e-books, comics, photo books, etc. or **e-Book Viewer** to view XMDf files on handset.

- BookSurfing® and e-Book Viewer are S! Appli.
- Download Content Keys (☞P.10-5) to read CCF/XMDf files.
- Some copy protected files have extensions different from the ones below.

Application	File Format
BookSurfing®	CCF (.ccf)
e-Book Viewer	XMDf (.zbf, .zbf, .zbf)

- Some PC content may not be viewable via e-Book Viewer.

Main Menu ▶ News/Entertainment

1 *BookSurfing* or *e-Book Viewer*

- See application Help menu for usage information.

Note

- Launch BookSurfing®/e-Book Viewer via S! Appli, or select a file from Books in Data Folder.
- When purchasing a new handset, move CCF/XMDf files via microSD Card. However, if CCF/XMDf files are copy protected, Content Keys backup may be needed (☞P.10-22). Some contents require another Content Key after being moved/copied to a new handset or can not be moved/copied at all.

Blogging

Save blog details to update or view blogs.

- Save up to 20 blog details.

Saving Blog Details

Main Menu ► News/Entertainment ► Post Blog

- 1  [New] → Select an item (See below)

Item	Operation/Description
Service name	Save a blog service name > Enter a service name
Blogger address	Save a mail address for posting to a blog by mail > Enter a mail address
Mail title	Save a title to enter automatically when posting to a blog by mail > Enter a title
Yahoo! Keitai URL	Save a URL for posting to a blog from Yahoo! Keitai > Enter a mail address
PC Site Browser	Save a URL for posting to a blog from PC Site Browser > Enter a mail address

- 2  [Finish]


Posting to Blogs

Main Menu ► News/Entertainment ► Post Blog

1 Post by Mail

Highlight an entry →  [Post] → Compose a message ( From Step 4 on P.14-4) →  [Send]


Post from Yahoo! Keitai/PC Site Browser


Highlight an entry →  [To site] →

By Yahoo! Keitai or **By PC Site Browser**
→ **YES**

Handset connects to the Network and website appears.
Follow onscreen instructions.

■ Post Images to Blogs

> While captured image is open, or from Data Folder, select an image
→  [Menu] → **Post blog*** → Follow Step 1 above


* When **Post blog** does not appear in sub menu, function is unavailable (e.g. when sub menu is opened from  [Folder] in Picture Viewfinder).

- Set **Auto save set** ( P.18-16) in Camera menu to **OFF** to capture and post images directly.


Blogging Functions


From ► **Main Menu** ► News/Entertainment ► Post Blog

■ Edit Entries

> Highlight an entry → [Edit] → Edit

■ Delete Entries

> Highlight an entry → [Menu] → *Delete* →
Select an item (See below)

Item	Operation/Description
Delete this	> <i>YES</i>
Delete selected	> Check entries →  [Finish] → <i>YES</i>
Delete all	> Enter Phone Password → <i>YES</i>