

Handset Security	13-2
Operations Security	13-2
Information Security.....	13-3

Function Control	13-4
Using Function Control.....	13-4
Additional Functions	13-5

13

Handset Security




Operations Security

Function Lock

Restrict access to handset functions.

Auto (Link to Slider)	Lock when Slider is closed
Auto	Lock when Display turns off
Once	One time lock
At Power On	Lock when handset is powered on

- 1 MENU** → **Settings** → **Phone/**  **tab** → **Locks**



Locks Menu

- 2 Function Lock**
- 3 Select option** → **Enter Handset Code** → **OK**

Unlocking Temporarily

While handset is locked, enter Handset Code → **OK**

Available Operations while Function Lock is Active

- Power handset on/off, answer calls, place callers on hold, end calls, etc.

PIN Entry

Activate PIN Entry to require PIN entry each time handset is powered on.

- 1 In Locks menu, PIN Entry** → **Switch On/Off**
- 2 On** → **Enter PIN** → **OK**

Secure Remote Lock

Lock a lost handset remotely via PC or another handset. Secure Remote Lock disables all operations except powering handset on, and activates IC Card Lock. For more about Secure Remote Lock, see SoftBank Mobile Website (P.17-23) or contact SoftBank Mobile Customer Center, General Information (P.17-42).

Advanced

-  ● Changing PIN
- Setting Secure Remote Lock activation message (P.13-5)

Information Security

Application Lock

Restrict access to these functions:

Phone Book


Mail

Calendar/Tasks

Notepad


Yahoo! Keitai

- MENU** ➔ **Settings** ➔ **Phone/**  **tab** ➔ **Locks**



Locks Menu

- Application Lock**



- Select item** (✓)

For Phone Book, tap **No Refer** (to hide entry names in message lists, Call Log, etc.) or **Refer**.

- OK** ➔ **Enter Handset Code** ➔ **OK**


Temporary Access to Functions

- When accessing functions, enter Handset Code and tap **OK**.

History Lock

Restrict access to Call Log and sent/received mail records.

- In Locks menu, *History Lock***



- Select item** (✓)

- OK** ➔ **Enter Handset Code** ➔ **OK**

Temporary Access to Records

- When accessing records, enter Handset Code and tap **OK**.

Show Secret Data

Activate Show Secret Data to access Secret entries.

- In Locks menu, *Show Secret Data***

- On** ➔ **Enter Handset Code** ➔ **OK**

Activating Temporarily with Motion Control

- Enter Handset Code** ➔ **Shake handset left or right** ➔ **OK**

- Use Keypad to enter Handset Code.
- Show Secret Data is canceled when Slider is closed or Display goes dark in Standby.



Using Function Control

Restrict access to the following functions remotely. (Available for administrators.)

Camera	Attach File
Infrared	Wi-Fi
Bluetooth	Yahoo! Keitai
Memory Card	PC Site Browser
USB	IP Service
Digital TV	S! Appli
Messaging	Osaifu-Keitai
Voice Call (placing)	PC Mail
Video Call (placing)	Streaming
USIM (writing)	Flash®
S! Mail	Mobile Widget

- A message appears while Function Control is in progress.
- May be unavailable depending on subscription. For details, contact the nearest SoftBank Shop or SoftBank Mobile Customer Center, General Information (P.17-42).

■ When Accessing Restricted Functions

A message (example shown below) appears; the function is inaccessible.




Message may not appear for some functions.

Checking Restriction Status

1 MENU ➔ Settings ➔ Phone/☎ tab ➔ Locks

2 Function Control



- Restriction status appears for each function.



PIN Entry

Changing PIN

MENU → *Settings* → *Phone/* *tab* → *Locks*
 → *PIN Entry* → *Change PIN* → Enter current
 PIN → *OK* → Enter new PIN → *OK* → Re-enter
 new PIN → *OK*

- Activate PIN Entry first.

Secure Remote Lock

Setting Secure
Remote Lock
activation message

(Start Here) *MENU* → *Settings* → *Phone/* *tab* →
Locks → *Set Lock Message* → See below

Saving Message

Message → Enter Handset Code → *OK* →
 Enter message → *Done* → *Yes*

Checking Message

Check Message

Suppressing Message

Display Setting → *Don't Show* → Enter
 Handset Code → *OK*

