9

Handy Extras

Calendar

Opening Calendar

1. ● ➡ *Tools* ➡ ● ➡ In PIM/
Lifestyle menu, *Calendar* ➡ ●

XX/XX/XX(Mo)

Options | View | Switch

Calendar Window

Toggling View

Press ⊙ to toggle Calendar window.

XX/XX/XX(Mo)

2 3 4 5 6 7 8
9 10 11 12 13 14 15
16 17 18 19 20 21 22
23 24 25 26 27 28 29
30 31 🗓:Stamp

Month View

XX/XX/XX(Mo)

1
2 3 4 5 6 7 8
9 10 11 12 13 14 15
16 17 18 19 20 21 22
23 24 25 26 27 28 29
30 31 🗓:Stamp

3Month View

20XX/XX

6Month View

XX/XX/XX(Mo)

9 10 11 12 13 14 15
S M T W T F S
08
10
12
14
16
18
20

Week View

Key Assignments

■ All Views

Open Previous Page	＊
Open Next Page	＃
Open Help	0

■ Month/3Month View

| Select Date | ⊙ |
| Go to Current Date | 5 |

■ 6Month View

| Go to Current Month | 5 |
| Select Month | ⊙ |

■ Week View

| Select Date | ⊙ |
| Select Time Block | ⊙ |

9

Handy Extras

Advanced

☜ ●Changing default view ●Jumping to specified date ●Changing date color ●Selecting task view option ●Adding stamps (Month/3Month View)
●Hiding schedules ●Saving additional holidays ●Removing/restoring holidays (**P.9-34**)

Saving Schedules

Follow these steps to save subject, start/
end date/time, Alarm and schedule details:
(Enter Subject or Description to save entry.)

1. **In Calendar window, select date ➡ ●**

2. **<Add New Entry> ➡ ●**

3. **Enter subject ➡ ●**

4. **Enter start date/time ➡ ●**

5. **End: ➡ ● ➡ Enter end date/time ➡ ●**

6. **Alarm: ➡ ●**

7. **Alarm Time: ➡ ● ➡ Select time ➡ ● ➡ ⊗**

8. **Description: ➡ ● ➡ Enter schedule details ➡ ●**

9. **⊗ ➡ Saved**

All-Day Schedule
In ④, ✉ ➡ ● ➡ From ❽
Custom Alarm Time
In ⑦, Alarm Time: ➡ ● ➡ Other ➡
● ➡ Enter date/time ➡ ● ➡ ⊗ ➡
From ❽

At Alarm Time

Alarm activates; sounds/vibrates by
related settings.

Stopping Alarm to Return to Standby
● While Alarm sounds/vibrates, press ●,
⬛ or ⬛.
Stopping Alarm to Open Schedule
● While Alarm sounds/vibrates, press a key
other than ●, ⬛ or ⬛.
When Another Function is Active
● Alarm may not activate until handset
returns to Standby.
Incoming Calls
● Active Alarm stops for incoming calls.
Information window opens after handset
returns to Standby.

9

Handy Extras

Advanced

✍ ●Setting Category/Location ●Creating Categories ●Saving repetitive schedules ●Editing entries ●Changing Alarm tone/video & duration ●Changing
Alarm volume ●Selecting Vibration option (And more on **P.9-35** - **9-36**)

Opening Schedules/Tasks

1 **In Calendar window, select date ▸ ●**

XX/XX/XX (Mo)
⇨ <Add New Entry>

🔔 ●Conference
16:00-17:00
🔔 ●Meet-up
19:00-19:15

Schedule List

2 **Select schedule or task ▸ ●**

3 **🔄 ▸ Standby returns**

Opening Task List
In 2, select task ▸ ⊠ ▸ *Go to Tasks* ▸ ●

Accessing Secret Entries
[Calendar Window] ⊠ ▸ *Unlock Temporarily* ▸ ● ▸ Enter Handset Code ▸ ●

Opening Related Message

Open schedule-related messages saved from Messaging message list.

1 **In schedule list, select schedule ▸ ●**

2 **⊠ ▸ *Related Mail* ▸ ●**
● Related message opens.
● To return to schedule window, press 🔲.

Deleting Message from Schedule
After 1, ● ▸ *Related Mail:* ▸ ● ▸ *Yes* ▸ ● ▸ ⓨ

Deleting Schedules

■ **One Entry**

1 **In schedule list, select schedule ▸ ⊠**

2 ***Delete* ▸ ● ▸ *This Appointment* ▸ ● ▸ *Yes* ▸ ●**

■ **All Entries of the Day**

1 **In Calendar window, select date ▸ ⊠**

2 ***Delete* ▸ ● ▸ *All This Day* ▸ ● ▸ *Yes* ▸ ●**

Advanced

🔟

Ⓑ ●Searching entries ●Checking memory status ●Deleting all entries ●Deleting entries by specifying week (Week View) ●Deleting entries by specifying month (Month/3Month View) ●Deleting entries in six months (6Month View) (**P.9-36**)

Tasks

Saving Tasks

Follow these steps to save subject, due date/time, Alarm and task details:
(Enter Subject or Description to save entry.)

1. ● ➜ *Tools* ➜ ● ➜ In PIM/ Lifestyle menu, *Tasks* ➜ ●

   > Tasks
   > All Incomplete Completed
   > ➜ <Add New Entry>

2. *<Add New Entry>* ➜ ●

3. Enter subject ➜ ●

   > Due Date & Time
   > 20XX XX XX
   > 20XX / XX / XX
   > 20XX XX XX
   >
   > 14 04
   > 15 : 05
   > 16 06
   >
   > ■No limit
   > Check | Accept

4. Enter due date/time ➜ ●

   > New Entry
   > Subject:
   > Birthday
   > Due Date:
   > XX/XX/XX 16:00
   > Alarm:
   > No Alarm
   > Priority:
   > Normal
   > Description:
   >
   > Secret:
   > Off

5. *Alarm:* ➜ ●

   > Alarm
   > Alarm Time:
   > No Alarm
   > Assign Tone/Video:
   > Alert 1
   > Duration:
   > 10 sec.

6. *Alarm Time:* ➜ ● ➜ Select time ➜ ● ➜ ⊙

7. *Description:* ➜ ● ➜ Enter task details ➜ ●

8. ⊙ ➜ Saved

Task with No Due Date/Time
In ❹, ✉ ➜ ● ➜ From ❼

Custom Alarm Time
In ❻, *Alarm Time:* ➜ ● ➜ *Other* ➜ ● ➜ Enter date/time ➜ ● ➜ ⊙ ➜ From ❼

Advanced

✎ ●Hiding tasks ●Editing tasks ●Setting priority ●Changing Alarm tone/video & duration ●Changing Alarm volume ●Selecting Vibration option ●Sounding Alarm tone even in Manner mode (**P.9-36** - **9-37**)

9
Handy Extras

At Alarm Time

Alarm activates; sounds/vibrates by related settings.

Tasks Alarm

Birthday
20XX/XX/XX 15:55

Stopping Alarm to Return to Standby
- While Alarm sounds/vibrates, press ●, ☎ or 🗺️.

Stopping Alarm to Open Task
- While Alarm sounds/vibrates, press a key other than ●, ☎ or 🗺️.

When Another Function is Active
- Alarm may not activate until handset returns to Standby.

Incoming Calls
- Active Alarm stops for incoming calls. Information window opens after handset returns to Standby.

### Opening Tasks

❶ ● ➡ *Tools* ➡ ● ➡ In PIM/ Lifestyle menu, *Tasks* ➡ ●

Tasks
All Incomplete Completed
⇒ <Add New Entry>
● ▉Birthday
XX/XX/XX 16:00

Task List

- Use ⊙ to open completed or uncompleted task list.

❷ Select task ➡ ●

Task
☐Birthday
📅20XX/XX/XX
16:00
🔔20XX/XX/XX
16:00
◉Normal

❸ ☎ ➡ Standby returns

Accessing Secret Entries
After ❶, ✉ ➡ *Unlock Temporarily* ➡
● ➡ Enter Handset Code ➡ ●
Marking Tasks as Completed
After ❶, select task ➡ 🔅

Deleting Tasks

■ **One Entry**

❶ In task list, select task ➡ ✉

❷ *Delete* ➡ ●

❸ *This Task* ➡ ● ➡ *Yes* ➡ ●

■ **All Completed Tasks**

❶ In task list, ✉

❷ *Delete* ➡ ●

❸ *All Comp. Tasks* ➡ ● ➡ *Yes* ➡ ●

9

Handy Extras

Advanced

🔌 ●Searching tasks ●Sorting tasks by priority ●Checking memory status ●Deleting all tasks (**P.9-37**)

Using Alarms

Setting Alarm

Follow these steps to set Alarm to sound at a specific time on a specific day of the week: (Set Snooze--Alarm repeats at set interval--Alarm Volume and Duration.)

1. ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Alarms* ➡ ●

   Alarm List

2. *--:--* ➡ ● ➡ Enter hour (24-hour format) ➡ Enter minutes ➡ ●

3. *Repeat:* ➡ ●

4. *Selected Days* ➡ ●

5. Select day ➡ ● (□/☑) ➡ Complete selection ➡ ✆

6. *Snooze:* ➡ ●

7. Select interval ➡ ●
   ● For custom intervals, select *Other*.

8. *Alarm Volume:* ➡ ●

9. Adjust level ➡ ●

10. *Duration:* ➡ ●

11. Select time ➡ ●
    ● For custom Duration, select *Other*.

12. ✆ ➡ Saved
    ● For more settings, repeat 2 - 12.

13. ☎ ➡ Alarm setting ends

Activating Alarm Once or Daily
In 4, *Once* or *Every Day (All)* ➡ ● ➡ From 6
Selecting/Canceling All Days
In 5, ✉ ➡ *Check All* or *Uncheck All* ➡ ●
Excluding Holidays
In 5, select day ➡ ● (□/☑) ➡ Complete selection ➡ *Except Holidays* ➡ ● ➡ ✆ ➡ From 6

Advanced

✎ ●Editing entries ●Saving entry name ●Changing Alarm tone/video ●Setting handset to vibrate at Alarm Time ●Sounding Alarm tone even in Manner mode ●Activating Alarm based on World Clock time (**P.9-38**)

9

Handy Extras

1

9-7

At Alarm Time

Alarm activates; sounds/vibrates by related settings.

Stopping Alarm
● Press a key.
When Another Function is Active
● Alarm may not activate until handset returns to Standby.
Incoming Calls
● Active Alarm stops for incoming calls. Information window opens after handset returns to Standby.

When Snooze is Set

Alarm repeats at the set interval.
Other Alarms do not activate while handset is Snoozing.

Canceling Snooze
While Snoozing, ● ➡ *Yes* ➡ ●
● Snooze is automatically canceled after a period of time.

Canceling Alarm

1 In Alarm list, select entry ➡ ⊠

2 *Switch Off* ➡ ●
● Reactivate entry to use the same settings.

Reactivating Entry
In **2**, *Switch On* ➡ ●

Deleting Alarm

■ **One Entry**

1 In Alarm list, select entry ➡ ⊠

2 *Reset Alarm* ➡ ●

3 *Yes* ➡ ●

■ **All Entries**

1 In Alarm list, select entry ➡ ⊠

2 *Clear All* ➡ ●

3 Enter Handset Code ➡ ●
➡ *Yes* ➡ ●

Using Wakeup TV

Setting Wakeup TV

Follow these steps to activate TV at a specific time on a specific day of the week:
● Complete TV Area Setup beforehand.
● TV may not activate in poor signal conditions.

1 ● ➡ *Tools* ➡ ● ➡ **In PIM/Lifestyle menu,** *Wakeup TV* ➡ ●

> Wakeup TV
> --:--
> --:--
> --:--
>
> Wakeup TV List

2 *--:--* ➡ ● ➡ **Enter hour (24-hour format)** ➡ **Enter minutes** ➡ ●

> Set Alarm
> Time:
> 08:00
> Repeat:
> Once
>
> Wakeup TV Menu

3 *Repeat:* ➡ ●

4 *Selected Days* ➡ ●

> Selected Days
> ■ Sunday
> ■ Monday
> ■ Tuesday
> ■ Wednesday
> ■ Thursday
> ■ Friday
> ■ Saturday
> ■ Except Holidays

5 **Select day** ➡ ● (□/☑) ➡ **Complete selection** ➡ ⊠

6 *Channel:* ➡ ●

7 **Select channel** ➡ ●

8 ⊠ ➡ **Saved**
● For more settings, repeat 2 - 8.

9 🔚 ➡ **Wakeup TV setting ends**

Activating TV Once or Daily
In 4, *Once* or *Every Day (All)* ➡ ●
➡ **From** 8

Selecting/Canceling All Days
In 5, 🖹 ➡ *Check All* or *Uncheck All*
➡ ●

Excluding Holidays
In 5, **select day** ➡ ● (□/☑) ➡
Complete selection ➡ *Except Holidays* ➡ ● ➡ ⊠ ➡ **From** 8

Canceling Alarm
● Alarm activates at Wakeup TV time. To cancel Alarm, follow these steps:
[Wakeup TV Menu] *Alarm On/Off:* ➡
● ➡ *Off* ➡ ● ➡ **From** 8

Adjusting Alarm Volume
[Wakeup TV Menu] *Alarm Volume:* ➡
● ➡ **Adjust level** ➡ ● ➡ **From** 8

Advanced

◌ ●Editing entries ●Changing Alarm tone/video ●Sounding Alarm tone even in Manner mode (**P.9-38**)

At Wakeup TV Time

TV activates after Alarm.


```
Tll●                    ⬛
        Wakeup TV


            🕐    ●



            08:00
```

Stopping Alarm Instantly
● While Alarm sounds/vibrates, press a key.
When Another Function is Active
● TV may not activate depending on the function.
After TV is On for a Period of Time
● Confirmation appears. Choose *Yes* and press ● to exit TV.

Canceling Wakeup TV

1 **In Wakeup TV list, select entry ▶ ⊠**

2 *Wakeup TV Off* ▶ ●
● Reactivate entry to use the same settings.

Reactivating Entry
In ❷, *Wakeup TV On* ▶ ●

Deleting Wakeup TV

■ **One Entry**

1 **In Wakeup TV list, select entry ▶ ⊠**

2 *Reset Alarm* ▶ ●

3 *Yes* ▶ ●

■ **All Entries**

1 **In Wakeup TV list, select entry ▶ ⊠**

2 *Clear All* ▶ ●

3 **Enter Handset Code ▶ ● ▶ *Yes* ▶ ●**

Playing Animation with Music & Illumination

Play preset animations or downloaded Flash® files with music and illumination. Set playback time, volume and illumination pattern as needed.

1. ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Relaxation Time* ➡ ●

2. Select type ➡ ●
   - Animation appears.
   - For *Flash®*, select a file and press ●.
     - Key LEDs do not illuminate for soundless Flash® files.

Setting Relaxation Time

Follow these steps to set playback time, volume and Key Illumination pattern:

1. ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Relaxation Time* ➡ ●

2. *Settings* ➡ ●

3. *Playback Time* ➡ ●

4. Select time ➡ ●
   - For custom playback time, select *Other*.

5. *Volume* ➡ ●

6. Adjust level ➡ ●

7. *Set Key Illumi* ➡ ●

8. *Key Pattern* ➡ ●

9. Select pattern ➡ ● ➡ ⓨ

10. ☎ ➡ Standby returns

Disabling Key Illumination
In ❸, *Set Key Illumi* ➡ ● ➡ *Switch On/Off* ➡ ● ➡ *Off* ➡ ● ➡ ⓨ

Using Calculator

1. ⬤ ➡ *Tools* ➡ ⬤ ➡ **In PIM/Lifestyle menu,** *Calculator* ➡ ⬤

Calculator Window

2. **Use Keypad to enter digits ➡ Calculate**

3. ☎ ➡ **Calculator ends**

Key Assignments	
+ (Add)	⊙
− (Subtract)	⊙
× (Multiply)	⬤
÷ (Divide)	⬤
= (Sum)	⬤
C·CE (Clear)	🔲
CM (Clear Memory)	🔲
RM (Recall Memory)	🔲
M+ (Add to Memory)	🔲
. (Decimal)	🔲
+/- (Positive/Negative Value)	🔲
% (Percentage)	🔲

Memory Calculation
- Clear Memory before starting new Memory calculations.
- Numbers saved in Memory remain until handset power is turned off.

Incoming Calls
- Calculations are not affected. End the call to return to Calculator.

Using % Function
Use 🔲 to find definite percentage of a known value.
Example: Calculate 30% of 800,000
  Enter *800,000* ➡ *x* ➡ *30* ➡ *%*
  ■ *240,000* appears.

Advanced

🔗 ●Copying calculation results ●Changing exchange rate for currency conversion ●Converting currencies (**P.9-38**)

Adding Expenses

Entering Expenses

1 Enter amount ➡ ⓠ

```
Enter Cost:

[*]:DecimalPoint

                    5040
           Accept │ Cancel
```

2 ●

```
         Category
◉ No Category
● Miscellaneous
```

3 Select Category ➡ ● ➡ Saved

Saving under Custom Category
In **3**, *Other* ➡ ● ➡ Enter name ➡ ●

Checking Entries

1 ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Expenses Memo* ➡ ●

```
      Expenses Memo
Add New Expense
Totals
Edit Category
```

2 *Totals* ➡ ●

```
         Totals
1)XX/XX/XX 15:05
Miscellaneo_         5040
```
Expenses Memo List

3 ☎ ➡ Standby returns

Saving Entries to Notepad
[Expenses Memo List] ✉ ➡ *Save to Notepad* ➡ ●
■ All expense details are saved as a single entry.

Deleting Entries

■ **One Entry**

1 In Expenses Memo list, select entry ➡ ✉

2 *Delete Item* ➡ ●

3 *Yes* ➡ ●

■ **All Entries**

1 In Expenses Memo list, ✉

2 *Delete All* ➡ ●

3 Enter Handset Code ➡ ● ➡ *Yes* ➡ ●

9
Handy Extras

Advanced

🖐 ●Changing Category of saved entry ●Changing amount ●Renaming Categories (**P.9-39**)

Osaifu-Keitai® (Japanese)

Osaifu-Keitai® describes IC Card-equipped handsets that support e-money or credit functions/services. Osaifu-Keitai® encompasses a range of IC Card-based services on FeliCa-compatible SoftBank handsets. 935SH supports Osaifu-Keitai®. To use e-money, e-ticketing and reward points, etc., hold handset over a compatible reader/writer at shops, restaurants, and other retail outlets, etc.

Basics

Before using Osaifu-Keitai®, activate Lifestyle-Appli, complete registration, customize settings and charge accounts.

Starting Lifestyle-Appli
● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Osaifu-Keitai* ➡ ● ➡ *Lifestyle-Appli* ➡ ● ➡ Select application ➡ ●

Lifestyle-Appli Precautions
● Contact Osaifu-Keitai® service providers for Lifestyle-Appli registration and usage details.
● Keep service passwords/customer service contact information, etc. in a separate place.

Using Osaifu-Keitai®

Follow these steps to conduct a transaction:
Example: Making an electronic payment
● Lifestyle-Appli activation is not necessary.
● Transactions are possible even when handset power is off (if battery is adequately charged).
● Calls/Internet transmissions do not affect transactions.

1. **Place ⌇ logo over reader/ writer ➡ Confirm scan results**

Place this part over reader/writer

● Align handset parallel to reader/writer.

Important Osaifu-Keitai® Usage Note
● SoftBank Mobile is not liable for damages resulting from accidental loss/alteration of IC Card data/settings.

When Placed Over Sensor
● If recognition is slow, move handset around slightly.
● Handset may respond automatically for some services.

9

Handy Extras

Advanced

○Enabling to view e-money balances ○Moving applications up/down Balance Info list ○Removing applications from Balance Info list (**P.9-39**)

Locking IC Card

IC Card Lock

Restrict access to/prevent unauthorized use of Osaifu-Keitai® on handset.

1. ● ➡ *Tools* ➡ ● ➡ In PIM/
   Lifestyle menu, *Osaifu-Keitai*
   ➡ ●

   > Osaifu-Keitai
   > Lifestyle-Appli
   > IC Card Settings

2. *IC Card Settings* ➡ ●

   > IC Card Settings
   > IC Card Status
   > IC Card Lock
   > Off
   > Remote Lock
   > Interface Settings
   > Balance Info
   > Off

   IC Card Settings Menu

3. *IC Card Lock* ➡ ● ➡ *On*
   ➡ ●

4. Enter Handset Code ➡ ●
   ➡ *Yes* ➡ ●

   Canceling IC Card Lock
   In 3, *IC Card Lock* ➡ ● ➡ *Off* ➡ ●
   ➡ Enter Handset Code ➡ ●

9

Handy Extras

Advanced

✎ ●Customizing handset response to reader/writer commands ●Opening IC Card properties ●Changing IC Card Lock notice recipient ●Changing required Missed Call count for Call Remote Lock ●Restoring default Osaifu-Keitai® settings (**P.9-39**)

Remote Lock

Disable Osaifu-Keitai® remotely by mail or phone.

Mail Remote Lock	Send mail to activate Remote Lock
Call Remote Lock	Call from a specified phone to activate Remote Lock

Mail Remote Lock

■ **Preparation on Handset**

1. ● ➡ *Tools* ➡ ● ➡ In PIM/ Lifestyle menu, *Osaifu-Keitai* ➡ ●

2. *IC Card Settings* ➡ ●

3. *Remote Lock* ➡ ● ➡ Enter Handset Code ➡ ●

```
Remote Lock
Mail Remote Lock
Off
Call Remote Lock
Off
```

4. *Mail Remote Lock* ➡ ●

```
Mail Remote Lock
Switch On/Off
Off
Remote Lock PW

Notice Settings
As Reply
```
Mail Remote Lock Menu

5. *Remote Lock PW* ➡ ●

6. Enter password ➡ ●

7. *Switch On/Off* ➡ ●

8. *On* ➡ ● ➡ ⊗

Canceling Mail Remote Lock
In 5, *Switch On/Off* ➡ ● ➡ *Off* ➡ ● ➡ ⊗

■ **Activating Remote Lock via Mail**
If handset cannot receive mail IC Card Lock is not set.

1. **Send S! Mail or e-mail to handset with password as subject**
   ● After handset receives message, IC Card Lock is set and notice is sent as a reply.

9

Handy Extras

9-16

Call Remote Lock

■ **Preparation on Handset**

1. ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Osaifu-Keitai* ➡ ●

2. *IC Card Settings* ➡ ●

3. *Remote Lock* ➡ ● ➡ Enter Handset Code ➡ ●

```
Remote Lock
Mail Remote Lock
Off
Call Remote Lock
Off
```

4. *Call Remote Lock* ➡ ●

```
Call Remote Lock
Switch On/Off
Off
Set Public Phone
Off
Phone No. to Lck 1
Phone No. to Lck 2
Count for Lock
3 times
```
Call Remote Lock Menu

5. *Phone No. to Lck 1* or *Phone No. to Lck 2* ➡ ●

```
Phone No. to Lck 1
Phone Book
Phone Number
```

6. *Phone Book* ➡ ● ➡ Select entry ➡ ● ➡ Select phone number ➡ ●
   - Select *Phone Number* to enter directly.

7. *Switch On/Off* ➡ ●

8. *On* ➡ ● ➡ ☒

Enabling Activation via Public Phone
In 5, *Set Public Phone* ➡ ● ➡ *On* ➡ ● ➡ From 7
Canceling Call Remote Lock
In 5, *Switch On/Off* ➡ ● ➡ *Off* ➡ ● ➡ ☒

■ **Activating Remote Lock via Phone**
If handset cannot receive calls IC Card Lock is not set.

1. **Using one of the specified phones, call handset**
   - Send Caller ID.

2. **Handset receives call ➡ End the call**
   - The call is recorded as a Missed Call.

3. **Within three minutes, repeat 1 - 2 twice**

```
IC Card Lock

IC

Answering
```

   - After the third Missed Call, IC Card Lock is set; a message announces Remote Lock activation. Confirm the message and end the call.

If Series is Interrupted by Another Call
- Missed Call count is reset. Start over from the beginning.

9

Handy Extras

9-17

Faking Incoming Calls

Handset rings to emulate an incoming call.
● Save name and phone number to show as Caller ID.
● Ringer may be muted by handset settings. To override Silent setting, see **P.9-40**.

Setting Simulated Call

1. ● ➡ *Tools* ➡ ● ➡ In PIM/ Lifestyle menu, *Simulated Call* ➡ ●

Simulated Call Menu

2. *Switch On/Off* ➡ ● ➡ *On* ➡ ●

3. *Set Caller* ➡ ●

4. *Name:* ➡ ● ➡ Enter name ➡ ●

5. *Phone Number:* ➡ ● ➡ Enter phone number ➡ ● ➡ ⊙

6. *Assign Tone* ➡ ● ➡ Select tone/file ➡ ●

7. ⊙ ➡ PIM/Lifestyle menu returns

When Name and Phone Number are Unset
● Handset rings with Caller ID "Withheld."
Canceling Simulated Call
  [Simulated Call Menu] *Switch On/Off* ➡ ● ➡ *Off* ➡ ● ➡ ⊙
Setting Wait Time
  [Simulated Call Menu] *Receive Timing* ➡ ● ➡ Select time ➡ ● ➡ ⊙

Using Simulated Call

Available with handset open.

1. ▶ (Long)
● Handset rings and incoming Voice Call window opens.
● Ringtone stops after a period of time.

2. In incoming Voice Call window, press 🔊
● Voice Call window opens. (Softkeys are dummies.)

3. 🔴 ➡ Simulated Call ends

When Receive Timing is Not *Immediately*
● Press 🔴 or ⌨ during wait time to cancel Simulated Call activation.
● Simulated Call activation is canceled by incoming calls, Alarms, etc. during wait time.

Advanced

○Starting via Simulated Call menu ○Clearing caller information ○Overriding Silent volume setting (**P.9-40**)

Using Stopwatch

Stopwatch stops when battery runs low.

1. ● ➡ *Tools* ➡ ● ➡ ☉
   Clocks/Gauges ➡ *Stopwatch*
   ➡ ●

   Stopwatch Window

2. ● ➡ **Stopwatch starts**

3. ● ➡ **Stopwatch stops**
   ● Press ● to resume.

4. ☎ ➡ *Yes* ➡ ● ➡
   Stopwatch ends
   ● Records are deleted when
   Stopwatch ends.

Recording Lap Times
   While Stopwatch is running, ☺
Saving Records to Notepad
   After ❸, ☺ ➡ *Save to Notepad* ➡ ●
Resetting Records
   After ❸, ☺ ➡ From ❷
Incoming Calls
● Stopwatch is not affected by incoming
  calls. End the call to return.

Using Countdown Timer

1. ● ➜ *Tools* ➜ ● ➜ ☉ *Clocks/Gauges* ➜ *Countdown Timer* ➜ ●

Countdown Timer

Enter Time
(1"~99'59")

99 : 59
00 : 00
01 : 01

Timer Entry Window

2. Enter minutes ➜ Enter seconds ➜ ●

Countdown Timer

Time Remaining

01:10

Countdown Timer Window

● Press ◙ to change time.

3. ● ➜ Countdown starts
● Press ● to stop/resume countdown.

4. Set time elapses ➜ Tone sounds

5. ☎ ➜ *Yes* ➜ ● ➜ Countdown Timer ends

Using Timer Records
After ❶, ◙ ➜ Select record ➜ ● ➜ ● ➜ From ❸
Resetting Countdown Timer
Stop countdown and ◙
Incoming Calls
● Countdown is not affected by incoming calls. End the call to return.

When Set Time Elapses

Tone sounds.

Countdown Timer

Timer Expired

Stopping Tone Instantly
● Press ● or a Side Key. (Tone stops automatically after a period of time.)
When Timer Time Elapsed during a Call
● Tone sounds after the call.

9 Handy Extras

9-20

Opening World Clock

1. ● ➜ *Tools* ➜ ● ➜ ◌
   Clocks/Gauges ➜ *World
   Clock* ➜ ●

   World Clock

   Tokyo ─────────── Local Time
                      Zone
   My Home City   15:05
   🏠
              20XX/XX/XX Mon

   Tokyo ─────────── World Time
                      Zone
   The Other City   15:05
   ◯

2. ●

   Set Time Zone

   Tokyo
   ±00:00
   15:05

   Set Time Zone Window

3. ◌ Select area ➜ ●

4. 📴 ➜ World Clock ends

   Advancing One Hour (Daylight Saving)
   [Set Time Zone Window] ✆
   ■ To cancel, press ✆.
   Adding Custom Time Zone
   [Set Time Zone Window] ✉ ➜ Enter
   city name ➜ ● ➜ *+* or *-* ➜ ◌ ➜
   Enter time difference ➜ ●

Opening World Clock in Standby

1. ● ➜ *Settings* ➜ ● ➜ In
   Phone menu, *Display* ➜ ●

2. *Standby Display* ➜ ●

   Standby Display
   Clock/Calendar
   Clock (W)
   Show Operator Name
   Off
   Pedometer
   Steps

3. *Clock/Calendar* ➜ ●

4. *World Clock (L)*, etc. ➜ ●

9
Handy Extras

9-21

Using Hour Minder

Setting Hour Minder

Follow these steps to activate the hourly time signal at selected hours:

1. ● ➜ *Tools* ➜ ● ➜ ☉ *Clocks/Gauges* ➜ *Hour Minder* ➜ ●

> Hour Minder
> Switch On/Off
> Off
> Select Time
> Every Hour
> Advanced
>
> Hour Minder Menu

2. *Switch On/Off* ➜ ● ➜ *On* ➜ ●

3. *Select Time* ➜ ●

> Select Time
> ☑ 0:00
> ☑ 1:00
> ☑ 2:00
> ☑ 3:00
> ☑ 4:00

4. Select hour ➜ ● (□/☑) ➜ Complete selection ➜ ⊙

5. ⊙ ➜ Saved

6. ☎ ➜ Hour Minder setting ends

Adjusting Hour Minder Volume
In ②, *Advanced* ➜ ● ➜ *Volume:* ➜ ● ➜ Adjust level ➜ ● ➜ ⊙ ➜ From ⑤

Changing Hour Minder Duration
In ②, *Advanced* ➜ ● ➜ *Duration:* ➜ ● ➜ Select time ➜ ● ➜ ⊙ ➜ From ⑤
■ For custom Duration, select *Other*.

Selecting/Canceling All Hours
In ④, ✉ ➜ *Check All* or *Uncheck All* ➜ ●

At Hour Minder Time

Hour Minder activates; sounds/vibrates by related settings.

> Hour Minder
> 18:00

Stopping Tone Instantly
● Press a key.
When Another Function is Active
● Hour Minder does not activate.
Incoming Calls
● Active Hour Minder stops for incoming calls.

Canceling Hour Minder

1. **In Hour Minder menu,** *Switch On/Off* ➜ ● ➜ *Off* ➜ ● ➜ ⊙

Advanced

📵 ●Changing Hour Minder tone/video ●Setting handset to vibrate at Hour Minder Time ●Sounding Hour Minder tone even in Manner mode ●Activating Hour Minder based on World Clock time (**P.9-40**)

Using Pedometer

Getting Started

- Count based on a pace of approximately 100 steps per minute over even terrain.
- Accuracy may be affected by course, terrain, walking style, etc.
- Avoid holding the handset; use a body worn case or a strap, or place handset inside a pocket or bag.
  - Avoid sudden/erratic movements.
- Steps are not counted in the following cases:
  - While handset is off
  - For the first few steps
  - While handset vibrates
- Handset use may affect accuracy.
- Use Pedometer only as a rough guide.

Adjusting Counter Sensitivity
● ➡ *Tools* ➡ ● ➡ ۞ *Clocks/Gauges* ➡ *Pedometer* ➡ ● ➡ *Settings* ➡ ● ➡ *Step Sensitivity* ➡ ● ➡ **Select option** ➡ ●
- Select *Low* when steps seem overcounted; select *High* when they seem undercounted.

Saving Body Information

Weight and pace entry required to view full Pedometer data.

1. ● ➡ *Tools* ➡ ● ➡ ۞ *Clocks/Gauges* ➡ *Pedometer* ➡ ●

   |Til●|
   |Pedometer|
   |Today's Walking|
   |Pedometer Calendar|
   |Accumulated Data|
   |Settings|
   |Switch On/Off|
   |Off|

   Pedometer Menu

2. *Settings* ➡ ● ➡ *Body Info.* ➡ ●

3. **Enter Handset Code** ➡ ●

   |Til●|
   |Body Info.|
   |Height|
   |<Unset>|
   |Weight|
   |<Unset>|
   |Pace|
   |<Unset>|

   Body Info Menu

4. *Height* ➡ ● ➡ **Enter height** ➡ ●

5. *Weight* ➡ ● ➡ **Enter weight** ➡ ●

6. *Pace* ➡ ● ➡ *Yes* or *No* ➡ ●
   - Choose *Yes* to enter pace automatically based on height.

7. **Enter pace** ➡ ● ➡ ۷

Editing Body Information
[Body Info Menu] **Select item** ➡ ● ➡ **Enter value** ➡ ● ➡ ۷
- For *Pace*, automatic calculation confirmation appears (when height is entered).

Activating Pedometer

1. **In Pedometer menu,** *Switch On/Off* ➡ ●

2. *On* ➡ ●

Canceling Pedometer
In ②, *Off* ➡ ●

9

Handy Extras

Pedometer Indicator

When Pedometer is active, today's step count appears in Standby.

Viewing Step Count Records

1 **In Pedometer menu, *Today's Walking* ➔ ●**

2 ●

Steps Window

- Press 🅨 to toggle daily/weekly view.
- Press ✳ to open previous day/week, or ✳ to open next day/week.

3 **Select time/date ➔ ●**

- Hourly/daily step counts appear.

4 **🔚 ➔ Standby returns**

Resetting Today's Step Count
In 2, ✉ ➔ *Reset Day's Data* ➔ ● ➔ *Yes* ➔ ●

Resetting Log
[Steps Window] ✉ ➔ *Walk Data Reset* ➔ ● ➔ Enter Handset Code ➔ ● ➔ *Yes* ➔ ●
■ Today's data is also reset.

Setting Targets

Information window opens, etc. when target is achieved for these items:

Steps	**Walking Time**
Exercise	**Calories**
Distance	**Fat burned**

1 **In Pedometer menu, *Settings* ➔ ● ➔ *Target* ➔ ●**

2 ***Target Settings* ➔ ●**

3 **Select item ➔ ● ➔ Enter value/time ➔ ●**

- Other target settings may consequently change.

Editing Targets
[Pedometer Menu] *Settings* ➔ ● ➔ *Target* ➔ ● ➔ *Target Settings* ➔ ● ➔ Select item ➔ ✉ ➔ Enter value/time ➔ ●

When Target is Achieved
- A tone sounds and Information window opens. (Select *Goal Achievement* and press ● to open Pedometer Calendar.) Follow these steps to mute achievement tone:
[Pedometer Menu] *Settings* ➔ ● ➔ *Target* ➔ ● ➔ *Goal Announce* ➔ ● ➔ *Off* ➔ ●

About Exercise (Ex)
- Ex and MET indicate amount and intensity of physical activity, respectively. Ex for walking is calculated by multiplying 3 METs by walking duration (hour).

Advanced

📖 ●Changing Pedometer indicator ●Using Pedometer Calendar ●Checking accumulated data ●Resetting accumulated data ●Customizing achievement notice (**P.9-40** - **9-41**)

Opening PC Documents

Supported File Formats:

PDF (.pdf)

Microsoft® Excel® (.xls)

Microsoft® Word (.doc)

Microsoft® PowerPoint® (.ppt)

- Some files may not appear correctly.
- Download files via the Internet.
- When transferring files from PCs, save to corresponding Memory Card folder (**P.15-24**).

1 ● → *Tools* → ● → ⊙ *Doc./Rec.* → *Document Viewer* → ●

```
Other Documents
Product_List.xls    XXKB


Product_
```

2 Select file → ●

Zooming In/Out with Loupe (Magnifier)
In open file, ⊜ (Long) → Specify portion → ⊜ → *Zoom Out* or *Zoom In* → ●

Key Assignments

View Whole Page	●
Scroll	⊙
View Upper Left	1
Toggle Full Screen View On/Off	2
View Upper Right	3
Zoom Out	4 / ▶
Continuous Zoom Out	4 (Long) ▶ (Long)
View Center	5
Zoom In	6 / ◀
Continuous Zoom In	6 (Long)
View Lower Left	7
Jump to Page	8
View Lower Right	9
Open Help	0
Next Page	#
Previous Page	✱
Fit Width	⌕
Rotate 90 Degrees	⊙

9

Handy Extras

Saving Text

New Notepad Entry

1 ● ➡ *Tools* ➡ ● ➡ ⊙
Doc./Rec. ➡ *Notepad* ➡ ●

```
Notepad          Accessed
⇨ <Add New Entry>
```

Notepad List

2 *<Add New Entry>* ➡ ●

```
Text:          0/8192
⇨a
```

3 Enter text ➡ ●

4 Select Category ➡ ● ➡
Saved

**Sorting Entries Temporarily
[Notepad List]** ⊙
■ Press to toggle sort options (Modified,
Created, Category and Accessed).
**Inserting Notepad Text during Text Entry
[Text Entry Window]** ☺ ➡ *Notepad*
➡ ● ➡ *Call Notepad* ➡ ● ➡
Select entry ➡ ●

Opening Notepad

1 In Notepad list, select entry
➡ ●

```
Notepad
☺ Private
Meeting time
```

2 ⌫ ➡ **List returns**

Deleting Entries

■ **One Entry**

1 In Notepad list, select entry
➡ ☺

2 *Delete Item* ➡ ● ➡ *Yes* ➡ ●

■ **Selected Entries**

1 In Notepad list, select entry ➡
☺ ➡ *Setting/Manage* ➡ ●

2 *Multiple Selection* ➡ ● ➡
Select entry ➡ ● (□/☑) ➡
Complete selection ➡ ☺

3 *Delete* ➡ ● ➡ *Yes* ➡ ●

**Unchecking All
In** 3, *Uncheck All* ➡ ●

■ **All Entries**

1 In Notepad list, select entry ➡
☺ ➡ *Setting/Manage* ➡ ●

2 *Delete All* ➡ ● ➡ Enter
Handset Code ➡ ● ➡ *Yes*
➡ ●

Advanced

✎ ●Editing Notepad ●Searching text within all entries ●Inserting Notepad text into message text ●Sending entries via S! Mail ●Creating text files
●Importing text files ●Checking memory status ●Opening properties (**P.9-41**)

Using ASCII Art

Inserting ASCII Art

1 **In message text entry window,** ⊠ ➡ *Call ASCII Art* ➡ ⦿

2 **Select entry** ➡ ⦿

Previewing ASCII Art
   In ➋**, select entry** ➡ ⊠
■ Press ⦿ to insert ASCII Art.

Editing Entries

1 ⦿ ➡ *Tools* ➡ ⦿ ➡ ⊙ *Doc./Rec.* ➡ *ASCII Art* ➡ ⦿

ASCII Art List

2 **Select entry** ➡ ⦿ ➡ **Edit** ➡ ⦿

Opening Entries
   In ➋**, select entry** ➡ ⊠ ➡ *View* ➡ ⦿
Adding New Entries
   In ➋**, *<Empty>*** ➡ ⦿ ➡ **Create ASCII Art** ➡ ⦿

Deleting Entries

1 **In ASCII Art list, select entry** ➡ ⊠ ➡ *Delete* ➡ ⦿

2 *Yes* ➡ ⦿

Recording/Playing Voice

Recording

- Recording stops if battery runs low while recording.
- Record conversations during calls via **Record Caller Voice**.

1 ● ➜ **Tools** ➜ ● ➜ ⊙ **Doc./Rec.** ➜ **Voice Recorder** ➜ ●

Voice Recorder

Recording Window

2 ● ➜ **Recording starts**

3 ● ➜ **Recording stops**

Voice Recorder
Save
Playback
Save and Send

- For **Extended Voice**, recording is saved automatically.

4 **Save** ➜ ●

Play Before Saving
In **4**, **Playback** ➜ ● ➜ Playback starts ➜ ⌨ ➜ Playback stops
Starting Over
In **4**, ⌨ ➜ From **2**

Playback

1 In recording window, ⌨ ➜ **Ring Songs·Tones** ➜ ●

RingSongs·Tones
Free: XXMB
Need size ---KB

voice001
XX/XX/XX 15:05   XXB

2 Select file ➜ ●

Playing Files via Data Folder
● ➜ **Data Folder** ➜ ● ➜ **Ring Songs·Tones** ➜ ● ➜ Select file ➜ ●

Playback Operations

|	
Adjust Volume	⌄
Pause/Resume	●
Stop	⌨

Advanced

⚙ ●Saving longer recordings ●Sending Voice files via S! Mail ●Switching storage media (**P.9-41** - **9-42**)

Scanning Barcodes

Scan UPC/JAN (1D barcodes) or QR Codes (2D barcodes).

- Membership file or password may be required when scanning barcodes.
- Some barcodes may not be scanned.

1. ● ➡ *Tools* ➡ ● ➡ ◌
   Doc./Rec. ➡ *Barcode/Scan*
   ➡ ●

   > Barcode/Scan
   > Scan Barcode
   > Open Barcode
   > Create QR Code
   > Scan Card
   > Kanji Grabber
   > Scan Text
   > Scanned Results

2. *Scan Barcode* ➡ ●

3. **Frame barcode in center of Display**

   Normal Scanning

   Press ✆ when it is hard to recognize.

   — Focus Adjustment Bar

   Scan Window

   - Use Focus Adjustment Bar as a guide (better focus in darker blue).
   - If focus is poor, press ☺ to switch to Shutter mode.

4. ● ➡ **Scan starts**

   - If recognition takes time, slowly adjust the distance between handset and barcode.
   - Press ☺ to stop scan.

5. **Tone sounds ➡ Scan results appear**

   Scan Result
   XX Restaurant
   [Open Hours]
   Lunch: 11 am - 3 pm
   Dinner: 6 pm - 10 pm
   [Contact]
   aabb@xxx. xx

   Split Data
   - After scanning, confirmation appears. Follow onscreen prompt(s).
   - Scan results do not appear until all split data is scanned.

   Starting Over
   After ⊟, ☺ ➡ *Yes* ➡ ● ➡ From ❸

   Key Assignments in Scan Window

Toggle Focus Mode	3
Switch to Photo Camera	7
Focus Lock	☆
Mobile Light On/Off	#
Adjust Brightness	◌
Open Help	0

Advanced

✎ ●Scanning during text entry ●Scanning continuously ●Reading saved barcode images ●Saving scan results ●Saving to Notepad ●Saving linked info to Phone Book ●Opening saved scan results ●Using linked info ●Using images as Wallpaper ●Saving images & melodies ●Copying text (And more on **P.9-42** - **9-43**)

## Creating QR Codes

Create QR Codes from these items on handset:

Phone Book	My Details
Text Input	Ring Songs･Tones
Pictures	Notepad

Large items are divided into multiple QR Codes.

Procedure

Follow these steps to create QR Codes from Data Folder files:

1. ● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ●

   Barcode/Scan
   Scan Barcode
   Open Barcode
   Create QR Code
   Scan Card
   Kanji Grabber
   Scan Text
   Scanned Results

2. *Create QR Code* ➡ ●

3. *Data Folder* ➡ ●

   Data Folder
   Pictures
   Ring Songs･Tones
   Notepad
   Other Documents

4. Select folder ➡ ● ➡ Select file or entry ➡ ●
   ● QR Code is created.

5. ●
   ● QR Code is saved to Data Folder (Pictures).

From Phone Book Entries
   In ③, *Phone Book* ➡ ● ➡ Select entry ➡ ● ➡ ⊟
From My Details
   In ③, *My Details* ➡ ● ➡ ⊠ ➡ ⊟
From Entered Text
   In ③, *Text Input* ➡ ● ➡ Enter text ➡ ● ➡ ⊟
Switching Storage Media
   In ⑤, ⊠ ➡ *Save to* ➡ ● ➡ *Phone* or *Memory Card* ➡ ● ➡ ●
Attaching to S! Mail
   In ⑤, ⊠ ➡ *Send As Message* ➡ ● ➡ Complete message ➡ �
Incoming Calls
   ● QR Code creation is not affected by incoming calls. End the call to return.

Scanning Business Cards

Scan business cards and save names, addresses, etc. to Phone Book.
- English business cards may not be scanned correctly.
- Some cards may not be scanned.

1. ● ➡ *Tools* ➡ ● ➡ ⊙
   Doc./Rec. ➡ *Barcode/Scan*
   ➡ ●

   > Barcode/Scan
   > Scan Barcode
   > Open Barcode
   > Create QR Code
   > Scan Card
   > Kanji Grabber
   > Scan Text
   > Scanned Results

2. *Scan Card* ➡ ●

3. **Frame card on Display**

   Scan Window

4. ●
   - Press ⊻ to stop scan.

5. ● ➡ **Scan results appear**

   > Scan Result
   > 木村
   > 哲也
   > キムラ
   > 03-1234-XXXX
   > 03-1234-XXXX

6. ● ➡ ⊻
   - New Phone Book entry is saved.

If Text Exceeds Phone Book Entry Item Character Limit
- Confirmation appears. Follow these steps to delete overage:
  Yes ➡ ●
Switching Storage Media
  After ⊖, ⊚ ➡ *Save to* ➡ ● ➡
  Select storage media ➡ ● ➡ ●
Saving Scanned Image as Phone Book Picture
  After ⊖, ⊚ ➡ *Add Image* ➡ ● ➡
  On ➡ ● ➡ ⊖
Starting Over
  After ⊖, ⊻ ➡ *Yes* ➡ ● ➡ From ❸

Key Assignments in Scan Window

Toggle Focus Mode	3
Switch to Photo Camera	7
Focus Lock	ⓐ
Mobile Light On/Off	#
Adjust Brightness	⊙
Open Help	0

9 Handy Extras

Advanced

⊛ ●Saving to Notepad ●Pasting to message text ●Copying text (**P.9-44**)

Scanning Text

Scan text and save it to Notepad, etc.
Available Modes:

Full	Capture text in full screen and scan a selected line
Line	Capture a few lines of text and scan a selected line

- To toggle mode, press ⊙ in scan window.
- Some text cannot be scanned.

1. ● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ●

```
Barcode/Scan
Scan Barcode
Open Barcode
Create QR Code
Scan Card
Kanji Grabber
Scan Text
Scanned Results
```

2. *Scan Text* ➡ ●
   - To change mode, press ⊙ in scan window.

3. **Frame text in center of Display**

```
●XX Co., Ltd.
●YY Co., Ltd.
●ZZ Co., Ltd.
●** Co., Ltd.
●?? Co., Ltd.
```
Scan Window

4. ● ➡ Scan starts
   - Press ⊙ to stop scan.

5. **Select line ➡ ● ➡ Scan results appear**

6. ●

```
Scanned Text
                    12/256
XX Co., Ltd.
```

7. ✉ ➡ *Notepad* ➡ ●

Correcting Text Type
After **⑤**, ✉ ➡ *Change Mode* ➡ ● ➡ Select type ➡ ● ➡ From **⑤**

Editing Scanned Text
After **⑤**, ✉ ➡ *Select/Edit* ➡ ● ➡ Select character ➡ Select alternative from list or edit directly ➡ From **⑤**

Starting Over
In **⑤**, ⊙ ➡ *Yes* ➡ ● ➡ From **③**

Key Assignments in Scan Window

Toggle Focus Mode	3
Switch to Photo Camera	7
Focus Lock	⚹
Mobile Light On/Off	#
Adjust Brightness	⊙
Open Help	0

Advanced

 ●Scanning and pasting during text entry ●Scanning more text ●Saving scan results ●Saving linked info to Phone Book ●Opening saved scan results ●Using linked info ●Pasting to message text ●Copying text (**P.9-44** - **9-45**)

Using Kanji Grabber

Scan a word of up to ten kanji and look it up in dictionaries.
Some text cannot be scanned.

1. **●** ➜ *Tools* ➜ **●** ➜ **◌**
   Doc./Rec. ➜ *Barcode/Scan*
   ➜ **●**

   Barcode/Scan
   Scan Barcode
   Open Barcode
   Create QR Code
   Scan Card
   Kanji Grabber
   Scan Text
   Scanned Results

2. *Kanji Grabber* ➜ **●**

3. **Frame kanji in Loupe**

   読み取り
   文字を読み取
   文字を読み取
   トとして利用

   — Loupe

   Scan Window

4. **●**
   ● Scan results (kanji) appear.

5. **●**

6. Select dictionary ➜ **●** ➜
   Search ➜ **●**

7. Select word, etc. ➜ **●**
   ● Definition/translation window opens.

Starting Over
In **5**, **ᵧ** ➜ **From 3**

Key Assignments in Scan Window

Toggle 2x Magnification On/Off	ᵧ
Toggle Focus Mode	3
Switch to Photo Camera	7
Focus Lock	⏃
Mobile Light On/Off	#
Adjust Brightness	◌
Open Help	0

9

Handy Extras

Advanced

🖑 ●Scanning and pasting during text entry (**P.9-45**)

Calendar

■ View Settings

Changing default view	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ ☺ ➡ *Calendar Settings* ➡ ● ➡ *Default View* ➡ ● ➡ Select type ➡ ●
Jumping to specified date	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ 8 ➡ Enter date ➡ ●
Changing date color	[Start Here] ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ See below
	By Days of the Week ☺ ➡ *Calendar Settings* ➡ ● ➡ *Set Color* ➡ ● ➡ *By Week* ➡ ● ➡ Select day ➡ ● ➡ Select color ➡ ●
	By Date Select date ➡ 4 ➡ Select color ➡ ● ● Not available in 6Month View.
	Resetting "By Date" Colors ☺ ➡ *Calendar Settings* ➡ ● ➡ *Set Color* ➡ ● ➡ *Reset Color* ➡ ● ➡ Select option ➡ ● ➡ *Yes* ➡ ●
Selecting task view option	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ ☺ ➡ *Calendar Settings* ➡ ● ➡ *Tasks View* ➡ ● ➡ Select option ➡ ●
Adding stamps (Month/3Month View)	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ Select date ➡ 2 ➡ Select stamp ➡ ●
Hiding schedules	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ Select date ➡ ● ➡ Select entry ➡ ● ➡ ● ➡ *Secret:* ➡ ● ➡ *On* ➡ ● ➡ ☺
Saving additional holidays	[Start Here] ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ ☺ ➡ *Calendar Settings* ➡ ● ➡ *Set Holiday* ➡ ● ➡ ☺ *Private* ➡ See below
	Adding Holidays *<Empty>* ➡ ● ➡ Enter name ➡ ● ➡ Enter date ➡ ● ➡ Select frequency ➡ ● ➡ ☺
	Editing Added Holidays Select holiday ➡ ☺ ➡ *Edit* ➡ ● ➡ *Name:* ➡ ● ➡ Enter name ➡ ● ➡ *Date:* ➡ ● ➡ Enter date ➡ ● ➡ Select frequency ➡ ● ➡ ☺
Removing/ restoring holidays	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ ☺ ➡ *Calendar Settings* ➡ ● ➡ *Set Holiday* ➡ ● ➡ ☺ *Private* or *Public* ➡ Select holiday ➡ ● (☐/☑)

■ Saving/Editing Schedules

<table>
<tr>
<td rowspan="3">Setting Category/Location</td>
<td><code>Start Here</code> ● ➡ Tools ➡ ● ➡ In PIM/Lifestyle menu, Calendar ➡ ● ➡ Select date ➡ ● ➡ Select entry ➡ ● ➡ ● ➡ See below</td>
</tr>
<tr>
<td>Category
Category: ➡ ● ➡ Select Category ➡ ● ➡ ⓨ</td>
</tr>
<tr>
<td>Location
Location: ➡ ● ➡ Enter location ➡ ● ➡ ⓨ</td>
</tr>
<tr>
<td rowspan="4">Creating Categories</td>
<td><code>Start Here</code> ● ➡ Tools ➡ ● ➡ In PIM/Lifestyle menu, Calendar ➡ ● ➡ ✉ ➡ Calendar Settings ➡ ● ➡ Set Category ➡ ● ➡ See below</td>
</tr>
<tr>
<td>Renaming Categories
Select Category ➡ ● ➡ Edit Category Name ➡ ● ➡ Enter name ➡ ●</td>
</tr>
<tr>
<td>Changing Icons
Select Category ➡ ● ➡ Change Icon ➡ ● ➡ Select Pictogram ➡ ●</td>
</tr>
<tr>
<td>Resetting
✉ ➡ Reset Settings ➡ ● ➡ Enter Handset Code ➡ ● ➡ Yes ➡ ●</td>
</tr>
<tr>
<td>Saving repetitive schedules</td>
<td>● ➡ Tools ➡ ● ➡ In PIM/Lifestyle menu, Calendar ➡ ● ➡ Select date ➡ ● ➡ Select entry ➡ ● ➡ ● ➡ Repeat: ➡ ● ➡ Select frequency ➡ ● ➡ Enter repeat time ➡ ● ➡ ⓨ
● Repeat time is not available for Every Year.</td>
</tr>
</table>

<table>
<tr>
<td rowspan="3">Saving S! Friend's Status information</td>
<td><code>Start Here</code> ● ➡ Tools ➡ ● ➡ In PIM/Lifestyle menu, Calendar ➡ ● ➡ Select date ➡ ● ➡ Select entry ➡ ● ➡ ● ➡ S! Friend'sStatus: ➡ ● ➡ Link Setting: ➡ ● ➡ Linked ➡ ● ➡ See below</td>
</tr>
<tr>
<td>Availability
Answer Status: ➡ ● ➡ Edit ➡ ⓨ ➡ ⓨ ➡ ⓨ
● Set Category first.</td>
</tr>
<tr>
<td>Comment
Comment: ➡ ● ➡ Enter text ➡ ● ➡ ⓨ ➡ ⓨ
● Set Category first.</td>
</tr>
<tr>
<td>Editing entries</td>
<td>● ➡ Tools ➡ ● ➡ In PIM/Lifestyle menu, Calendar ➡ ● ➡ Select date ➡ ● ➡ Select entry ➡ ● ➡ ● ➡ Select item ➡ ● ➡ Edit in the same manner as saving schedules ➡ ⓨ</td>
</tr>
<tr>
<td rowspan="3">Changing Alarm tone/video & duration</td>
<td><code>Start Here</code> ● ➡ Tools ➡ ● ➡ In PIM/Lifestyle menu, Calendar ➡ ● ➡ Select date ➡ ● ➡ Select entry ➡ ● ➡ ● ➡ Alarm: ➡ ● ➡ See below</td>
</tr>
<tr>
<td>Alarm Tone/Video
Assign Tone/Video: ➡ ● ➡ Select folder ➡ ● ➡ Select tone/file ➡ ● ➡ ⓨ ➡ ⓨ
● Select start point if required.</td>
</tr>
<tr>
<td>Duration
Duration: ➡ ● ➡ Select time ➡ ● ➡ ⓨ ➡ ⓨ</td>
</tr>
<tr>
<td>Changing Alarm volume</td>
<td>● ➡ Tools ➡ ● ➡ In PIM/Lifestyle menu, Calendar ➡ ● ➡ ✉ ➡ Alarm Settings ➡ ● ➡ Alarm Volume: ➡ ● ➡ Adjust level ➡ ●</td>
</tr>
<tr>
<td>Selecting Vibration option</td>
<td>● ➡ Tools ➡ ● ➡ In PIM/Lifestyle menu, Calendar ➡ ● ➡ ✉ ➡ Alarm Settings ➡ ● ➡ Vibration: ➡ ● ➡ Select option ➡ ●</td>
</tr>
</table>

Sounding Alarm tone even in Manner mode	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ 🖂 ➡ *Alarm Settings* ➡ ● ➡ *For Manner Mode:* ➡ ● ➡ *Ring* ➡ ● ➡ *Yes* ➡ ●

■ **Managing Schedules**

Searching entries	Start Here ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ See below
	By Subject 6 ➡ Enter subject ➡ ●
	By Category 9 ➡ Select Category ➡ ●
Checking memory status	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ Select date ➡ 🖂 ➡ *Memory Status* ➡ ●
Deleting all entries	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ 🖂 ➡ *Delete* ➡ ● ➡ *All Appointments* ➡ ● ➡ Enter Handset Code ➡ ● ➡ *Yes* ➡ ●
Deleting entries by specifying week (Week View)	Start Here ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ See below
	Within One Week Select date ➡ 🖂 ➡ *Delete* ➡ ● ➡ *All This Week* ➡ ● ➡ *Yes* ➡ ●
	Up to the End of Previous Week Select date ➡ 🖂 ➡ *Delete* ➡ ● ➡ *Up to Last Week* ➡ ● ➡ *Yes* ➡ ●
Deleting entries by specifying month (Month/3Month View)	Start Here ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ See below
	Within One Month Select date ➡ 🖂 ➡ *Delete* ➡ ● ➡ *All This Month* ➡ ● ➡ *Yes* ➡ ●
	Up to the End of Previous Month Select date ➡ 🖂 ➡ *Delete* ➡ ● ➡ *Up to Last Month* ➡ ● ➡ *Yes* ➡ ●
Deleting entries in six months (6Month View)	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ 🖂 ➡ *Delete* ➡ ● ➡ *All This 6Months* ➡ ● ➡ *Yes* ➡ ●

Tasks

■ **Task List**

Hiding tasks	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Tasks* ➡ ● ➡ Select task ➡ 🖂 ➡ *Edit* ➡ ● ➡ *Secret:* ➡ ● ➡ *On* ➡ ● ➡ Y

■ **Saving/Editing Tasks**

Editing tasks	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Tasks* ➡ ● ➡ Select task ➡ 🖂 ➡ *Edit* ➡ ● ➡ Select item ➡ ● ➡ Edit in the same manner as saving tasks ➡ Y
Setting priority	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Tasks* ➡ ● ➡ Select task ➡ 🖂 ➡ *Edit* ➡ ● ➡ *Priority:* ➡ ● ➡ Select priority ➡ ● ➡ Y

Changing Alarm tone/ video & duration	Start Here ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Tasks* ➡ ● ➡ Select task ➡ ✉ ➡ *Edit* ➡ ● ➡ *Alarm:* ➡ ● ➡ See below
	Alarm Tone/Video
	Assign Tone/Video: ➡ ● ➡ Select folder ➡ ● ➡ Select tone/file ➡ ● ➡ ⊻ ➡ ⊻
	● Select start point if required.
	Duration
	Duration: ➡ ● ➡ Select time ➡ ● ➡ ⊻ ➡ ⊻
Changing Alarm volume	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Tasks* ➡ ● ➡ ✉ ➡ *Alarm Settings* ➡ ● ➡ *Alarm Volume:* ➡ ● ➡ Adjust level ➡ ●
Selecting Vibration option	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Tasks* ➡ ● ➡ ✉ ➡ *Alarm Settings* ➡ ● ➡ *Vibration:* ➡ ● ➡ Select option ➡ ●
Sounding Alarm tone even in Manner mode	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Tasks* ➡ ● ➡ ✉ ➡ *Alarm Settings* ➡ ● ➡ *For Manner Mode:* ➡ ● ➡ *Ring* ➡ ● ➡ *Yes* ➡ ●

■ Managing Tasks

Searching tasks	Start Here ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Tasks* ➡ ● ➡ ✉ ➡ *Find* ➡ ● ➡ See below
	By Subject
	By Subject ➡ ● ➡ Enter subject ➡ ●
	By Due Date
	By Due Date ➡ ● ➡ Enter date ➡ ●
Sorting tasks by priority	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Tasks* ➡ ● ➡ ✉ ➡ *Sort* ➡ ● ➡ *Priority* ➡ ●
Checking memory status	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Tasks* ➡ ● ➡ ✉ ➡ *Memory Status* ➡ ●
Deleting all tasks	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Tasks* ➡ ● ➡ ✉ ➡ *Delete* ➡ ● ➡ *All Tasks* ➡ ● ➡ Enter Handset Code ➡ ● ➡ *Yes* ➡ ●

Alarms

Editing entries	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Alarms* ➡ ● ➡ Select entry ➡ ● ➡ Select item ➡ ● ➡ Edit in the same manner as saving entries ➡ ⓨ
Saving entry name	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Alarms* ➡ ● ➡ Select entry ➡ ● ➡ *Subject:* ➡ ● ➡ Enter name ➡ ● ➡ ⓨ
Changing Alarm tone/video	[Start Here] ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Alarms* ➡ ● ➡ Select entry ➡ ● ➡ *Assign Tone/Video:* ➡ ● ➡ See below
	Using Preset Tone or Data Folder File Select folder ➡ ● ➡ Select tone/file ➡ ● ➡ ⓨ ● Select start point if required.
	Using Customized Screen Tone/Video *Customized Screen* ➡ ● ➡ ⓨ
Setting handset to vibrate at Alarm Time	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Alarms* ➡ ● ➡ Select entry ➡ ● ➡ *Vibration:* ➡ ● ➡ *On* or *Link to Sound* ➡ ● ➡ ⓨ ● Select *Link to Sound* to allow compatible SMAF files to control vibration.
Sounding Alarm tone even in Manner mode	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Alarms* ➡ ● ➡ *Settings* ➡ ● ➡ *For Manner Mode* ➡ ● ➡ *Ring* ➡ ● ➡ *Yes* ➡ ●
Activating Alarm based on World Clock time	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Alarms* ➡ ● ➡ *Settings* ➡ ● ➡ *Link to World Clk* ➡ ● ➡ *On* ➡ ●

Wakeup TV

Editing entries	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Wakeup TV* ➡ ● ➡ Select entry ➡ ● ➡ Select item ➡ ● ➡ Edit in the same manner as saving entries ➡ ⓨ
Changing Alarm tone/video	[Start Here] ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Wakeup TV* ➡ ● ➡ Select entry ➡ ● ➡ *Assign Tone/Video:* ➡ ● ➡ See below
	Using Preset Tone or Data Folder File Select folder ➡ ● ➡ Select tone/file ➡ ● ➡ ⓨ ● Select start point if required.
	Using Customized Screen Tone/Video *Customized Screen* ➡ ● ➡ ⓨ
Sounding Alarm tone even in Manner mode	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Wakeup TV* ➡ ● ➡ *For Manner Mode* ➡ ● ➡ *Ring* ➡ ● ➡ *Yes* ➡ ●

Calculator

Copying calculation results	While result appears, ⓢ ➡ *Copy* ➡ ●
Changing exchange rate for currency conversion	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calculator* ➡ ● ➡ ⓢ ➡ *Money Converter* ➡ ● ➡ *Exchange Rate* ➡ ● ➡ *Domestic* or *Foreign* ➡ ● ➡ Enter rate ➡ ●
Converting currencies	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calculator* ➡ ● ➡ Enter amount of money ➡ ⓢ ➡ *Money Converter* ➡ ● ➡ *To Domestic* or *To Foreign* ➡ ● ● Set Exchange Rate first.

9

Handy Extras

Expenses Memo

Changing Category of saved entry	● ➜ *Tools* ➜ ● ➜ In PIM/Lifestyle menu, *Expenses Memo* ➜ ● ➜ *Totals* ➜ ● ➜ Select entry ➜ ● ➜ Select Category ➜ ●
Changing amount	● ➜ *Tools* ➜ ● ➜ In PIM/Lifestyle menu, *Expenses Memo* ➜ ● ➜ *Totals* ➜ ● ➜ Select entry ➜ ⊠ ➜ *Change Amount* ➜ ● ➜ Edit ➜ ●
Renaming Categories	● ➜ *Tools* ➜ ● ➜ In PIM/Lifestyle menu, *Expenses Memo* ➜ ● ➜ *Edit Category* ➜ ● ➜ Select Category ➜ ● ➜ Enter name ➜ ●

Osaifu-Keitai®

Enabling to view e-money balances	● ➜ *Tools* ➜ ● ➜ In PIM/Lifestyle menu, *Osaifu-Keitai* ➜ ● ➜ *IC Card Settings* ➜ ● ➜ *Balance Info* ➜ ● ➜ Enter Handset Code ➜ ● ➜ *<Empty>* ➜ ● ➜ *S! Appli* or *Lifestyle-Appli* ➜ ● ➜ Select application ➜ ● ● For use with compatible Lifestyle-Applications. ● Start Lifestyle-Appli once before adding it to Balance Info list.
Moving applications up/down Balance Info list	● ➜ *Tools* ➜ ● ➜ In PIM/Lifestyle menu, *Osaifu-Keitai* ➜ ● ➜ *IC Card Settings* ➜ ● ➜ *Balance Info* ➜ ● ➜ Enter Handset Code ➜ ● ➜ Select application ➜ ⊠ ➜ *Move* ➜ ● ➜ Select target location ➜ ●
Removing applications from Balance Info list	● ➜ *Tools* ➜ ● ➜ In PIM/Lifestyle menu, *Osaifu-Keitai* ➜ ● ➜ *IC Card Settings* ➜ ● ➜ *Balance Info* ➜ ● ➜ Enter Handset Code ➜ ● ➜ Select application ➜ ⊠ ➜ *Delete* ➜ ●

Customizing handset response to reader/writer commands	● ➜ *Tools* ➜ ● ➜ In PIM/Lifestyle menu, *Osaifu-Keitai* ➜ ● ➜ *IC Card Settings* ➜ ● ➜ *Interface Settings* ➜ ● ➜ Enter Handset Code ➜ ● ➜ Select item ➜ ● ➜ *Off* ➜ ●
Opening IC Card properties	● ➜ *Tools* ➜ ● ➜ In PIM/Lifestyle menu, *Osaifu-Keitai* ➜ ● ➜ *IC Card Settings* ➜ ● ➜ *IC Card Status* ➜ ●
Changing IC Card Lock notice recipient	[Start Here] ● ➜ *Tools* ➜ ● ➜ In PIM/Lifestyle menu, *Osaifu-Keitai* ➜ ● ➜ *IC Card Settings* ➜ ● ➜ *Remote Lock* ➜ ● ➜ Enter Handset Code ➜ ● ➜ *Mail Remote Lock* ➜ ● ➜ *Notice Settings* ➜ ● ➜ *Send Notice* ➜ ● ➜ See below **Changing Recipient** *To Set Recipient* ➜ ● ➜ *Set Recipient* ➜ ● ➜ Select method ➜ ● ➜ Select/enter number/address ➜ ● ➜ 🔤 ➜ ⓨ ● Omit step of pressing 🔤 when selecting *Phone Book* as setting method. **Disabling Notice** *Off* ➜ ● ➜ 🔤 ➜ ⓨ
Changing required Missed Call count for Call Remote Lock	● ➜ *Tools* ➜ ● ➜ In PIM/Lifestyle menu, *Osaifu-Keitai* ➜ ● ➜ *IC Card Settings* ➜ ● ➜ *Remote Lock* ➜ ● ➜ Enter Handset Code ➜ ● ➜ *Call Remote Lock* ➜ ● ➜ *Count for Lock* ➜ ● ➜ Enter Missed Call count ➜ ● ➜ ⓨ
Restoring default Osaifu-Keitai® settings	● ➜ *Tools* ➜ ● ➜ In PIM/Lifestyle menu, *Osaifu-Keitai* ➜ ● ➜ *IC Card Settings* ➜ ● ➜ *Set to Default* ➜ ● ➜ Enter Handset Code ➜ ● ➜ *Yes* ➜ ●

9

Handy Extras

Simulated Call

Starting via Simulated Call menu	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Simulated Call* ➡ ● ➡ *Receive Simulated Call* ➡ ● ➡ *Yes* ➡ ● ● Simulated Call starts immediately regardless of Receive Timing setting. ● Settings remain even after starting Simulated Call during setup.
Clearing caller information	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Simulated Call* ➡ ● ➡ *Set Caller* ➡ ● ➡ ✉ ➡ *Yes* ➡ ● ➡ ⌄ ➡ ⌄
Overriding Silent volume setting	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Simulated Call* ➡ ● ➡ *For Silent Mode* ➡ ● ➡ *Ring* ➡ ● ➡ *Yes* ➡ ● ➡ ⌄

Hour Minder

Changing Hour Minder tone/video	● ➡ *Tools* ➡ ● ➡ ⊙ *Clocks/Gauges* ➡ *Hour Minder* ➡ ● ➡ *Advanced* ➡ ● ➡ *Assign Tone/Video:* ➡ ● ➡ Select folder ➡ ● ➡ Select tone/file ➡ ● ➡ ⌄ ➡ ⌄ ● Select start point if required.
Setting handset to vibrate at Hour Minder Time	● ➡ *Tools* ➡ ● ➡ ⊙ *Clocks/Gauges* ➡ *Hour Minder* ➡ ● ➡ *Advanced* ➡ ● ➡ *Vibration:* ➡ ● ➡ *On* or *Link to Sound* ➡ ● ➡ ⌄ ➡ ⌄ ● Select *Link to Sound* to allow compatible SMAF files to control vibration.

Sounding Hour Minder tone even in Manner mode	● ➡ *Tools* ➡ ● ➡ ⊙ *Clocks/Gauges* ➡ *Hour Minder* ➡ ● ➡ *Advanced* ➡ ● ➡ *For Manner Mode:* ➡ ● ➡ *Ring* ➡ ● ➡ *Yes* ➡ ● ➡ ⌄ ➡ ⌄
Activating Hour Minder based on World Clock time	● ➡ *Tools* ➡ ● ➡ ⊙ *Clocks/Gauges* ➡ *Hour Minder* ➡ ● ➡ *Advanced* ➡ ● ➡ *Link to World Clk:* ➡ ● ➡ *On* ➡ ● ➡ ⌄ ➡ ⌄

Pedometer

Changing Pedometer indicator	● ➡ *Settings* ➡ ● ➡ In Phone menu, *Display* ➡ ● ➡ *Standby Display* ➡ ● ➡ *Pedometer* ➡ ● ➡ Select item ➡ ●
Using Pedometer Calendar	● ➡ *Tools* ➡ ● ➡ ⊙ *Clocks/Gauges* ➡ *Pedometer* ➡ ● ➡ *Pedometer Calendar* ➡ ● ➡ Select date ➡ ● ● Degree of achievement appears. ● Press ✳ or ♯ to view previous or next month.
Checking accumulated data	● ➡ *Tools* ➡ ● ➡ ⊙ *Clocks/Gauges* ➡ *Pedometer* ➡ ● ➡ *Accumulated Data* ➡ ● ● Change in body information is reflected in the data.
Resetting accumulated data	● ➡ *Tools* ➡ ● ➡ ⊙ *Clocks/Gauges* ➡ *Pedometer* ➡ ● ➡ *Accumulated Data* ➡ ● ➡ ✉ ➡ *Reset Walk Data* ➡ ● ➡ Enter Handset Code ➡ ● ➡ *Yes* ➡ ● ● Averages are also reset.

Customizing achievement notice	**Start Here** ● ➡ *Tools* ➡ ● ➡ ⊙ *Clocks/Gauges* ➡ *Pedometer* ➡ ● ➡ *Settings* ➡ ● ➡ *Target* ➡ ● ➡ *Goal Announce* ➡ ● ➡ *On* ➡ ● ➡ **See below**
	Changing Tone *Goal Sound* ➡ ● ➡ Select pattern ➡ ●
	Changing Tone Volume *Goal Volume* ➡ ● ➡ Adjust level ➡ ●
	Selecting Vibration Option *Vibration* ➡ ● ➡ Select option ➡ ●
	Changing Duration *Duration* ➡ ● ➡ Select time ➡ ● ● For custom Duration, select *Other* and press ●.

Notepad

Editing Notepad	**Start Here** ● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Notepad* ➡ ● ➡ Select entry ➡ ⊞ ➡ **See below**
	Editing Text *Edit Text* ➡ ● ➡ Edit ➡ ●
	Changing Category *Change Category* ➡ ● ➡ Select Category ➡ ●
Searching text within all entries	● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Notepad* ➡ ● ➡ Select entry ➡ ⊞ ➡ *Search* ➡ ● ➡ Enter text ➡ ●
Inserting Notepad text into message text	● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Notepad* ➡ ● ➡ Select entry ➡ ⊞ ➡ *Send* ➡ ● ➡ *As Message Text* ➡ ● ➡ *S! Mail* or *SMS* ➡ ● ➡ Complete message ➡ ⊽ ● S! Mail Composition window opens automatically depending on character count.

Sending entries via S! Mail	● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Notepad* ➡ ● ➡ Select entry ➡ ⊞ ➡ *Send* ➡ ● ➡ *Via Message* ➡ ● ➡ Complete message ➡ ⊽
Creating text files	● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Notepad* ➡ ● ➡ Select entry ➡ ⊞ ➡ *Setting/Manage* ➡ ● ➡ *Create Text File* ➡ ● ➡ Enter name ➡ ● ➡ *Save here* ➡ ●
Importing text files	● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Notepad* ➡ ● ➡ Select entry ➡ ⊞ ➡ *Setting/Manage* ➡ ● ➡ *Import Text File* ➡ ● ➡ Select file ➡ ●
Checking memory status	● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Notepad* ➡ ● ➡ Select entry ➡ ⊞ ➡ *Setting/Manage* ➡ ● ➡ *Memory Status* ➡ ●
Opening properties	● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Notepad* ➡ ● ➡ Select entry ➡ ⊞ ➡ *Details* ➡ ●

Voice Recorder

Saving longer recordings	● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Voice Recorder* ➡ ● ➡ ⊞ ➡ *Record Time* ➡ ● ➡ *Extended Voice* ➡ ● ➡ ● ➡ Recording starts ➡ ● ➡ Recording ends ● Insert Memory Card to record in *Extended Voice* mode. (Recording is saved automatically.)
Sending Voice files via S! Mail	● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Voice Recorder* ➡ ● ➡ ● ➡ Recording starts ➡ ● ➡ Recording ends ➡ *Save and Send* ➡ ● ➡ Complete message ➡ ⊽ ● Available in *For Message* mode.

9 Handy Extras

Switching storage media	● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Voice Recorder* ➡ ● ➡ ⊠ *Save Recording to* ➡ ● ➡ **Select option** ➡ ●
	● Available in *For Message* mode.
	● Set to *Ask Each Time* to select media after every recording.

Scan Barcode

Scanning during text entry	**Start Here** In a text entry window, ⊠ ➡ *Scan* ➡ ● ➡ *Scan Code* ➡ ● ➡ Frame barcode in center of Display ➡ ● ➡ See below
	Pasting All Scan Results
	●
	Pasting a Part of Scan Results
	⊠ ➡ Select first character ➡ ● ➡ Highlight text range ➡ ●
Scanning continuously	● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ● ➡ *Scan Barcode* ➡ ● ➡ ⊠ ➡ *Continuous Scan* ➡ ● ➡ *On* ➡ ● ➡ Frame barcode in center of Display ➡ ●
	● Choose *Yes* to continue scanning or *No* and press ● to view scan results.
Reading saved barcode images	● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ● ➡ *Open Barcode* ➡ ● ➡ Select file ➡ ●
Saving scan results	● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ● ➡ *Scan Barcode* ➡ ● ➡ Frame barcode in center of Display ➡ ● ➡ ⊠ ➡ *Save* ➡ ●

Saving to Notepad	● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ● ➡ *Scan Barcode* ➡ ● ➡ Frame barcode in center of Display ➡ ● ➡ ⊠ ➡ *Notepad* ➡ ●
Saving linked info to Phone Book	● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ● ➡ *Scan Barcode* ➡ ● ➡ Frame barcode in center of Display ➡ ● ➡ Select number or mail address ➡ ⊠ ➡ *Save to Ph.Book* ➡ ● ➡ *As New Entry* ➡ ● ➡ Complete other fields ➡ ⊚
	● To add to an existing entry, select *As New Detail*.
	● When *MEMORY:* appears in scan results, press ● to enter the items underlined with a dotted line automatically in Phone Book entry window.
Opening saved scan results	● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ● ➡ *Scanned Results* ➡ ● ➡ Select file ➡ ●
	● Select a file and press ⊠ to rename files, open properties or delete files.
	● Some files may not open.
Using linked info	**Start Here** ● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ● ➡ *Scan Barcode* ➡ ● ➡ Frame barcode in center of Display ➡ ● ➡ See below
	Dialing Numbers
	Select phone number ➡ ● ➡ ⌇
	Sending Messages
	Select mail address ➡ ● ➡ Complete message ➡ ⊚
	● When *MAILTO:* appears in scan results, press ● to enter the items underlined with a dotted line automatically in Composition window.
	Accessing Internet Sites
	Select URL ➡ ●

Using images as Wallpaper	● ▶ *Tools* ▶ ● ▶ ⊙ *Doc./Rec.* ▶ *Barcode/ Scan* ▶ ● ▶ *Scan Barcode* ▶ ● ▶ **Frame barcode in center of Display** ▶ ● ▶ **Select image** ▶ ☺ ▶ *Set as Wallpaper* ▶ ● ▶ ● ● For images smaller or larger than Display, Wallpaper Display options appear; follow onscreen prompts.
Saving images & melodies	● ▶ *Tools* ▶ ● ▶ ⊙ *Doc./Rec.* ▶ *Barcode/ Scan* ▶ ● ▶ *Scan Barcode* ▶ ● ▶ **Frame barcode in center of Display** ▶ ● ▶ **Select file** ▶ ☺ ▶ *To Data Folder* ▶ ●
Opening or playing files	● ▶ *Tools* ▶ ● ▶ ⊙ *Doc./Rec.* ▶ *Barcode/ Scan* ▶ ● ▶ *Scan Barcode* ▶ ● ▶ **Frame barcode in center of Display** ▶ ● ▶ **Select file** ▶ ●
Using images for System Graphics	● ▶ *Tools* ▶ ● ▶ ⊙ *Doc./Rec.* ▶ *Barcode/ Scan* ▶ ● ▶ *Scan Barcode* ▶ ● ▶ **Frame barcode in center of Display** ▶ ● ▶ **Select image** ▶ ☺ ▶ *As System* ▶ ● ▶ **Select item** ▶ ● ▶ **Specify image area** ▶ ● ● Some images may be usable without specifying image area.

Pasting to message text	Start Here ● ▶ *Tools* ▶ ● ▶ ⊙ *Doc./Rec.* ▶ *Barcode/Scan* ▶ ● ▶ *Scan Barcode* ▶ ● ▶ **Frame barcode in center of Display** ▶ ● ▶ ☺ ▶ *Send Message* ▶ ● ▶ **See below**
	All Text ● ▶ *S! Mail* or *SMS* ▶ ● ▶ **Complete message** ▶ ⓨ ● S! Mail Composition window opens automatically depending on character count.
	Selected Text ☺ ▶ **Select first character** ▶ ● ▶ **Highlight text range** ▶ ● ▶ *S! Mail* or *SMS* ▶ ● ▶ **Complete message** ▶ ⓨ ● S! Mail Composition window opens automatically depending on character count.
Copying text	Start Here ● ▶ *Tools* ▶ ● ▶ ⊙ *Doc./Rec.* ▶ *Barcode/Scan* ▶ ● ▶ *Scan Barcode* ▶ ● ▶ **Frame barcode in center of Display** ▶ ● ▶ **See below**
	Text ☺ ▶ *Copy* ▶ ● ▶ **Select first character** ▶ ● ▶ **Highlight text range** ▶ ●
	Number, Address or URL **Select number, mail address or URL** ▶ ☺ ▶ *Copy Telephone*, *Copy Address* or *Copy URL* ▶ ●

9

Handy Extras

Scan Card

Saving to Notepad	● ➜ *Tools* ➜ ● ➜ ⊙ *Doc./Rec.* ➜ *Barcode/Scan* ➜ ● ➜ *Scan Card* ➜ ● ➜ Frame card in center of Display ➜ ● ➜ ● ➜ ✉ ➜ *Notepad* ➜ ●
Pasting to message text	Start Here ● ➜ *Tools* ➜ ● ➜ ⊙ *Doc./Rec.* ➜ *Barcode/Scan* ➜ ● ➜ *Scan Card* ➜ ● ➜ Frame card in center of Display ➜ ● ➜ ● ➜ ✉ ➜ *Send Message* ➜ ● ➜ See below
	All Text ● ➜ *S! Mail* or *SMS* ➜ ● ➜ Complete message ➜ ⊻ ● S! Mail Composition window opens automatically depending on character count.
	Selected Text ✉ ➜ Select first character ➜ ● ➜ Highlight text range ➜ ● ➜ *S! Mail* or *SMS* ➜ ● ➜ Complete message ➜ ⊻ ● S! Mail Composition window opens automatically depending on character count.
Copying text	Start Here ● ➜ *Tools* ➜ ● ➜ ⊙ *Doc./Rec.* ➜ *Barcode/Scan* ➜ ● ➜ *Scan Card* ➜ ● ➜ Frame card in center of Display ➜ ● ➜ ● ➜ See below
	Text ✉ ➜ *Copy* ➜ ● ➜ Select first character ➜ ● ➜ Highlight text range ➜ ●

Scan Text

Scanning and pasting during text entry	In a text entry window, ✉ ➜ *Scan* ➜ ● ➜ *Scan Text* ➜ ● ➜ Frame text in center of Display ➜ ● ➜ Select line ➜ ● ➜ ●
Scanning more text	● ➜ *Tools* ➜ ● ➜ ⊙ *Doc./Rec.* ➜ *Barcode/Scan* ➜ ● ➜ *Scan Text* ➜ ● ➜ Frame text in center of Display ➜ ● ➜ Select line ➜ ● ➜ ● ➜ ✉ ➜ *Continue Part* or *Scan More* ➜ ● ● Select *Continue Part* to enter additional text or *Scan More* to enter text after a line break.
Saving scan results	● ➜ *Tools* ➜ ● ➜ ⊙ *Doc./Rec.* ➜ *Barcode/Scan* ➜ ● ➜ *Scan Text* ➜ ● ➜ Frame text in center of Display ➜ ● ➜ Select line ➜ ● ➜ ● ➜ ✉ ➜ *Save* ➜ ●
Saving linked info to Phone Book	● ➜ *Tools* ➜ ● ➜ ⊙ *Doc./Rec.* ➜ *Barcode/Scan* ➜ ● ➜ *Scan Text* ➜ ● ➜ Frame text in center of Display ➜ ● ➜ Select line ➜ ● ➜ Select number or mail address ➜ ✉ ➜ *Save to Ph.Book* ➜ ● ➜ *As New Entry* ➜ ● ➜ Complete other fields ➜ ⊻ ● To add to an existing entry, select *As New Detail*.
Opening saved scan results	● ➜ *Tools* ➜ ● ➜ ⊙ *Doc./Rec.* ➜ *Barcode/Scan* ➜ ● ➜ *Scanned Results* ➜ ● ➜ Select file ➜ ● ● Select a file and press ✉ to rename files, open properties or delete files. ● Some files may not open.

Using linked info	Start Here ● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ● ➡ *Scan Text* ➡ ● ➡ **Frame text in center of Display** ➡ ● ➡ **Select line** ➡ ● ➡ ● ➡ **See below**
	Dialing Numbers Select phone number ➡ ● ➡ ☎
	Sending Messages Select mail address ➡ ● ➡ **Complete message** ➡ ☼
	Accessing Internet Sites Select URL ➡ ●
Pasting to message text	Start Here ● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ● ➡ *Scan Text* ➡ ● ➡ **Frame text in center of Display** ➡ ● ➡ **Select line** ➡ ● ➡ ● ➡ ⊠ ➡ *Send Message* ➡ ● ➡ **See below**
	All Text ● ➡ *S! Mail* or *SMS* ➡ ● ➡ **Complete message** ➡ ☼ ● S! Mail Composition window opens automatically depending on character count.
	Selected Text ⊠ ➡ **Select first character** ➡ ● ➡ **Highlight text range** ➡ ● ➡ *S! Mail* or *SMS* ➡ ● ➡ **Complete message** ➡ ☼ ● S! Mail Composition window opens automatically depending on character count.

Copying text	Start Here ● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ● ➡ *Scan Text* ➡ ● ➡ **Frame text in center of Display** ➡ ● ➡ **Select line** ➡ ● ➡ ● ➡ **See below**
	Text ⊠ ➡ *Copy* ➡ ● ➡ **Select first character** ➡ ● ➡ **Highlight text range** ➡ ●
	Number, Address or URL Select number, mail address or URL ➡ ⊠ ➡ *Copy Telephone*, *Copy Address* or *Copy URL* ➡ ●

Kanji Grabber

Scanning and pasting during text entry	In a text entry window, ⊠ ➡ *Scan* ➡ ● ➡ *Kanji Grabber* ➡ ● ➡ **Frame kanji in Loupe** ➡ ● ➡ **Scan results appear** ➡ ●

9

Handy Extras

Osaifu-Keitai®

❓ Cannot use Osaifu-Keitai® (S! FeliCa)

● Battery may be low. Charge battery or install a charged battery.

❓ Recognition via reader/writer takes time

● Check 🔁 logo area. Foreign articles can block/hamper recognition.

❓ Call Remote Lock does not activate even after specified number of Missed Calls

● Missed Call count is reset by calls from other numbers. If series is interrupted, start over from the beginning.
● When Call Forwarding is active, Missed Calls may not be recorded.

Wakeup TV

❓ TV does not activate with specified channel

● If Wakeup TV Time arrives while TV is active, channel does not switch to the specified one.

Voice Recorder

❓ Cannot record properly

● If incompatible microphone is connected, recording may fail.

❓ Noise/skipping occurs

● Avoid shocks to handset while recording; may cause noise or skipping.

❓ Recording takes time to start

● Recording window may take longer to open as more Voice files are saved on Memory Card.

Scanning Barcode/Card/Text

❓ Cannot read barcodes properly

● Scan may fail if barcode is dirty or unclear.
● Scan may fail if barcode is scanned under inadequate light.
● Scan may fail if multiple barcodes are captured at one time.

❓ Cannot read barcodes during text entry

● Scanning is not available during calls or when mobile camera is active.

❓ Cannot read barcode images in Data Folder automatically

● When scan fails, follow onscreen instructions and select next barcode image manually.

❓ Cannot scan business cards properly

● Scan fails if business card is printed in light-colored text on a dark background, handwritten or printed in casual/decorative fonts, decorated with a background pattern, or designed with both vertical and horizontal text.
● Scan may fail if business card is printed in light-colored text on a light background, printed in italics or extremely small fonts, decorated with a logo or logo-like text, printed on a glossy paper or other material, or dirty/folded.

❓ Cannot scan text properly

● Scanning over 35 characters at one time may yield poor results.
● Adjust to frame text in [ ]. Letters at the ends may be distorted.