Internet Services

5

Internet Services

Access Mobile sites via Yahoo! Keitai or Internet sites via PC Site Browser.
View Web page contents or download media files.

The Internet

Mobile Sites

Tap Yahoo! to access Yahoo! Keitai

Yahoo! Keitai

PC Sites

Use PC Site Browser to access PC sites

- In this guide, "Yahoo! Keitai" refers to SoftBank Mobile Internet portal and service itself. "PC sites" are sites accessible via PC Site Browser. "Internet" refers to both Internet and Mobile Internet sites.
- A separate subscription is required for Internet services.
- Before using Internet, retrieve Network information.

Note

- Internet connections incur Packet Communication charges.

Web Certificates (SSL/TLS)

Secure Sockets Layer (SSL) and Transport Layer Security (TLS) are encryption protocols for secure Internet transmissions of important/sensitive information (credit card numbers, etc.) and authentication.
Confirm electronic certificates saved on handset (P.5-12, P.5-14).

Note

- Using SSL/TLS
  When a security notice appears, subscribers must decide for themselves whether or not to open a page.
  Opening secure pages constitutes agreement to the terms of usage, SOFTBANK MOBILE Corp., VeriSign Japan K.K., Cybertrust Japan Co., Ltd., Entrust Japan Co., Ltd., GlobalSign K.K., RSA Security Inc. and SECOM Trust Systems Co., Ltd. are not liable for the security of SSL/TLS. No liability is assumed for any damage associated with SSL/TLS use.

Opening Saved Pages

Retrieved Mobile Internet pages are temporarily saved in a cache. The cache remains even after a session ends or handset is turned off. When full, the oldest pages are automatically deleted to make room for new ones.
When a saved page is opened again, it may open from the Cache. For the latest content, reload the page.

- When another USIM Card is inserted, cache contents are automatically deleted.
- When a page with an expiry date is saved, the page is automatically deleted upon expiry.

Yahoo! Keitai

Use Yahoo! Keitai to view page contents or download image/music files.
Alternatively, access Yahoo! Keitai from Main menu, History, Bookmarks, Web search, or by entering URL.

Yahoo! Keitai Main Menu

1 **Tap Yahoo!**

2 **Select an item**

- When accessing Mobile site for the first time, a screen for Retrieving Network Information appears at **1**. After the retrieval, website appears.
- To open PC Site Browser from Yahoo! Keitai, tap More → *Switch to PC site browser* → *This page* or *Link*.

Note

- When *Send referer* is set to *Not send*, pages may not appear (⊘P.5-12).

Viewing Page from Yahoo! Keitai Menu List

1 **Tap Menu → Tap Yahoo! →** *Menu list*

Entering URL

1 **Tap Menu → Tap Yahoo! →** *Enter URL*

- Default: "http://" is set.

2 **Enter URL**

- Alternatively, in a page, tap More → *Enter URL* → Enter URL.

Entering URL from History

Accessed URLs from Yahoo! Keitai are saved in Yahoo! Keitai History.
Access URL to save up to 50 History.

1 **Tap Menu → Tap Yahoo! →** *History*

2 **Select website**

- Alternatively, in a page, tap More → *History* → Select website.

Advanced

🔧 Settings

PC Site Browser

Use PC Site Browser to view page contents or download image/music files from PC sites. Alternatively, access PC Site Browser from Homepage, History, Bookmarks, Web search, or by entering URL.

PC Site Browser Homepage

1 **Tap Menu → Tap Yahoo! →** *PC site browser → Homepage*

● If a warning appears, tap OK.

2 **Select an item**

●Activate PC Site Browser, 📄 appears.
●In PC Site Browser, only document files and widgets can be downloaded or streamed.
●Some sites may not appear correctly.
●To open Yahoo! Keitai from PC Site Browser, tap More → *Switch to Yahoo! Keitai*.

Note

● When *Send referer* is set to *Not send*, pages may not open (❷P.5-14).
● Viewing rich contents sites may incur high Packet Communication charges.

Entering URL

1 **Tap Menu → Tap Yahoo! →** *PC site browser → Enter URL*

● Default: "http://" is set.

2 **Enter URL**

● If a warning appears, tap OK.

Entering URL from History

Accessed URLs from PC Site Browser are saved in History.
Access URL to save up to 50 items in History.

1 **Tap Menu → Tap Yahoo! →** *PC site browser → History*

2 **Select website**

● When warning appears, tap OK.

●Alternatively, in a page, tap More → *History* → Select website.

Advanced

Advanced Settings ☞P.5-12

● Deleting Access History
● Sending Access History
● Viewing Access History Details

Settings

● Delete Cache/Cookie/Certificates/RSS Feed List (☞P.14-14)
● Show/Hide Manufacture Number (☞P.14-15)
● Send/Hide Referrer (☞P.14-15)
● Select Cookie Setting (☞P.14-15)
● Select Script Setting (☞P.14-15)
● Confirm Root Certificate (☞P.14-15)
● Set Certificate Retention Period (☞P.14-15)
● Show/Hide Warning (☞P.14-15)
● Show/Hide Secure Prompt (☞P.14-15)
● Initialize Browser (☞P.14-15)
● Reset Settings (☞P.14-15)

Page Operations

Text and images shown in page can be zoom in/out.
Alternatively, select menu to link target page, set function with radio button.

Selecting Menu

Yahoo! Keitai
Top Page

1 ◄ / ▲ / ▼ / ►: **Scroll to up/down/left/right, or move the cursor**

2 **Highlight menu → Select**

● Alternatively, tap an item directly to select the link.
● Alternatively, touch the screen directly to scroll.
● Press CLEAR with no previous page, you are prompted to close Internet connection. Choose **Yes** to close it.
● Tap Back or press CLEAR to return previous page.
● Highlight link and tap Select; move to target page.
● Tap Forward to back to the status before tapping Back or pressing CLEAR.
● Rotate handset to show image view horizontally to Landscape view.
  Operations are the same as Landscape view.
● Press ⦿ to change to full screen view. Press it again to return to the previous view.
● In case of PC Site Browser, touching and holding an item will open it in a new tab (not available in full screen view).
● Press ⦿ for 1 + seconds to mute BGM in page.

Entering Text

1 **Select Text field**

2 **Enter text**

Note

● Text entry and item selection varies by page.

Page Zoom

1 **Tap More → *Zoom in/out***

2 **Tap 🔘 / 🔘 to adjust zoom level**

● Alternatively, use 🔘 to adjust zoom.

● For PC Site Browser, tap Zoom → tap 🔘 / 🔘 to adjust zoom level.

● For PC Site Browser, touch and hold place on screen without link to view zoom button. Move stylus upward/downward to adjust zoom.

Multi Page (Tab)

Use tabs at the top of Display to view pages.
Open up to three pages simultaneously.

1 **Tap ➕**

2 **Tap tab → Access target information(◉P.5-15)**

3 **Select tab to Toggle Pages**

● Tap ➖ to close viewing tab.

● Yahoo! Keitai and PC sites cannot be open simultaneously.

● Some pages may open in a new tab automatically.

● When multiple tabs are open, some pages may be partially obscured. Close unnecessary tabs.

Buttons & Check Boxes

❶ Radio button
Select an item only. Select an item with
○ to select it (appearing as ◉).

❷ Menu field
Open a menu and select an item.
Highlight menu → select an item.

❸ Check box
Select multiple items. Select an item with
☐ to select it (appearing as ☑).

❹ Command button
Perform operations assigned to a button.
Highlight a command button → select
an item.

Streaming from Page Link

1 Open a page containing a page link

2 Select a link

Advanced

🔧 Advanced Settings

■ Yahoo! Keitai (☞P.5-10)
● Showing/Hiding Keypad on Pages
● Copying Text
● Refreshing Page
● Entering URL from History
● Searching with New Window
● Searching Text
● Moving to Top/Bottom of Page
● Sending URL
● Zooming Page in/out
● Viewing Flash®

● Viewing Only Selected Frame
● Viewing Page Details
● Moving to Main Menu
● Exiting Browser
■ PC Site Browser (☞P.5-12)
● Capturing Screen in a Page
● Copying Text
● Entering URL from History
● Searching with New Window
● Searching Text
● Sending URL
● Moving to Top/Bottom of Page
● Viewing Flash®
● Viewing Only Selected Frame
● Viewing Page Details
● Opening Homepage
● Changing Page Layout
● Exiting Browser

🔧 Settings

■ Yahoo! Keitai
● Set Text Size in Yahoo! Keitai Pages (☞P.14-4)
● Change Page Font Size (☞P.14-13)
● Set Page Scroll Unit (☞P.14-13)
● Show/Hide Page Images (☞P.14-13)
● Play/Mute Page Sounds (☞P.14-13)

■ PC Site Browser
● Set Text Size in PC Site Browser (☞P.14-4)
● Change Page Font Size (☞P.14-13)
● Show/Hide Page Navigation When Zooming (☞P.14-14)
● Show/Hide Page Images (☞P.14-14)
● Play/Mute Page Sounds (☞P.14-14)

Bookmarks & Saved Pages

Save site URLs to Bookmarks. Save page content to Saved Pages. Open pages without establishing an Internet connection.

Saving Bookmarks

Save up to 50 bookmarks for Yahoo! Keitai and PC site, each.

1 **Open a page**

2 **Tap Bookmark → *Save***

3 **Enter title**

Accessing Bookmarks

1 **Tap Menu → Tap Yahoo! →** *PC site browser* **as required →** *Bookmarks*

2 **Select a bookmark**

Note

● Internet connections may incur Packet Communication charges.

Saving Pages

Save up to 30 pages each for Yahoo! Keitai and PC Sites, each.

1 **Open a page**

2 **Tap More (for some windows, tap More → *Saved pages*) →** *Save*

3 **Enter title**

Opening Saved Pages

1 **Tap Menu → Tap Yahoo! →** *PC site browser* **as required →** *Saved pages*

2 **Select a page**

Note

● If USIM Card inserted when page was saved is replaced, saved page will not open.

Advanced

🔧 **Advanced Settings** ☞ P.5-15

● Opening Bookmarked Website
● Saving Bookmark by Direct Entry
● Editing Bookmark Title/URL
● Deleting Bookmarks
● Creating Folders in Bookmark List
● Sending Bookmark URL
● Sending Bookmark URL via Bluetooth®
● Sending Bookmark URL via Infrared
● Sending Bookmark URL via IC Transmission
● Moving Bookmark to Folders
● Changing Bookmark Order
● Saving Bookmark to Data Folder
● Viewing Bookmark Details
● Opening Saved Pages in a Page
● Renaming Saved Pages
● Deleting Saved Pages
● Changing Order of Saved Pages

RSS Feed

Register RSS compatible websites; viewing content updates without accessing websites.

Registering RSS

Open RSS compatible website, 🔝 appears.

1 Tap More → *Register in RSS feed*

2 Select RSS to register → Tap **Select**

● After registration, Auto update confirmation appears. Tap Yes to start automatic update. Tap No not to start automatic update.

●In a page with RSS link, select link to register.

Viewing Update Information

1 Tap Menu → Tap Yahoo! → *PC site browser* → *RSS feed*

2 Select RSS to view → Select **items from list**

●When there is no update information, confirmation appears. Choose *Yes*.
●When selecting titles in contents list, confirmation appears. Choose *Yes* or *No*.
●View Read/Unread with 📑 / 📑 located at the side of feed list title.

Updating RSS

1 Tap Menu → Tap Yahoo! → *PC site browser* → *RSS feed*

2 Tap Refresh

3 RSS Update operation

■**To Update Selected RSS**
Each item → Check RSS to update → Tap *Refresh*

■**To Update All RSS at Once**
All items
● Tap Cancel to stop update.

Advanced Settings

📞 **Advanced Settings**

Yahoo! Keitai

Showing/Hiding Keypad on Pages

In a page, tap More → *Show keypad* or *Hide keypad*

● In some pages, tap numbers on Keypad, ✻ , or # to select an item.

● Move slide shown to adjust the transparency of Keypad.

Copying Text

In a page, tap More → *Copy text*

■ **To Copy Selected Text**
Tap the first character to copy → Tap Start point → Tap the last character to copy → Tap End point

■ **To Copy All Text in Text Entry Window**
Tap All

Refreshing Page

In a page, tap More → *Refresh*

Entering URL from History

■ **From Yahoo! Keitai**
Tap Menu → Tap Yahoo! → *Enter URL* → Tap More → *Insert* → *EnterURL logs* → Select URL

■ **From a Page**
In a page, tap More → *Enter URL* → Tap More → *Insert* → *EnterURL logs* → Select URL

● Up to ten URL logs appear, the latest first. When the limit is reached, the oldest page is deleted automatically.

Searching with New Window

In a page, tap More → *Web search* → Enter text

● Alternatively, tap Menu → Tap Yahoo! → *Web Search*.

Searching Text

In a page, tap More → *Search* → Enter text to search

● Words that match are highlighted. Tap Prev. or Next to search for the previous or next match.

Moving to Top/Bottom of Page

In a page, tap More → *Jump* → *Top/Bottom*

Sending URL

In a page, tap More → *Send URL* → *S! Mail* or *SMS* → (🔾P.4-4 S! Mail ❷, P.4-7 SMS ❷)

Deleting Access History

Tap Menu → Tap Yahoo! → *History* → Tap Delete
→ Check history to delete → Tap Delete → *Yes*

● Alternatively, in a page, tap More → *History* →
Tap Delete → Check history to delete →
Tap Delete → *Yes*.

Sending Access History

Tap Menu → Tap Yahoo! → *History* → Tap
Send URL → *S! Mail* or *SMS* → Select history
to send → *Yes* → (◎P.4-4 S! Mail ❷, P.4-7 SMS ❷)

● Alternatively, in a page, tap More → *History*
→ Tap Send URL → *S! Mail* or *SMS* → Select
history to send → *Yes*.

Viewing Access History Details

Tap Menu → Tap Yahoo! → *History* →
Tap Details → Select history

● Alternatively, in a page, tap More → *History* →
Tap Details → Select history.

Zooming Page in/out

In a page, tap More → *Zoom in/out* → Adjust size

Viewing Flash®

In a page, open Flash® file, and tap More →
Flash® menu

■ **To Pause/Play**
Pause or *Play*

■ **To Play from Beginning**
Play from start

Viewing Only Selected Frame

In a page, tap More → *Frame in*

● Some pages may be divided into multiple sections.
Such a section is referred to as "Frame".

● To return to the normal display, tap More →
Frame out.

Viewing Page Details

In a page, tap More → *Details*

■ **To View Page Information**
Page information

■ **To View Server Certificate**
Server certification

Moving to Main Menu

In a page, tap More → *Yahoo! Keitai*

Showing/Hiding Navigation Bar

In a page, tap More → *Settings* →
Under *Navigation bar*, *On* or *Off*

Changing Font Size

In a page, tap More → *Settings* → *Font size* →
Select an item

Changing Scroll Unit

In a page, tap More → *Settings* → *Scroll unit*
→ Select an item

Changing Character Code

In a page, tap More → *Settings* → *Encoding*
→ Select an item

● If page text appears garbled, changing character
encoding may solve the problem.

Setting Show/Play of Image/Sound

In a page, tap More → *Settings* → *Downloads*

■ **To Set Image**
Under *Display image, On* or *Off*

■ **To Set Sound**
Under *Play sounds, On* or *Off*

Setting Saving Location

In a page, tap More → *Settings* → *Save to* →
Phone/Memory card/Ask each time

Clearing Cache

In a page, tap More → *Settings* → *Memory
manager* → *Clear cache* → *Yes*

Deleting Cookies

In a page, tap More → *Settings* → *Memory
manager* → *Delete cookies* → *Yes*

Deleting Certificates

In a page, tap More → *Settings* → *Memory
manager* → *Delete certificates* → *Yes*

Setting Manufacture Number Notification

In a page, tap More → *Settings* → *Security* →
Under *Manufacture number*, *On* or *Off*

Sending/Not Sending Referrer Information

In a page, tap More → *Settings* → *Security* → *Send referer* → Select an item

● Referrer is a link source URL information. It is sent to Web server when accessing websites.

Enabling Cookies

In a page, tap More → *Settings* → *Security* → *Cookies* → Select an item

● Select *Confirm* for acceptance confirmation every time before a Cookie is saved.

● Cookie automatically saves identification information of visitors to handset. Cookies contain user information and allow sites to recognize users and track preferences.

Enabling Script

In a page, tap More → *Settings* → *Security* → *Script* → Select an item

Checking Root Certificates

In a page, tap More → *Settings* → *Security* → *Root certificates* → Select a certificate

● View electronic certificate preinstalled on handset.

Certificating Retention

In a page, tap More → *Settings* → *Security* → *Certificate retention* → Select an item

Showing/Hiding Secure Prompt

In a page, tap More → *Settings* → *Security* → Under *Secure prompt, On* or *Off*

Initializing Saved Information

In a page, tap More → *Settings* → *Initialized browser* → Enter Phone Password → Tap OK → *Yes*

● Initialize browser settings or information such as Bookmarks or Saved pages.

Resetting Yahoo! Keitai Settings

In a page, tap More → *Settings* → *Reset settings* → Enter Phone Password → Tap OK → *Yes*

Exiting Browser

In a page, tap More → *Exit* → *Yes*

PC Site Browser

Capturing Screen in a Page

In a page, tap More → *Capture screen*

● Save screen to Pictures folder.

Copying Text

In a page, tap More → *Copy text*

■ To Copy Selected Text
Tap the first character to copy → Tap Start point → Tap the last character to copy → Tap End point

■ To Copy All Text in Text Entry Window
Tap All

Entering URL from History

■ From PC Site Browser
Tap Menu → Tap Yahoo! → *PC site browser* → *Enter URL* → Tap More → *Insert* → *EnterURL logs* → Select URL

■ From a Page
In a page, tap URL field → Tap More → *Insert* → *EnterURL logs* → Select URL

● Up to ten URL logs appear, the latest first. When the limit is reached, the oldest page is deleted automatically.

Searching with New Window

In a page, tap More → *Web search* → Enter text

● Alternatively, tap Menu → Tap Yahoo! → *PC site browser* → *Web Search*.
● If a warning appears, tap OK.

Searching Text

In a page, tap More → *Search* → Enter text to search

● Matching words are highlighted. Tap Prev. or Next to search for previous or next match.

Sending URL

In a page, tap More → *Send URL* → *S! Mail* or *SMS* → (◎P.4-4 S! Mail ➋, P.4-7 SMS ➋)

Moving to Top/Bottom of Page

In a page, tap More → *Quick movement* → Tap area to view → Tap Select

Deleting Access History

Tap Menu → Tap Yahoo! → *PC site browser* → *History* → Tap Delete → Check history to delete → Tap Delete → *Yes*

● Alternatively, in a page, tap More → *History* → Tap Delete → Check history to delete → Tap Delete → *Yes*.

Sending Access History

Tap Menu → Tap Yahoo! → *PC site browser* → *History* → Tap Send URL → *S! Mail* or *SMS* → Select history to send → *Yes* → (◎P.4-4 S! Mail ➋, P.4-7 SMS ➋)

● Alternatively, in a page, tap More → *History* → Tap Send URL → *S! Mail* or *SMS* → Select history to send → *Yes*.

Viewing Access History Details

Tap Menu → Tap Yahoo! → *PC site browser* → *History* → Tap Details → Select history

● Alternatively, in a page, tap More → *History* → Tap Details → Select history.

Viewing Flash®

In a page, open Flash® file, and tap More → *Flash® menu*

■ **To Pause/Play**
 Pause or *Play*

■ **To Play from Beginning**
 Play from start

Viewing Only Selected Frame

In a page, tap More → *Frame in*

● Some pages may be divided into multiple sections. Such a section is referred to as "Frame".
● To return to the normal display, tap More → *Frame out.*

Viewing Page Details

In a page, tap More → *Details*

■ **To View Page Information**
 Page information

■ **To View Server Certificate**
 Server certification

Opening Homepage

In a page, tap More → *Homepage*

Changing Font Size

In a page, tap More → *Settings* → *Font size* → Select an item

Setting the Guide Show/Hide When Zoom

In a page, tap More → *Settings* → Under *Page navigation, On* or *Off*

Changing Character Code

In a page, tap More → *Settings* → *Encoding* → Select an item

● If page text appears garbled, changing character encoding may solve the problem.

Setting Show/Play of Image/Sound

In a page, tap More → *Settings* → *Downloads*

■ **To Set Image**
 Under *Display image, On* or *Off*

■ **To Set Sound**
 Under *Play sounds, On* or *Off*

Setting the Saving Location

In a page, tap More → *Settings* →
Save to → *Phone/Memory card/Ask each time*

Clearing Cache

In a page, tap More → *Settings* →
Memory manager → *Clear cache* → *Yes*

Deleting Cookies

In a page, tap More → *Settings* →
Memory manager → *Delete cookies* → *Yes*

Deleting Certificates

In a page, tap More → *Settings* →
Memory manager → *Delete certificates* → *Yes*

Deleting RSS Feed List

In a page, tap More → *Settings* →
Memory manager → *Delete RSS feed list* →
Enter Phone Password → Tap OK → *Yes*

Setting Manufacture Number Notification

In a page, tap More → *Settings* → *Security* →
Under *Manufacture number, On* or *Off*

Sending/Not Sending Referrer Information

In a page, tap More → *Settings* → *Security* →
Send referer → Select an item

● Referrer is a link source URL information. It is sent
to Web server when accessing websites.

Enabling Cookies

In a page, tap More → *Settings* → *Security* →
Cookies → Select an item

● Select *Confirm* to show acceptance confirmation
every time before a Cookie is saved.

● Cookie automatically saves identification
information of visitors to handset. Cookies contain
user information and allow websites to recognize
users and track preferences.

Enabling Script

In a page, tap More → *Settings* → *Security* →
Script → Select an item

Checking Root Certificates

In a page, tap More → *Settings* → *Security* →
Root certificates → Select a certificate

● View electronic certificate preinstalled on handset.

Certificate Retention

In a page, tap More → *Settings* → *Security* →
Certificate retention → Select an item

Showing/Hiding Secure Prompt

In a page, tap More → *Settings* → *Security* →
Under *Secure prompt*, *On/Off*

Viewing Warning Messages

In a page, tap More → *Settings* → Under
Warning messages, *On/Off*

Initializing Saved Information

In a page, tap More → *Settings* → *Initialized browser*
→ Enter Phone Password → Tap OK → *Yes*

● Initialize browser settings or information such as
Bookmarks or Saved pages.

Resetting PC Site Browser

In a page, tap More → *Settings* → *Reset settings*
→ Enter Phone Password → Tap OK → *Yes*

Changing Page Layout

In a page, tap More → *Small screen* or *PC screen*

Exiting Browser

In a page, tap More → *Exit*

Page Operations

Saving Phone Number/Mail Address

In a page containing phone number/mail address, select phone number or mail address → *Save Number* → *Phone* or *USIM*

■ To Save as a New Entry
New → (**☉**P.2-17 Creating New Entries **②**)

■ To Update Entry
Update → Search and select Phone Book entry (**☉**P.2-18) → Enter each item (**☉**P.2-17)

● Available phone numbers and mail addresses appear underlined.

Sending Mail to Number/Mail Address

In a page containing phone number/mail address, select phone number or mail address → *Create Message* → *S! Mail* or *SMS* → (**☉**P.4-5 S! Mail **⑤**, P.4-7 SMS **⑤**)

● Available phone numbers and mail addresses appear underlined.

Calling Phone Number

In a page containing phone number, select phone number → *Voice Call* or *Video Call*

● Available phone numbers appear underlined.

Using URL to Open Another Page

Select URL in a page

● Available URLs appear underlined.

Saving Images/Other Files from Pages

■ To Save Page Images
In a page, tap More → *Save files* → *Save items* → Select image to save → Tap Save

●For Yahoo! Keitai, select an image to save only when there are multiple images.

●If image is saved as GIF file or JPEG file and is not copy protected file, *Pictures*/*My Pictograms*/*Mail Art* may appear when saving.
Select *Pictures* to saved to Pictures in Data Folder.
Select *My Pictograms* to saved to My Pictograms in Data Folder.
Select *Mail Art* to save to Mail Art in Data Folder.

■ To Save Background Images
In a page, tap More → *Save files* → *Save BG image* → Tap Save → Select save location

■ To Save Background Sound
In a page, tap More → *Save files* → *Save items* → Select background sound to save → Tap Save

●They cannot be saved with PC Site Browser.

●In a page with image, tap 🎵 to save sound.

■ To Save Linked Files
In a page, select a link → Tap Save

●For Auto Save files, tap link to save files.

●If file details appear, select from following options: (available options vary by file type).
Play: Play file (e.g., media file)
Back to browser: Return to page
Set as: Save file to Ringtone

●If files with same name exist, notification appears, choose *Yes* to save it with a different name. Choose *No* to edit the file name.

Bookmarks

Opening Bookmarked Website

In a page, tap Bookmark → *Open list* → Select a bookmark

● Tap 📋 or 📷 in Bookmark list to toggle between List view and Thumbnail view.

Saving Bookmark by Direct Entry

■ In Yahoo! Keitai
Tap Menu → Tap Yahoo! → *Bookmarks* → Tap Add → Tap URL field → Enter URL → Tap Name field → Enter name → Tap Save

■ In PC Site Browser
Tap Menu → Tap Yahoo! → *PC site browser* → *Bookmarks* → Tap Add → Tap URL field → Enter URL → Tap Name field → Enter name → Tap Save

■ In a Page
In a page, tap Bookmark → *Open list* → Tap Add → Tap URL field → Enter URL → Tap Name field → Enter name → Tap Save

Editing Bookmark Title/URL

■ In Yahoo! Keitai
Tap Menu → Tap Yahoo! → *Bookmarks* → Tap Edit → Select bookmark to edit → Tap URL field → Enter URL → Tap Name field → Enter name → Tap Save

■ In PC Site Browser
Tap Menu → Tap Yahoo! → *PC site browser* → *Bookmarks* → Tap Edit → Select bookmark to edit → Tap URL field → Enter URL → Tap Name field → Enter name → Tap Save

■ In a Page

In a page, tap Bookmark → *Open list* → Tap Edit → Select bookmark to edit → Tap URL field → Enter URL → Tap Name field → Enter name → Tap Save

Deleting Bookmarks

■ In Yahoo! Keitai

Tap Menu → Tap Yahoo! → *Bookmarks* → Tap Delete → Check bookmarks to delete → Tap Delete → *Yes*

■ In PC Site Browser

Tap Menu → Tap Yahoo! → *PC site browser* → *Bookmarks* → Tap Delete → Check bookmarks to delete → Tap Delete → *Yes*

■ In a Page

In a page, tap Bookmark → *Open list* → Tap Delete → Check bookmarks to delete → Tap Delete → *Yes*

● In Thumbnail view, select bookmarks to delete → *Yes*.

Creating Folders in Bookmark List

■ In Yahoo! Keitai

Tap Menu → Tap Yahoo! → *Bookmarks* → Tap More → *Create folder* → Enter folder name

■ In PC Site Browser

Tap Menu → Tap Yahoo! → *PC site browser* → *Bookmarks* → Tap More → *Create folder* → Enter folder name

■ In a Page

In a page, tap Bookmark → *Open list* → Tap More → *Create folder* → Enter folder name

Sending Bookmark URL

■ In Yahoo! Keitai

Tap Menu → Tap Yahoo! → *Bookmarks* → Tap More → *Send* → *Via message* → *S! Mail* or *SMS* → Check bookmarks to send → Tap Send → (●P.4-4 S! Mail ②, P.4-7 SMS ②)

■ In PC Site Browser

Tap Menu → Tap Yahoo! → *PC site browser* → *Bookmarks* → Tap More → *Send* → *Via message* → *S! Mail* or *SMS* → Check bookmark to send → Tap Send → (●P.4-4 S! Mail ②, P.4-7 SMS ②)

■ In a Page

In a page, tap Bookmark → *Open list* → Tap More → *Send* → *Via message* → *S! Mail* or *SMS* → Check bookmark to send → Tap Send → (●P.4-4 S! Mail ②, P.4-7 SMS ②)

● In Thumbnail view, select bookmarks to send.

Sending Bookmark URL via Bluetooth®

■ In Yahoo! Keitai

Tap Menu → Tap Yahoo! → *Bookmarks* → Tap More → *Send* → *Via Bluetooth* → Check bookmarks to send → Tap Send → (●P.13-6 Sending One Item at a Time ②)

■ In PC Site Browser

Tap Menu → Tap Yahoo! → *PC site browser* → *Bookmarks* → Tap More → *Send* → *Via Bluetooth* → Check bookmarks to send → Tap Send → (●P.13-6 Sending One Item at a Time ②)

■ In a Page

In a page, tap Bookmark → *Open list* → Tap More → *Send* → *Via Bluetooth* → Check bookmarks to send → Tap Send → (●P.13-6 Sending One Item at a Time ②)

● In Thumbnail view, select bookmarks to send.

Sending Bookmark URL via Infrared

■ In Yahoo! Keitai

Tap Menu → Tap Yahoo! → *Bookmarks* → Tap More → *Send* → *Via infrared* → Check bookmarks to send → Tap Send (●P.13-3)

■ In PC Site Browser

Tap Menu → Tap Yahoo! → *PC site browser* → *Bookmarks* → Tap More → *Send* → *Via infrared* → Check bookmarks to send → Tap Send (●P.13-3)

■ In a Page

In a page, tap Bookmark → *Open list* → Tap More → *Send* → *Via infrared* → Check bookmarks to send → Tap Send (●P.13-3)

● In Thumbnail view, select bookmarks to send.

Sending Bookmark URL via IC Transmission

■ In Yahoo! Keitai

Tap Menu → Tap Yahoo! → *Bookmarks* → Tap More → *Send* → *Via IC transmission* → Check bookmark to send → Tap Send (●P.13-8)

■ In PC Site Browser

Tap Menu → Tap Yahoo! → *PC site browser* → *Bookmarks* → Tap More → *Send* → *Via IC transmission* → Check bookmark to send → Tap Send (●P.13-8)

■ In a Page

In a page, tap Bookmark → *Open list* → Tap More → *Send* → *Via IC transmission* → Check bookmark to send → Tap Send (●P.13-8)

● In Thumbnail view, select bookmarks to send.

Moving Bookmark to Folders

■From Yahoo! Keitai

Tap Menu → Tap Yahoo! → *Bookmarks* →
Tap More → *Move* → Check bookmarks to move
→ Tap Move → Select a destination folder

■From PC Site Browser

Tap Menu → Tap Yahoo! → *PC site browser* →
Bookmarks → Tap More → *Move* →
Check bookmarks to move → Tap Move →
Select a destination folder

■From a Page

In a page, tap Bookmark → *Open list* → Tap
More → *Move* → Check bookmarks to move →
Tap Move → Select a destination folder

● To create a new folder to move an item, tap Create
Folder → Enter a new folder name.
● In Thumbnail view, select a bookmark to move →
Select a destination folder.

Changing Bookmark Order

■In Yahoo! Keitai

Tap Menu → Tap Yahoo! → *Bookmarks* →
Tap More → *Change order* → If confirmation
appears, tap OK → Drag a bookmark to desired
location → Tap Done

■In PC Site Browser

Tap Menu → Tap Yahoo! → *PC site browser*
→ *Bookmarks* → Tap More → *Change order*
→ If confirmation appears, tap OK → Drag a
bookmark to desired location → Tap Done

■In a Page

In a page, tap Bookmark → *Open list* →
Tap More → *Change order* → If confirmation
appears, tap OK → Drag a bookmark to desired
location → Tap Done

Saving Bookmark to Data Folder

■In Yahoo! Keitai

Tap Menu → Tap Yahoo! → *Bookmarks* →
Tap More → *Save to Data Folder* → *Phone/
Memory Card* → Select bookmark to save →
Yes

■In PC Site Browser

Tap Menu → Tap Yahoo! → *PC site browser*
→ *Bookmarks* → Tap More → *Save to Data
Folder* → *Phone/Memory Card* → Select
bookmark to save → *Yes*

■In a Page

In a page, tap Bookmark → *Open list* →
Tap More → *Save to Data Folder* → *Phone/
Memory Card* → Select bookmark to save →
Yes

● To save a file to *Memory Card*, insert Memory
Card.

Viewing Bookmark Details

■In Yahoo! Keitai

Tap Menu → Tap Yahoo! → *Bookmarks* →
Tap More → *Details* → Select bookmark

■In PC Site Browser

Tap Menu → Tap Yahoo! → *PC site browser* →
Bookmarks → Tap More → *Details* → Select
bookmark

■In a Page

In a page, tap Bookmark → *Open list* →
Tap More → *Details* → Select bookmark

Saved Pages

Opening Saved Pages in a Page

In a page, tap Saved pages (for some windows,
tap More → *Saved pages*) → *Open list* →
Select saved pages

● In Saved Pages, tap ▤ or ▥ to toggle List/Thumbnail
view.

Renaming Saved Pages

■In Yahoo! Keitai

Tap Menu → Tap Yahoo! → *Saved pages* →
Tap Rename → Select saved pages to edit →
Enter name

■In PC Site Browser

Tap Menu → Tap Yahoo! → *PC site browser*
→ *Saved pages* → Tap Rename → Select saved
pages to edit → Enter name

■In a Page

In a page, tap Saved pages (for some windows,
tap More → *Saved pages*) → *Open list* →
Tap Rename → Select saved pages to edit →
Enter name

Deleting Saved Pages

■ **In Yahoo! Keitai**

Tap Menu → Tap Yahoo! → *Saved pages* →
Tap Delete → Select saved pages to delete → *Yes*

■ **In PC Site Browser**

Tap Menu → Tap Yahoo! → *PC site browser*
→ *Saved pages* → Tap Delete → Select saved
pages to delete → *Yes*

■ **In a Page**

In a page, tap Saved pages (for some windows,
tap More → *Saved pages*) → *Open list* →
Tap Delete → Select saved pages to delete → *Yes*

● In the list, check a saved pages to delete →
Tap Delete → *Yes*.

Changing Order of Saved Pages

■ **In Yahoo! Keitai**

Tap Menu → Tap Yahoo! → *Saved pages* →
Tap Change order → If confirmation appears, tap
OK → Drag saved pages to desired location →
Tap Done

■ **In PC Site Browser**

Tap Menu → Tap Yahoo! → *PC site browser*
→ *Saved pages* → Tap Change order → If
confirmation appears, tap OK → Drag saved page
to desired location → Tap Done

■ **In a Page**

In a page, tap Saved pages (for some windows,
tap More → *Saved pages*) → *Open list* →
Tap Change order → If confirmation appears, tap
OK → Drag saved pages to desired location →
Tap Done

RSS Feed

Prohibiting RSS Update

Tap Menu → Tap Yahoo! → *PC site browser*
→ *RSS feed* → Tap More → *Restrict update* →
Check RSS to prohibit → Tap Select

Deleting RSS

Tap Menu → Tap Yahoo! → *PC site browser* →
RSS feed → Tap Delete → Check RSS to delete
→ Tap Delete → *Yes*

● If *Mark all* is selected, tap Delete → Enter
Phone Password → Tap OK → *Yes*.

Creating Folders in RSS List

Tap Menu → Tap Yahoo! → *PC site browser* →
RSS feed → Tap More → *Create folder* → Enter
folder name

Changing RSS Folder Name

Tap Menu → Tap Yahoo! → *PC site browser*
→ *RSS feed* → Tap More → *Rename folder* →
Select folder → Enter folder name

Sending RSS via Message

Tap Menu → Tap Yahoo! → *PC site browser* →
RSS feed → Tap More → *Send* → *Via message*
→ Check RSS to send → Tap Select → (&P.4-4
Creating/Sending Messages❷)

Sending RSS via Bluetooth®

Tap Menu → Tap Yahoo! → *PC site browser* →
RSS feed → Tap More → *Send* → *Via Bluetooth*
→ Check RSS to send → Tap Select → (&P.13-7
Receiving One Item at a Time❷)

Sending RSS via Infrared

Tap Menu → Tap Yahoo! → *PC site browser* →
RSS feed → Tap More → *Send* → *Via infrared*
→ Check RSS to send → Tap Select (&P.13-3)

Sending RSS via IC Transmission

Tap Menu → Tap Yahoo! → *PC site browser*
→ *RSS feed* → Tap More → *Send* → *Via IC
transmission* → Check RSS to send → Tap Select
(&P.13-8)

Moving RSS to Folder

Tap Menu → Tap Yahoo! → *PC site browser* →
RSS feed → Tap More → *Move* → Check RSS to
move → Tap Select → Select folder to move

● To create a new folder to move to, tap Create
folder → Enter folder name.

Sorting RSS

Tap Menu → Tap Yahoo! → *PC site browser* →
RSS feed → Tap Change order → Drag RSS to
desired location → Tap OK

Saving RSS to Data Folder

Tap Menu → Tap Yahoo! → *PC site browser*
→ *RSS feed* → Tap More → *Export* → *Phone/
Memory card* → *Yes*

- The save location can be set to Memory Card if
  inserted.

Loading RSS

Tap Menu → Tap Yahoo! → *PC site browser* →
RSS feed → Tap More → *Import* → Select file
to load

■ To Add RSS Feed
Add → *Yes*/*No*

■ To Delete All and Add RSS Feed
Delete & Overwrite → Enter Phone Password
→ Tap OK

- After saving, Update confirmation appears. Choose
  Yes to update.

Viewing RSS Details

Tap Menu → Tap Yahoo! → *PC site browser* →
RSS feed → Tap More → *Details* → Select RSS

Memo