9

Handy Extras

Calendar

Opening Calendar

1 ● ➜ *Tools* ➜ ● ➜ In PIM/Lifestyle menu, *Calendar* ➜ ●

Calendar Window

Key Assignments

✳	Open previous page	8	Go to (Enter Date)
#	Open next page	9	Find (By Category)
2	Stamp[1]	0	Help
4	Set Color	☈	Toggle view
5	Go to (Today)	◉	Select week[2]
6	Find (By Subject)	◉	Select date

[1]Available in Month/3Month View.
[2]In Week View, select time block.

Saving Schedules

Follow these steps to save subject, start/end date/time, Alarm and schedule details: Either Subject or Description must be saved per entry.

1 **In Calendar window, select date ➜ ●**

2 *<Add New Entry>* ➜ ●

3 **Enter subject ➜ ●**

Start Date&Time

XXXX / XX / XX
YYYY   MM   DD

15 : 05
HH   MM

4 **Enter start date/time ➜ ●**

New Entry

Subject:
Conference
Start:
XX/XX/XX 16:00
End:
XX/XX/XX 16:00

5 *End:* ➜ ● ➜ Enter end date/time ➜ ●

6 *Alarm:* ➜ ●

7 *Alarm Time:* ➜ ● ➜ Select time ➜ ● ➜ ✉

8 *Description:* ➜ ● ➜ Enter schedule details ➜ ●

9 ✉ ➜ Saved

All-Day Schedule
In 4, ✉ ➜ ● ➜ From 8
Custom Alarm Time
In 7, ◉ *Alarm Time:* ➜ ● ➜ *Other* ➜ ● ➜ Enter date/time ➜ ● ➜ ✉ ➜ From 8

Advanced

🔗 ●Changing default view ●Changing date color ●Changing task view option ●Adding stamps (Month View) ●Hiding entries ●Removing/restoring preset holidays ●Setting Category/Location ●Saving repetitive schedules (And more on **P.9-30** - **9-31**)

At Alarm Time

Alarm activates; sounds/vibrates by related settings.

To stop Alarm, press a key.

Opening Schedule
 While Alarm sounds/vibrates, ⌨
When Another Function is Active
● Alarm may not activate until handset returns to Standby.
Incoming Calls
● Active Alarm stops for incoming calls. Information window opens after handset returns to Standby.

Opening Schedules/Tasks

1 In Calendar window, select date ➡ ●

Schedule List

2 Select schedule or task ➡ ●

3 [CLEAR/BACK] ➡ List returns

Opening Task List
 In **2**, select task ➡ ⌨ ➡ *Go to Tasks* ➡ ●
Opening Related Message
 After **2**, ⌨ ➡ *Related Mail* ➡ ●
Deleting Message from Schedule
 After **2**, ● ➡ *Related Mail:* ➡ ● ➡ *Yes* ➡ ● ➡ ⌨
Accessing Secret Entries
 [Calendar Window] ⌨ ➡ *Unlock Temporarily* ➡ ● ➡ Enter Handset Code ➡ ●

Deleting Schedules

■ **One Entry**

1 In schedule list, select schedule ➡ ⌨

2 *Delete* ➡ ●

3 *This Appointment* ➡ ● ➡ *Yes* ➡ ●

■ **All Entries of the Day**

1 In Calendar window, select date ➡ ⌨

2 *Delete* ➡ ● ➡ *All This Day* ➡ ● ➡ *Yes* ➡ ●

9
Handy Extras

Advanced

  ●Searching entries ●Checking memory status ●Deleting all schedules ●Deleting entries by specifying week (Week View) ●Deleting entries by specifying month (Month/3Month View) ●Deleting entries in two/six months (2Month/6Month View) (**P.9-31** - **9-32**)

1

Tasks

Saving Tasks

Follow these steps to save subject, due date/time, Alarm and task details:
Either Subject or Description must be saved per entry.

1. ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Tasks* ➡ ●

```
Tll@          1505
   All Tasks
 ⇒ <Add New Entr...
```

2. *<Add New Entry>* ➡ ●

3. Enter subject ➡ ●

```
Tll@          1505
  Due Date & Time

XXXX / XX / XX
YYYY   MM   DD

  15 : 05
  HH   MM
```

4. Enter due date/time ➡ ●

```
Tll@          1505
   New Entry
Subject:
Birthday
Due Date:
XX/XX/XX 16:00
Alarm:
No Alarm
```

5. *Alarm:* ➡ ●

```
Tll@          1505
    Alarm
Alarm Time:
No Alarm
Assign Tone/Video:
Alert 1
Duration:
10 sec.
```

6. *Alarm Time:* ➡ ● ➡ Select time ➡ ● ➡ ⊠

7. *Description:* ➡ ● ➡ Enter task details ➡ ●

8. ⊠ ➡ Saved

Task with No Due Date/Time
In ④, ✉ ➡ ● ➡ From ⑦
Custom Alarm Time
In ⑥, ☺ *Alarm Time:* ➡ ● ➡ *Other* ➡ ● ➡ Enter date/time ➡ ● ➡ ⊠ ➡ From ⑦

Advanced

🔟

✎ ●Hiding entries ●Editing tasks ●Setting priority ●Changing Alarm tone/video & duration ●Changing Alarm volume ●Changing Vibration option ●Sounding Alarm tone even in Manner mode (**P.9-32**)

At Alarm Time

Alarm activates; sounds/vibrates by related settings.

```
Tall◎         15:05
    Tasks Alarm



    ·    🕐
```

To stop Alarm, press a key.

Opening Task
**While Alarm sounds/vibrates,** ☑
When Another Function is Active
● Alarm may not activate until handset returns to Standby.
Incoming Calls
● Active Alarm stops for incoming calls. Information window opens after handset returns to Standby.

Opening Tasks

1 ● ➡ *Tools* ➡ ● ➡ In PIM/
Lifestyle menu, *Tasks* ➡ ●

```
Tall◎         15:05
      All Tasks
  ☑     ■   ▼    ☑
  ➡ <Add New Entr…

  □ ● Birthday
       XX/XX/XX 16:00
```

Task List
● Use ⊙ to open completed or uncompleted task list.

2 Select task ➡ ●

```
Tall◎         15:05
        Task
  □ Birthday
  🗓 XXXX/XX/XX
     16:00
  🔔 XXXX/XX/XX
     16:00
```

3 ⌫ ➡ List returns

Accessing Secret Entries
After ①, ☑ ➡ *Unlock Temporarily*
➡ ● ➡ Enter Handset Code ➡ ●
Marking Tasks as Completed
After ①, select task ➡ ☑

Deleting Tasks

■ **One Entry**

1 In task list, select task ➡ ☑

2 *Delete* ➡ ●

3 *This Task* ➡ ● ➡ *Yes* ➡ ●

■ **All Completed Tasks**

1 In task list, ☑

2 *Delete* ➡ ● ➡ *All Comp.
Tasks* ➡ ● ➡ *Yes* ➡ ●

9

Handy Extras

Advanced

🄑 ●Searching tasks ●Sorting entries by priority ●Checking memory status ●Deleting all tasks (**P.9-33**)

1

9-5

Using Alarms

Setting Alarm

Follow these steps to set Alarm to sound at a specific time on a specific day of the week:
Set Snooze (Alarm repeats at set interval), Alarm Volume and Duration.

1️⃣ ● ➡ *Tools* ➡ ● ➡ **In PIM/Lifestyle menu,** *Alarms* ➡ ●

```
Yıl @                    15:05
        Alarms
--:--
--:--
--:--
--:--
```
Alarm List

2️⃣ *--:--* ➡ ● ➡ Enter hour (24-hour format) ➡ Enter minutes ➡ ●

```
Yıl @                    15:05
      Set Alarm
Time:
06:00
Subject:
Alarm 1
Repeat:
Once
```

3️⃣ *Repeat:* ➡ ●

```
Yıl @                    15:05
        Repeat
● Once
○ Every Day (All)
○ Selected Days
```

4️⃣ *Selected Days* ➡ ●

```
Yıl @                    15:05
    Selected Days
□ Sunday
□ Monday
□ Tuesday
□ Wednesday
□ Thursday
□ Friday
□ Saturday
□ Except Holidays
```

5️⃣ Select day ➡ ● (□/☑) ➡ Complete selection ➡ ᵞ

6️⃣ *Snooze:* ➡ ●

7️⃣ Select interval ➡ ●
● For custom intervals, select *Other*.

8️⃣ *Alarm Volume:* ➡ ●

9️⃣ Adjust level ➡ ●

🔟 *Duration:* ➡ ●

1️⃣1️⃣ Select time ➡ ●
● For custom Duration, select *Other*.

1️⃣2️⃣ ᵞ ➡ **Saved**
● For more settings, repeat 2️⃣ - 1️⃣2️⃣.

1️⃣3️⃣ ☎ ➡ **Alarm setting ends**

Selecting/Canceling All Days
  In 5️⃣, ✉ ➡ *Check All* or *Uncheck All* ➡ ●
Excluding Holidays
  In 5️⃣, select day ➡ ● (□/☑) ➡ Complete selection ➡ *Except Holidays* ➡ ● ➡ ᵞ ➡ From 5️⃣
Activating Alarm Once or Daily
  In 4️⃣, *Once* or *Every Day (All)* ➡ ● ➡ From 6️⃣

Advanced

🔟 ●Editing entries ●Saving entry name ●Changing Alarm tone/video ●Setting handset to vibrate at Alarm Time ●Sounding Alarm tone even in Manner mode ●Activating Alarm based on World Clock time (**P.9-33**)

At Alarm Time

Alarm activates; sounds/vibrates by related settings.

To stop Alarm, press a key.

When Another Function is Active
● Alarm may not activate until handset returns to Standby.
Incoming Calls
● Active Alarm stops for incoming calls. Information window opens after handset returns to Standby.

When Snooze is Set

Alarm repeats at the set interval. Other Alarms do not activate while handset is Snoozing.

Canceling Snooze
  While Snoozing, ● ➜ *Yes* ➜ ●
● Snooze is automatically canceled after a period of time.

Canceling Alarm

  ❶In Alarm list, select entry ➜ ✉/

  ❷*Switch Off* ➜ ●
    ● Reactivate entry to use the same settings.

Reactivating Entry
  In ❷, *Switch On* ➜ ●

Deleting Alarm

■ **One Entry**

  ❶In Alarm list, select entry ➜ ✉/

  ❷*Reset Alarm* ➜ ●

  ❸*Yes* ➜ ●

■ **All Entries**

  ❶In Alarm list, select entry ➜ ✉/ ➜ *Clear All* ➜ ●

  ❷Enter Handset Code ➜ ● ➜ *Yes* ➜ ●

9

Handy Extras

9-7

Using Wakeup TV

Setting Wakeup TV

Follow these steps to activate TV at a specific time on a specific day of the week:
● Complete Area Setup (**P.6-4**) beforehand.
● TV may not activate in poor signal conditions.

1. ● ➜ *Tools* ➜ ● ➜ In PIM/Lifestyle menu, *Wakeup TV* ➜ ●

   Wakeup TV List

2. *--:--* ➜ ● ➜ Enter hour (24-hour format) ➜ Enter minutes ➜ ●

   Wakeup TV Menu

3. *Repeat:* ➜ ●

4. *Selected Days* ➜ ●

5. Select day ➜ ● (□/☑) ➜ Complete selection ➜ ✉

6. *Channel:* ➜ ●

7. Select channel ➜ ●

8. ✉ ➜ Saved
   ● For more settings, repeat ② - ⑧.

9. ☎ ➜ Wakeup TV setting ends

Selecting/Canceling All Days
   In ⑤, ✉ ➜ *Check All* or *Uncheck All* ➜ ●
Excluding Holidays
   In ⑤, select day ➜ ● (□/☑) ➜ Complete selection ➜ *Except Holidays* ➜ ● ➜ ✉ ➜ From ⑥
Activating TV Once or Daily
   In ④, *Once* or *Every Day (All)* ➜ ● ➜ From ⑥
Canceling Alarm
   ● Alarm activates at Wakeup TV time. To cancel Alarm, follow these steps:
   [Wakeup TV Menu] *Alarm On/Off:* ➜ ● ➜ *Off* ➜ ● ➜ From ⑥
Adjusting Alarm Volume
   [Wakeup TV Menu] *Alarm Volume:* ➜ ● ➜ Adjust level ➜ ● ➜ From ⑥

9

Handy Extras

Advanced

🔧 ●Editing entries ●Changing Alarm tone/video ●Sounding Alarm tone even in Manner mode (**P.9-34**)

At Wakeup TV Time

TV activates after Alarm.

Stopping Alarm Instantly
● While Alarm sounds/vibrates, press a key.
When Another Function is Active
● TV may not activate depending on the function.
After TV is On for a Period of Time
● Confirmation appears. Choose *Yes* and press ● to exit TV.

Canceling Wakeup TV

1 **In Wakeup TV list, select entry ➜ ☑**

2 *Wakeup TV Off* ➜ ●
● Reactivate entry to use the same settings.

Reactivating Entry
In ②, *Wakeup TV On* ➜ ●

Deleting Wakeup TV

■ **One Entry**

1 **In Wakeup TV list, select entry ➜ ☑**

2 *Reset Alarm* ➜ ●

3 *Yes* ➜ ●

■ **All Entries**

1 **In Wakeup TV list, select entry ➜ ☑ ➜ *Clear All* ➜ ●**

2 **Enter Handset Code ➜ ●
➜ *Yes* ➜ ●**

9

Handy Extras

9-9

Using Calculator

1 ● ➔ *Tools* ➔ ● ➔ **In PIM/Lifestyle menu,** *Calculator* ➔ ●

Calculator Window

2 **Use Keypad to enter digits ➔ Calculate**

- Clear Memory before starting new Memory calculations.

3 ☎ ➔ **Calculator ends**

Key Assignments	
+ (Add)	⊙
- (Subtract)	⊙
x (Multiply)	⊙
÷ (Divide)	⊙
= (Sum)	●
C·CE (Clear)	CLEAR/BACK
CM (Clear Memory)	📧
RM (Recall Memory)	🔊
M+ (Add to Memory)	Y
. (Decimal)	✱
+/- (Positive/Negative Value)	#
% (Percentage)	A

Memory Calculation
- Numbers saved in Memory remain until handset power is turned off.

Incoming Calls
- Calculations are not affected. End the call to return to Calculator.

Using % Function
Use A to find definite percentage of a known value.
Example: Calculate 30% of 800,000
　　　Enter *800,000* ➔ *x* ➔ *30* ➔ *%*
- *240,000* appears.

9

Handy Extras

Advanced

🔖 ●Copying calculation results ●Changing exchange rate for currency conversion ●Converting currencies (**P.9-34**)

Adding Expenses

Entering Expenses

1 Enter amount ➔ ⊙

```
Enter Cost:

☒:DecimalPoint



                     5040
```

2 ⊙

```
        Category
● No Category
○ Miscellaneous
○ Vehicle
○ Airfare
○ Shopping
```

3 Select Category ➔ ⊙ ➔ **Saved**

Saving under Custom Category
In ❸, *Other* ➔ ⊙ ➔ Enter name ➔ ⊙

Checking Entries

1 ⊙ ➔ *Tools* ➔ ⊙ ➔ In PIM/ Lifestyle menu, *Expenses Memo* ➔ ⊙

```
      Expenses Memo
Add New Expense
Totals
Edit Category
```

2 *Totals* ➔ ⊙

```
          Totals
1)XX/XX/XX 15:05
Miscell…          5040
```
Expenses Memo List

3 [CLEAR/BACK] ➔ **Menu returns**

Saving Entries to Notepad
[Expenses Memo List] ✉ ➔ *Save to Notepad* ➔ ⊙

Deleting Entries

■ **One Entry**

1 In Expenses Memo list, select entry ➔ ✉

2 *Delete Item* ➔ ⊙ ➔ *Yes* ➔ ⊙

■ **All Entries**

1 In Expenses Memo list, ✉ ➔ *Delete All* ➔ ⊙

2 Enter Handset Code ➔ ⊙ ➔ *Yes* ➔ ⊙

9

Handy Extras

Advanced

⚙ ●Changing Category of saved entry ●Changing amount ●Renaming Categories (**P.9-34**)

Osaifu-Keitai® (Japanese)

Osaifu-Keitai® describes IC Card-equipped handsets that support e-money or credit functions/services. Osaifu-Keitai® encompasses a range of IC Card-based services on FeliCa-compatible SoftBank handsets. 930SH supports Osaifu-Keitai®. To use e-money, e-ticketing and reward points, etc., hold handset over a compatible reader/writer at shops, restaurants, and other retail outlets, etc.

Basics

Before using Osaifu-Keitai®, activate Lifestyle-Appli, complete registration, customize settings and charge accounts.

Starting Lifestyle-Appli
ⓔ ➜ *Tools* ➜ ⓔ ➜ In PIM/Lifestyle menu, *Osaifu-Keitai* ➜ ⓔ ➜ *Lifestyle-Appli* ➜ ⓔ ➜ Select application ➜ ⓔ

Lifestyle-Appli Precautions
- Contact Osaifu-Keitai® service providers for Lifestyle-Appli registration and usage details.
- Keep service passwords/customer service contact information, etc. in a separate place.

Using Osaifu-Keitai®

Follow these steps to conduct a transaction: Example: Making an electronic payment
- Complete transactions without activating a Lifestyle-Appli. Make sure battery is adequately charged.
- Transactions are possible even when handset power is off or during calls or Internet transmissions.

1 Place ⤳ logo over reader/writer ➜ Confirm scan results

Place this part over reader/writer
- Align handset parallel to reader/writer.

Important Osaifu-Keitai® Usage Note
SoftBank is not liable for damages resulting from accidental loss/alteration of IC Card data/settings.
When Placed Over Sensor
- If recognition is slow, move handset around slightly.
- Handset may respond automatically for some services.

Advanced

●Enabling to view e-money balances ●Checking e-money balance on External Display ●Moving applications up/down Balance Info list ●Removing applications from Balance Info list (**P.9-35**)

Locking IC Card

IC Card Lock

Use this function to restrict access to/prevent unauthorized use of Osaifu-Keitai® on handset.

1. ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Osaifu-Keitai* ➡ ●

   ```
   ▾ᵢₗ◉        15:05
        Osaifu-Keitai
   ⚫Lifestyle-Appli
   ⊘ IC Card Settings
   ```

2. *IC Card Settings* ➡ ●

   ```
   ▾ᵢₗ◉        15:05
         Settings
   IC Card Status
   
   IC Card Lock
   Off
   ```
   IC Card Settings Menu

3. *IC Card Lock* ➡ ● ➡ *On* ➡ ●

4. Enter Handset Code ➡ ● ➡ *Yes* ➡ ●

Canceling IC Card Lock
In ❸, *IC Card Lock* ➡ ● ➡ *Off* ➡ ●
➡ Enter Handset Code ➡ ●

Remote Lock

Disable Osaifu-Keitai® remotely by mail or phone.

Mail Remote Lock	Send mail to activate Remote Lock
Call Remote Lock	Call from a specified phone to activate Remote Lock

Mail Remote Lock

■ **Preparation on Handset**

1. In IC Card Settings menu, *Remote Lock* ➡ ● ➡ Enter Handset Code ➡ ●

   ```
   ▾ᵢₗ◉        15:05
        Remote Lock
   Mail Remote Lock
   Off
   Call Remote Lock
   Off
   ```

2. *Mail Remote Lock* ➡ ●

   ```
   ▾ᵢₗ◉        15:05
        Mail Lock
   Switch On/Off
   Off
   Remote Lock PW
   ```
   Mail Remote Lock Menu

3. *Remote Lock PW* ➡ ●

4. Enter password ➡ ●

5. *Switch On/Off* ➡ ●

6. *On* ➡ ● ➡ ✉

Canceling Mail Remote Lock
In ❻, *Off* ➡ ● ➡ ✉

■ **Activating Remote Lock via Mail**
If handset cannot receive mail IC Card Lock is not set.

1. Send S! Mail or e-mail to handset with password as subject
   ● Leave other fields blank.
   ● After handset receives message, IC Card Lock is set and notice is sent as a reply.

Advanced

🔧 ●Customizing handset response to reader/writer commands ●Opening IC Card properties ●Changing IC Card Lock notice recipient ●Changing required Missed Call count for Call Remote Lock ●Restoring default Osaifu-Keitai® settings (**P.9-35**)

9

Handy Extras

Call Remote Lock

■ **Preparation on Handset**

1. **In IC Card Settings menu, *Remote Lock* ➜ ● ➜ Enter Handset Code ➜ ●**

   ```
   Remote Lock
   Mail Remote Lock
   Off
   Call Remote Lock
   Off
   ```

2. ***Call Remote Lock* ➜ ●**

   ```
   Call Lock
   Switch On/Off
   Off
   Set Public Phone
   Off
   ```
   Call Remote Lock Menu

3. ***Phone No. to Lck 1* or *Phone No. to Lck 2* ➜ ●**

   ```
   Ph. No. to Lck1
   Phone Book
   Phone Number
   ```

4. ***Phone Book* ➜ ● ➜ Select entry ➜ ● Select phone number ➜ ●**
   - Select *Phone Number* to enter directly.

5. ***Switch On/Off* ➜ ●**

6. ***On* ➜ ● ➜ ⟨Y'⟩**

   Enabling Activation via Public Phone
   In ③, *Set Public Phone* ➜ ● ➜ *On* ➜ ● ➜ From ⑤
   Canceling Call Remote Lock
   In ⑥, *Off* ➜ ● ➜ ⟨Y'⟩

■ **Activating Remote Lock via Phone**
If handset cannot receive calls IC Card Lock is not set.

1. **Using one of the specified phones, call handset**
   - Send Caller ID.

2. **Handset receives call ➜ End the call**
   - The call is recorded as a Missed Call.

3. **Within three minutes, repeat ❶ - ❷ twice**

   ```
   IC Card Lock
   Answering
   ```

   - After the third Missed Call, IC Card Lock is set; a message announces Remote Lock activation. Confirm the message and end the call.

   If Series is Interrupted by Another Call
   - Missed Call count is reset. Start over from the beginning.

Faking Incoming Calls

Handset rings to emulate an incoming call.
- Pretense Call ringtone is fixed.
- Ringer may be muted by handset settings. To override Silent setting, see **P.9-36**.

Setting Pretense Call

1 ● ➡ *Tools* ➡ ● ➡ In PIM/ Lifestyle menu, *Pretense Call* ➡ ●

> Ƭ⊪⊗ ⊹   15:05
> Pretense Call
> **Run Pretense Call**
>
> Switch On/Off
> Off
> Set Caller
> Empty
> Calling Timing
> Immediacy
> Set Silent
> Do not Ring

Pretense Call Menu

2 *Switch On/Off* ➡ ● ➡ *On* ➡ ●

3 *Set Caller* ➡ ●

> Ƭ⊪⊗ ⊹   15:05
> Set Caller
> Name:
> Empty
> Phone Number:
> Empty

4 *Name:* ➡ ● ➡ Enter name ➡ ●

5 *Phone Number:* ➡ ● ➡ Enter phone number ➡ ● ➡ ⌧

6 ⌧ ➡ PIM/Lifestyle menu returns

When Name and Phone Number are Unset
- Handset rings with Caller ID "Withheld."

Canceling Pretense Call
 [Pretense Call Menu] *Switch On/Off* ➡ ● ➡ *Off* ➡ ● ➡ ⌧

Using Pretense Call

1 ► (Long)
- Available regardless of handset position.
- Handset rings and incoming Voice Call window opens.
- Ringtone stops after a period of time.

2 In incoming Voice Call window, press 🔊
- Voice Call window opens. (Softkeys are dummies.)

3 🔚 ➡ Pretense Call ends

Setting Wait Time
 [Pretense Call Menu] *Calling Timing* ➡ ● ➡ Select time ➡ ● ➡ ⌧
When Calling Timing is Not *Immediacy*
- Press 🔚 or ⌫ during wait time to cancel Pretense Call activation.
- Pretense Call activation is canceled by incoming calls, Alarms, etc. during wait time.

9

Handy Extras

9-15

Using Stopwatch

Stopwatch stops when battery runs low.

1. ● ➡ *Tools* ➡ ● ➡ ⊙
   Timer/Clock ➡ *Stopwatch*
   ➡ ●

   ```
   Yil◈          1505
         Stopwatch

   LAP
   1
   2
   3
   4




   00:00:00
   ```
   Stopwatch Window

2. ● ➡ **Stopwatch starts**

3. ● ➡ **Stopwatch stops**
   ● Press ● to resume.

4. 🔚 ➡ *Yes* ➡ ● ➡
   Stopwatch ends
   ● Records are deleted when
     Stopwatch ends.

Recording Lap Times
    While Stopwatch is running, ✉
Saving Records to Notepad
    After ③, ✉ ➡ *Save to Notepad* ➡ ●
Resetting Records
    After ③, ✉ ➡ *Reset* ➡ ● ➡ From ②
Incoming Calls
● Stopwatch is not affected by incoming
  calls. End the call to return.

9

Handy Extras

1

9-16

Using Countdown Timer

1 ● ➡ *Tools* ➡ ● ➡ ◉
Timer/Clock ➡ *Countdown
Timer* ➡ ●

Countdown Timer

Enter Time
(1sec-60min)

00 : 00

Timer Entry Window

2 Enter minutes ➡ Enter
seconds ➡ ●

Countdown Timer

Time Remaining

01:10

Countdown Timer Window
● Press ✉ to change time.

3 ● ➡ Countdown starts
● Press ● to stop/resume countdown.

4 Set time elapses ➡ Tone
sounds

5 🕾 ➡ *Yes* ➡ ● ➡
Countdown Timer ends

Resetting Timer
    Stop countdown and ✉
Incoming Calls
● Countdown is not affected by incoming
  calls. End the call to return.

When Set Time Elapses

Tone sounds.

Countdown Timer

Timer Expired

To stop tone instantly, press ✉ or a Side
Key. (Tone stops automatically after a
period of time.)

When Timer Time Elapsed during a Call
● Tone sounds after the call.

9

Handy Extras

9-17

Opening World Clock

 1 ● ➜ *Tools* ➜ ● ➜ ⊙ *Timer/Clock* ➜ *World Clock* ➜ ●

- Local Time Zone
- World Time Zone

 2 ●

Set Time Zone Window

 3 Select area ➜ ●

 4 ☎ ➜ World Clock ends

Advancing One Hour (Daylight Saving)
[Set Time Zone Window] ✉
- To cancel, press ✉.

Adding Custom Time Zone
[Set Time Zone Window] ✉ ➜ Enter city name ➜ ● ➜ + or - ➜ ⊙ ➜ Enter time difference ➜ ●

Opening World Clock in Standby

 1 ● ➜ *Settings* ➜ ● ➜ In Phone Settings menu, *Display* ➜ ●

 2 *Standby Display* ➜ ●

 3 *Clock/Calendar* ➜ ●

 4 *World Clock (L)*, etc. ➜ ●

Using Hour Minder

Setting Hour Minder

Follow these steps to activate the hourly time signal at selected hours:

1. ● ➡ *Tools* ➡ ● ➡ ⊙
    Timer/Clock ➡ *Hour Minder*
    ➡ ●

    Hour Minder Menu

2. *Switch On/Off* ➡ ● ➡ *On*
    ➡ ●

3. *Select Time* ➡ ●

4. Select hour ➡ ● (□/☑) ➡
    Complete selection ➡ ☒

5. ☒ ➡ Saved

6. 📞 ➡ Hour Minder setting
    ends

Adjusting Hour Minder Volume
In ❷, *Advanced* ➡ ● ➡ *Volume:* ➡
● ➡ Adjust level ➡ ● ➡ ☒ ➡
From ❺
Changing Hour Minder Duration
In ❷, *Advanced* ➡ ● ➡ *Duration:*
➡ ● ➡ Select time ➡ ● ➡ ☒ ➡
From ❺
■ For custom Duration, select *Other*.
Selecting/Canceling All Hours
In ❹, ✉ ➡ *Check All* or *Uncheck All*
➡ ●

At Hour Minder Time

Hour Minder activates; sounds/vibrates by related settings.

To stop tone instantly, press a key.

When Another Function is Active
● Hour Minder does not activate.
Incoming Calls
● Active Hour Minder stops for incoming calls.

Canceling Hour Minder

1. **In Hour Minder menu,**
    Switch On/Off ➡ ● ➡ *Off*
    ➡ ● ➡ ☒

Advanced

🔧 ●Changing Hour Minder tone/video ●Setting handset to vibrate at Hour Minder Time ●Sounding Hour Minder tone even in Manner mode ●Activating Hour Minder based on World Clock time (**P.9-36**)

Opening PC Documents

Supported File Formats:

PDF (.pdf)

Microsoft® Excel® (.xls)

Microsoft® Word (.doc)

Microsoft® PowerPoint® (.ppt)

● Some files may not appear correctly.
● Download files via the Internet.
● When transferring files from PCs, save to corresponding Memory Card folder (**P.14-23**).

1 ● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Document Viewer* ➡ ●

```
Other Docs
XXXXXXXXXX.xls          51KB

```

2 Select file ➡ ●

Key Assignments

Key	Function
●	View whole page
⊙	Scroll
1	View upper left
2	Toggle full screen view on/off
3	View upper right
4/▶	Zoom out
4 (Long) ▶ (Long)	Continuous zoom out
5	View center
6/◀	Zoom in
6 (Long) ◀ (Long)	Continuous zoom in
7	View lower left
8	Jump to page
9	View lower right
0	Open Help
#	Next page
✳	Previous page
▷	Fit width
�	Rotate 90°

Zooming In/Out with Loupe (Magnifier)
In open file, ⎧ (Long) ➡ Specify portion ➡ ⊠ ➡ *Zoom Out* or *Zoom In* ➡ ●

Saving Text

New Notepad Entry

1
● ➡ *Tools* ➡ ● ➡ ◌
Doc./Rec. ➡ *Notepad* ➡ ●

```
Yil⊕  ⇓         1505
    Notepad         Accessed
→ <Add New Entry>
♪ ガンバレ日本⊡
♪ おめでとう⑩
```
Notepad List

2
<Add New Entry> ➡ ●

```
Yil⊕  ⇓         1505
Text:
_a            0/8192
```

3
Enter text ➡ ●

4
Select Category ➡ ● ➡
Saved

Sorting Entries Temporarily
[Notepad List] ✉
■ Press ✉ repeatedly to toggle sort
options (Modified, Created, Category
and Accessed).

Inserting Notepad Text during Text Entry
In a text entry window, ✉ ➡
Notepad ➡ ● ➡ *Call Notepad* ➡ ●
➡ Select entry ➡ ●

Opening Notepad

1
In Notepad list, select entry
➡ ●

```
Yil⊕  ⇓         1505
      Notepad
⊕ Private
Meeting spot
```

2
CLEAR/BACK ➡ **List returns**

Deleting Entries

■ **One Entry**

1
In Notepad list, select entry
➡ ✉

2
Delete Item ➡ ● ➡ *Yes*
➡ ●

■ **All Entries**

1
In Notepad list, select entry
➡ ✉ ➡ *Setting/Manage*
➡ ●

2
Delete All ➡ ● ➡ Enter
Handset Code ➡ ● ➡ *Yes*
➡ ●

9

Handy Extras

Advanced

⚙ ●Editing Notepad ●Searching text within all entries ●Inserting Notepad text into message text ●Sending entries via S! Mail ●Creating text files
●Importing text files ●Checking memory status ●Opening properties (**P.9-36** - **9-37**)

Recording/Playing Voice

Recording

- If battery runs low while recording, Voice Recorder shuts off.
- Record conversations during calls via *Record Caller Voice* (**P.3-15**).

1 ● ➜ *Tools* ➜ ● ➜ ⊙ *Doc./Rec.* ➜ *Voice Recorder* ➜ ●

Recording Window

2 ● ➜ **Recording starts**

3 ● ➜ **Recording stops**

- For *Extended Voice*, recording is saved automatically.

4 *Save* ➜ ●

Play Before Saving
In ❸, *Playback* ➜ ● ➜ Playback starts ➜ [CLEAR/BACK] ➜ Playback stops
Starting Over
In ❸, [CLEAR/BACK] ➜ From ❷

Playback

1 In recording window, ✉ ➜ *Ring Songs·Tones* ➜ ●

2 Select file ➜ ●

- Use ⊙ to adjust volume.
- Press ● to pause/resume. Press [CLEAR/BACK] to stop playback.

Playing Data Folder Files
● ➜ *Data Folder* ➜ ● ➜ *Ring Tones* ➜ ● ➜ Select file ➜ ●

9

Handy Extras

1

Advanced

🔖 ●Saving longer recordings ●Sending Voice files via S! Mail ●Switching storage media (**P.9-37**)

9-22

Scanning Barcodes

Scan UPC/JAN (1D barcodes) or QR Codes (2D barcodes).

- Membership file or password may be required when scanning barcodes.
- Some barcodes may not be scanned.

1 **● ➔ *Tools* ➔ ● ➔ ◌ *Doc./Rec.* ➔ *Barcode/Scan* ➔ ●**

```
Barcode/Scan
Scan Barcode
Open Barcode
Create QR Code
Scan Card
Scan Text
Scanned Results
```

2 ***Scan Barcode* ➔ ●**

3 **Frame barcode in center of Display**

```
Normal Scanning
```
Focus Adjustment Bar

Scan Window

- Use Focus Adjustment Bar as a guide (better focus in darker blue).
- If focus is poor, press ⌨ to switch to Shutter mode.

4 **● ➔ Scan starts**

- If recognition takes time, slowly adjust the distance between handset and barcode.
- Press ⌨ to stop scan.

5 **Tone sounds ➔ Scan results appear**

```
Scan Result
XX Restaurant
[Open Hours]
Lunch: 11 am - 3 pm
Dinner: 6 pm - 10 pm
[Contact]
aabb@xxx.xx
```

Key Assignments in Scan Window
- ⌨³: **Toggle focus mode**
- ⌨: **Focus Lock**
- ⌨#: **Mobile Light on/off**
- ◌: **Adjust brightness**
- ⌨0: **Open Help**

Split Data
- After scanning, confirmation appears. Follow onscreen prompt(s).
- Scan results do not appear until all split data is scanned.

Starting Over
After 5, ⌨ ➔ *Yes* ➔ ● ➔ From 3

Advanced

✎ ●Scanning during text entry ●Scanning continuously ●Reading saved barcode images ●Saving scan results ●Saving to Notepad ●Saving linked info to Phone Book ●Opening saved scan results ●Using linked info ●Using images as Wallpaper ●Saving images & melodies (And more on **P.9-37** - **9-38**)

9

Handy Extras

Creating QR Codes

Create QR Codes from these items on handset:

Phone Book	My Details
Text Input	Ring Songs·Tones
Pictures	Notepad

Large items are divided into multiple QR Codes.

Procedure

Follow these steps to create QR codes from Data Folder files:

1. ● ➜ *Tools* ➜ ● ➜ ⊙ *Doc./Rec.* ➜ *Barcode/Scan* ➜ ●

   ```
   Barcode/Scan
   Scan Barcode
   Open Barcode
   Create QR Code
   Scan Card
   Scan Text
   Scanned Results
   ```

2. *Create QR Code* ➜ ●

3. *Data Folder* ➜ ●

   ```
   Data Folder
   Pictures
   Ring Songs·Tones
   Notepad
   Other Documents
   ```

4. Select folder ➜ ● ➜ Select file or entry ➜ ●
   ● QR Code is created.

5. ●
   ● QR Code is saved to Data Folder (Pictures).

From Phone Book Entries
In ❸, ◌ *Phone Book* ➜ ● ➜ ⊙ Select entry ➜ ● ➜ ❺

From My Details
In ❸, *My Details* ➜ ● ➜ Select item ➜ ● ➜ ❺

From Entered Text
In ❸, *Text Input* ➜ ● ➜ Enter text ➜ ● ➜ ❺

Switching Storage Media
In ❺, ✉ ➜ *Save to* ➜ ● ➜ *Phone* or *Memory Card* ➜ ● ➜ ●

Attaching to S! Mail
In ❺, ✉ ➜ *Send As* ➜ ● ➜ Complete message ➜ ✉

Incoming Calls
● QR Code creation is not affected by incoming calls. End the call to return.

Scanning Business Cards

Scan business cards and save names, addresses, etc. to Phone Book.
● English business cards may not be scanned correctly.
● Some cards may not be scanned.

1️⃣ ● ➡ *Tools* ➡ ● ➡ ⊙
   Doc./Rec. ➡ *Barcode/Scan*
   ➡ ●

   ```
   Barcode/Scan
   Scan Barcode
   Open Barcode
   Create QR Code
   Scan Card
   Scan Text
   Scanned Results
   ```

2️⃣ *Scan Card* ➡ ●

3️⃣ **Frame card on Display**

   XXXX 株式会社
   XX区XX通X丁目
   主任
   植田 ミキオ

   Scan Window

4️⃣ ●
   ● Press ⌫ to stop scan.

5️⃣ ● ➡ **Scan results appear**

   ```
   Scan Result
   植田
   ミキオ
   ウエダ
   XX-XXXX-XXXX
   XX-XXXX-XXXX
   ```

6️⃣ ● ➡ ⌫
   ● New Phone Book entry is saved.

Key Assignments in Scan Window
   ⓷: **Toggle focus mode**
   🔅: **Focus Lock**
   ⌗: **Mobile Light on/off**
   ⊙: **Adjust brightness**
   ⓪: **Open Help**
If Text Exceeds Phone Book Entry Item Character Limit
● Confirmation appears. Follow these steps to delete overage:
   Yes ➡ ●
Changing Save Location
   After ⊖, ✉ *Save to* ➡ ● ➡ Select location ➡ ● ➡ ⊖
Saving Scanned Image as Phone Book Picture
   After ⊖, ✉ ➡ *Add Image* ➡ ● ➡ *On* ➡ ●
Starting Over
   After ⊖, ⌫ ➡ *Yes* ➡ ● ➡ From 3️⃣

9
Handy Extras

Advanced

◎ ●Saving to Notepad ●Pasting to message text ●Copying text (**P.9-39**)

Scanning Text

Scan text (URLs, mail addresses, phone numbers or alphanumerics).
Some text cannot be scanned.

1 ● ➡ *Tools* ➡ ● ➡ ⊙
Doc./Rec. ➡ *Barcode/Scan*
➡ ●

Barcode/Scan
Scan Barcode
Open Barcode
Create QR Code
Scan Card
Scan Text
Scanned Results

2 *Scan Text* ➡ ●

3 **Frame text in center of Display**

Text Scanner

1. Capture
characters.

xxxxxxxxxxxxxxxxxxx ← Focus Adjustment Bar

2. Scan when bar is
the bluest.

Scan Window

- Adjust to frame text in [ ].
- Use Focus Adjustment Bar as a guide (better focus in darker blue).

4 ●
- Press ⊠ to stop scan.

5 **Select line ➡ ● ➡ Scan results appear**

6 ●

Scanned Text
22/256
xxxxxxxxxxxxxxxxxxxxxx

Key Assignments in Scan Window
⁎3⁑**: Toggle focus mode**
⁎**: Focus Lock**
⁑#⁑**: Mobile Light on/off**
⊙**: Adjust brightness**
⁑0⁑**: Open Help**
For White Text on Black Background
In 3, ☑ ➡ *Reversed Text* ➡ ● ➡
Reversed ➡ ● ➡ From 4
Correcting Text Type
After 5, ☑ ➡ *Change Mode* ➡ ●
➡ Select type ➡ ● ➡ 6
Editing Scanned Text
After 5, ☑ ➡ *Select/Edit* ➡ ● ➡
Select character ➡ Select alternative
from list or edit directly ➡ 6
Starting Over
In 6, ⊠ ➡ *Yes* ➡ ● ➡ From 3

9

Handy Extras

Advanced

🖐 **Scanning during text entry** ●**Scanning more text** ●**Saving scan results** ●**Saving linked info to Phone Book** ●**Saving to Notepad** ●**Opening saved scan results** ●**Using linked info** ●**Pasting to message text** ●**Copying text** (**P.9-40** - **9-41**)

Receiving Content Updates (Japanese)

View content updates or breaking news.
Transmission fees apply.

Registering S! Quick News Items

1 ● ➡ *Entertainment* ➡ ●
➡ *S! Quick News* ➡ ●

```
Tll@          15:05
    S! Quick News
S! Quick News List
S! Loop List
Settings
```

2 *S! Quick News List* ➡ ●

```
Tll@          15:05
🔲 登録はこちら       🔲$
🔘 S!速報ニュースとは ▶  🔺と
－ ＜未登録＞           ▼
－ ＜未登録＞           ▲コ
－ ＜未登録＞           ▽お
```

S! Quick News List

3 *登録はこちら* ➡ ● ➡ *Yes*
➡ ●

● Handset connects to the Internet.

4 Select item ➡ ●
● Follow onscreen instructions.

Opening Information

1 In S! Quick News List,
select item ➡ ●
● Title list appears.

2 Select title ➡ ●

```
Tll@          15:05
🔲 ニュース速報
台風7号接近
今年最大級の台風7
号が九州地方に接近
中。今夜にも上陸の
おそれ。河川の増水
```

● Press ✉ to return to title list, or ✉
to open next title.

Updating Items Manually
[S! Quick News List] Select item ➡
✉ ➡ *更新* ➡ ● ➡ *一件* or *全件* ➡ ●

Indicators

🔳	Unread Special news
🔳	Read Special news
🔳	Unread News Flash
🔳	Read News Flash
🔳	Unread General news
🔳	Read General news
⊠	Auto update disabled

9

Handy Extras

Advanced

🔊 ●Receiving S! Loop item updates ●Updating list automatically ●Checking update schedule ●Changing background image ●Deleting S! Quick News items ●Updating S! Loop items manually ●Accessing source sites ●Disabling image download ●Deleting S! Loop items ●Resetting S! Quick News List and S! Loop List (**P.9-41** - **9-42**)

S! Information Channel & Weather Indicator (Japanese)

Transmission fees apply.

Service Registration & Content Subscription

1 ● ➡ *Entertainment* ➡ ● ➡ *S! Information Channel/ Weather* ➡ ●

```
Yil◎ ↔                    1505
    S!Info. Channel
What's New

Back Issue

Registration/Canc…
```

S! Information Channel Menu

2 *Registration/Cancel* ➡ ●
● Handset connects to the Internet. Follow onscreen instructions.

New Received Information

Information window opens for new S! Information Channel info delivery.

1 **While Information window appears, *S! Info. Channel* ➡ ●**
● S! Information Channel page opens. Follow onscreen instructions.
● S! Information Channel page handling is similar to that of Yahoo! Keitai.

2 ☎ ➡ **Page closes**

Opening Unread Latest Issue
  [S! Information Channel Menu]
  What's New ➡ ●
Opening Back Issues
  [S! Information Channel Menu] *Back Issue* ➡ ● ➡ Select date ➡ ●

Using Weather Indicator

After S! Information Channel registration, local area weather indicator appears in Standby.

☀	Clear skies (day)	❄	Snow
☽	Clear skies (night)	ϟ	Thunder showers
☁	Cloudy	▷	Then
☂	Rain	/	Partly/chance of

Example: ☁ / ☂ ➡ Partly cloudy with a chance of rain
Indicators other than the above also appear for more information.

Manual Update
  [S! Information Channel Menu]
  Weather Indicator ➡ ● ➡ *Manual Update* ➡ ● ➡ *Yes* ➡ ●

Advanced

🔧 **Hiding Information window for new received info** ●**Changing Display Size** ●**Changing scroll unit** ●**Copying text** ●**Hiding Weather Indicator in Standby** ●**Canceling Weather Indicator automatic updates** ●**Hiding Information window for weather updates** (And more on **P.9-42** - **9-43**)

Reading e-Books (Japanese)

Downloading e-Books

1 ⟨ｘ⟩ ➔ *メニューリスト* ➔ ⦿

2 *書籍・コミック・写真集* ➔ ⦿
 ● Follow onscreen instructions.
 ● Downloaded e-Books are saved to Data Folder (Books).

Note
 ● Alternatively, visit SH-web to download e-Books.

e-Book Viewer

Read XMDF books and dictionary files. Some files may not be supported.

1 ⦿ ➔ *Entertainment* ➔ ⦿

> 📶⦿ ↓   07/7/M
>   1505⬛
>   Entertainment
> 🌀 S! Quick News
> ⚡ S! Information …
> 📖 BookSurfing
> 📖 e-Book Viewer

Entertainment Menu

2 *e-Book Viewer* ➔ ⦿
 ● e-Book Viewer starts. Refer to the e-Book Viewer help menu for operational instructions.

BookSurfing®

Download Contents Keys and read CCF files. Some files may not be supported.

1 **In Entertainment menu, *BookSurfing* ➔ ⦿**
 ● BookSurfing® S! Application starts. Refer to the BookSurfing® help menu for operational instructions.

Moving CCF Files via Memory Card
 ● When purchasing a new handset, move CCF files and retrieve Contents Keys to open the files. Some files may need to be re-downloaded.

9

Handy Extras

Advanced

1

9-29

Calendar

■ View Settings

Changing default view	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ ✉ ➡ *Calendar Settings* ➡ ● ➡ *Default View* ➡ ● ➡ Select type ➡ ●
Changing date color	Start Here ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ See below
	By Days of the Week ✉ ➡ *Calendar Settings* ➡ ● ➡ *Set Color* ➡ ● ➡ *By Week* ➡ ● ➡ Select day ➡ ● ➡ Select color ➡ ●
	By Date Select date ➡ 4 ➡ Select color ➡ ●
	Resetting "By Date" Colors ✉ ➡ *Calendar Settings* ➡ ● ➡ *Set Color* ➡ ● ➡ *Reset Color* ➡ ● ➡ Select option ➡ ● ➡ *Yes* ➡ ●
Changing task view option	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ ✉ ➡ *Calendar Settings* ➡ ● ➡ *Tasks View* ➡ ● ➡ Select option ➡ ●
Adding stamps (Month View)	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ Select date ➡ 2 ➡ Select stamp ➡ ●
Hiding entries	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ Select date ➡ ● ➡ Select entry ➡ ● ➡ ● ➡ *Secret:* ➡ ● ➡ *On* ➡ ● ➡ ✉

Removing/ restoring preset holidays	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ ✉ ➡ *Calendar Settings* ➡ ● ➡ *Set Holiday* ➡ ● ➡ ⊙ *Set My Holidays* or *Public Holidays* ➡ Select holiday ➡ ● (□/☑)

■ Saving/Editing Entries

Setting Category/ Location	Start Here ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ Select date ➡ ● ➡ Select entry ➡ ● ➡ ● ➡ See below
	Category *Category:* ➡ ● ➡ Select Category ➡ ● ➡ ✉
	Location *Location:* ➡ ● ➡ Enter location ➡ ● ➡ ✉
Saving repetitive schedules	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ Select date ➡ ● ➡ Select entry ➡ ● ➡ ● ➡ *Repeat:* ➡ ● ➡ Select frequency ➡ ● ➡ Enter repeat time ➡ ● ➡ ✉ ● Repeat time is not available for *Every Year*.
Saving S! Friend's Status information	Start Here ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ Select date ➡ ● ➡ Select entry ➡ ● ➡ ● ➡ *S! Friend'sStatus:* ➡ ● ➡ *Link Setting:* ➡ ● ➡ *Linked* ➡ ● ➡ See below
	Availability *Answer Status:* ➡ ● ➡ Edit ➡ ● ➡ ✉ ➡ ✉ ➡ ✉ ● Set Category first.
	Comment *Comment:* ➡ ● ➡ Enter text ➡ ● ➡ ✉ ➡ ✉ ● Set Category first.

Saving additional holidays	Start Here ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ ☒ ➡ *Calendar Settings* ➡ ● ➡ *Set Holiday* ➡ ● ➡ ⊙ *Set My Holidays* ➡ See below
	Adding Holidays *<Empty>* ➡ ● ➡ Enter name ➡ ● ➡ Enter date ➡ ● ➡ Select frequency ➡ ● ➡ ☒
	Editing Added Holidays Select holiday ➡ ☒ ➡ *Edit* ➡ ● ➡ *Name:* ➡ ● ➡ Enter name ➡ ● ➡ *Date:* ➡ ● ➡ Enter date ➡ ● ➡ Select frequency ➡ ● ➡ ☒
Editing schedules	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ Select date ➡ ● ➡ Select entry ➡ ● ➡ Select item ➡ ● ➡ Edit in the same manner as saving schedules ➡ ● ➡ ☒
Changing Alarm tone/video & duration	Start Here ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ Select date ➡ ● ➡ Select entry ➡ ● ➡ ● ➡ *Alarm:* ➡ ● ➡ See below
	Alarm Tone/Video: *Assign Tone/Video:* ➡ ● ➡ Select folder ➡ ● ➡ Select tone/file ➡ ● ➡ ☒ ➡ ☒ ● Select start point if required.
	Duration *Duration:* ➡ ● ➡ Select time ➡ ● ➡ ☒ ➡ ☒
Changing Alarm volume	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ ☒ ➡ *Alarm Settings* ➡ ● ➡ *Alarm Volume:* ➡ ● ➡ Adjust level ➡ ●
Changing Vibration option	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ ☒ ➡ *Alarm Settings* ➡ ● ➡ *Vibration:* ➡ ● ➡ Select option ➡ ●

Sounding Alarm tone even in Manner mode	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ ☒ ➡ *Alarm Settings* ➡ ● ➡ *For Manner Mode:* ➡ ● ➡ *Ring* ➡ ● ➡ *Yes* ➡ ●

■ **Managing Entries**

Searching entries	Start Here ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ See below
	By Subject ⬛6⬛ ➡ Enter text ➡ ●
	By Category ⬛9⬛ ➡ Select Category ➡ ●
Checking memory status	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ Select date ➡ ☒ ➡ *Memory Status* ➡ ●
Deleting all schedules	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ ☒ ➡ *Delete* ➡ ● ➡ *All Appointments* ➡ ● ➡ Enter Handset Code ➡ ● ➡ *Yes* ➡ ●
Deleting entries by specifying week (Week View)	Start Here ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ See below
	Within One Week Select week ➡ ☒ ➡ *Delete* ➡ ● ➡ *All This Week* ➡ ● ➡ *Yes* ➡ ●
	Up to the End of Previous Week Select week ➡ ☒ ➡ *Delete* ➡ ● ➡ *Up to Last Week* ➡ ● ➡ *Yes* ➡ ●

9

Handy Extras

Deleting entries by specifying month (Month/3Month View)	Start Here ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ See below **Within One Month** Select month ➡ ☑ ➡ *Delete* ➡ ● ➡ *All This Month* ➡ ● ➡ *Yes* ➡ ● **Up to the End of Previous Month** Select month ➡ ☑ ➡ *Delete* ➡ ● ➡ *Up to Last Month* ➡ ● ➡ *Yes* ➡ ●
Deleting entries in two/six months (2Month/6Month View)	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calendar* ➡ ● ➡ ☑ ➡ *Delete* ➡ ● ➡ *All This 2Months* (or *All 6Months*) ➡ ● ➡ *Yes* ➡ ●

Tasks

■ Task List

Hiding entries	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Tasks* ➡ ● ➡ Select task ➡ ☑ ➡ *Edit* ➡ ● ➡ *Secret:* ➡ ● ➡ *On* ➡ ● ➡ ☑

■ Saving/Editing Entries

Editing tasks	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Tasks* ➡ ● ➡ Select task ➡ ☑ ➡ *Edit* ➡ ● ➡ Select item ➡ ● ➡ Edit in the same manner as saving tasks ➡ ● ➡ ☑
Setting priority	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Tasks* ➡ ● ➡ Select task ➡ ☑ ➡ *Edit* ➡ ● ➡ *Priority:* ➡ ● ➡ Select option ➡ ● ➡ ☑

Changing Alarm tone/video & duration	Start Here ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Tasks* ➡ ● ➡ Select task ➡ ☑ ➡ *Edit* ➡ ● ➡ *Alarm:* ➡ ● ➡ See below **Alarm Tone/Video** *Assign Tone/Video:* ➡ ● ➡ Select folder ➡ ● ➡ Select tone/file ➡ ● ➡ ☑ ➡ ☑ ● Select start point if required. **Duration** *Duration:* ➡ ● ➡ Select time ➡ ● ➡ ☑ ➡ ☑
Changing Alarm volume	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Tasks* ➡ ● ➡ ☑ ➡ *Alarm Settings* ➡ ● ➡ *Alarm Volume:* ➡ ● ➡ Adjust level ➡ ●
Changing Vibration option	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Tasks* ➡ ● ➡ ☑ ➡ *Alarm Settings* ➡ ● ➡ *Vibration:* ➡ ● ➡ Select option ➡ ●
Sounding Alarm tone even in Manner mode	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Tasks* ➡ ● ➡ ☑ ➡ *Alarm Settings* ➡ ● ➡ *For Manner Mode:* ➡ ● ➡ *Ring* ➡ ● ➡ *Yes* ➡ ●

■ **Managing Entries**

Searching tasks	Start Here ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Tasks* ➡ ● ➡ ✉ ➡ *Find* ➡ ● ➡ **See below**
	By Subject
	By Subject ➡ ● ➡ Enter text ➡ ●
	By Due Date
	By Due Date ➡ ● ➡ Enter date ➡ ●
Sorting entries by priority	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Tasks* ➡ ● ➡ ✉ ➡ *Sort* ➡ ● ➡ *Priority* ➡ ●
Checking memory status	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Tasks* ➡ ● ➡ ✉ ➡ *Memory Status* ➡ ●
Deleting all tasks	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Tasks* ➡ ● ➡ ✉ ➡ *Delete* ➡ ● ➡ *All Tasks* ➡ ● ➡ Enter Handset Code ➡ ● ➡ *Yes* ➡ ●

Alarms

Editing entries	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Alarms* ➡ ● ➡ Select entry ➡ ● ➡ Select item ➡ ● ➡ Edit in the same manner as saving entries ➡ ● ➡ ✉
Saving entry name	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Alarms* ➡ ● ➡ Select entry ➡ ● ➡ *Subject:* ➡ ● ➡ Enter name ➡ ● ➡ ✉
Changing Alarm tone/video	Start Here ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Alarms* ➡ ● ➡ Select entry ➡ ● ➡ *Assign Tone/Video:* ➡ ● ➡ **See below**
	Using Preset Tone or Data Folder File
	Select folder ➡ ● ➡ Select tone/file ➡ ● ➡ ✉
	● Select start point if required.
	Using Customized Screen Tone/Video
	Customized Screen ➡ ● ➡ ✉
Setting handset to vibrate at Alarm Time	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Alarms* ➡ ● ➡ Select entry ➡ ● ➡ *Vibration:* ➡ ● ➡ *On* or *Link to Sound* ➡ ● ➡ ✉
	● Select *Link to Sound* to allow compatible SMAF files to control vibration.
Sounding Alarm tone even in Manner mode	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Alarms* ➡ ● ➡ *Settings* ➡ ● ➡ *For Manner Mode* ➡ ● ➡ *Ring* ➡ ● ➡ *Yes* ➡ ●
Activating Alarm based on World Clock time	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Alarms* ➡ ● ➡ *Settings* ➡ ● ➡ *Link to World Clk* ➡ ● ➡ *On* ➡ ●

9

Handy Extras

9-33

Wakeup TV

Editing entries	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Wakeup TV* ➡ ● ➡ Select entry ➡ ● ➡ Select item ➡ ● ➡ Edit in the same manner as saving entries ➡ ● ➡ ⌨
Changing Alarm tone/video	Start Here ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Wakeup TV* ➡ ● ➡ Select entry ➡ ● ➡ *Assign Tone/Video:* ➡ ● ➡ See below
	Using Preset Tone or Data Folder File Select folder ➡ ● ➡ Select tone/file ➡ ● ➡ ⌨ • Select start point if required.
	Using Customized Screen Tone/Video *Customized Screen* ➡ ● ➡ ⌨
Sounding Alarm tone even in Manner mode	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Wakeup TV* ➡ ● ➡ *For Manner Mode* ➡ ● ➡ *Ring* ➡ ● ➡ *Yes* ➡ ●

Calculator

Copying calculation results	While result appears, ⌨ ➡ *Copy* ➡ ●
Changing exchange rate for currency conversion	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calculator* ➡ ● ➡ ⌨ ➡ *Money Converter* ➡ ● ➡ *Exchange Rate* ➡ ● ➡ *Domestic* or *Foreign* ➡ ● ➡ Enter rate ➡ ●
Converting currencies	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Calculator* ➡ ● ➡ Enter amount of money ➡ ⌨ ➡ *Money Converter* ➡ ● ➡ *To Domestic* or *To Foreign* ➡ ● • Set Exchange Rate first.

Expenses Memo

Changing Category of saved entry	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Expenses Memo* ➡ ● ➡ *Totals* ➡ ● ➡ Select entry ➡ ● ➡ Select Category ➡ ●
Changing amount	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Expenses Memo* ➡ ● ➡ *Totals* ➡ ● ➡ Select entry ➡ ⌨ ➡ *Change Amount* ➡ ● ➡ Edit ➡ ●
Renaming Categories	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Expenses Memo* ➡ ● ➡ *Edit Category* ➡ ● ➡ Select Category ➡ ● ➡ Enter name ➡ ●

Osaifu-Keitai®

Enabling to view e-money balances	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Osaifu-Keitai* ➡ ● ➡ *IC Card Settings* ➡ ● ➡ *Balance Info* ➡ ● ➡ Enter Handset Code ➡ ● ➡ *Empty* ➡ ● ➡ *S! Appli* or *Lifestyle-Appli* ➡ ● ➡ Select application ➡ ● ● For use with compatible Lifestyle-Applications. ● Start Lifestyle-Appli once before adding it to Balance Info list.
Checking e-money balance on External Display	With handset closed, ◀ (Long) ➡ Balance appears ➡ ☐ ➡ Balance disappears ● Use ◀▶ to view balances of listed entries. ● Save Lifestyle-Appli to Balance Info list beforehand. ● Balances do not appear if IC Card Lock is active.
Moving applications up/down Balance Info list	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Osaifu-Keitai* ➡ ● ➡ *IC Card Settings* ➡ ● ➡ *Balance Info* ➡ ● ➡ Enter Handset Code ➡ ● ➡ Select application ➡ ☒ ➡ *Move* ➡ ● ➡ Select location ➡ ●
Removing applications from Balance Info list	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Osaifu-Keitai* ➡ ● ➡ *IC Card Settings* ➡ ● ➡ *Balance Info* ➡ ● ➡ Enter Handset Code ➡ ● ➡ Select application ➡ ☒ ➡ *Delete* ➡ ●
Customizing handset response to reader/writer commands	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Osaifu-Keitai* ➡ ● ➡ *IC Card Settings* ➡ ● ➡ *Interface Settings* ➡ ● ➡ Enter Handset Code ➡ ● ➡ Select item ➡ ● ➡ *Off* ➡ ●
Opening IC Card properties	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Osaifu-Keitai* ➡ ● ➡ *IC Card Settings* ➡ ● ➡ *IC Card Status* ➡ ●

Changing IC Card Lock notice recipient	Start Here ● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Osaifu-Keitai* ➡ ● ➡ *IC Card Settings* ➡ ● ➡ *Remote Lock* ➡ ● ➡ Enter Handset Code ➡ ● ➡ *Mail Remote Lock* ➡ ● ➡ *Notice Settings* ➡ ● ➡ *Send Notice* ➡ ● ➡ See below
	Changing Recipient *To Set Recipient* ➡ ● ➡ *Set Recipient* ➡ ● ➡ Select method ➡ ● ➡ Select/enter number/address ➡ ● ➡ ☒
	Disabling Notice *Off* ➡ ● ➡ CLEAR/BACK ➡ ☒
Changing required Missed Call count for Call Remote Lock	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Osaifu-Keitai* ➡ ● ➡ *IC Card Settings* ➡ ● ➡ *Remote Lock* ➡ ● ➡ Enter Handset Code ➡ ● ➡ *Call Remote Lock* ➡ ● ➡ *Count for Lock* ➡ ● ➡ Enter Missed Call count ➡ ● ➡ ☒
Restoring default Osaifu-Keitai® settings	● ➡ *Tools* ➡ ● ➡ In PIM/Lifestyle menu, *Osaifu-Keitai* ➡ ● ➡ *IC Card Settings* ➡ ● ➡ *Set to Default* ➡ ● ➡ Enter Handset Code ➡ ● ➡ *Yes* ➡ ●

Pretense Call

Starting via Pretense Call menu	(●) ▶ *Tools* ▶ (●) ▶ In PIM/Lifestyle menu, *Pretense Call* ▶ (●) ▶ *Run Pretense Call* ▶ (●) ▶ *Yes* ▶ (●) ● Pretense Call starts immediately regardless of Calling Timing setting. ● Settings remain even after starting Pretense Call during setup.
Clearing caller information	(●) ▶ *Tools* ▶ (●) ▶ In PIM/Lifestyle menu, *Pretense Call* ▶ (●) ▶ *Set Caller* ▶ (●) ▶ ✉ ▶ *Yes* ▶ (●) ▶ ☜ ▶ ☜
Overriding Silent volume setting	(●) ▶ *Tools* ▶ (●) ▶ In PIM/Lifestyle menu, *Pretense Call* ▶ (●) ▶ *Set Silent* ▶ (●) ▶ *Ring* ▶ (●) ▶ *Yes* ▶ (●) ▶ ☜

Hour Minder

Changing Hour Minder tone/video	**Start Here** (●) ▶ *Tools* ▶ (●) ▶ Timer/Clock ▶ *Hour Minder* ▶ (●) ▶ *Advanced* ▶ (●) ▶ *Assign Tone/Video:* ▶ (●) ▶ **See below** **Using Preset Tone or Data Folder File** Select folder ▶ (●) ▶ Select tone/file ▶ (●) ▶ ☜ ▶ ☜ ● Select start point if required. **Using Customized Screen Tone/Video** *Customized Screen* ▶ (●) ▶ ☜ ▶ ☜
Setting handset to vibrate at Hour Minder Time	(●) ▶ *Tools* ▶ (●) ▶ Timer/Clock ▶ *Hour Minder* ▶ (●) ▶ *Advanced* ▶ (●) ▶ *Vibration:* ▶ (●) ▶ *On* or *Link to Sound* ▶ (●) ▶ ☜ ▶ ☜ ● Select *Link to Sound* to allow compatible SMAF files to control vibration.

Sounding Hour Minder tone even in Manner mode	(●) ▶ *Tools* ▶ (●) ▶ Timer/Clock ▶ *Hour Minder* ▶ (●) ▶ *Advanced* ▶ (●) ▶ *For Manner Mode:* ▶ (●) ▶ *Ring* ▶ (●) ▶ *Yes* ▶ (●) ▶ ☜ ▶ ☜
Activating Hour Minder based on World Clock time	(●) ▶ *Tools* ▶ (●) ▶ Timer/Clock ▶ *Hour Minder* ▶ (●) ▶ *Advanced* ▶ (●) ▶ *Link to World Clk:* ▶ (●) ▶ *On* ▶ (●) ▶ ☜ ▶ ☜

Notepad

Editing Notepad	**Start Here** (●) ▶ *Tools* ▶ (●) ▶ *Doc./Rec.* ▶ *Notepad* ▶ (●) ▶ Select entry ▶ ✉ ▶ **See below** **Editing Text** *Edit Text* ▶ (●) ▶ Edit ▶ (●) **Changing Category** *Change Category* ▶ (●) ▶ Select Category ▶ (●)
Searching text within all entries	(●) ▶ *Tools* ▶ (●) ▶ *Doc./Rec.* ▶ *Notepad* ▶ (●) ▶ Select entry ▶ ✉ ▶ *Search* ▶ (●) ▶ Enter text ▶ (●)
Inserting Notepad text into message text	(●) ▶ *Tools* ▶ (●) ▶ *Doc./Rec.* ▶ *Notepad* ▶ (●) ▶ Select entry ▶ ✉ ▶ *Send* ▶ (●) ▶ *As Message Text* ▶ (●) ▶ *S! Mail* or *SMS* ▶ (●) ▶ Complete message ▶ ☜ ● S! Mail Composition window opens automatically depending on character count.
Sending entries via S! Mail	(●) ▶ *Tools* ▶ (●) ▶ *Doc./Rec.* ▶ *Notepad* ▶ (●) ▶ Select entry ▶ ✉ ▶ *Send* ▶ (●) ▶ *Via Message* ▶ (●) ▶ Complete message ▶ ☜
Creating text files	(●) ▶ *Tools* ▶ (●) ▶ *Doc./Rec.* ▶ *Notepad* ▶ (●) ▶ Select entry ▶ ✉ ▶ *Setting/Manage* ▶ (●) ▶ *Create Text File* ▶ (●) ▶ Enter name ▶ (●) ▶ *Save here* ▶ (●)

Importing text files	● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Notepad* ➡ ● ➡ Select entry ➡ ☑ ➡ *Setting/Manage* ➡ ● ➡ *Import Text File* ➡ ● ➡ Select file ➡ ●
Checking memory status	● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Notepad* ➡ ● ➡ Select entry ➡ ☑ ➡ *Setting/Manage* ➡ ● ➡ *Memory Status* ➡ ●
Opening properties	● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Notepad* ➡ ● ➡ Select entry ➡ ☑ ➡ *Details* ➡ ●

Voice Recorder

Saving longer recordings	● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Voice Recorder* ➡ ● ➡ ☑ ➡ *Record Time* ➡ ● ➡ *Extended Voice* ➡ ● ➡ ● ➡ Recording starts ➡ ● ➡ Recording ends ● Insert Memory Card to record in *Extended Voice* mode. (Recording is saved automatically.)
Sending Voice files via S! Mail	● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Voice Recorder* ➡ ● ➡ ● ➡ Recording starts ➡ ● ➡ Recording ends ➡ *Save and Send* ➡ ● ➡ Complete message ➡ ✉ ● Available in *For Message* mode.
Switching storage media	● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Voice Recorder* ➡ ● ➡ ☑ ➡ *Save Recording to* ➡ ● ➡ Select option ➡ ● ● Available in *For Message* mode. ● Set to *Ask Each Time* to select media after every recording.

Scan Barcode

Scanning during text entry	<u>Start Here</u> In a text entry window, ☑ ➡ *Scan* ➡ ● ➡ *Scan Code* ➡ ● ➡ Frame barcode in center of Display ➡ ● ➡ See below
	Pasting All Scan Results ●
	Pasting a Part of Scan Results ☑ ➡ Select first character ➡ ● ➡ Highlight text range ➡ ●
Scanning continuously	● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ● ➡ *Scan Barcode* ➡ ● ➡ ☑ ➡ *Continuous Scan* ➡ ● ➡ *On* ➡ ● ➡ Frame barcode in center of Display ➡ ● ● Choose *Yes* to continue scanning or *No* and press ● to view scan results.
Reading saved barcode images	● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ● ➡ *Open Barcode* ➡ ● ➡ Select file ➡ ●
Saving scan results	● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ● ➡ *Scan Barcode* ➡ ● ➡ Frame barcode in center of Display ➡ ● ➡ ☑ ➡ *Save* ➡ ●
Saving to Notepad	● ➡ *Tools* ➡ ● ➡ ⊙ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ● ➡ *Scan Barcode* ➡ ● ➡ Frame barcode in center of Display ➡ ● ➡ ☑ ➡ *Notepad* ➡ ●

9

Handy Extras

9-37

Saving linked info to Phone Book	⦿ ➡ *Tools* ➡ ⦿ ➡ ⊙ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ⦿ ➡ *Scan Barcode* ➡ ⦿ ➡ **Frame barcode in center of Display** ➡ ⦿ ➡ **Select number or mail address** ➡ ✉ ➡ *Save to Ph.Book* ➡ ⦿ ➡ *As New Entry* ➡ ⦿ ➡ **Complete other fields** ➡ ▽
• To add to an existing entry, select *As New Detail*.
• When *MEMORY:* appears in scan results, press ⦿ to enter the items underlined with a dotted line automatically in Phone Book entry window.
Opening saved scan results	⦿ ➡ *Tools* ➡ ⦿ ➡ ⊙ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ⦿ ➡ *Scanned Results* ➡ ⦿ ➡ **Select file** ➡ ⦿
• Select a file and press ✉ to rename files, open properties or delete files.
• Some files may not open.
Using linked info	Start Here ⦿ ➡ *Tools* ➡ ⦿ ➡ ⊙ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ⦿ ➡ *Scan Barcode* ➡ ⦿ ➡ **Frame barcode in center of Display** ➡ ⦿ ➡ **See below**
Dialing Numbers
Select phone number ➡ ⦿ ➡ ☎
Sending Messages
Select mail address ➡ ⦿ ➡ **Complete message** ➡ ▽
• When *MAIL TO:* appears in scan results, press ⦿ to enter the items underlined with a dotted line automatically in Composition window.
Accessing Internet Sites
Select URL ➡ ⦿

Using images as Wallpaper	⦿ ➡ *Tools* ➡ ⦿ ➡ ⊙ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ⦿ ➡ *Scan Barcode* ➡ ⦿ ➡ **Frame barcode in center of Display** ➡ ⦿ ➡ **Select image** ➡ ✉ ➡ *Set as Wallpaper* ➡ ⦿ ➡ ⦿
• If Wallpaper Display options appear, follow onscreen prompts.
Saving images & melodies	⦿ ➡ *Tools* ➡ ⦿ ➡ ⊙ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ⦿ ➡ *Scan Barcode* ➡ ⦿ ➡ **Frame barcode in center of Display** ➡ ⦿ ➡ **Select file** ➡ ✉ ➡ *To Data Folder* ➡ ⦿
Opening or playing files	⦿ ➡ *Tools* ➡ ⦿ ➡ ⊙ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ⦿ ➡ *Scan Barcode* ➡ ⦿ ➡ **Frame barcode in center of Display** ➡ ⦿ ➡ **Select file** ➡ ⦿
Using images for System Graphics	⦿ ➡ *Tools* ➡ ⦿ ➡ ⊙ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ⦿ ➡ *Scan Barcode* ➡ ⦿ ➡ **Frame barcode in center of Display** ➡ ⦿ ➡ **Select image** ➡ ✉ ➡ *As System* ➡ ⦿ ➡ **Select item** ➡ ⦿ ➡ **Specify display area** ➡ ⦿
• Some images may be usable without specifying display area.

Pasting to message text	[Start Here] ● ➡ *Tools* ➡ ● ➡ ☉ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ● ➡ *Scan Barcode* ➡ ● ➡ **Frame barcode in center of Display** ➡ ● ➡ ☑ ➡ *Send Message* ➡ ● ➡ **See below** **All Text** ● ➡ *S! Mail* or *SMS* ➡ ● ➡ **Complete message** ➡ ☑ ● S! Mail Composition window opens automatically depending on character count. **Selected Text** ☑ ➡ **Select first character** ➡ ● ➡ **Highlight text range** ➡ ● ➡ *S! Mail* or *SMS* ➡ ● ➡ **Complete message** ➡ ☑ ● S! Mail Composition window opens automatically depending on character count.
Copying text	[Start Here] ● ➡ *Tools* ➡ ● ➡ ☉ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ● ➡ *Scan Barcode* ➡ ● ➡ **Frame barcode in center of Display** ➡ ● ➡ **See below** **Text** ☑ ➡ *Copy* ➡ ● ➡ **Select first character** ➡ ● ➡ **Highlight text range** ➡ ● **Number, Address or URL** **Select number, mail address or URL** ➡ ☑ ➡ *Copy Telephone*, *Copy Address* or *Copy URL* ➡ ●

Scan Card

Saving to Notepad	● ➡ *Tools* ➡ ● ➡ ☉ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ● ➡ *Scan Card* ➡ ● ➡ **Frame card in center of Display** ➡ ● ➡ ● ➡ ☑ ➡ *Notepad* ➡ ●
Pasting to message text	[Start Here] ● ➡ *Tools* ➡ ● ➡ ☉ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ● ➡ *Scan Card* ➡ ● ➡ **Frame card in center of Display** ➡ ● ➡ ● ➡ ☑ ➡ *Send Message* ➡ ● ➡ **See below** **All Text** ● ➡ *S! Mail* or *SMS* ➡ ● ➡ **Complete message** ➡ ☑ ● S! Mail Composition window opens automatically depending on character count. **Selected Text** ☑ ➡ **Select first character** ➡ ● ➡ **Highlight text range** ➡ ● ➡ *S! Mail* or *SMS* ➡ ● ➡ **Complete message** ➡ ☑ ● S! Mail Composition window opens automatically depending on character count.
Copying text	[Start Here] ● ➡ *Tools* ➡ ● ➡ ☉ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ● ➡ *Scan Card* ➡ ● ➡ **Frame card in center of Display** ➡ ● ➡ ● ➡ **See below** **Text** ☑ ➡ *Copy* ➡ ● ➡ **Select first character** ➡ ● ➡ **Highlight text range** ➡ ●

9

Handy Extras

9-39

Scan Text

Scanning during text entry	In a text entry window, $\boxdot$ ➡ *Scan* ➡ $\circledast$ ➡ *Text Scanner* ➡ $\circledast$ ➡ **Frame text in center of Display** ➡ $\circledast$ ➡ **Select line** ➡ $\circledast$ ➡ $\circledast$
Scanning more text	$\circledast$ ➡ *Tools* ➡ $\circledast$ ➡ $\odot$ *Doc./Rec.* ➡ *Barcode/ Scan* ➡ $\circledast$ ➡ *Scan Text* ➡ $\circledast$ ➡ **Frame text in center of Display** ➡ $\circledast$ ➡ **Select line** ➡ $\circledast$ ➡ $\circledast$ ➡ $\boxdot$ ➡ *Continue Part* or *Scan More* ➡ $\circledast$ ● Select *Continue Part* to enter additional text or *Scan More* to enter text after a line break.
Saving scan results	$\circledast$ ➡ *Tools* ➡ $\circledast$ ➡ $\odot$ *Doc./Rec.* ➡ *Barcode/ Scan* ➡ $\circledast$ ➡ *Scan Text* ➡ $\circledast$ ➡ **Frame text in center of Display** ➡ $\circledast$ ➡ **Select line** ➡ $\circledast$ ➡ $\circledast$ ➡ $\boxdot$ ➡ *Save* ➡ $\circledast$
Saving linked info to Phone Book	$\circledast$ ➡ *Tools* ➡ $\circledast$ ➡ $\odot$ *Doc./Rec.* ➡ *Barcode/ Scan* ➡ $\circledast$ ➡ *Scan Text* ➡ $\circledast$ ➡ **Frame text in center of Display** ➡ $\circledast$ ➡ **Select line** ➡ $\circledast$ ➡ **Select number or mail address** ➡ $\boxdot$ ➡ *Save to Ph.Book* ➡ $\circledast$ ➡ *As New Entry* ➡ $\circledast$ ➡ **Complete other fields** ➡ $\boxed{Y}$ ● To add to an existing entry, select *As New Detail*.
Saving to Notepad	$\circledast$ ➡ *Tools* ➡ $\circledast$ ➡ $\odot$ *Doc./Rec.* ➡ *Barcode/ Scan* ➡ $\circledast$ ➡ *Scan Text* ➡ $\circledast$ ➡ **Frame text in center of Display** ➡ $\circledast$ ➡ **Select line** ➡ $\circledast$ ➡ $\circledast$ ➡ $\boxdot$ ➡ *Notepad* ➡ $\circledast$

Opening saved scan results	$\circledast$ ➡ *Tools* ➡ $\circledast$ ➡ $\odot$ *Doc./Rec.* ➡ *Barcode/ Scan* ➡ $\circledast$ ➡ *Scanned Results* ➡ $\circledast$ ➡ **Select file** ➡ $\circledast$ ● Select a file and press $\boxdot$ to rename files, open properties or delete files. ● Some files may not open.
Using linked info	$\boxed{\text{Start Here}}$ $\circledast$ ➡ *Tools* ➡ $\circledast$ ➡ $\odot$ *Doc./Rec.* ➡ *Barcode/Scan* ➡ $\circledast$ ➡ *Scan Text* ➡ $\circledast$ ➡ **Frame text in center of Display** ➡ $\circledast$ ➡ **Select line** ➡ $\circledast$ ➡ $\circledast$ ➡ **See below** **Dialing Numbers** **Select phone number** ➡ $\circledast$ ➡ $\boxed{\text{☎}}$ **Sending Messages** **Select mail address** ➡ $\circledast$ ➡ **Complete message** ➡ $\boxed{Y}$ **Accessing Internet Sites** **Select URL** ➡ $\circledast$
Pasting to message text	$\boxed{\text{Start Here}}$ $\circledast$ ➡ *Tools* ➡ $\circledast$ ➡ $\odot$ *Doc./Rec.* ➡ *Barcode/Scan* ➡ $\circledast$ ➡ *Scan Text* ➡ $\circledast$ ➡ **Frame text in center of Display** ➡ $\circledast$ ➡ **Select line** ➡ $\circledast$ ➡ $\circledast$ ➡ $\boxdot$ ➡ *Send Message* ➡ $\circledast$ ➡ **See below** **All Text** $\circledast$ ➡ *S! Mail* or *SMS* ➡ $\circledast$ ➡ **Complete message** ➡ $\boxed{Y}$ ● S! Mail Composition window opens automatically depending on character count. **Selected Text** $\boxdot$ ➡ **Select first character** ➡ $\circledast$ ➡ **Highlight text range** ➡ $\circledast$ ➡ *S! Mail* or *SMS* ➡ $\circledast$ ➡ **Complete message** ➡ $\boxed{Y}$ ● S! Mail Composition window opens automatically depending on character count.

Copying text	Start Here ⑥ ➡ *Tools* ➡ ⑥ ➡ ⊙ *Doc./Rec.* ➡ *Barcode/Scan* ➡ ⑥ ➡ *Scan Text* ➡ ⑥ ➡ **Frame text in center of Display** ➡ ⑥ ➡ **Select line** ➡ ⑥ ➡ ⑥ ➡ **See below**
	Text ✉ ➡ *Copy* ➡ ⑥ ➡ **Select first character** ➡ ⑥ ➡ **Highlight text range** ➡ ⑥
	Number, Address or URL **Select number, mail address or URL** ➡ ✉ ➡ *Copy Telephone*, *Copy Address* or *Copy URL* ➡ ⑥

S! Quick News

Receiving S! Loop item updates	Start Here ⑥ ➡ *Entertainment* ➡ ⑥ ➡ *S! Quick News* ➡ ⑥ ➡ *S! Loop List* ➡ ⑥ ➡ **See below**
	Registering with S! Loop Items *S!ル-プ にアクセス* ➡ ⑥ ➡ *Yes* ➡ ⑥ ● Handset connects to the Internet. Refer to the S! Loop help menu for operational instructions.
	Opening Information **Select item** ➡ ⑥ ➡ **Select title** ➡ ⑥
Updating list automatically	Start Here ⑥ ➡ *Entertainment* ➡ ⑥ ➡ *S! Quick News* ➡ ⑥ ➡ *Settings* ➡ ⑥ ➡ *Automatic Update* ➡ ⑥ ➡ **See below**
	S! Quick News List *S! Quick News* ➡ ⑥ ➡ **Select item** ➡ ⑥ ➡ ⑥ ➡ **Select interval or choose *On*** ➡ ⑥ ● When a confirmation appears, press ⑥. ● When Special is set to *On*, items are updated every four hours. ● When General is set to *On*, items are updated once a day. ● To cancel automatic update, choose *Off* and press ⑥. ● Updating items may incur high charges. ● Only available in Japan.
	S! Loop List *S! Loop* ➡ ⑥ ➡ ⑥ ➡ *On* ➡ ⑥ ➡ ⑥ ● Items are updated about four times a day. ● Only available in Japan.

9

Handy Extras

1

9-41

Checking update schedule	$\bullet$ $\blacktriangleright$ *Entertainment* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *S! Quick News* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *Settings* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *Check Schedule* $\blacktriangleright$ $\bullet$
Changing background image	$\bullet$ $\blacktriangleright$ *Entertainment* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *S! Quick News* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *Settings* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *Change Skin* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ Select pattern $\blacktriangleright$ $\bullet$
Deleting S! Quick News items	[Start Here] $\bullet$ $\Rightarrow$ *Entertainment* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *S! Quick News* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *S! Quick News List* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ Select item $\blacktriangleright$ $\boxdot$ $\blacktriangleright$ See below
	One Entry 一件 $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *Yes* $\blacktriangleright$ $\bullet$
	All Entries 全件 $\blacktriangleright$ $\bullet$ $\blacktriangleright$ Enter Handset Code $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *Yes* $\blacktriangleright$ $\bullet$
Updating S! Loop items manually	[Start Here] $\bullet$ $\Rightarrow$ *Entertainment* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *S! Quick News* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *S! Loop List* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ See below
	One Entry Select item $\blacktriangleright$ $\boxed{Y}$ $\blacktriangleright$ 更新 $\blacktriangleright$ $\bullet$ $\blacktriangleright$ 一件 $\blacktriangleright$ $\bullet$
	All Entries $\boxed{Y}$ $\blacktriangleright$ 更新 $\blacktriangleright$ $\bullet$ $\blacktriangleright$ 全件 $\blacktriangleright$ $\bullet$
Accessing source sites	$\bullet$ $\blacktriangleright$ *Entertainment* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *S! Quick News* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ Select list $\blacktriangleright$ $\bullet$ $\blacktriangleright$ Select item $\blacktriangleright$ $\bullet$ $\blacktriangleright$ Select title $\blacktriangleright$ $\bullet$ $\blacktriangleright$ Select title $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *Yes* $\blacktriangleright$ $\bullet$
Disabling image download	$\bullet$ $\blacktriangleright$ *Entertainment* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *S! Quick News* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *Settings* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *Show Image* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *Off* $\blacktriangleright$ $\bullet$

Deleting S! Loop items	[Start Here] $\bullet$ $\Rightarrow$ *Entertainment* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *S! Quick News* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *S! Loop List* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ Select item $\blacktriangleright$ $\boxdot$ $\blacktriangleright$ See below
	One Entry 一件 $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *Yes* $\blacktriangleright$ $\bullet$
	All Entries 全件 $\blacktriangleright$ $\bullet$ $\blacktriangleright$ Enter Handset Code $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *Yes* $\blacktriangleright$ $\bullet$
Resetting S! Quick News List and S! Loop List	$\bullet$ $\blacktriangleright$ *Entertainment* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *S! Quick News* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *Settings* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *Delete S! Quick News Lists* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ Enter Handset Code $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *Yes* $\blacktriangleright$ $\bullet$ ● Not available during automatic updates.

S! Information Channel

Hiding Information window for new received info	$\bullet$ $\blacktriangleright$ *Entertainment* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *S! Information Channel/Weather* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *Notification* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *Off* $\blacktriangleright$ $\bullet$
Changing Display Size	On a page, $\boxdot$ $\blacktriangleright$ *Settings* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *Display Size* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ Select size $\blacktriangleright$ $\bullet$
Changing scroll unit	On a page, $\boxdot$ $\blacktriangleright$ *Settings* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ *Scroll Unit* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ Select unit $\blacktriangleright$ $\bullet$
Copying text	On a page, $\boxdot$ $\blacktriangleright$ *Copy Text* $\blacktriangleright$ $\bullet$ $\blacktriangleright$ Select first character $\blacktriangleright$ $\bullet$ $\blacktriangleright$ Highlight text range $\blacktriangleright$ $\bullet$

9

Handy Extras

Saving files to Data Folder	On a page, ☑ ➡ *Save Items* ➡ ● ➡ Select file ➡ ● ➡ *Save* ➡ ● ➡ Enter name ➡ ● ➡ *Save here* ➡ ● ● Some files are saved automatically.
Requesting re-delivery	● ➡ *Entertainment* ➡ ● ➡ *S! Information Channel/Weather* ➡ ● ➡ *Get Latest Contents* ➡ ● ➡ *Yes* ➡ ●
Opening page properties	On a page, ☑ ➡ *PageInformation* ➡ ●
Checking weather forecast	● ➡ *Entertainment* ➡ ● ➡ *S! Information Channel/Weather* ➡ ● ➡ *Weather Indicator* ➡ ● ➡ *Weather* ➡ ●
Changing weather forecast page font size	On a page, ☑ ➡ *Settings* ➡ ● ➡ *Font Size* ➡ ● ➡ Select size ➡ ●
Hiding Weather Indicator in Standby	● ➡ *Entertainment* ➡ ● ➡ *S! Information Channel/Weather* ➡ ● ➡ *Weather Indicator* ➡ ● ➡ *Settings* ➡ ● ➡ *Standby Setting* ➡ ● ➡ *Off* ➡ ●
Canceling Weather Indicator automatic updates	● ➡ *Entertainment* ➡ ● ➡ *S! Information Channel/Weather* ➡ ● ➡ *Weather Indicator* ➡ ● ➡ *Settings* ➡ ● ➡ *Icon Update* ➡ ● ➡ *Off* ➡ ●
Hiding Information window for weather updates	● ➡ *Entertainment* ➡ ● ➡ *S! Information Channel/Weather* ➡ ● ➡ *Weather Indicator* ➡ ● ➡ *Settings* ➡ ● ➡ *Weather Notif.* ➡ ● ➡ *Off* ➡ ●

e-Books

Copying text	In open page, ☒ ➡ *文字列をコヒ゜ -* ➡ ● ➡ Select first character ➡ ● ➡ Highlight text range ➡ ●
Opening non-930SH e-Books (Library)	● ➡ *Entertainment* ➡ ● ➡ *e-Book Viewer* ➡ ☑ ➡ Select file ➡ ● ● Some files may not open.
Using Library	Start Here ● ➡ *Entertainment* ➡ ● ➡ *e-Book Viewer* ➡ ☑ ➡ See below **Adding Folders** ☑ ➡ *New Folder* ➡ ● ➡ Enter name ➡ ● **Switching Folders** ☑ ➡ *Switch Folders* ➡ ● ➡ Select folder ➡ ● **Renaming Folders/Files** Select folder/file ➡ ☑ ➡ *Change Name* ➡ ● ➡ Enter name ➡ ● **Moving Files** Select file ➡ ☑ ➡ *Move* ➡ ● ➡ Select folder ➡ ● ➡ *Move here* ➡ ● **Deleting Folders/Files** Select folder/file ➡ ☑ ➡ *Delete* ➡ ● ➡ *Yes* ➡ ● **Opening File Properties** Select file ➡ ☑ ➡ *Details* ➡ ●

9

Handy Extras

Osaifu-Keitai®

❓ **Cannot use Osaifu-Keitai® (S! FeliCa)**

● Battery may be low. Charge battery or install a charged battery.

❓ **Recognition via reader/writer takes time**

● Check ⊋ logo area. Foreign articles can block/hamper recognition.

❓ **Call Remote Lock does not activate even after specified number of Missed Calls**

● Missed Call count is reset by calls from other numbers. If series is interrupted, start over from the beginning.
● When Call Forwarding is active, Missed Calls may not be recorded.

Wakeup TV

❓ **TV does not activate with specified channel**

● If Wakeup TV Time arrives while TV is active, channel does not switch to the specified one.

Voice Recorder

❓ **Cannot record properly**

● If incompatible microphone is connected, recording may fail.

❓ **Noise/skipping occurs**

● Avoid shocks to handset while recording; may cause noise or skipping.

❓ **Recording takes time to start**

● Recording window may take longer to open as more Voice files are saved on Memory Card.

Scanning Barcode/Card/Text

Cannot read barcodes properly

- Scan may fail if barcode is dirty or unclear.
- Scan may fail if barcode is scanned under inadequate light.
- Scan may fail if multiple barcodes are captured at one time.

Cannot read barcodes during text entry

- Scanning is not available during calls or when mobile camera is active.

Cannot read barcode images in Data Folder automatically

- When scan fails, follow onscreen instructions and select next barcode image manually.

Cannot scan business cards properly

- Scan fails if business card is printed in light-colored text on a dark background, handwritten or printed in casual/decorative fonts, decorated with a background pattern, or designed with both vertical and horizontal text.
- Scan may fail if business card is printed in light-colored text on a light background, printed in italics or extremely small fonts, decorated with a logo or logo-like text, printed on a glossy paper or other material, or dirty/folded.

Cannot scan text properly

- Scanning over 35 characters at one time may yield poor results.
- Adjust to frame text in [ ]. Letters at the ends may be distorted.

S! Quick News

Cannot receive content updates

- Update may fail out-of-range or in poor signal conditions.
- Automatic Update does not affect S! Quick News List News Flash or S! Loop List update items overnight.
- USIM Card replacement cancels Automatic Update.

9

Handy Extras