

# Calling



<b>Overview</b> .....	<b>3-2</b>	<b>Advanced Features</b> .....	<b>3-16</b>
<b>Voice Call</b> .....	<b>3-3</b>	Outgoing Call Functions .....	3-16
Making Voice Calls .....	3-3	International Calls .....	3-16
International Calls .....	3-3	Handling Incoming Calls .....	3-16
Answering Voice Calls .....	3-4	Engaged Call Operations .....	3-17
Recording the Other Party's Voice .....	3-4	Answering Machine .....	3-18
Answering Machine .....	3-4	Call Logs .....	3-18
Playing Messages .....	3-5	Speed Dial .....	3-18
<b>Video Call</b> .....	<b>3-7</b>	Optional Services .....	3-19
Video Call Window .....	3-7		
Making Video Calls .....	3-7		
Answering Video Calls .....	3-8		
<b>Call Logs</b> .....	<b>3-10</b>		
Dialing from Call Logs .....	3-10		
Call Time & Cost .....	3-11		
<b>Speed Dialing</b> .....	<b>3-12</b>		
Speed Dial .....	3-12		
Tomo-Den .....	3-12		
<b>Calling While Abroad (Global Roaming)</b> ..	<b>3-13</b>		
Calling Japan and Other Countries .....	3-13		
Calling within the Same Country .....	3-13		
<b>Optional Services</b> .....	<b>3-14</b>		
Overview .....	3-14		

# 3





# Overview

Voice call and video call are available on handset.


3  
Calling

### Voice Call

Make Calls to:

SoftBank Handsets    Non-SoftBank Mobile Phones



Landlines

### Video Call


Make Calls to:





SoftBank Handsets    Non-SoftBank Mobile Phones    Landlines

Other party must use a video call compatible phone



#### International Call

### Calling Abroad from Japan

Make/receive voice and video calls.

- International phone service available without separate application.

#### Global Roaming

### Using Handset Abroad

Handset is Global Roaming Service eligible. (Prior application may be required.)

- For details, see: [http://mb.softbank.jp/en/global\\_services/global\\_roaming/](http://mb.softbank.jp/en/global_services/global_roaming/) or contact SoftBank Mobile Customer Center, General Information (P. 15-53).

## Emergency Calls

Your location is automatically reported to the corresponding agency (police, etc.) when you place emergency calls (110, 119 or 118) with Softbank 3G handsets.

(Emergency Location Report)

930N reports Location Information based on positioning signals from radio stations.

- Registration and transmission fees do not apply.
- Positioning accuracy is affected by location and signal conditions. Always provide your location and purpose on the phone.
- Location Information is not reported when emergency calls are placed without Caller ID (such as when the number is prefixed with 184). However, the corresponding agency may obtain your Location Information in a life threatening situation.
- Not available during international roaming.

## Emergency calls are possible even while some handset restrictions are active.

- Restrict Dialing (P. 2-23)
- Keypad Lock (P. 4-4)
- Set Max Cost Limit (P. 14-14)
- Emission OFF Mode (P. 4-6)
- PIN1 Code Entry Set (P. 4-2)



## Making Voice Calls

### 1 Enter phone number



Phone Number Entry Window


#### ■ Correcting Misentries

→ to scroll cursor → to delete (press and hold to delete all numbers to the left) → Reenter number(s)

#### ■ Deleting Phone Number

→

### 2



Voice Call Window

### 3 to end call

#### Note

- The other party may hear a short beep when to , or are pressed during a call.

#### Tip

- Always include the area code even when dialing from the same area.
- When you hear a busy tone, the other party is on another line.
- When you hear a message saying that the other party cannot be reached, the other party's mobile phone is off or is out of signal range.
- When you hear a message asking for your caller ID, call again with your number revealed.

- After Display backlight turns off during a call, if no keys are pressed for about two minutes, Display goes off and handset enters power saving mode regardless of Lighting setting for Backlight (P. 14-5). Handset can be operated in power saving mode in the same way as when Display is lit.
- Call ends when handset is closed. Connect stereo earphone-microphone to talk with handset closed.

## Available Keys during Voice Calls

Adjust Earpiece Volume	Press and hold
	or
Hold Call	

## International Calls

Application not required.

1 Enter phone number → → *Int'l call* →

2 Select a country code → → Select an international prefix number → →

3 to end call



## Answering Voice Calls

- 1 When a call arrives →
- 2 to end call

## Recording the Other Party's Voice

- 1 Press and hold during a call  
A short beep sounds through the earpiece and recording starts. When remaining recording time reaches five seconds, a short beep sounds. When recording is finished, two short beeps sound.  
To stop recording, press or press and hold .

## Answering Machine

Record caller's messages on handset when you are unable to answer voice or video calls.

### Setting Answering Machine


- 1 → **Settings** → → **Incoming Call** → → **Answering Machine** →
- 2 **ON** → → **Select an outgoing message** →
- 3 **Enter ring time**

#### Tip

- When Voice Mail or Call Forward is activated, set a shorter ring time for Answering Machine than that for Voice Mail or Call Forward.
- Answering Machine can be set or canceled by pressing and holding **CLEAR** in Standby.
- Answering Machine is unavailable when power is off, in a place with no signal reception, or in Emission OFF Mode. Use Voice Mail instead (see P. 3-14).

## When a Call Arrives

Answering Machine activates after the set ring time. Outgoing message plays, and the caller's voice/video message is recorded. Handset returns to Standby when recording is complete. Answering Machine notification and Display indicator appear. The indicator shows the number of messages.



- **To Answer Call during Recording**  
→

### Activate When Call Arrives

Activate Answering Machine when unable to answer an incoming call. Answering Machine setting returns, after message is recorded.

- 1 **When a call arrives** → **CLEAR** or   
Answering Machine is activated and starts recording.



## Note


- Answering Machine cannot be activated when memory is full.

## Tip

- Alternatively, press **[#]** when a call arrives. When answering with **[#]**, handset enters Manner Mode.

## Playing Messages

- 1 **Select notification** or



Play/Delete Voice Message Window

Items with a message recorded are indicated by ★.

- 2 **Select a message**

## Tip

- To delete a message while playing it: **Erase** **YES**

## Available Keys during Playback

Play Next Message	
Stop	or <b>CLEAR</b>
Return a Voice Call	
Return a Video Call	

## Tip

- Pressing **CLEAR** in Standby also plays recorded voice messages. When there is a voice memo but no voice message, the voice memo plays.
- To play voice messages from Main Menu: **Tools** **Play/Erase Msg.**

## Available Keys during Video Message Playback

Play Previous/Next Message	
Adjust Volume	
	or
Pause/Play	
Stop	<b>CLEAR</b>
Return a Voice Call	
Return a Video Call	

## Tip

- To play video messages from Main Menu: **Tools** **Play/Erase VC Msg.**



## More Features

### Advanced

#### Outgoing Call Functions

- Show/Hide Caller ID
- Add Area Code and Country Code (Prefix Numbers) **(▶ P. 3-16)**

#### International Calls

- Enter “+” to Call Abroad **(▶ P. 3-16)**

#### Handling Incoming Calls

- Reject Calls
- Place Calls on Hold
- Forward Calls
- Forward Calls to Voice Mail Center **(▶ P. 3-16)**

#### Engaged Call Operations

- Handsfree
- Toggle Device (Handset and Bluetooth® Device)
- Make Other Party Clearer to Hear (Hyper Clear Voice)
- Send Touch Tones **(▶ P. 3-17)**

#### Answering Machine

- Delete Recorded Messages **(▶ P. 3-18)**

### Customize

#### Outgoing Calls

- Save Area Code and Country Code as Prefix Numbers

- Save Touch Tones
- Set Numbers after “\*” as Sub Address **(▶ P. 14-12)**

#### Display Settings

- Set an Outgoing Call Image
- Set an Incoming Call, Message Image or Video **(▶ P. 14-4)**

#### International Calls

- Change International Access Code
- Change a Country Code
- Save an International Access Code **(▶ P. 14-13)**

#### Incoming Call Alerts

- Adjust Ringtone Volume
- Set a Ringtone
- Set Random Playback of Melodies as Ringtones
- Set Vibration
- Set Illumination Color
- Set Illumination Pattern
- Set Illumination to Flash for Missed Calls
- Set an Incoming Call Image
- Show Phone Book Entry Images for Incoming Calls **(▶ P. 14-8)**

#### Answering Incoming Calls

- Set to Answer Calls by Pressing Any Key
- Set to Mute Ringtone by Pressing Any Key **(▶ P. 14-9)**

#### Call Settings

- Set Reconnection Tone
- Set Noise Reduction
- Set Weak Signal Alarm
- Set Clarity of Other Party Voice
- Automatically Record During Voice Call
- Change Color of Illumination While Calling
- Set a Hold Message
- Set Closing Sound Off
- End Call By Closing Handset **(▶ P. 14-13)**

#### Sounds

- Record Sound to Set as Ringtone or Outgoing Message
- Play Recorded Sound
- Delete Recorded Sound **(▶ P. 14-10)**

#### Earphone-Microphone


- Audio Output
- Microphone Setting
- Answer Calls Automatically
- Save a Phone Number to Dial with an Earphone-Microphone **(▶ P. 14-10)**

#### Key Illumination

- Set Illumination for Incoming or Outgoing Calls
- Set Illumination for Call Start **(▶ P. 14-28)**



## Video Call Window



## Video Call Indicators

	Hyper Clear Voice High
	Hyper Clear Voice Low
	Transmitting Audio
	Transmission Failed
	Transmitting Video
	Transmission Failed
	Sending Camera Image
	Substitute Image
	Handsfree ON
	Handsfree OFF
	Mute
	Visual Check

- Photo Mode Portrait
- Photo Mode Scenery
- Photo Mode Close-up

## Making Video Calls

### 1 Enter phone number



Phone Number Entry Window

#### ■ Correcting Misentries

→ to scroll cursor → Reenter number(s)

#### ■ Deleting Numbers

→ Select a number →

Press and hold to delete all numbers to the left of the selected number.

#### ■ Deleting Phone Number

→

### 2



Video Call Window

### 3 to end call

#### Note

- The other party may hear a short beep when to , \* or # are pressed during a call.



## Tip

- Always include the area code even when dialing from the same area.
- Video calls made to emergency numbers (110, 119 and 118) are automatically switched to voice calls.
- An error message with a possible cause appears when a video call fails to be connected.
- Charging may automatically stop or camera image may switch to substitute image if charging while making a video call, depending on temperature and handset usage (ex. also recording TV).
- Call ends when handset is closed. Connect stereo earphone-microphone to talk with handset closed.

## Available Keys during Video Calls

Adjust Earpiece Volume	or press and hold
	or
Hold Call	
Toggle Main Window Images	Press and hold  to toggle image as follows: The other party's image → Your image → The other party's image (sub window off) → Your image (sub window off)
Toggle Outgoing Camera Image	Press  to toggle Rear Camera and Front Camera.
Zoom In/Out Outgoing Camera Image	
Mute Audio	or press and hold . To cancel mute, press again.

## Answering Video Calls

- 1 When a video call arrives →
- 2 to end call

## More Features

### Advanced

#### Outgoing Call Functions

- Show/Hide Caller ID
- Add Area Code and Country Code (Prefix Numbers)

▶ P. 3-16

#### Handling Incoming Calls

- Reject Calls
- Place Calls on Hold
- Forward Calls

▶ P. 3-16

#### Engaged Call Operations

- Handsfree
- Toggle Device (Handset and Bluetooth® Device)
- Make Other Party Clearer to Hear (Hyper Clear Voice)
- Set Image Quality
- Adjust Brightness
- Change White Balance
- Change Color Tone
- Change Photo Mode
- Backlight Lighting Time

▶ P. 3-17





## Customize

### Outgoing Calls

- Save Area Code and Country Code as Prefix Numbers
  - Set Numbers after “\*” as Sub Address
- (▶ P. 14-12)

### Display Settings

- Set an Outgoing Call Image
- (▶ P. 14-4)

### Incoming Call Alerts

- Adjust Ringtone Volume
  - Set a Ringtone
  - Set Random Playback of Melodies as Ringtones
  - Set Vibration
  - Set Illumination Color
  - Set Illumination Pattern
  - Set Illumination to Flash for Missed Calls
  - Set an Incoming Call Image
  - Show Phone Book Entry Images for Incoming Calls
- (▶ P. 14-8)

### Answering Incoming Calls

- Set to Answer Calls by Pressing Any Key
  - Set to Mute Ringtone by Pressing Any Key
- (▶ P. 14-9)

### Call Settings

- Set Reconnection Tone
  - Set Noise Reduction
  - Set Weak Signal Alarm
  - Set Clarity of Other Party Voice
  - Change Color of Illumination While Calling
  - Set a Hold Message
  - Set Closing Sound Off
  - End Call By Closing Handset
- (▶ P. 14-13)

### Earphone-Microphone

- Audio Output
  - Microphone Setting
  - Answer Calls Automatically
  - Save a Phone Number to Dial with an Earphone-Microphone
- (▶ P. 14-10)

### Video Calls

- Set an Image to be Sent during Video Calls
  - Redial Automatically as Voice Call When Video Call Connection Fails
  - Set an Image to Appear in Main Window
  - Reverse Front Camera Image
  - Automatically Switch to Handsfree Mode in Video Calls
- (▶ P. 14-14)

### Key Illumination

- Set Illumination for Incoming or Outgoing Calls
  - Set Illumination for Call Start
- (▶ P. 14-28)



### Dialing from Call Logs

Phone numbers and dates and times of incoming and outgoing calls are saved on handset as call logs. Access call logs to return calls quickly.

### Call Log Indicators

The following indicators appear in Redial, Dialed Calls and Received Calls windows.

Voice Calls	
	Outgoing & Incoming
	Missed
	Unchecked Missed
International Calls	
	Outgoing & Incoming
	Missed
	Unchecked Missed
Video Calls	
	Outgoing & Incoming
	Missed
	Unchecked Missed
International Video Calls	
	Outgoing & Incoming
	Missed
	Unchecked Missed

	Answering Machine
	Voice Messages
	Video Messages
	Packet Transmission
	Outgoing & Incoming Calls Appears when outside the GMT+09 time zone.

### Redial/Received Calls

1 or



Redial Window



Received Calls Window

2 Select a record or

Select a Redial or Received Calls record and press to check its details.

### Dialed Calls

1 **Dialed Calls**



Dialed Calls Window

2 Select a record or

Select a Dialed Calls record and press to check its details.

### Checking Number of Missed Calls

1

**Received Calls**

The total number of incoming calls, number of missed calls, and number of unchecked missed calls appear.

2 **All Calls** or **Missed Calls**



## Missed Calls

Illumination flashes.

Select the "Missed Call" icon to check details or select the icon and press and hold **[CLEAR]** to turn off illumination.

## Call Time & Cost

Check the total and last call times and costs.

**Call cost and cost limit may be unavailable depending on your subscription.**

**1** ⇒ **Settings** ⇒ ⇒ **Call Time/Charge** ⇒ ⇒ **Call Data** ⇒

### Tip

- Use indicated call times and costs only as a guide. The actual call time and cost may be different. Your handset may not indicate call costs depending on the service you subscribe. Indicated costs do not include consumption tax.
- When the last or total call time exceeds 199 hours 59 minutes 59 seconds, counting restarts from zero seconds.

## More Features

### Advanced

#### Redial, Dialed Calls & Received Calls

- Change Font Size
- Show Ring Time (Missed Calls)
- Delete Records

**▶ P. 3-18**

#### Call Time & Cost

- Reset Total Call Time
- Reset Total Call Cost

**▶ P. 3-18**

### Customize

#### Incoming Call Alerts

- Set Illumination to Flash for Missed Calls

**▶ P. 14-8**

#### Checking Call Logs

- Notify Missed Calls with Tone (When Pressed)
- Change Colors of Names, Phone Numbers and E-mail Addresses in Call and Message Log Windows

**▶ P. 14-10**

#### Call Costs

- Set Auto Reset of Total Call Cost
- Set a Maximum Call Cost Limit

**▶ P. 14-14**

#### Key Illumination

- Set Illumination for Missed Call

**▶ P. 14-28**



## Speed Dial

Enter Phone Book entry number (000 to 009) and press for direct access to that entry.

- If a Phone Book entry has more than one phone number, handset dials the first number.

1 to → or


## Tomo-Den

Save up to five Phone Book entries to Tomo-Den for quick access.

- Tomo-Den is unavailable in Secret Data Only Mode.
- Tomo-Den is available in Secret Mode, however secret entries cannot be saved to Tomo-Den.

## Saving Entries to Tomo-Den

1



Tomo-Den Window

2 → Select a tab →

- ▶ To Search from Phone Book  
**View Phone Book** → → Search Phone Book → Select an entry →
- ▶ To Enter the Information  
**Direct input** → → Enter items →

3 Select a phone number or e-mail address →

When a checkbox is selected, other numbers/addresses become grayed and cannot be selected. To select another number/address, first cancel the currently selected checkbox.

4

## Using Tomo-Den

1

2 → Select an entry → **CALL**, **MAIL** or **VIDEO CALL** →

## More Features

### Advanced

#### Speed Dial

- Cancel Entries from Tomo-Den
  - Change Tomo-Den Entry Image
  - To Send an S! Mail to All Tomo-Den Entries
- (▶ P. 3-18)



# Calling While Abroad (Global Roaming)

Make calls while overseas.

- Global Roaming Service may require prior application. Details are available online at [http://mb.softbank.jp/en/global\\_services/global\\_roaming/](http://mb.softbank.jp/en/global_services/global_roaming/) or by contacting SoftBank Mobile Customer Center, General Information (P. 15-53).
- 930N is compatible with 3G and GSM networks.

## Calling Japan and Other Countries

**1** Press and hold

"+" is entered.

**2** Enter country code and phone number (omit first "0" from area code) ⇨

### Tip

- Do not omit the first "0" from area code when calling Italy.

## Calling within the Same Country

**1** Enter phone number with area code ⇨

Do not omit "0" from area code.  
Country code not required.

## More Features

### Customize

#### Global Roaming

- Set Operator
- Search Available Operator
- Set Priority for Operators
- Change Network
- Show Operator Name While Roaming

▶ P. 14-15



### Overview

The following services are available with your handset.

Call Forward	Forward calls to a preset phone number.
Voice Mail	Forward calls to Voice Mail Center when unable to answer a call. <b>Missed Call Notification</b> Notification (SMS) arrives for missed calls while handset was off, out of range or engaged, etc.
Call Waiting*	Place the current call on hold to answer another incoming call. Talk with two parties alternately.
Group Calling*	Call others during a call and talk with multiple parties simultaneously.
Call Barring	Select whether to restrict incoming and outgoing calls and SMS.
Caller ID	Select whether to show or hide your number when making calls.

\* Separate application is required.

### Activating Call Forward

<Example> Forward calls to a specified number after a set ring time

- 1 ⇒ **Settings** ⇒ ⇒ ⇒ **Optional Services** ⇒ ⇒ ⇒ **Voice Mail/Divert** ⇒



Voice Mail/Divert Window

- 2 **Divert ON** ⇒ ⇒ **YES** ⇒ ⇒ ⇒ **Voice/Video Calls, Voice Calls or Video Calls** ⇒ ⇒

▶ **To Enter Phone Number**  
Enter phone number ⇒

▶ **To Search from Phone Book**  
 ⇒ Search Phone Book ⇒ Select an entry ⇒ ⇒ Select a phone number ⇒ (twice)

- 3 **No Answer** ⇒ ⇒ Select a ring time ⇒

To forward calls immediately, select **Always** and press .

### Tip

- If **No Answer** is set, press to answer incoming call before the call is forwarded. If **Always** is set, handset does not ring/vibrate and all calls are forwarded to the preset number.
- Call Forward and Voice Mail cannot be set simultaneously. Call Forward for video calls is only available with Voice Mail.
- If you activate Call Forward when Voice Mail has already been set, Voice Mail is canceled.

### Activating Voice Mail

<Example> Forward calls to Voice Mail Center after a set ring time

- 1 [Voice Mail/Divert] window ⇒ **Voice Mail ON** ⇒ ⇒ **YES** ⇒

- 2 **No Answer** ⇒ ⇒ Select a ring time ⇒

To forward calls to Voice Mail Center immediately, select **Always** and press .



## Tip

- If *No Answer* is set, press to answer incoming call before the call is forwarded to Voice Mail Center. If *Always* is set, handset does not ring or vibrate and all calls are forwarded to Voice Mail Center.
- Voice Mail and Call Forward cannot be set simultaneously. Voice Mail is only available with Call Forward for video calls.
- If you activate Voice Mail when Call Forward has already been set, Call Forward is canceled.

## Missed Call Notification

SMS notification informs you of missed calls while handset was off, out of range, engaged, etc.



Follow voice guidance.

## To Play Messages

- 1** [Voice Mail/Divert] window ⇨  
**Play Messages** ⇨ ● ⇨ **YES** ⇨ ●

## Canceling Call Forward & Voice Mail

- 1** [Voice Mail/Divert] window ⇨  
**Voice Mail/Divert OFF** ⇨ ● ⇨  
**YES** ⇨ ●

## More Features

### Advanced

#### Call Forward & Voice Mail

- Delete Icons for Notifying Recorded Messages
  - Check Current Setting Status
- ▶ P. 3-19

#### Call Waiting

- Set Call Waiting
  - Answer Incoming Calls during Calls
  - Check Current Setting Status
- ▶ P. 3-19

#### Group Calling

- Hold Current Call to Make Another Call
  - Switch Parties
  - Talk with Multiple Parties Simultaneously
  - Talk with a Specific Party
  - End Call with a Specific Party
- ▶ P. 3-19

#### Call Barring

- Restrict Incoming/Outgoing Calls & SMS
  - Cancel Call Barring
  - Change Network Password
  - Check Current Setting Status
- ▶ P. 3-20

#### Caller ID

- Show/Hide Phone Number
  - Check Current Setting Status
- ▶ P. 3-20



### Outgoing Call Functions

#### Show/Hide Caller ID

Enter phone number → → **Notify Caller ID** → ● → **OFF, ON** or **Cancel Prefix** → ● → or

Alternatively, enter "186" before the phone number to show your number, or "184" to hide your number.

Show/hide Caller ID each time you dial from Phone Book or call logs (Redial, Dialed Calls or Received Calls).

#### Add Area Code and Country Code (Prefix Numbers)

Enter phone number → → **Prefix Numbers** → ● → Select an item → ● → or

Store area codes and country codes beforehand. Enter prefixes before making calls.

Add prefix from Phone Book entry, Redial, Dialed Calls or Received Calls windows.

0046010 as **國際発信**, **184** and **186** are set by default.

### International Calls

#### Enter "+" to Call Abroad

Press and hold → Enter country code → Enter area code → Enter phone number → → **Dial** → ●

"+" appears when you press and hold , indicating that the international code set in **Auto Int'l Call Set** is entered.

### Handling Incoming Calls

#### Voice & Video Calls

##### Reject Calls

When a call arrives → → **Call Rejection** → ●

##### Place Calls on Hold

When a call arrives → → To answer call →   
 Press again to end the call on hold.

### Forward Calls

When a call arrives → → **Call Forwarding** → ●

This procedure is available when Call Forward has been activated from Voice Mail/Divert window.

### Voice Calls

#### Forward Calls to Voice Mail Center

When a call arrives → → **Call Forwarding** → ●

This procedure is available when Voice Mail has been activated from Voice Mail/Divert window.





## Engaged Call Operations

### Start Here

[Voice Call] window ..... P. 3-3

[Video Call] window..... P. 3-7

## Voice & Video Calls

### Handsfree

[Voice Call] window/ [Video Call] window  
→

Press again to cancel handsfree mode.

### Toggle Device (Handset and Bluetooth® Device)

[Voice Call] window/ [Video Call] window  
→ → **Bluetooth/Phone** →

### Make Other Party Clearer to Hear (Hyper Clear Voice)

[Voice Call] window/ [Video Call] window  
→

Press to toggle setting High, Off or Low.

Unavailable when handsfree is On or when an external device (ex. stereo earphone-microphone) is connected.

## Voice Calls

### Send Touch Tones

[Voice Call] window → (twice) → **Settings** → → **Dialing** → → **Pause Dial** → (three times)

- To send touch tones all at once:
  - Press and hold → **Send at one time** →

Each time you press , a touch tone sequence until "p" (pause) is sent.

Save touch tones in advance (P. 14-12).

## Video Calls

### Set Image Quality

[Video Call] window → → **V. Call Settings** → → **Visual Prefer.** → → Select an item →

### Adjust Brightness

[Video Call] window → → **V. Call Settings** → → **Brightness** → → Select a level →

Available when sending camera image.

### Change White Balance

[Video Call] window → → **V. Call Settings** → → **White Balance** → → Select an item →

Available when sending camera image.

### Change Color Tone

[Video Call] window → → **V. Call Settings** → → **Color Mode Set** → → Select an item →

Available when sending camera image.

### Change Photo Mode

[Video Call] window → → **V. Call Settings** → → **Photo Mode** → → Select a mode →

Available when sending Rear Camera image.

### Backlight Lighting Time

[Video Call] window → → **Display Light** → → **All Time ON** or **Same as Backlight** →



## Answering Machine

### Start Here

[Play/Delete Voice Message] window ..... P. 3-5

### Delete Recorded Messages

[Play/Delete Voice Message] window →  
Select a message → → *Delete This*,  
*Delete Rec. Msg.* or *Delete All* → ● → YES  
→ ●

Selecting *Delete All* also deletes a voice memo if it has been saved.

## Call Logs

### Start Here

[Redial] window ..... P. 3-10  
[Dialed Calls] window ..... P. 3-10  
[Received Calls] window ..... P. 3-10

## Redial, Dialed Calls & Received Calls

### Change Font Size

[Redial] window, [Dialed Calls] window  
or [Received Calls] window → → *Font Setting* → ● → *Standard Font* or *Big Font*  
→ ●

## Show Ring Time (Missed Calls)

[Received Calls] window → → *Ring Time* → ●

## Delete Records

[Redial] window, [Dialed Calls] window or  
[Received Calls] window → → *Delete*  
→ ●

- Delete Selected Entry  
→ *Delete This* → ● → YES → ●
- Select Entries to Delete  
→ *Delete selected* → ● → Select records  
→ ● → → YES → ●
- Delete All Entries  
→ *Delete All* → ● → Enter Security Code  
→ ● → YES → ●

Selecting *Delete All* in Redial window or Dialed Calls window deletes all records from both Redial and Dialed Calls.

## Call Time & Cost

### Reset Total Call Time

→ *Settings* → ● → *Call Time/Charge*  
→ ● → *Reset Total* → ● → Enter  
Security Code → ● → *Reset Total*  
*Duration* → ● → YES → ●

## Reset Total Call Cost

→ *Settings* → ● →  
*Call Time/Charge* → ● → *Reset Total* →  
● → Enter Security Code → ● → *Reset*  
*Total Cost* → ● → YES → ● → Enter  
PIN2 → ●

## Speed Dial

### Start Here

[Tomo-Den] window ..... P. 3-12

### Cancel Entries from Tomo-Den

[Tomo-Den] window → → Select a tab  
→

- To Release Selected Entry  
→ *Release This* → ● → YES → ●
- To Release All Entries  
→ *Release All* → ● → Enter Security  
Code → ● → YES → ●

### Change Tomo-Den Entry Image

[Tomo-Den] window → → Select a tab  
→ → *Image* → ● → Select a folder  
→ ● → Select an image → ●



# Advanced Features

## To Send an S! Mail to All Tomo-Den Entries

[Tomo-Den] window → → **Broadcast Mail** → → Create S! Mail →

## Optional Services

### Start Here

[Voice Mail/Divert] window ..... P. 3-14

[Voice Call] window ..... P. 3-3

## Call Forward & Voice Mail

### Delete Icons for Notifying Recorded Messages

[Voice Mail/Divert] window → **Erase Icon** → → **YES** →

### Check Current Setting Status

[Voice Mail/Divert] window → **Get Status** →

## Call Waiting

### Set Call Waiting

→ **Settings** → → **Optional Services** → → **Call Waiting** → → **ON** or **OFF** → → **YES** →

### Answer Incoming Calls during Calls

[Voice Call] window → Call waiting tone sounds →

Press to toggle between two parties.

### Check Current Setting Status

→ **Settings** → → **Optional Services** → → **Call Waiting** → → **Get Status** →

## Group Calling

### Hold Current Call to Make Another Call

[Voice Call] window → Enter phone number →

To dial from Phone Book, press or , search Phone Book, select a number and then press .

To dial from Dialed/Received Calls, press or , select a phone number or name and then press .

### Switch Parties

[Voice Call] window →

Press to toggle parties.

### Talk with Multiple Parties Simultaneously

[Voice Call] window → While talking with one party → → **Join Multi Party** →

### Talk with a Specific Party

[Voice Call] window → While talking with multiple parties → → **Select Ans. Call** → → Select a party →

The other parties are placed on hold while talking with the selected party.



### End Call with a Specific Party

[Voice Call] window ⇨ While talking with multiple parties ⇨ ⇨ **Select Disc Call** ⇨ ● ⇨ Select a party ⇨ ●

### Call Barring

#### Restrict Incoming/Outgoing Calls & SMS

⇨ **Settings** ⇨ ● ⇨ **Optional Services** ⇨ ● ⇨ **Call Barring** ⇨ ● ⇨ **Outgoing Calls** or **Incoming Calls** ⇨ ● ⇨ Select an item ⇨ ● ⇨ **YES** ⇨ ● ⇨ Enter Network Password ⇨ ●

Emergency numbers 110, 119 and 118 are available even when Call Barring is set.

When **Bar All Outgoing Calls** or **Bar All Incoming Calls** is set for Call Barring, Call Forward is unavailable (When Call Forward is set, Call Barring is unavailable).

If Network Password is incorrectly entered three times consecutively, Call Barring settings are locked. Network Password and Center Access Code must be changed. For details, contact SoftBank Mobile Customer Center, General Information (P. 15-53).

### Cancel Call Barring

⇨ **Settings** ⇨ ● ⇨ **Optional Services** ⇨ ● ⇨ **Call Barring** ⇨ ● ⇨ **Cancel All Barring** ⇨ ● ⇨ **YES** ⇨ ● ⇨ Enter Network Password ⇨ ●

### Change Network Password

⇨ **Settings** ⇨ ● ⇨ **Optional Services** ⇨ ● ⇨ **Call Barring** ⇨ ● ⇨ **Set NW Password** ⇨ ● ⇨ **YES** ⇨ ● ⇨ Enter current Network Password ⇨ ● ⇨ Enter new Network Password ⇨ ● ⇨ Enter new Network Password again for confirmation ⇨ ●

### Check Current Setting Status

⇨ **Settings** ⇨ ● ⇨ **Optional Services** ⇨ ● ⇨ **Call Barring** ⇨ ● ⇨ **Get Status** ⇨ ● ⇨ Select an item ⇨ ●

### Caller ID

#### Show/Hide Phone Number

⇨ **Settings** ⇨ ● ⇨ **Optional Services** ⇨ ● ⇨ **Caller ID Notification** ⇨ ● ⇨ **Activate/Deactivate** ⇨ ● ⇨ **ON** or **OFF** ⇨ ● ⇨ **YES** ⇨ ●

### Check Current Setting Status

⇨ **Settings** ⇨ ● ⇨ **Optional Services** ⇨ ● ⇨ **Caller ID Notification** ⇨ ● ⇨ **Get Status** ⇨ ●