# **Camera & Imaging**

Capturing Picture, Recording Movie & Editing	7-2
Camera	7-3
Using Display as Viewfinder	7-3
Single Shot	
Normal	
Scene	
Face Shot	
Capturing Still Images with Frame	
Photo Combination	7-7
Panorama Shot	
Viewing Captured Pictures (Quick Play)	7-8
Video	7-9
Using Display as Viewfinder	
Recording Video	
Video Mode	
Viewing Recorded Video (Quick Play)	7-11
Editing Images	7-12
Editing Still Images	
Oekaki Anime	7-12
Printing Still Images	7-14
Printing via Bluetooth®	
Printing via USB	7-15
Advanced Settings	
Capturing Still Images	
Recording Videos	
Editing Still Images	/-18



## **Capturing Picture, Recording Movie & Editing**

Use handset camera to capture pictures and record movies. Edit pictures and print them via Bluetooth® or USB-compatible printers.

## **Capturing Pictures & Recording Movie Clips**

Select Scene, Multi Shot, etc. (�P.7-3). Record up to two hours per clip (�P.7-9).





## **Editing Pictures**



Editing pictures: Resize or draw, etc. (♠P.7-12).

## **Printing Pictures**

Send pictures to printer via Bluetooth® or USB cable (♦P.7-14).







Capturing options and corresponding image sizes:

Capture Mode	Image Size
Normal Scene Face shot	Mail (240x320/320x240) Wide 5 (240x400/400x240) Wallpaper (480x800/800x480) 0.3M (480x640/640x480) 1M (960x1280/1280x960) 2M (1200x1600/1600x1200) 3M (1536x2048/2048x1536) 5M (1920x2560/2560x1920)
Multi shot Photo combi Frame shot	Wallpaper (480x800/800x480) 0.3M (480x640/640x480)
Video	SQCIF (128x96) QCIF (176x144) QVGA (320x240) VGA (640x480) S! Mail (176x144) S! Mail (128x96)

### Camera

For taking still pictures, select Shooting mode: *Normal* to shoot single picture, *Multi shot* or *Photo combi* to shoot multi-shot, *Frame shot* to shoot picture with frame, *Night* to shoot in sunset or night situation. Captured images are saved to *Pictures*. Insert Memory Card to save images to *Digital camera*.


#### Note

Avoid getting too close to light. Eyesight may be affected.

## **Using Display as Viewfinder**

Hold handset sideways to change Display to Landscape view. Hold handset vertically to change Display to Portrait view.

- The view does not change between Portrait and Landscape view during Multi-shot, Photo Combination, or video recording.
- Operations are described in Landscape view in this guide.





🛕 : Normal

: Scene

: Auto\*

: Landscape\*

Sports\*
C★: Night\*

🏠 : Indoor\*

: Beach/Snow\*

🗻 : Dusk/Dawn\*

 $\mathbf{T}$ : Text\*

🚷 : Face shot

: Type (Natural)\*

: Type (Dramatic)\*

: Multi shot

☐: 6/9 Photos (6 photos)\*

□ : 6/9 Photos (9 photos)\*

Fast : Speed (Fast)\*

□ F Speed (Normal)\*

□::: Speed (Slow)\*

□□ : Speed (Manual)\*

: Frame shot

: Photo combi

🔄 : Panorama shot

<sup>\*</sup>Displayed between shooting mode and shooting size.

2 Size (the size varies on the view)

镖: 5M (2560×1920) \*

**믢**: 3M (2048×1536) \*

: 2M (1600×1200) \*

: 1M (1280×960) \*

## : Wallpaper (800×480)

盟: 0.3M (640×480)

姗: Wide S (400×240) \*

3 : Mail (320×240) \*

\*Only when the shooting mode is set to Normal, Scene or Face shot.

6 Focus

Macro : AF

4 Light

On FF: Off

6 Timer

Conds: Off Conds: 3 seconds

: 5 seconds : 10 seconds

6 White balance

Nii : Auto 🗼 : Daylight

் : Incandescent ≒ : Fluorescent

: Cloudy

Anti-shake

(100): Anti-shake On None: Anti-shake Off 8 Quality

: Superfine

: Fine

A: Normal

🚣 : Economy

ISO

Auto : 100 : 200 : 400 : 80 : 800

10 Exposure metering

[3]: Matrix [3]: Center-weight

[o]: Spot

Shutter

12 Battery Level

Focus frame

Available remaining shooting number

Save to

♪ Phone or Ask each time

) : Memory card or Digital camera

• Tapping the icons (2) to (3) at the left side of Viewfinder opens a menu.

• Tapping an image on Viewfinder shows or hides icons/the current settings.

## **Single Shot**



Tapping the icon at the left side of Viewfinder opens a menu.



In Picture settings, Tap OK



Tap Shutter



Save image confirmation appears only if *Auto save* is *Off*.

- Adjusting size and brightness are available for still pictures (�P.14-19).
- To attach picture to message (♠P.4-5) and to print (♠P.7-14), set Auto save (♠P.14-19) to Off.

Shooting Mode	Description	
Normal	Capture still image and select size for purpose; attach images to S! Mail, save as Wallpaper, etc.	
Scene	Capture still image that suits for taking a portrait (person) or scene.	
Face shot	Capture still image that suits for taking person.	
Multi shot	Press shutter once to capture six or nine sequential images.	
Frame shot	Capture still image with Frame.	
Photo combi	Capture sequential images manually. Select Frame to automatically combine images into a composite image.	
Panorama shot	Ideal for landscape. Capture up to six images to automatically composite into a single panoramic image.	

#### Normal

Captured images are saved to Pictures. Insert Memory Card to save images (*0.3M* images and larger) to *Digital camera*.

- When Memory Card is not inserted and save location is set to *Digital camera*, *Mail* and *Wide S*, images are automatically saved to *Pictures* folder.
- 1 □ a (2 + seconds)
  - Alternatively, tap Menu → Camera → Camera.
  - Adjust settings before capturing as required.
- 2 Frame image in Viewfinder
  - Press 🖺 / 🖟 to zoom in/out.



- 3 □ □ / 🐷
  - Images are saved automatically.
- ●When Auto save is Off (◆P.14-19)

Still Image Saved Confirmation window is displayed after step 3.

To redo, press Q.

To save, tap

Using Auto Focus

When Focus is set to AF, Auto Focus is available; automatically focusing a subject at the center of the frame. Half-press  $\square \square \square$  to focus on. Then press  $\square \square \square$  to take a picture.

Frame turns green when image is in focus. Frame turns brown if image is not in focus.

#### Scene

- 1 □ □ (2 + seconds)
- 3 Tap icon area left of Viewfinder

  → Scene → Select a scene →
  Tap OK
  - Adjust settings before capturing as required.
  - To close the menu, tap an area other than menu items
- Frame image in Viewfinder
  - Press 🖺 / 🖟 to zoom in/out.
- 5 🗀 🗖 / 📷
  - Images are saved automatically.
- ●When Auto save is Off (�P.14-19)

Still Image Saved Confirmation window is displayed after step **5**.

To redo, press Q.

To save, tap

 Macro, Anti-shake, ISO, Exposure metering, and Wide dynamic range are not available for a scene shooting.

#### **Face Shot**

Changing shooting types for Face shot.

- 1 □ □ (2 + seconds)
- 3 Tap icon area left of Viewfinder → Type → Select type → Tap OK
  - Adjust settings before capturing as required.
  - To close the menu, tap an area other than menu items
- 4 Frame image in Viewfinder
  - Press A / to zoom in/out.
- 5 🗀 o / 🚃
  - Images are saved automatically.
- ●When Auto save is Off (�P.14-19)

Still Image Saved Confirmation window is displayed after step **5**.

To redo, press O.

To save, tap

 Anti-shake, ISO, Exposure metering, and Wide dynamic range are not available for Face shot.

## **Multi Shot**

- 1 □ □ (2 + seconds)
- 3 Tap the icon area located at the left side of Viewfinder → 6/9 photos → Select image count → Tap OK
- 4 Speed → Fast, Normal, Slow or Manual
  - Adjust settings before capturing as required.
  - To close the menu, tap an area other than menu items.
- 5 Frame image in Viewfinder
  - Press 🖺 / 🖫 to zoom in/out.
- 6 🗆 🗅 / 🔤
  - Images are saved automatically when capturing images end.
  - If Speed is set to Manual, repeat Step
     Tap to stop shooting and save the images. To redo, tap or press .

#### ●When Auto save is Off (�P.14-19)

Still Image Saved Confirmation window is displayed after step  $\bigcirc$ . To redo, tap  $\bigcirc$  or press  $\bigcirc$ .

To save, check image and tap

 Anti-shake, and Wide dynamic range are not available for Multi shot.

## **Capturing Still Images with Frame**

- 1 □ □ (2 + seconds)
- 3 Tap the icon area located at the left side of Viewfinder → Frames → Select a frame → Tap OK
  - Adjust settings before capturing as required.
  - To close the menu, tap an area other than menu items.
- 4 Frame image in Viewfinder
  - Press 🐧 / 🖟 to zoom in/out.
- 5 □ Þ / 🐷
  - $\bullet$  Images are saved automatically.
- ●When Auto save is Off (�P.14-19)

Still Image Saved Confirmation window is displayed after step  ${\color{red} oldsymbol{5}}$  .

To redo, press 🔐

To save, tap

 Anti-shake, and Wide dynamic range are not available for Frame shot

## **Photo Combination**

- □ □ □ (2 + seconds)
- 2 🙍 → Photo combi
- 3 Tap the icon area located at the top of Viewfinder → Style → Select a style → Tap OK
  - Adjust settings before capturing as required.
  - To close the menu, tap an area other than menu items.
- 4 Frame image in Viewfinder → Apply selected frame and press □ □
- 5 Repeat step 4 to capture images → □ / ■■
  - To redo, tap or press .
  - Images are saved automatically when capturing images end.
- ●When *Auto save* is *Off* (�P.14-19)

Still Image Saved Confirmation window is displayed after step **5** .

To redo, tap or press Q.

To save, tap

 Anti-shake, and Wide dynamic range are not available for Photo Combination.

#### Panorama Shot

- □ (2 + seconds)
- ightharpoonup Panorama shot
  - Viewfinder appears in Landscape.
  - · Adjust settings before capturing as required.
  - To close the menu, tap an area other than menu items.
- Frame image in Viewfinder
  - Press A / To zoom in/out.
- Move handset to capture an image (vertically or horizontally)
  - → Adjust small black border inside big border to automatically capture image
- Repeat step 👩 to capture range  $\rightarrow \square \square / \square$ 
  - To redo, tap 🔁 or press 🔘.
  - Capturing ends. Alternatively, capturing six images automatically ends capturing.
  - Panorama images are created and saved automatically.

Depending on the number of images to be captured, producing may take time.

•When Auto save is Off (♠P.14-19)

Still Image Saved Confirmation window is displayed after step 6.

To redo, tap ⊃ or press O.


To save, tap

- Anti-shake, and Wide dynamic range are not available for Panorama shot
- Move handset slowly to capture panoramic image.
- Panorama is ideal for capturing landscapes. Stand at least 10 meters from subject. If too close panoramic image creation may fail.
- •Low light or high contrast may hinder panoramic image creation.

## **Viewing Captured Pictures** (Quick Play)

Use Quick Play to view still images.

 $\square$   $\circ$  (2 + seconds)  $\rightarrow$   $\circ$ 



- With Memory Card inserted, Memory card or **Digital camera** is selectable.
- Alternatively, check still image from Data Folder (€P.12-4).

#### Advanced

Advanced Settings P.7-15

- Sending Captured Still Images
- Entering File Name of Captured Still Image
- Setting Captured Still Image as Wallpaper etc.
- Editing Quick Play Still Image
- Using Oekaki anime with Quick Play Still Image
- Using Quick Play Still Image as Wallpaper, etc.
- Viewing Quick Play Image Details
- Playing Quick Play Image Slide Show
- Sending Quick Play Still Images
- Deleting Quick Play Images
- Exiting Quick Play

#### **₹** Settings

- Set Anti-Shake (TP P.14-19)
- Activate or cancel Auto Save ( P.14-19)
- Set Contrast ( P.14-19)
- Set Saturation (P.14-19)
- Set Sharpness (P.14-19)
- Adjusting Brightness (TP.14-19)
- Setting Shooting Size ( P.14-19)
- Select Quality (P.14-20)
- Set ISO (@P.14-20)
- Set Exposure metering ( P.14-20)
- Set Wide Dynamic Range (P.14-20)
- Set save location when Memory Card is inserted ( P.14-20)
- Show or hide Guideline ( P.14-20)
- Set Face Link Display ( P.14-20)
- Set Shutter Sound ( P.14-20)


## Video

Capture clips easily. Files are saved in 3GP format to Video folder in Data Folder. When recording a video to attach or insert into an S! Mail, set Shooting size to *S! Mail* (�P.14-19).

#### Note

Avoid getting too close to light. Eyesight may be affected.

## **Using Display as Viewfinder**



- Mode
  - : Video
- 2 Size (the size varies on the view)

때 : VGA (640×480) \*

端: QVGA (320×240) \*

대 : QCIF (176×144)

课: SQCIF (128×96)

រដ្ឋ : S! Mail (176×144)

聞: S! Mail (128×96)

- \* Only for Landscape view
- 3 Focus

Macro : AF

4 Light

**20N** : On **20FF** : Off

6 Timer

Off : 3 seconds

😘 : 5 seconds 😘 : 10 seconds

6 White balance

Nii : Auto 🐞 : Daylight

: Incandescent 🚟 : Fluorescent

: Cloudy

Sound

¶
n : On 
¶
n : Off

8 Anti-shake

( : Anti-shake On None: Anti-shake Off

Quality

🖺 : Fine 🔓 : Normal 🔓 : Economy

Focus frame

Shutter

- 12 Battery Level
- Progress bar
- Expected video size/Available memory at the time you started the shooting
  - •If Size is set to *S! Mail*, the shooting data size/available shooting size appear.
- (5) Elapsed recording time/Available recording time
  - If Size is set to S! Mail, only the elapsed recording time appears.
- 16 Save to
  - ▷ Phone or Ask each time
  - ) : Memory card or Digital camera
- Tapping the icons (2) to 7) at the left side of Viewfinder opens a menu.
- Tapping an image on Viewfinder shows or hides icons/the current settings.

Shooting Mode	Description
Video	Record video that suits for attaching to S! Mail or save to handset.

## **Recording Video**



Tapping the icon area located at the left side of Viewfinder.



Tap OK at Video setting



**Tapping Shutter** 



Video Saved Confirmation window to save, send, and register image is displayed, only when *Auto save* is *Off*.

- Adjusting size and brightness are available for video (�P.14-19).
- To attach video to mail (♠P.4-5), and to print (♠P.7-14), set Auto save (♠P.14-19) to Off.

#### Video Mode

Up to 2 hours can be recorded for 1 clip.

- 1 Tap Menu → Camera → Video camera
  - Adjust settings before capturing as required.
- 2 Frame image in Viewfinder
  - Press 🖺 / 🖟 to zoom in/out.
- 3 🗀 º / 📷
  - To pause while recording, tap III. To resume the recording, tap III.
- 4 □ or Tap
  - Video is saved automatically. When recordable time has elapsed, recording automatically ends.

#### •When Auto save is Off

Video Saved Confirmation window is displayed after step 4.

To redo, press Q.

To save, tap save.

#### Using Auto Focus

When *Focus* is set to *AF*, Auto Focus is available; automatically focusing a subject at the center of the frame (the focus is locked while recording a video).

Press 
halfway to focus on. Then press 
all the way to start recording.

Frame turns green when image is in focus. Frame turns brown if image is not in focus.

• Wide dynamic range are not available for recording video.

# Viewing Recorded Video (Quick Play)

View Recorded Video by Quick Play

- 1 Tap Menu → Camera → Video camera → Tap 🗈
  - 2 < ∫ | > to view Video
    - Alternatively, check video from Data Folder ( P.12-4).

#### Advanced

### • Advanced Settings P.7-17

- Sending Recorded Video
- Entering File Name of Recorded Video
- Using Recorded Video as Ringtone
- Using Quick Play Video as Ringtone
- Viewing Quick Play Video Details
- Sending Quick Play Video
  - Deleting Quick Play Video
- Exiting Quick Play

#### **₹** Settings

- Set Anti-Shake ( P.14-19)
- Activate or cancel Auto Save ( P.14-19)
- Set Contrast ( P.14-19)
- Set Saturation ( P.14-19)
- Set Sharpness ( P.14-19)
- Adjusting Brightness ( P.14-19)
- Setting Shooting Size ( P.14-19)
- Select Quality ( P.14-20)
- Set save location ( P.14-20)
- Show or hide Guideline (TP.14-20)

## **Editing Images**

Change image size and brightness. Alternatively, draw on images or add motion.

## **Editing Still Images**

Edit still images saved in Data Folder. Set picture brightness, size and effect.

- 1 Tap Menu → Data Folder → Select a folder
- Select a file
- 3 Tap Edit → Image editor
- 4 Edit image
  - To set Effects on image

Tap Effect  $\rightarrow$  *Filter, Style, Warp* or *Finger warp*  $\rightarrow$  Select an effect or drag image  $\rightarrow$  Tap Done

- For some effects, adjust the effect level.
- To adjust an image automatically

  Tap Adjust → Auto level
- To adjust an image

Tap Adjust  $\rightarrow$  *Brightness, Contrast* or *Color*  $\rightarrow$  Adjust image  $\rightarrow$  Tap Done

To resize an image

Tap Transform → *Resize* → Select a size • After selecting *Customize*, enter *Width* and *Height*, and tap Done.

To rotate an image

Tap Transform  $\rightarrow$  *Rotate*  $\rightarrow$   $\bigcirc$  or  $\bigcirc$   $\rightarrow$  Tap Done

To flip an image

Tap Transform  $\rightarrow$  *Flip*  $\rightarrow$  M or  $\cong$   $\rightarrow$  Tap Done

- To undo, tap a or press o.
- 5 Tap Save → Enter file name

## **Oekaki Anime**

Draw lines/shapes or insert text on still image. In addition, add motions to drawings to create Flash® images.

- Tap Menu → Oekaki anime
- 2 Tap Canvas → Pictures or Digital camera → Select a still image
  - To select a file from Digital camera folder, insert Memory Card.

## 3 Select image size

To set image to Wallpaper, etc.


Normal

- Images are automatically resized to smaller than 800 x 480 pixels.
- To attach image to messages to send

S! Mail

Images will be resized to sendable size.

## 4 Draw



Oekaki anime Window

#### To draw lines

Tap Mode switch icon  $\rightarrow$  *Pen*  $\rightarrow$   $\bigcirc$   $\rightarrow$  Select a line type  $\rightarrow$   $\rightarrow$  Select a line width  $\rightarrow$   $\bigcirc$   $\rightarrow$  Select a line color  $\rightarrow$  Draw lines

### To draw shapes

Tap Mode switch icon  $\rightarrow$  *Shape*  $\rightarrow$   $\longrightarrow$  Select a shape  $\rightarrow$   $\longrightarrow$  Select a line width  $\rightarrow$   $\longrightarrow$  Select a Contour color  $\rightarrow$   $\longrightarrow$  Select a color  $\rightarrow$  Draw shapes

• Drag as if tracing a diagonal line.

#### To insert text

Tap Mode switch icon  $\rightarrow$  *Text*  $\rightarrow$   $\blacksquare$   $\rightarrow$  Enter text  $\rightarrow$   $\lozenge$   $\triangleright$  Select a font size  $\rightarrow$   $\lozenge$   $\triangleright$  Select a font style  $\rightarrow$   $\triangleright$  Select a font color  $\rightarrow$  Drag text to desired place

#### To insert stamps

Tap Mode switch icon  $\rightarrow$  *Stamp*  $\rightarrow$  - *Preset stamp*  $\rightarrow$  -  $\rightarrow$  Select a stamp  $\rightarrow$  Tap an area to paste the stamp

#### To add a motion to the pasted stamp

Tap Motion → Tap a stamp to add a motion → Tap OK → Preset → Select a motion → Tap OK

 Each icon represents the current setting. Changing settings changes the corresponding icon. 5 Tap More → *Preview* → Confirm the image



Preview

- Redrawing allows you to perform the following operations:
  - III / Pause/Resume
- 6 Tap Save → Save as Flash® or Save as image → Enter file name
  - To save a file to *Memory card*, insert Memory Card.

#### Advanced

#### • Advanced Settings P.7-18

- Cropping and Editing Still Images
- Using Oekaki anime with Camera Images
- Using Oekaki anime with Colored Background
- Undoing Edit Operation of Oekaki anime
- Setting Created Image to Wallpaper
- Saving and Sending Created Image

## **Printing Still Images**

Print still images saved on handset by connecting a printer via Bluetooth® or USB.

For more information about printer operations and paper setting, see printer User Manual.

## Printing via Bluetooth®

- Print images with Bluetooth® printer.
- Pair Bluetooth® printer beforehand.
- 1 Tap Menu → *Data Folder* → Select a file location
- 2 Tap More → Print
- 3 Via Bluetooth → Check files to print → Tap Print
- Drag device to connect to
  - If no device is registered, search and register new device.

- Set items as required
  - To set whether to print a Frame or not

Under Frame, On or Off

To set paper size

Paper size → Select a paper size

To set the number of copies

*Number of copies*  $\rightarrow$  Enter the number of copies (1 to 99)

To set the number of pages to print per sheet

Page format → Select an item

- When selecting *Duplicate*, select *Pages per sheet* → Select a setting (1 to 16
   up).
- To set whether to print the date or not

Under Print date, On or Off

- To set print quality

  Print quality → Select an item
- 6 Tap Preview → Tap Print

## **Printing via USB**

- 1 Tap Menu → *Data Folder* → Select a file location
- 3 Via USB → Check files to print → Tap Print → Yes
- 4 Connect handset to a printer via USB
- 5 Set items as required
  - To set whether to print a Frame or not Under *Frame*, *On* or *Off*
  - To set paper size

    Paper size → Select a paper size
  - To set the number of copies

    Number of copies → Enter the number of copies (1 to 99)
  - To set the number of pages to print per sheet

Page format → Select an item

- When selecting *Duplicate*, select *Pages* per sheet → Select a setting (1 to 16 up)
- To set whether to print the date or not Under *Print date*, *On* or *Off*
- To set print quality

  Print quality → Select an item
- 6 Tap Preview → Tap Print

## **Advanced Settings**

## Advanced Settings

## **Capturing Still Images**

#### **Setting Macro**

Tap the icon area located at the left side of Viewfinder  $\rightarrow$  *Focus*  $\rightarrow$  *Macro* 

## **Setting Light**

Tap the icon area located at the left side of Viewfinder  $\rightarrow Light \rightarrow On$  or Off

## **Setting Timer**

Tap the icon area located at the left side of Viewfinder  $\rightarrow$  Timer  $\rightarrow$  Select an item

#### **Setting White Balance**

Tap the icon area located at the left side of Viewfinder  $\rightarrow$  White balance  $\rightarrow$  Select an item

#### Setting Effect (Color Tone)

Tap the icon area located at the left side of Viewfinder  $\rightarrow$  *Effects*  $\rightarrow$  Select an item

Sending Captured Still Images

After taking Still Image, tap Send

To operate above, set Auto save to Off (◆P.14-19).

#### To send via message

 $Via\ message \rightarrow (\bigcirc P.4-4 \ S! \ Mail \ 2)$ 

- If the captured image size exceeds 300 KB, a window for resizing the image appears after saving the image to Data Folder. Resize the image before attaching it (�P.4-5 Attaching Files)
- To send via Bluetooth®

  Via Bluetooth → (�P.13-7 Sending Data ②)
- To send via infrared Via infrared (◆P.13-3)

## Entering File Name of Captured Still Image After taking Still Image, tap Rename → Enter

After taking still image, tap kename  $\rightarrow$  Enter file name

• To operate above, set *Auto save* to *Off* (**•** P.14-19).

## Setting Captured Still Image as Wallpaper etc. After taking Still Image, tap Set as

- To operate above, set *Auto save* to *Off* (♠P.14-19)
- To set image to Wallpaper

  Wallpaper → Tap Rotate as required → ☐ or

  to toggle direction or tap Zoom → ❷ or ❷ to

  adjust zoom level → Tap Set
- To set image to Incoming image

  Caller ID → Search Phonebook and select an entry (�P.2-18) → Tap Set
- To set image to Alternative picture

  Still image → Tap OK

Viewing Quick Play Still Image

 $\square \bullet$  (2 + seconds)  $\rightarrow \square \rightarrow \bigcirc / \bigcirc$  to view Image

 The data saved in media set as Save to will be viewed. To change the media, change Save to (◆P.14-20).

## **Editing Quick Play Still Image**

Using Oekaki anime with Quick Play Still Image

 The data saved in media set as Save to will be viewed. To change the media, change Save to (♠P.14-20). Using Quick Play Still Image as Wallpaper, etc.

 $\square$  (2 + seconds)  $\rightarrow$   $\square$   $\rightarrow$   $\bigcirc$  /  $\bigcirc$  to view Image  $\rightarrow$  Tap Set as

#### To set image to Wallpaper

*Wallpaper* → Tap Rotate as required →  $\bigcirc$  or  $\bigcirc$  to toggle direction or tap Zoom →  $\bigcirc$  or  $\bigcirc$  to adjust size → Tap Set

To set image to Incoming image

Caller ID → Search and select a phonebook (�P.2-18) → Tap Set

## To set image to Alternative picture Still image → Tap OK

 The data saved in media set as Save to will be viewed. To change the media, change Save to (♠P.14-20).

Viewing Quick Play Image Details

 The data saved in media set as Save to will be viewed. To change the media, change Save to (♠P.14-20). Playing Quick Play Image Slide Show

 $\square \square$  (2 + seconds)  $\rightarrow \square \square$  Tap Slide show

- Press O during playback to cancel Slide show.
- The data saved in media set as Save to will be viewed. To change the media, change Save to (♠P.14-20).

Sending Quick Play Still Images

 $\square$  (2 + seconds)  $\rightarrow$   $\square$   $\rightarrow$   $\bigcirc$  /  $\bigcirc$  to view image  $\rightarrow$  Tap Send

To send via message

Via message → (�P.4-4 S! Mail ②)

To send via Bluetooth®

Via Bluetooth → (♠ P.13-7 Sending Data ②)

To send via infrared Via infrared (�P.13-3)

 The data saved in media set as Save to will be viewed. To change the media, change Save to (♠P.14-20).

**Deleting Quick Play Images** 

 The data saved in media set as Save to will be viewed. To change the media, change Save to (◆P.14-20).

**Exiting Quick Play** 

Tap Back to Camera during Quick play

## **Recording Videos**

#### **Setting Macro**

Tap the icon area located at the left side of Viewfinder  $\rightarrow$  *Focus*  $\rightarrow$  *Macro* 

### **Setting Light**

Tap the icon area located at the left side of Viewfinder  $\rightarrow Light \rightarrow On/Off$ 

## **Setting Timer**

Tap the icon area located at the left side of Viewfinder  $\rightarrow$  *Timer*  $\rightarrow$  Select an item

## **Setting White Balance**

Tap the icon area located at the left side of Viewfinder  $\rightarrow$  White balance  $\rightarrow$  Select an item

## Setting Effect (Color Tone)

Tap the icon area located at the left side of Viewfinder  $\rightarrow$  *Effects*  $\rightarrow$  Select an item

#### **Setting Sound Recording**

Tap the icon area located at the left side of Viewfinder  $\rightarrow$  *Sound*  $\rightarrow$  *On/Off* 

Viewing Recorded Video before Saving

After recording video,

• To operate following, set *Auto save* to *Off* (♦P.14-19).

#### Sending Recorded Video

After recording video, tap Send

- To operate above, set Auto save to Off (◆P.14-19).
- To send via message

  Via message → (♠P.4-4 S! Mail ②)
- To send via Bluetooth®

  Via Bluetooth → (�P.13-7 Sending Data ②)
- To send via infrared

  Via infrared (�P.13-3)

Entering File Name of Recorded Video

After recording video, tap Rename → Enter
file name

• To operate above, set *Auto save* to *Off* (♠P.14-19).

## Using Recorded Video as Ringtone

After recording video, tap Set as

- To operate above, set Auto save to Off (♠P.14-19).
- To set video to Voice ringtone Voice ringtone
- To set video to Video ringtone Video ringtone
- To set video to Caller ringtone

  Caller ringtone → Select phonebook (�P.2-18)

Viewing Recorded Video via Ouick Play

Tap Menu  $\rightarrow$  *Camera*  $\rightarrow$  *Video camera*  $\rightarrow$   $\triangleright$   $\rightarrow$   $\bigcirc$  /  $\bigcirc$  to view a video

 The data saved in media set as Save to will be viewed. To change the media, change Save to (◆P.14-20).

Using Quick Play Video as Ringtone

Tap Menu  $\rightarrow$  Camera  $\rightarrow$  Video camera  $\rightarrow$   $\triangleright$   $\rightarrow$   $\bigcirc$  /  $\bigcirc$  to view a video  $\rightarrow$  Tap Set as

- To set video to Voice ringtone Voice ringtone
- To set video to Video ringtone Video ringtone
- To set video to Caller ringtone

  Caller ringtone → Search and select a phonebook (♠P.2-18)
- The data saved in media set as Save to will be viewed. To change the media, change Save to (♠P.14-20).

Viewing Quick Play Video Details

Tap Menu  $\rightarrow$  *Camera*  $\rightarrow$  *Video camera*  $\rightarrow$   $\triangleright$   $\rightarrow$   $\bigcirc$  /  $\bigcirc$  to view a video  $\rightarrow$  Tap Details

 The data saved in media set as Save to will be viewed. To change the media, change Save to (♠P.14-20).

#### Sending Ouick Play Video

Tap Menu  $\rightarrow$  *Camera*  $\rightarrow$  *Video camera*  $\rightarrow$   $\triangleright$   $\rightarrow$   $\bigcirc$  /  $\bigcirc$  to view a video  $\rightarrow$  Tap Send

To send via message

Via message → (�P.4-4 S! Mail ②)

To send via Bluetooth®

Via Bluetooth → (♦P.13-7 Sending Data ②)

To send via infrared Via infrared (◆P.13-3)

 The data saved in media set as Save to will be viewed. To change the media, change Save to (♠P.14-20).

## Deleting Quick Play Video

Tap Menu  $\rightarrow$  *Camera*  $\rightarrow$  *Video camera*  $\rightarrow$   $\square$   $\rightarrow$   $\bigcirc$  /  $\bigcirc$  to view a video  $\rightarrow$  Tap Delete  $\rightarrow$  *Yes* 

 The data saved in media set as Save to will be viewed. To change the media, change Save to (♠P.14-20).

#### **Exiting Quick Play**

Tap Back to Camcorder during Quick play

## **Editing Still Images**

## **Cropping and Editing Still Images**

Tap Menu  $\rightarrow$  *Data Folder*  $\rightarrow$  Select a file location  $\rightarrow$  Select a file  $\rightarrow$  Tap Edit  $\rightarrow$  *Image editor*  $\rightarrow$  Tap Transform  $\rightarrow$  *Crop* 

## To adjust cropping area

Touch and hold inside cropping frame and drag ightharpoonup Tap Crop ightharpoonup Tap Save ightharpoonup Enter an image name

To change cropping size or shape
Stretch cropping frame → Tap Crop → Tap Save
→ Enter an image name

Using Oekaki anime with Camera Images

Tap Menu  $\rightarrow$  *Oekaki anime*  $\rightarrow$  Tap Canvas  $\rightarrow$  *Take photo*  $\rightarrow$  Capture an image  $\rightarrow$  *Normal/S! Mail* 

Using Oekaki anime with Colored Background

Tap Menu → *Oekaki anime* → Tap Canvas → *Color canvas* → Select a background color

#### **Editing Entered Text**

In Oekaki anime window, tap 

→ Text →

Tap text you already entered → Tap T / 

→ Change the Font size, Font,

Font color, or the location of the text

Adding Emoticon Clip Art to Still Images
In Oekaki anime window, tap  $\bigcirc \rightarrow Stamp \rightarrow$ 

→ Photo stamp → as required
 To select from saved still images

**Pictures** or **Digital camera** → Select a still image for a stamp → Tap Yes/No as required → Tap area to paste it

- To select a file from *Digital camera* folder, insert Memory Card.
- To capture an image by Camera

  Take photo → Take a still picture →

  Yes (When cropping, crop)/No (When not cropping) → Tap an area to paste it as a stamp
- Each icon represents the current setting. Changing settings changes the corresponding icons.

Adding Motions to Lines or Shapes You Drew
In Oekaki anime window, tap Motion →
Tap Window → Drag to enclose a line or
shape to add a motion → Tap OK → *Preset* →
Select a motion → Tap OK

• Drag as if tracing a diagonal line of the area to add the motion.

#### Moving along with a Line

In Oekaki anime window, tap Motion → Tap Window

#### For lines or shapes

Drag to enclose the desired line or shape  $\rightarrow$  Tap OK  $\rightarrow$  *Motion line*  $\rightarrow$  Draw a motion line starting from the selected line or shape  $\rightarrow$  *Preview*  $\rightarrow$  Tap OK

 Drag as if tracing a diagonal line of the desired area.

### For stamps

Tap the desired stamp  $\rightarrow$  Tap OK  $\rightarrow$  *Motion line*  $\rightarrow$  Draw a motion line starting from the selected stamp  $\rightarrow$  *Preview*  $\rightarrow$  Tap OK

• To delete the motion line and draw again, tap *Undo*.

## **Deleting Motions**

In Oekaki anime window, tap Motion  $\rightarrow$  Tap a line, shape, or stamp to remove the motion  $\rightarrow$  Tap OK

#### To delete Preset

**Preset** → 🗞 → Tap OK

## To delete Motion line Motion line $\rightarrow$ Off $\rightarrow$ Tap OK

Undoing Edit Operation of Oekaki anime In Oekaki anime window, tap Undo

 Undo the last operation performed in Oekaki anime window such as drawing a line or selecting a setting option. Deleting Lines, Shapes, Text, or Stamps

In Oekaki anime window, tap Mode switch icon → *Delete* 

## For lines or shapes without any motion Drag to enclose the line or shape to delete

• Drag as if tracing a diagonal line of the area to delete

## For lines or shapes with motions

Tap a line or shape to delete

#### For text or stamps

Tap text or stamp to delete

## Setting Created Image to Wallpaper

Tap More  $\rightarrow$  *Preview*  $\rightarrow$  Tap Set as wallpaper  $\rightarrow$  *Flash*®/*Image*  $\rightarrow$  Enter file name

## Saving and Sending Created Image

Tap More → Preview → tap Send

#### To send via Message

Via message → Flash®/Image → (�P.4-4 S! Mail ②)

#### To send via Bluetooth®

Via Bluetooth → Flash®/Image → (♠P.13-7 Sending Data ②)

#### To send via infrared

 $Via\ infrared \rightarrow Flash @/Image \rightarrow (\bigcirc P.13-3)$ 

Changing Saving Location for Created Images

In Oekaki anime window, tap More → Settings → Under Save to, Phone, Memory card, or Ask each time

 When no Memory Card is inserted, the saving location is automatically set to *Phone*.

## Setting Oekaki Process Playback Speed

In Oekaki anime window, tap More  $\rightarrow$  *Settings*  $\rightarrow$  Adjust Oekaki process playback speed

#### **Compressing Files**

In Oekaki anime window, tap More → **Settings** → Under **File compression**, **High/Normal** → Tap OK

