Calendar & Tasks	9-2
Calendar	9-2
Tasks	9-5
Alarms	9-7
Using Alarms	9-7
Wakeup TV	9-9
Using Wakeup TV	9-9
Calculator	9-11
Using Calculator	9-11
Expenses Memo	9-12
Adding Expenses	9-12
Osaifu-Keitai®	9-13
Osaifu-Keitai® (Japanese)	9-13
Locking IC Card	
Simulated Call	9-17
Faking Incoming Calls	9-17
Stopwatch	9-18
Using Stopwatch	9-18
Countdown Timer	9-19
Using Countdown Timer	9-19
World Clock	9-20
Opening World Clock	9-20

Hour Minder	9-21
Using Hour Minder	9-21
Document Viewer	9-22
Opening PC Documents	9-22
Notepad	9-23
Saving Text	
ASCII Art	
Using ASCII Art	9-24
Voice Recorder	9-25
Recording/Playing Voice	9-25
Scan Barcode	9-26
Scanning Barcodes	9-26
Create QR Code	9-27
Creating QR Codes	
Scan Card	
Scanning Business Cards	9-28
Text Scanner	9-29
Scanning Text	
Additional Functions	
Troubleshooting	

# 9

**Handy Extras** 



#### Calendar

#### **Opening Calendar**





Calendar Window

#### **Opening Help** [Calendar Window] [0]

#### **Toggling View**

Press repeatedly to toggle Calendar window.



Month View



2Month View



Week View

#### **Key Assignments**

#### All Views

100 X + 100 X X	Open previous page
\$ # ¥	Open next page
«5 f	Go to the current date
20	Open Help

#### Month/2Month View

<b>.</b>	Select date
----------	-------------

#### Week View

•••	Select date
<b>\Q</b>	Select time block





🖑 Changing default view Jumping to specified date Changing date color Selecting task view option Adding stamps (Month View) Hiding schedules Saving additional holidays Removing/restoring preset holidays (P.9-30)

#### Saving Schedules

Follow these steps to save subject, start/ end date/time, Alarm and schedule details. Either Subject or Description must be saved per entry.

In Calendar window, select date 


olimits 

olimits



- ∠ <Add New Entry> 

  ■
- 💽 Enter subject 🖈 💽



Enter start date/time → ■



- End: 

   Enter end date/time
- 😭 Alarm: 🖈 💽
- Alarm Time: 

  ◆ ◆ Select time 

  ◆ ◆ 

  □
- Description: ▶ ► Enter schedule details ▶ ●
- Saved



#### At Alarm Time

Alarm activates; sounds/vibrates by related settings.



#### Stopping Alarm to Return to Standby

While Alarm sounds/vibrates, press •,
 or •.

#### Stopping Alarm to Open Schedule


 While Alarm sounds/vibrates, press a key other than ●, ③ or .

#### When Another Function is Active

 Alarm may not activate until handset returns to Standby.

#### **Incoming Calls**

 Active Alarm stops for incoming calls.
 Information window opens after handset returns to Standby.





Schedule List

- Select schedule or task ▶ •

Opening Task List
In ⊘, select task → □ → Go to Tasks
→ ■

Accessing Secret Entries

[Calendar Window] □ → Unlock

Temporarily → ■ → Enter Handset

#### Opening Related Message

Open schedule-related messages saved from Messaging message list.

- In schedule list, select schedule ▶ •
- 🔁 🖻 🖈 Related Mail 🖈 💽
  - Related message opens.
  - To return to schedule window, press

Deleting Message from Schedule
After ①, ● → Related Mail: → ● →
Yes → ● →

#### **Deleting Schedules**

- One Entry
- In schedule list, select schedule ▶ □
- Delete → •
- This Appointment ⇒ ⇒
  Yes •
- All Entries of the Day
- In Calendar window, select date ▶ □
- Delete → → All This Day

  → → Yes → ●

#### Advanced

Code **▶** •




Handy

Extras

#### Tasks

#### Saving Tasks


Follow these steps to save subject, due date/time, Alarm and task details: Either Subject or Description must be saved per entry.

























Handy Extras





#### At Alarm Time

Alarm activates; sounds/vibrates by related settings.



#### Stopping Alarm to Return to Standby

While Alarm sounds/vibrates, press ●,
 or □□□

#### **Stopping Alarm to Open Task**

 While Alarm sounds/vibrates, press a key other than , or ...

#### When Another Function is Active


Alarm may not activate until handset

#### **Incoming Calls**

returns to Standby.

 Active Alarm stops for incoming calls.
 Information window opens after handset returns to Standby.

#### **Opening Tasks**





Task List

- Use to open completed or uncompleted task list.
- Select task ⇒ •



## Standby returns

#### **Accessing Secret Entries**

After ①, ☐ → Unlock Temporarily →

■ Enter Handset Code → ■

Marking Tasks as Completed

After ①, select task ▶ 🗹

#### **Deleting Tasks**

- One Entry
  - \rceil In task list, select task 🖈 🖻
- Delete →
  - 🜏 This Task 🕈 💿 🖈 Yes 🕈 💿
- All Completed Tasks
- In task list, □
- Delete → → All Comp.
  Tasks → → Yes → ●



#### **Using Alarms**

#### **Setting Alarm**

Follow these steps to set Alarm to sound at a specific time on a specific day of the week:

Set Snooze (Alarm repeats at set interval), Alarm Volume and Duration.






Alarm List















- Select day **→** (□/√) **→** Complete selection **→** ⊡
- 吝 Snooze: Þ 💽
- 🥏 Select interval 🖈 💽
  - For custom intervals, select Other.

















In  $\odot$ , select day  $\blacktriangleright$   $\bullet$  ( $\square/\square$ )  $\blacktriangleright$  Complete selection  $\blacktriangleright$  Except Holidays  $\blacktriangleright$   $\bullet$   $\blacktriangleright$   $\square$   $\blacktriangleright$  From  $\odot$ 





#### Stopping Alarm

• Press a kev.

#### When Another Function is Active

 Alarm may not activate until handset returns to Standby.

#### **Incoming Calls**

• Active Alarm stops for incoming calls. Information window opens after handset returns to Standby.

#### When Snooze is Set


Alarm repeats at the set interval. Other Alarms do not activate while handset is Snoozing.

#### **Canceling Snooze**

While Snoozing, ● → Yes → ●

 Snooze is automatically canceled after a period of time.

#### Canceling Alarm





· Reactivate entry to use the same settinas.

#### Reactivating Entry

In ②, Switch On ▶ •

#### **Deleting Alarm**

#### One Entry

In Alarm list, select entry **▶** □





All Entries

In Alarm list, select entry ▶

Enter Handset Code **→** • Yes →

### Using Wakeup TV

#### **Setting Wakeup TV**

Follow these steps to activate TV at a specific time on a specific day of the week:

- Complete TV Area Setup beforehand.
- TV may not activate in poor signal conditions.
- **→** Tools **→ →** In PIM/ Lifestyle menu, Wakeup TV




Wakeup TV List





Wakeup TV Menu







- Select day **▶ ●** (□/☑) **▶** Complete selection **→** 🔄

- **⇒** Saved • For more settings, repeat @ - 3.
- Wakeup TV setting ends



#### **Canceling Alarm**

 Alarm activates at Wakeup TV time. To cancel Alarm, follow these steps:

[Wakeup TV Menu] Alarm On/Off: ▶ • **→** Off **→** • **From** ③

#### **Adjusting Alarm Volume**

[Wakeup TV Menu] Alarm Volume: >

Adjust level ⇒ From





#### At Wakeup TV Time

TV activates after Alarm.



#### **Stopping Alarm Instantly**

- While Alarm sounds/vibrates, press a key.
  When Another Function is Active
- TV may not activate depending on the function.

#### After TV is On for a Period of Time

Confirmation appears. Choose *Yes* and press 

 to exit TV.

#### Canceling Wakeup TV

- In Wakeup TV list, select entry ▶ □
- Wakeup TV Off 

   Reactivate entry to use the same settings.

## Reactivating Entry In ②, Wakeup TV On ▶ ■

#### **Deleting Wakeup TV**

- One Entry
- In Wakeup TV list, select entry ▶ □
- 🕟 Reset Alarm 🕈 💽
- ? Yes **→** •
- All Entries
- In Wakeup TV list, select entry ▶ □ ▶ Clear All ▶ ●

#### Using Calculator


● **→** Tools **→** • **→** In PIM/ Lifestyle menu, Calculator



Calculator Window

- Use Keypad to enter digits Calculate





#### **Key Assignments** + (Add) - (Subtract) • x (Multiply) ÷ (Divide) 0 = (Sum) C·CE (Clear) CM (Clear Memory) RM (Recall Memory) 3 Y M+ (Add to Memory) #/X+ . (Decimal) +/- (Positive/Negative Value) °# 7 % (Percentage)

#### **Memory Calculation**

- Clear Memory before starting new Memory calculations.
- Numbers saved in Memory remain until handset power is turned off.

#### Incoming Calls

 Calculations are not affected. End the call to return to Calculator.

#### **Using % Function**

Use (a) to find definite percentage of a known value.

Example: Calculate 30% of 800,000

Enter  $800,000 \Rightarrow x \Rightarrow 30 \Rightarrow \%$ 

■ 240,000 appears.





20



Select Category 

▶ 

■ Saved

Saving under Custom Category In ⓒ, Other ▶ • Enter name ▶ •

#### **Checking Entries**

• **→** *Tools* **→** • **→** In PIM/ Lifestyle menu, Expenses Memo **→** •



Totals **▶** •



Expenses Memo List

#### Standby returns

Saving Entries to Notepad Notepad **▶** •

■ All expense details are saved as a single entry.

#### **Deleting Entries**

#### One Entry

- In Expenses Memo list, select entry ▶ 🖾
- Delete Item 

  ◆ Yes 

  •

#### All Entries

- In Expenses Memo list, □ →
- Enter Handset Code **→** Yes ⇒



## Osaifu-Keitai® (Japanese)

Osaifu-Keitai® describes IC Card-equipped handsets that support e-money or credit functions/services. Osaifu-Keitai® encompasses a range of IC Card-based services on FeliCa-compatible SoftBank handsets. 831SH supports Osaifu-Keitai®. To use e-money, e-ticketing and reward points, etc., hold handset over a compatible reader/writer at shops, restaurants, and other retail outlets, etc.

#### Basics

Before using Osaifu-Keitai®, activate Lifestyle-Appli, complete registration, customize settings and charge accounts.

#### Starting Lifestyle-Appli

● **Tools** • In PIM/Lifestyle menu. Osaifu-Keitai 🖈 💿 🖈 Lifestvle-Appli → • Select application **▶** •

#### Lifestyle-Appli Precautions


- Contact Osaifu-Keitai<sup>®</sup> service providers for Lifestyle-Appli registration and usage details
- Keep service passwords/customer service contact information, etc. in a separate place.

#### Using Osaifu-Keitai®

Follow these steps to conduct a transaction: Example: Making an electronic payment

- Lifestyle-Appli activation is not necessary.
- Transactions are possible even when handset power is off (if battery is adequately charged).
- Calls/Internet transmissions do not affect transactions






Align handset parallel to reader/writer.

#### Important Osaifu-Keitai® Usage Note

SoftBank is not liable for damages resulting from accidental loss/alteration of IC Card data/settings.

#### When Placed Over Sensor


- If recognition is slow, move handset around slightly.
- Handset may respond automatically for some services.





● → Tools → ● In PIM/ Lifestyle menu, Osaifu-Keitai







IC Card Settings Menu



Canceling IC Card Lock
In ⑤, IC Card Lock ▶ ● → Off ▶ ●

Enter Handset Code ▶ ●






#### **Remote Lock**

Disable Osaifu-Keitai® remotely by mail or phone.

Lock	Send mail to activate Remote Lock
Call Remote Lock	Call from a specified phone to activate Remote Lock



■ Preparation on Handset





Remote Lock → ● ► Enter Handset Code → ●








Mail Remote Lock Menu

- 🕞 Remote Lock PW 🖈 💽
- 🖺 Enter password 🕈 💽
- Switch On/Off →
  - **On → →** 🗹

Canceling Mail Remote Lock In ③, Off ▶ • ▶ ☑ ■ Activating Remote Lock via Mail
If handset cannot receive mail IC Card
Lock is not set.



 After handset receives message, IC Card Lock is set and notice is sent as a reply.



- Preparation on Handset
- → Tools → In PIM/ Lifestyle menu, Osaifu-Keitai
- IC Card Settings → ●
- Remote Lock → ► Enter Handset Code → ●



Call Remote Lock ⇒ ■



Call Remote Lock Menu

Phone No. to Lck 1 or Phone No. to Lck 2 ▶ •



- Phone Book 

  Select entry

  Select phone number

  Phone Book

  Select phone
  - Select Phone Number to enter directly.
- Switch On/Off ▶ •
- On → ●

Enabling Activation via Public Phone
In ⑤, Set Public Phone ▶ ● ▶ On
▶ ● ▶ From ∅

Canceling Call Remote Lock In ③, *Off* ▶ • ▶ ☑

- Activating Remote Lock via Phone
  If handset cannot receive calls IC Card
  Lock is not set
- Using one of the specified phones, call handset

   Send Caller ID.
- Handset receives call ⇒
  End the call
- The call is recorded as a Missed Call.
- Within three minutes, repeat

  O ② twice



- After the third Missed Call, IC Card Lock is set; a message announces Remote Lock activation. Confirm the message and end the call.
- If Series is Interrupted by Another Call
- Missed Call count is reset. Start over from the beginning.

#### Faking Incoming Calls

Handset rings to emulate an incoming call.

- Save name and phone number to show as Caller ID.
- Ringer may be muted by handset settings. To override Silent setting, see P.9-36.

#### **Setting Simulated Call**





Simulated Call Menu







- Name: 

   Enter name
- Phone Number: 

  ▶ 

   Enter phone number **→** •
- Assign Tone → Select tone/file **→** •
- PIM/Lifestyle menu returns

When Name and Phone Number are Unset

 Handset rings with Caller ID "Withheld." Canceling Simulated Call

[Simulated Call Menu] Switch On/Off → Off → □ → □

**Setting Wait Time** 

[Simulated Call Menu] Receive Timing Select time → □ → □

#### **Using Simulated Call**


- Long)
  - Available regardless of handset position.
  - Handset rings and incoming Voice Call window opens.
  - Ringtone stops after a period of time.
- In incoming Voice Call window, press
  - Voice Call window opens. (Softkeys are dummies.)
- Simulated Call ends

#### When Receive Timing is Not Immediately

- Press or during wait time to cancel Simulated Call activation.
- Simulated Call activation is canceled by incoming calls, Alarms, etc. during wait time.

## **Using Stopwatch**

Stopwatch stops when battery runs low.






Stopwatch Window







· Records are deleted when Stopwatch ends.

**Recording Lap Times** While Stopwatch is running, Saving Records to Notepad After €, 

Save to Notepad 

Output

Description: Resetting Records After €, 🕝 **>** From ⊘ **Incoming Calls**  Stopwatch is not affected by incoming calls. End the call to return.



#### **Using Countdown Timer**



Timer Entry Window


Enter minutes → Enter seconds → •



Countdown Timer Window

 $\bullet$  Press  $\ensuremath{\boxdot}$  to change time.

- Countdown starts
  - Press to stop/resume countdown.
- Set time elapses ⇒ Tone sounds



#### **Using Timer Records**

After ①, □ → Select record → ● →

From ⓒ

#### **Resetting Timer**

Stop countdown and

#### **Incoming Calls**

 Countdown is not affected by incoming calls. End the call to return.

#### When Set Time Elapses

Tone sounds.



#### **Stopping Tone Instantly**

- Press or a Side Key. (Tone stops automatically after a period of time.)
- When Timer Time Elapsed during a Call
- Tone sounds after the call.



- Select area → •
- **➡** World Clock ends

Advancing One Hour (Daylight Saving) [Set Time Zone Window] 🔄 ■ To cancel, press 🗹. **Adding Custom Time Zone** 

Enter time difference ▶ •

**Opening World Clock in Standby** 

- **Settings ●** In Phone menu, *Display* **▶** •
- Standby Display **▶** •



- World Clock (L), etc. 

  ●



Set Time Zone Window


## **Setting Hour Minder**

Follow these steps to activate the hourly time signal at selected hours:





Hour Minder Menu







Select hour **▶ ●** (□/☑) **▶** Complete selection **▶** 🗹



Saved



→ Hour Minder setting ends



## In ②. □ → Check All or Uncheck All

#### At Hour Minder Time

Hour Minder activates: sounds/vibrates by related settings.



#### Stopping Tone Instantly

• Press a key.

When Another Function is Active

- Hour Minder does not activate. Incoming Calls
- Active Hour Minder stops for incoming calls.

#### **Canceling Hour Minder**





<sup>🖄 🌑</sup> Changing Hour Minder tone/video 🜑 Setting handset to vibrate at Hour Minder Time 🌑 Sounding Hour Minder tone even in Manner mode 🜑 Activating Hour Minder based on World Clock time (P.9-36)

#### **Opening PC Documents**

Supported File Formats:

PDF (.pdf)

Microsoft® Excel® (.xls)

Microsoft® Word (.doc)

Microsoft® PowerPoint® (.ppt)

- Some files may not appear correctly.
- Download files via the Internet.
- When transferring files from PCs, save to corresponding Memory Card folder (P.15-23).




Select file 🕈 💿

Zooming In/Out with Loupe (Magnifier)
In open file, ☐ (Long) → Specify
portion → ☐ → Zoom Out or Zoom
In → ●

Key Assignments	
•	View whole page
<b>.</b>	Scroll
* 1 °	View upper left
÷2 €	Toggle full screen view on/off
<b>∞3</b>	View upper right
≈4 <sup>a</sup> /	Zoom out
E4∄ (Long)  Long)	Continuous zoom out
<b>≈5</b> €	View center
<u>∞68</u> /	Zoom in
(Long) (Long)	Continuous zoom in
*7 <sup>5</sup>	View lower left
.84 .84	Jump to page
e 9 M	View lower right
20	Open Help
° # ₹	Next page
## X +	Previous page
ت	Fit width
Y/	Rotate 90°

#### **Saving Text**

#### New Notepad Entry





Notepad List





- Enter text ▶ •
- Select Category → → Saved

## Sorting Entries Temporarily [Notepad List] [v]

■ Press preparedly to toggle sort options (Modified, Created, Category and Accessed).


#### **Opening Notepad**



DEM → List returns

#### **Deleting Entries**

One Entry





All Entries

In Notepad list, select entry →

☐ → Setting/Manage →

☐

In message text entry window,

□ → Call ASCII Art → •




Select entry ▶ ■



Previewing ASCII Art
In ②, select entry ▶ □
■ Press ● to insert ASCII Art.

#### **Editing Entries**





ASCII Art List

Art ▶ •

Opening Entries
In ⊘, select entry → □ → View → □
Adding New Entries
In ⊘, <Empty> → □ → Create ASCII

#### **Deleting Entries**


- In ASCII Art list, select entry

  → □ → Delete → •
- Yes ⇒ •

### Recording/Playing Voice

#### Recording

- If battery runs low while recording, Voice Recorder shuts off.
- Record conversations during calls via Record Caller Voice.





Recording Window



- Recording starts



- For Extended Voice, recording is saved automatically.
- Save → ●

Play Before Saving
In ②, Playback → ● → Playback
starts → ➡ → Playback stops
Starting Over
In ②, ➡ → From ②

#### Playback

In recording window, □ → Ring Songs Tones → ●



Select file ▶ •




#### Playback Operations

Ç	Adjust volume
•	Pause/resume
CLEAR IS	Stop

## **Scanning Barcodes**


Scan UPC/JAN (1D barcodes) or QR Codes (2D barcodes).

- Membership file or password may be required when scanning barcodes.
- Some barcodes may not be scanned.











Scan Window

 Use Focus Adjustment Bar as a guide (better focus in darker blue).



#### ■ Scan starts

- If recognition takes time, slowly adjust the distance between handset and barcode.
- Press to stop scan.

## Tone sounds → Scan results appear




#### Key Assignments in Scan Window

- ▶10: Toggle focus mode
- Switch to Photo Camera
- : Focus Lock
- : Mobile Light on/off
- : Adjust brightness
- : Open Help

#### Split Data

- After scanning, confirmation appears.
  - Follow onscreen prompt(s).
- Scan results do not appear until all split data is scanned.

#### **Starting Over**




#### **Advanced**



Scanning during text entry Scanning continuously Reading saved barcode images Saving scan results Saving to Notepad Saving linked info to Phone Book Opening saved scan results Using linked info Using images as Wallpaper Saving images & melodies Copying text (And more on P.9-38 - 9-39)

### **Creating QR Codes**

Create QR Codes from these items on handset:



Large items are divided into multiple QR Codes.

#### Procedure

Follow these steps to create QR Codes from Data Folder files:





Create QR Code ▶ •





- Select folder 

  Select file or entry 

  Select
  - QR Code is created.




 QR Code is saved to Data Folder (Pictures).



#### **Scanning Business Cards**

Scan business cards and save names. addresses, etc. to Phone Book.

- English business cards may not be scanned correctly.
- Some cards may not be scanned.







Frame card on Display




Scan Window

- Press 🗹 to stop scan.
- Scan results appear









#### Scanning Text


Some text cannot be scanned.





Scan Text 

●





Scan Window


- Adjust to frame text in [].
- Use Focus Adjustment Bar as a guide (better focus in darker blue).
- - Press 🖾 to stop scan.
  - Select line **→** Scan results appear















After ⑤. ☐ → Select/Edit → ● Select character 

◆ Select alternative from list or edit directly > 3

#### Starting Over









Calendar	
■ View Settings	
Changing default view	■ Tools ■ In PIM/Lifestyle menu,  Calendar ■ □ □ Calendar Settings ■  Default View ■ Select type ■
Jumping to specified date	● → Tools → ● → In PIM/Lifestyle menu,  Calendar → ● → -8: → Enter date → ●
	Start Here ● → Tools → ● In PIM/Lifestyle menu, Calendar → ● → See below
Changing date color	By Days of the Week
	By Date Select date ⇒ •4: ⇒ Select color ⇒ •
	Resetting "By Date" Colors
Selecting task view option	■ * Tools * ■ In PIM/Lifestyle menu,  Calendar * ■ □ * Calendar Settings * ■ * Tasks View * ■ * Select option * ■
Adding stamps (Month View)	● * Tools * ● * In PIM/Lifestyle menu,  Calendar * • * Select date * 21 * Select  stamp * ●  • Available in Month View only.
Hiding schedules	■ * Tools * ■ * In PIM/Lifestyle menu,  Calendar * ■ * Select date * ■ * Select  entry * ■ * ■ * Secret: * ■ * On * ■  **  **

Saving additional holidays	Start Here ● → Tools → ● → In PIM/Lifestyle menu, Calendar → ● → □ → Calendar Settings → ● → Set Holiday → ● → ○ Private → See below	
	Adding Holidays <empty> ▶ ● ▶ Enter name ▶ ● ▶ Enter date ▶ ● ▶ Select frequency ▶ ● ▶ №</empty>	
	Editing Added Holidays  Select holiday	
Removing/restoring preset holidays	■ * Tools * ■ In PIM/Lifestyle menu,  Calendar * ■ * □ * Calendar Settings * ■ * Set Holiday * ■ * ○ Private or Public  Select holiday * ■ (□/√)	
Saving/Editing Schedules		
Setting Category/ Location	Start Here ● → Tools → ● → In PIM/Lifestyle menu, Calendar → ● → Select date → ● → Select entry → ● → ● > See below	
	Category  Category:   Select Category	
	Location  Location:   ■ Enter location   □ □	
Saving repetitive schedules	● * Tools * ● * In PIM/Lifestyle menu,  Calendar * • * Select date * • * Select  entry * • • • * Repeat: * • * Select  frequency * • Enter repeat time * • *  • Repeat time is not available for Every Year.	

Saving S! Friend's	Start Here
Status information	Availability  Answer Status:   ■ Edit  ■ □ ■ □ ■ □ ■ □ ■ □ ■ □ ■ □ ■ □ ■ □ ■
	Comment:   Comment:   Set Category first.
Editing entries	■ ** Tools ** ■ In PIM/Lifestyle menu,  Calendar ** ■ ** Select date ** ● ** Select  entry ** ■ ** ● ** Select item ** ● ** Edit in  the same manner as saving schedules ** **  **P
Changing Alarm tone/video & duration	Start Here ● → Tools → ● → In PIM/Lifestyle menu, Calendar → ● → Select date → ● → Select entry → ● → ● → Alarm: → ● → See below
	Alarm Tone/Video  Assign Tone/Video:   Select folder  Select tone/file  Select start point if required.
	Duration  Duration:   Select time   Duration:   Durat
Changing Alarm volume	■ Tools ■ In PIM/Lifestyle menu, Calendar ■ □ → Alarm Settings ■ ■ Alarm Volume: ■ ■ Adjust level ■
Selecting Vibration option	■ Tools ■ In PIM/Lifestyle menu,  Calendar ■ Alarm Settings ■  Vibration: ■ Select option ■

Sounding Alarm tone even in Manner mode	Tools ■ In PIM/Lifestyle menu, Calendar ■ Alarm Settings ■ For Manner Mode: ■ Ring ■ Yes ■
■ Managing Sche	dules
Searching entries	Start Here ● → Tools → ● In PIM/Lifestyle menu, Calendar → ● → See below
	By Subject  □6i → Enter text → ■
	By Category
Checking memory status	● → Tools → ● → In PIM/Lifestyle menu,  Calendar → ● → Select date → □ → Memory  Status → ●
Deleting all entries	■ Tools ■ In PIM/Lifestyle menu, Calendar ■ □ Delete ■ All Appointments ■ Enter Handset Code ■ ■ Yes ■ ■
	Start Here ● → Tools → ● In PIM/Lifestyle menu, Calendar → ● → See below
Deleting entries by specifying week (Week View)	Within One Week Select date
	Up to the End of Previous Week Select date ♦ ☐ ♦ Delete ♦ ■ ♥ Up to Last Week ♦ ● ♦ Yes ♦ ●

	Start Here ● → Tools → ● In PIM/Lifestyle menu, Calendar → ● → See below
Deleting entries by specifying month (Month View)	Within One Month Select date
	Up to the End of Previous Month Select date ⇒ □ → Delete ⇒ ● Up to Last Month ⇒ ● → Yes ⇒ ●
Deleting entries in two months (2Month View)	■ → Tools → ■ In PIM/Lifestyle menu, Calendar → ■ → □ → Delete → ■ → All This 2Months → ■ → Yes → ■

#### Tasks

#### ■ Task List

Secret. 7 01 7 0	Hiding tasks	● * Tools * • In PIM/Lifestyle menu,  Tasks * • Select task * □ * Edit * • *  Secret: • • On * • *
------------------	--------------	--

#### ■ Saving/Editing Tasks

Editing tasks	● → Tools → ● In PIM/Lifestyle menu,  Tasks → ● → Select task → □ → Edit → ● →  Select item → ● → Edit in the same manner as saving tasks → □
Setting priority	■ * Tools * • In PIM/Lifestyle menu,  Tasks * • * Select task * • * Edit * • *  Priority: * • * Select option * • *

	Start Here
Changing Alarm tone/video & duration	Alarm Tone/Video  Assign Tone/Video:   Select folder  Select tone/file  Select start point if required.
	Duration  Duration:   Select time   Duration:   Durat
Changing Alarm volume	■ Tools ■ In PIM/Lifestyle menu,  Tasks ■ □ □ Alarm Settings ■ ■  Alarm Volume: ■ Adjust level ■
Selecting Vibration option	■ Tools ■ In PIM/Lifestyle menu,  Tasks ■ □ □ Alarm Settings ■ ■  Vibration: ■ Select option ■
Sounding Alarm tone even in Manner mode	■ * Tools * ■ In PIM/Lifestyle menu,  Tasks * ■ * □ * Alarm Settings * ■ *  For Manner Mode: * ■ * Ring * ■ * Yes  ■

#### ■ Managing Tasks

Indiagnig racks	<u></u>
Searching tasks	Start Here $●$ $♦$ $Tools$ $♦$ $●$ $♦$ In PIM/Lifestyle menu, $Tasks$ $♦$ $●$ $♦$ $○$ $♦$ $Find$ $♦$ $●$ See below
	By Subject  By Subject  ■ Enter text  ■
	By Due Date  By Due Date   ■ Enter date   ■
Sorting tasks by priority	→ Tools →
Checking memory status	● → Tools → ● → In PIM/Lifestyle menu,  Tasks → ● → □ → Memory Status → ●
Deleting all tasks	■ Tools ■ In PIM/Lifestyle menu,  Tasks ■ □ □ Delete ■ All Tasks ■ ■ Enter Handset Code ■ ■ Yes ■

Alarms	
Editing entries	■ → Tools → ■ In PIM/Lifestyle menu,  Alarms → ■ → Select entry → ■ → Select item → ■ → Edit in the same manner as saving entries → ¬
Saving entry name	● → Tools → ● In PIM/Lifestyle menu,  Alarms → ● → Select entry → ● → Subject:  • ● → Enter name → ● → □
	Start Here ● → Tools → ● → In PIM/Lifestyle menu, Alarms → ● → Select entry → ● → Assign Tone/Video: → ● → See below
Changing Alarm tone/video	Using Preset Tone or Data Folder File  Select folder   ■ Select tone/file   ■   Select start point if required.
	Using Customized Screen Tone/Video  Customized Screen
Setting handset to vibrate at Alarm Time	■ Tools ■ In PIM/Lifestyle menu,  Alarms ■ Select entry ■ Vibration: ■ On or Link to Sound ■ ▼  Select Link to Sound to allow compatible SMAF files to control vibration.
Sounding Alarm tone even in Manner mode	■ * Tools * • In PIM/Lifestyle menu, Alarms * • * Settings * • * For Manner Mode * • * Ring * • * Yes * •
Activating Alarm based on World Clock time	■ Tools ■ In PIM/Lifestyle menu, Alarms ■ Settings ■ Link to World Clk ■ On ■ ■

Hand
~
Extras

Wakeup IV	
Editing entries	● * Tools * • In PIM/Lifestyle menu,  Wakeup TV * • Select entry * • Select item * • Edit in the same manner as saving entries * •
	Start Here ● → Tools → ● In PIM/Lifestyle menu, Wakeup TV → ● → Select entry → ● → Assign Tone/Video: → ● → See below
Changing Alarm tone/video	Using Preset Tone or Data Folder File  Select folder   Select tone/file   Select start point if required.
	Using Customized Screen Tone/Video  Customized Screen
Sounding Alarm tone even in Manner mode	Tools  In PIM/Lifestyle menu,  Wakeup TV  For Manner Mode  Ring  Yes     Tools  Tools

Calculator		
Copying calculation results	While result appears,	
Changing exchange rate for currency conversion	■ Tools ■ In PIM/Lifestyle menu,  Calculator ■ In Money Converter  ■ Exchange Rate ■ Domestic or  Foreign ■ Enter rate ■ In Indian Ind	
Converting currencies	■ Tools ■ In PIM/Lifestyle menu,  Calculator ■ Enter amount of money ■  Money Converter ■ To Domestic or  To Foreign ■ ■  Set Exchange Rate first.	
Expenses Memo		
Changing Category of saved entry	Tools	
Changing amount	● → Tools → ● → In PIM/Lifestyle menu,  Expenses Memo → ● → Totals → ● →  Select entry → ● → Change Amount → ● →  Edit → ●	

Renaming Categories ■ \*\* Tools \*\* • \* In PIM/Lifestyle menu,

Expenses Memo \*\* • \*\* Edit Category \*\* •

\*\* Select Category \*\* • \*\* Enter name \*\* •



Osaifu-Keitai <sup>®</sup>	
Enabling to view e-money balances	■ Tools ■ In PIM/Lifestyle menu, Osaifu-Keitai ■ IC Card Settings ■ Balance Info ■ Enter Handset Code ■ <a href="#"> Empty&gt; ■ S! Appli or Lifestyle-Appli ■ Seet application ■  ■ For use with compatible Lifestyle-Applications. ■ Start Lifestyle-Appli once before adding it to Balance Info list.</a>
Checking e-money balance on External Display  Moving applications up/down Balance Info list	With handset closed,
Removing applications from Balance Info list	■ Tools ■ In PIM/Lifestyle menu, Osaifu-Keitai ■ IC Card Settings ■ Balance Info ■ Enter Handset Code ■ Select application ■ Delete ■ ■
Customizing handset response to reader/writer commands	Osaifu-Keitai → In PIM/Lifestyle menu,  Osaifu-Keitai → In PIM/Lifestyle menu,  Interface Settings → Interface Settings → Enter Handset  Code → Interface Settings → Interface S
Opening IC Card properties	● Tools ● In PIM/Lifestyle menu, Osaifu-Keitai ● IC Card Settings ● IC Card Status ●

	Start Here
Changing IC Card	Changing Recipient
Lock notice	To Set Recipient ⇒ ● ⇒ Set Recipient ⇒ ●
recipient	⇒ Select method ⇒ ● ⇒ Select/enter number/address ⇒ ● ⇒  ⇒ ¬
	Omit step of pressing when selecting <i>Phone</i>
	<b>Book</b> as setting method.
	Disabling Notice  Off
Changing required Missed Call count for Call Remote Lock	■ **Tools ** ■ In PIM/Lifestyle menu, Osaifu-Keitai ** ■ **IC Card Settings ** ■ ** Remote Lock ** ■ ** Enter Handset Code ** ■ **Call Remote Lock ** ■ ** Count for Lock ■ ** Enter Missed Call count ** ■ **  • **
Restoring default Osaifu-Keitai® settings	■ Tools ■ In PIM/Lifestyle menu, Osaifu-Keitai ■ IC Card Settings ■ Set to Default ■ Enter Handset Code ■ Yes ■



#### Simulated Call

Starting via Simulated Call menu	● * Tools * • In PIM/Lifestyle menu, Simulated Call * • Receive Simulated Call • • Wes • • • Simulated Call starts immediately regardless of Receive Timing setting. • Settings remain even after starting Simulated Call during setup.
Clearing caller information	● → Tools → ● In PIM/Lifestyle menu, Simulated Call → ● → Set Caller → ● → □  → Yes → ● → ₩ → ₩
Overriding Silent volume setting	● ➤ Tools → ● In PIM/Lifestyle menu, Simulated Call → ● ➤ For Silent Mode → ●  Ring → ● ➤ Yes → ● ➤

#### Hour Minder

Changing Hour Minder tone/video	Start Here ● → Tools → ● → Clocks/Gauges → Hour Minder → ● → Advanced → ● → Assign Tone/Video: → ● → See below
	Using Preset Tone or Data Folder File Select folder → ● Select tone/file → ●  □ → □  • Select start point if required.
	Using Customized Screen Tone/Video Customized Screen
Setting handset to vibrate at Hour Minder Time	■ Tools ■ Clocks/Gauges Hour Minder ■ Advanced ■ Wibration: ■ On or Link to Sound ■ Select Link to Sound to allow compatible SMAF files to control vibration.
Sounding Hour Minder tone even in Manner mode	■ Tools → ■ Clocks/Gauges → Hour Minder → ■ Advanced → ■ For Manner Mode: → ■ Ring → ■ Yes → ■
Activating Hour Minder based on World Clock time	■ Tools ■ Clocks/Gauges ■ Hour Minder ■ Advanced ■ Link to World Clk: ■ On ■ W W

Notepad	
Editing Notepad	Start Here ● → Tools → ● → Doc./Rec. → Notepad → ● → Select entry → □ → See below
	Editing Text  Edit Text → ● ⇒ Edit ⇒ ●
	Changing Category  Change Category   Select Category  ■
Searching text within all entries	● → Tools → ● → ✓ Doc./Rec. → Notepad → ● → Select entry → □ → Search → ● Enter text → ●
Inserting Notepad text into message text	■ Tools ■ Doc./Rec. Notepad ■ Select entry ■ Send ■ As  Message Text ■ SI Mail or SMS ■ Complete message ■ ■ SI Mail Composition window opens automatically depending on character count.
Sending entries via S! Mail	● → Tools → ● → O Doc./Rec. → Notepad → ● → Select entry → □ → Send → ● → Via  Message → ● → Complete message → ¬
Creating text files	■ Tools ■ Doc./Rec. Notepad ■ Select entry ■ Setting/Manage ■ Create Text File ■ Enter name ■ Save here ■
Importing text files	■ * Tools * ■ * * Doc./Rec. * Notepad  • • Select entry * • * Setting/Manage * • Import Text File * • * Select file * •
Checking memory status	■ Tools ■ Doc./Rec. Notepad ■ Select entry ■ Setting/Manage ■ Memory Status ■

Voice Recorder	
Saving longer recordings Saving longer starts	Tools • • Doc./Rec. Voice  der • • • Hecord Time • •  ded Voice • • • Recording  Recording ends  t Memory Card to record in Extended Voice e. (Recording is saved automatically.)
Sending Voice files via S! Mail  Recor  → Rec  Comp	Tools • • • Doc./Rec. Voice  der • • • Recording starts • •  cording ends • Save and Send • •  lete message • •  able in For Message mode.
Switching storage media  Recor  Avail  Set t	Tools • • • Doc./Rec. Voice der • • • Save Recording to Select option • • able in For Message mode. o Ask Each Time to select media after every ding.

Scan Barcode	
	Start Here In a text entry window,   → Scan Code → → Frame barcode in center of Display → → See below
Scanning during text entry	Pasting All Scan Results  •
	Pasting a Part of Scan Results
Scanning continuously	■ Tools ■ Doc./Rec. Barcode/ Scan ■ Scan Barcode ■ □ ▼ Continuous Scan ■ On ■ Frame barcode in center of Display ■ ■ Choose Yes to continue scanning or No and press ■ to view scan results.
Reading saved barcode images	● → Tools → ● → O Doc./Rec. → Barcode/ Scan → ● → Open Barcode → ● → Select file → ●
Saving scan results	■ → Tools → ■ → ODoc./Rec. → Barcode/ Scan → ■ → Scan Barcode → ■ → Frame barcode in center of Display → ■ → □ → Save → ■
Saving to Notepad	■ * Tools * ■ * Doc./Rec. * Barcode/ Scan * • * Scan Barcode * • * Frame barcode in center of Display * • * □ * Notepad * •

	T
Saving linked info to Phone Book	■ Tools ■ Doc./Rec. Barcode/ Scan ■ Scan Barcode ■ Frame barcode in center of Display ■ Select number or mail address ■ Save to Ph.Book ■ As New Entry ■ ■ Complete other fields ■ To add to an existing entry, select As New Detail. When MEMORY: appears in scan results, press ■ to enter the items underlined with a dotted line automatically in Phone Book entry window.
Opening saved scan results	■ * Tools * • Doc./Rec. * Barcode/ Scan * • Scanned Results * • Select file * • • Select a file and press • to rename files, open properties or delete files. • Some files may not open.
Using linked info	Start Here ● → Tools → ● → Doc./Rec. →  Barcode/Scan → ● → Scan Barcode → ● →  Frame barcode in center of Display → ● →  See below
	Dialing Numbers Select phone number   ● ●   □
	Sending Messages Select mail address ▶ ● Complete message ▶ №  • When MAILTO: appears in scan results, press • to enter the items underlined with a dotted line automatically in Composition window.
	Accessing Internet Sites Select URL   ●

Using images as Wallpaper	■ Tools Doc./Rec. Barcode/ Scan Doc./Rec. Barcode/ Scan Scan Barcode Display Scan Scan Barcode  ■ Scan Scan Barcode Display Scan Barcode Display Display Scan Barcode Display Display Mallpaper Display options appear; follow onscreen prompts.
Saving images & melodies	■ Tools ■ Doc./Rec. Barcode/ Scan ■ Scan Barcode ■ Frame barcode in center of Display ■ Select file ■ To Data Folder ■ ■
Opening or playing files	■ Tools Doc./Rec. Barcode/ Scan Scan Scan Barcode Frame barcode in center of Display Select file
Using images for System Graphics	■ Tools ■ Doc./Rec. Barcode/ Scan ■ Scan Barcode ■ Frame barcode in center of Display ■ Select image ■ As System ■ Select item ■ Specify display area ■ ■ Some images may be usable without specifying display area.

Pasting to message text	Start Here ● → Tools → ● → ☑ Doc./Rec. →  Barcode/Scan → ● → Scan Barcode → ● →  Frame barcode in center of Display → ● → □  → Send Message → ● → See below
	All Text  ■ → S! Mail or SMS → ■ Complete  message → □  ■ S! Mail Composition window opens automatically depending on character count.
	Selected Text  Select first character → ● → Highlight text range → ● → S! Mail or SMS → ● → Complete message → □  S! Mail Composition window opens automatically depending on character count.
Copying text	Start Here ● → Tools → ● → △ Doc./Rec. →  Barcode/Scan → ● → Scan Barcode → ● →  Frame barcode in center of Display → ● →  See below
	Text  ② → Copy → ● → Select first character → ●  → Highlight text range → ●
	Number, Address or URL Select number, mail address or URL   ©  Copy Telephone, Copy Address or Copy URL

#### Scan Card

Saving to Notepad	● → Tools → ● → Doc./Rec. → Barcode/ Scan → ● → Scan Card → ● → Frame card in center of Display → ● ● → □ → Notepad → ●
Pasting to message text	Start Here ● → Tools → ● → Doc./Rec. →  Barcode/Scan → ● → Scan Card → ● →  Frame card in center of Display → ● → ● →  □ → Send Message → ● → See below
	All Text  ■ S! Mail or SMS ■ Complete  message ■  ■ S! Mail Composition window opens automatically depending on character count.
	Selected Text  □ → Select first character → ● → Highlight text range → ● → S! Mail or SMS → ● → Complete message → □  • S! Mail Composition window opens automatically depending on character count.
Copying text	Start Here ● → Tools → ● → Doc./Rec. →  Barcode/Scan → ● → Scan Card → ● →  Frame card in center of Display → ● → ●  See below
	Text

#### Scan Text

Scanning during text entry	In a text entry window,
Scanning more text	■ Tools ■ Doc./Rec. Barcode/ Scan ■ Scan Text ■ Frame text in center of Display ■ Select line ■ ■ Continue Part to enter additional text or Scan More to enter text after a line break.
Saving scan results	■ Tools ■ Doc./Rec. Barcode/ Scan ■ Scan Text ■ Frame text in center of Display ■ Select line ■ ■ ■ Save ■ ■
Saving linked info to Phone Book	■ Tools ■ Doc./Rec. Barcode/ Scan ■ Scan Text ■ Frame text in center of Display ■ Select line ■ ■ Select number or mail address ■ Save to Ph.Book ■ As New Entry ■ Complete other fields ■ ■ To add to an existing entry, select As New Detail.
Saving to Notepad	■ Tools Doc./Rec. Barcode/ Scan ■ Scan Text ■ Frame text in center of Display ■ Select line ■ Notepad ■
Opening saved scan results	■ Tools Doc./Rec. Barcode/ Scan Doc./Rec. Barcode/ Scan Doc./Rec. Barcode/ Scan Doc./Rec. Barcode/ Select afle and press to rename files, open properties or delete files. Some files may not open.

# Extras

#### Osaifu-Keitai®



#### Cannot use Osaifu-Keitai® (S! FeliCa)

• Battery may be low. Charge battery or install a charged battery.



#### Recognition via reader/writer takes time

• Check logo area. Foreign articles can block/hamper recognition.



#### Call Remote Lock does not activate even after specified number of Missed Calls

- . Missed Call count is reset by calls from other numbers. If series is interrupted, start over from the beginning.
- When Call Forwarding is active, Missed Calls may not be recorded.

#### Wakeup TV



#### TV does not activate with specified channel

• If Wakeup TV Time arrives while TV is active, channel does not switch to the specified one.

#### Voice Recorder



#### Cannot record properly

• If incompatible microphone is connected, recording may fail.



#### Noise/skipping occurs

 Avoid shocks to handset while recording; may cause noise or skipping.



#### Recording takes time to start

• Recording window may take longer to open as more Voice files are saved on Memory Card.

#### Scanning Barcode/Card/Text



#### Cannot read barcodes properly

- · Scan may fail if barcode is dirty or unclear.
- · Scan may fail if barcode is scanned under inadequate light.
- · Scan may fail if multiple barcodes are captured at one time.



#### Cannot read barcodes during text entry

· Scanning is not available during calls or when mobile camera is active.



#### Cannot read barcode images in **Data Folder automatically**

· When scan fails, follow onscreen instructions and select next barcode image manually.



#### Cannot scan business cards properly

- Scan fails if business card is printed in light-colored text on a dark background, handwritten or printed in casual/decorative fonts, decorated with a background pattern, or designed with both vertical and horizontal text.
- · Scan may fail if business card is printed in light-colored text on a light background, printed in italics or extremely small fonts, decorated with a logo or logo-like text, printed on a glossy paper or other material, or dirty/folded.



#### Cannot scan text properly

- Scanning over 35 characters at one time may yield poor results.
- · Adjust to frame text in []. Letters at the ends may be distorted.

