

Mail



Overview	5-2	Advanced Features	5-20
Customizing Handset Address	5-4	Sending Messages	5-20
Setting PC Mail Accounts	5-4	Receiving/Opening Messages	5-23
Sending Messages	5-6	Managing/Using Messages	5-25
Sending S! Mail	5-6		
Sending SMS Messages	5-7		
Sending PC Mail	5-7		
Attaching Files	5-7		
Saving Addresses to Blog/Mail Member	5-8		
Receiving & Opening Messages	5-10		
Opening New Messages	5-10		
Opening S! Mail & SMS Inbox Messages	5-10		
Replying to S! Mail/SMS Messages	5-11		
Using Mail List (S! Mail)	5-11		
Retrieving New PC Mail	5-12		
Opening PC Mail Inbox Messages	5-12		
Replying to PC Mail Messages	5-12		
Handling Messages	5-14		
Message Folders	5-14		
Opening Sent & Received Messages	5-14		
Sorting Messages	5-16		
Using Tomomato-Mail	5-16		
Prohibiting Access to Messages	5-17		
Saving Attachments	5-18		


5



Overview

Handset supports SMS, S! Mail and PC Mail.

5
Mail






Send and receive messages for PC e-mail addresses.

PC Mail

Set your PC Mail account on handset to receive and send messages from your PC Mail or Yahoo! account.



New PC Mail is managed in a separate folder from S! Mail and SMS messages. Press in Mail menu to toggle Mail menu and PC Mail menu. Set the default mail menu in *Priority Mail Menu* (P. 14-19).

Precautions

- Receiving mail for the first time after account setup may incur high transmission fees. Note also that transmission fees may be incurred for checking messages, even if no new messages are received.
- Setting handset to automatically retrieve mail may incur high transmission fees, especially while abroad.
- Checking for new mail may slow down other functions in use.
- Single-byte katakana may not be supported on receiving device.
- Pictographs in incoming HTML messages appear on handset. However, handset does not support pictographs for outgoing messages.
- Attachments are encoded when sending PC Mail. Since files are larger when encoded, the maximum size when including attachments is smaller than 2 MB.



Customizing Handset Address

Change handset address (portion before @) to reduce the risk of receiving spam. The default address is random alphanumeric.

- For details, see:
http://www.softbank.jp
or contact SoftBank Mobile Customer Center, General Information (P. 15-61).

1 ⇒ **Mail Setting** ⇒ ●

2 **Custom Mail Address** ⇒ ●
Follow onscreen instructions.

Setting PC Mail Accounts

Set up to three e-mail accounts. For details on Yahoo! Mail setup, see P. 5-5.

- Check your ISP settings before setup.
- PC Mail service may be unavailable depending on your mail account subscription, settings or specifications. Make sure your PC mail system supports POP retrieval and SMTP transmission.
- Check the following information prior to setup.
 - E-mail address
 - User name (user ID)
 - Password
 - POP server
 - SMTP server

Send Settings (SMTP Settings)

Check your provider settings before setup.


1 ⇒ ⇒ **PC Mail Settings** ⇒ ●

2 **Account Settings** ⇒ ● ⇒ Select an account (アカウント1, アカウント2 or アカウント3) ⇒ ●



PC Mail Account Settings Window

3 **Manual Settings** ⇒ ●



Manual Settings Window

4 **SMTP Settings** ⇒ ●

5 **SMTP Server Address** ⇒ ● ⇒ Enter address ⇒ ●

6 **Mail Address** ⇒ ● ⇒ Enter address ⇒ ●

■ To Set a Port Number
⇒ **SMTP Server Port** ⇒ ● ⇒ Enter server port ⇒ ●
Setting is "587" by default.

■ To Set POP before SMTP
⇒ **POP before SMTP** ⇒ ● ⇒ ON or OFF ⇒ ●

■ To Set SMTP over SSL
⇒ **SMTP over SSL** ⇒ ● ⇒ SSL, STARTTLS or OFF ⇒ ●

7 **SMTP Auth.** ⇒ ● ▶

▶ When ON Is Set
ON ⇒ ● ⇒ **SMTP Auth. User ID** and **SMTP Auth. Password** ⇒ ● ⇒ Enter ID and password ⇒ ●

▶ When OFF Is Set
OFF ⇒ ●

8



Retrieval Settings (POP3 Settings)

Check your provider settings before setting.

- 1 [Manual Settings] window ⇨
POP3 Settings ⇨ ●
- 2 **POP3 Server Address** ⇨ ● ⇨
Enter address ⇨ ●
- 3 **POP3 Login ID** ⇨ ● ⇨ Enter
address ⇨ ●
- 4 **POP3 Login Password** ⇨ ● ⇨
Enter password ⇨ ●
 - To Set a Port Number
⇨ **POP3 Server Port** ⇨ ● ⇨ Enter
server port ⇨ ●
Setting is "110" by default.
 - To Set Receiving Authentication
⇨ **APOP Auth.** ⇨ ● ⇨ **ON** or **OFF** ⇨
●
 - To Set POP3 over SSL
⇨ **POP3 over SSL** ⇨ ● ⇨ **SSL**,
STARTTLS or **OFF** ⇨ ●
 - To Set to Leave/Delete Messages on
Server
⇨ **Delete Server Mail** ⇨ ● ⇨ **ON** or
OFF ⇨ ●

5

Yahoo! Mail Setup

If you have a Yahoo! Mail account, enter an e-mail address and password to configure the account setting.

- 1 [PC Mail Account Settings]
window ⇨ **Set Quick Yahoo!**
Mail ⇨ ●
- 2 **Mail Address** ⇨ ● ⇨ Enter
Yahoo! Mail address ⇨ ●
- 3 **Password** ⇨ ● ⇨ Enter
password ⇨ ●
- 4

Note

- If you edit your account, the following operations become unavailable for some previously received messages:
 - full-text retrieval
 - reply
 - forward
 - re-edit
 - resend

Tip

- To obtain a Yahoo! Japan ID:
[PC Mail Account Settings] window ⇨
Yahoo! JAPAN ID ⇨ ●

More Features

Customize

PC Mail Account Settings

- Edit Account Name
- Reset PC Mail Account Settings

(▶ P. 14-19)


5

Mail



Sending S! Mail

1 Press and hold



S! Mail Composition Window

2 → ● → **Enter Address** → ●

● → **Enter address** → ●

To add more recipients, Select , press ● and repeat the same step. After adding recipients, press .

3 → ● → **Enter subject** → ●

4 → ● → **Enter text** → ●



S! Mail Text Entry Window

5

■ To Cancel Transmission

→ When *Start Packet Connection* appears → ●

Alternatively, press during transmission.

■ If *Resend mail?* Appears

→ YES → ●

Tip

• Add up to 20 recipients total between To, Cc and Bcc fields.

Graphic Mail

Create html messages to change font color/size and background color. Add scrolling text, paste images, etc.

<Example> Change font size, background color, insert an image and set flashing text.

1 [S! Mail Text Entry] window →

→ → ● → **Select a font size** → ● → **Enter text** → ●

2 → ● → → **Select a background color** → ●

Press while selecting to toggle between 25-color and 256-color palettes.

3 → ● → **Select a folder** → ●

→ **Select an image** → ●

■ **Inserting Images with Large File Size**

→ *Insert Mail* or *SubQCIF Scale Down* → ● (→ Check an image → ●)

4 → ● → → ● → **Enter**

text → ● → → ● → → ●


5 → ●



Sending SMS Messages

Send short text messages to SoftBank handsets, using recipient's phone number.

- 1 → **Compose SMS** →



SMS Composition Window


- 2 **To** → → **Enter Address** → → **Enter phone number** →
- 3 → → **Enter text** →
- 4

Sending PC Mail

- 1 → → **Compose PC Mail** →

■ When Several Accounts Are Set

- **From** → → Select PC Mail account →



PC Mail Composition Window

- 2 **To** → → **Enter Address** → → **Enter address** →
- 3 **Subject** → → **Enter subject** →
- 4 → → **Enter text** →



PC Mail Text Entry Window

- 5

Attaching Files

Attach the following files to S! Mail/PC Mail:

- Images
- Melodies
- Documents
- Books
- Phone Book entries
- Schedule (To Do List)
- Videos
- PDF files
- Music (Songs)
- Widgets
- Account Details
- Bookmarks

- For information about image, video, melody, PDF, other document, music files, book and widgets, see P. 12-2.

- 1 **[S! Mail Composition] window/[PC Mail Composition] window** →
- 2 **Select a file type** → (→ **Enter Security Code** →) → **Select a file** →

■ Images with Large File Size

- **Attach Mail, FullHD Scale Down, VGA Scale Down** or **QVGA Scale Down** →
 (→ **YES** →) (→ **Check an image** →)

Note

- Copy protected files cannot be sent as attachments or output to external devices.



Tip

- To open or play an attached file:
Select the file → ●

Saving Addresses to Blog/Mail Member

Use Blog/Mail Member to group mail addresses together. Create up to 20 groups; save up to 20 addresses per group. Also, save a blog address for easy access when posting blog entries.

5**Mail**

- **Own Data** → ● → **Blog/Mail Member** → ●



Blog/Mail Member List

- Select a Blog/Mail Member list → ●



Blog/Mail Member Window

3 <Not Stored>

- ▶ **To Enter an Address**
 → Enter address → ●
- ▶ **To Save an Address From Phone Book or Sent/Received Address List (S! Mail & SMS)**
 → **Look-up address** → ● → **Phone Book, Sent Address or Received Address** → ● → Select an address → ● (→ ●)

Setting Default Blog Address

Save blog addresses to Blog/Mail Members and set one address as the default upload address. Save blog address beforehand.

- Select item →

★ appears next to the default address.

Tip

- To cancel default blog address:
Select item with ★ →

More Features

Advanced

Composing Messages

- Enter Address from Phone Book
- Enter Address from Sent/Received Address List (S! Mail & SMS)
- Enter Address from Blog/Mail Member List
- Set To, Cc or Bcc
- Delete an Address
- Insert Header/Signature
- Enter My Pictograms
- Delete Text
- Change SMS Message to S! Mail
- Change S! Mail to PC Mail

▶ P. 5-20

Sending Messages

- Change Size of S! Mail to Send
- Set Priority (S! Mail)
- Server Storage Period (SMS)
- Request Delivery Report (S! Mail/SMS)
- Save Messages to Draft
- Quit Composing and Delete Message

▶ P. 5-21

Attaching Files

- Capture and Attach Still Image/Video
- Delete Files Attached to S! Mail/PC Mail

▶ P. 5-21



Blog/Mail Member

- Edit an Address
- Delete Addresses from a Blog/Mail Member List
- Edit a Blog/Mail Member List Name
- Reset a Blog/Mail Member List Name

(▶ P. 5-22)

Graphic Mail

- Add/Edit Text Decoration
- Undo
- Preview Graphic Mail
- Cancel All Decoration
- Create Graphic Mail Automatically
- Save Graphic Mail as a Template
- Download Templates
- Create Graphic Mail from a Template
- Edit a Template
- Edit Title of a Template
- Delete Templates

(▶ P. 5-22)

Customize

Display Settings

- Set an Outgoing Message Image

(▶ P. 14-4)

Header/Signature Settings

- Edit Header/Signature
- Insert Header/Signature Automatically

(▶ P. 14-16)

S! Mail Settings

- Request Delivery Report
- Set Default Mail Size

(▶ P. 14-16)

SMS Settings

- Request Delivery Report
- Set Server Storage Period of SMS Messages
- Set SMS Input Language

(▶ P. 14-16)

PC Mail Setting

- Set Default Account

(▶ P. 14-17)

Key Illumination

- Set Illumination for Sending Messages

(▶ P. 14-30)



Opening New Messages

Auto Receiving (P. 14-17) is **Auto(1MB)** by default and S! Mail and SMS messages are received automatically. When receiving messages that exceed 300 KB, packet transmission fees are incurred regardless of your subscription.

● Pictograms

	Hurry		Advice
	Like		Cheer
	Dislike		Join
	Happy		Impression
	Angry		Request
	Sad		Notice
	Fun		OK
	Surprise		Reply
	Question		Other


Tip

- Alternatively open new S! Mail/SMS messages from desktop notification. Desktop notifications are unavailable for PC Mail.
- Indicator may not always correspond to message content.
- — appears if message content does not match any of the above moods or information.

5

Emotion-Expressing Mail

When a message is received, a pictogram matching the message content appears in Received Result Window and Message List. Set the Keyword setting on, to show Keyword indicators when messages include user-set keywords (P. 14-17).



Received Result Window

1 [Received Result] window ⇨ Mail




2 Select a message ⇨ ●

Note

- By default, complete S! Mail messages (including attachments) are automatically retrieved. Transmission fees apply, depending on your subscription plan. While traveling abroad, message retrieval may incur high transmission fees.

Opening S! Mail & SMS Inbox Messages

1 ⇨ Inbox ⇨ ●



Folder List



2 Select a folder ⇨ ●



Message List

3 Select a message ⇨ ●



Message Window

To check previous/next message, press ●.

Tip

- Some attachments may require content keys to open/play the file.

Replying to S! Mail/SMS Messages

1 [Inbox Message List] ⇨ Select a message ⇨ ● ⇨ ✉

■ When Original Message Has Multiple Recipients

⇨ *To Sender* or *To All* ⇨ ●

2 Edit subject/text ⇨ ✉

Replying (Quote Message)

1 [Inbox Message List] ⇨ Select a message ⇨ ● ⇨ ✉

■ When Original Message Has Multiple Recipients

⇨ *To Sender* or *To All* ⇨ ●

2 Edit subject/text ⇨ ✉

Note

- If *To All* is selected, your address is also included in the reply. Save your address to Account Details (P. 1-21) to exclude your address as a destination.

Tip

- Attachments are automatically deleted from reply messages.
- Quoting text is unavailable for SMS replies.

Using Mail List (S! Mail)

Retrieve Mail List and select messages to download or forward.

1 ✉ ⇨ **Server Mail** ⇨ ● ⇨ **Mail List** ⇨ ● (⇨ **YES** ⇨ ●)



Mail List

2 Select a message ⇨ ✉ ⇨ **Message Receive** ⇨ ● ⇨

▶ **To Receive a Message Receive This** ⇨ ●



Receiving & Opening Messages


- ▶ To Receive Multiple Messages
Receive Selected → ● → Select messages → ● →
- ▶ To Receive All Messages
Receive All → ●

Tip

- If download fails while retrieving all messages, download is canceled.
- When there is only one message, message opens upon retrieval.

Opening PC Mail Inbox Messages

- 1 → → *PC Mail Inbox* → ●




PC Mail Folder List

- 2 Select a folder → ●



PC Mail Message List

- 3 Select a message → ●



PC Mail Message Window

To check previous/next message, press .

Retrieving New PC Mail

Retrieve new messages.

- When retrieving a large number of messages, some may be unreceivable at the same time.

- 1 →

- 2 *Retrieve New* → ●

- 3 Select an account → ●

Tip

- Use *Auto Check* (P. 14-18) to set to receive automatically. *Auto Check* is *Manual* by default. When set to *Auto*, expensive packet transmission fees may be incurred.

Replying to PC Mail Messages

- 1 [PC Mail Folder List] → Select a message → ● →

- When Original Message Has Multiple Recipients

→ *To Sender* or *To All* → ●

- 2 Edit subject/text →



Replying (Quote Message)

1 [PC Mail Message List] ⇨ Select a message ⇨ ● ⇨ ☒

■ When Original Message Has Multiple Recipients

⇨ To Sender or To All ⇨ ●

2 Edit subject/text ⇨ ☒

Note

- If *To All* is selected, your address is also included in the reply. Save your address to Account Details (P. 1-21) to exclude your address as a destination.
- When replying to HTML messages, pictograms/decorations are deleted from quoted text.

Tip

- Files attached to an originally sent PC Mail are deleted from the reply message.

More Features

Advanced

Receiving Messages

- Manually Retrieve Messages (S! Mail) (▶ P. 5-23)

Checking Messages

- Retrieve Complete S! Mail/PC Mail Manually
- Delete S! Mail from Server

- Read Out Messages
- Check Message Information (▶ P. 5-24)

Server Message Operations

- Update Mail List
- Switch Mail List Views
- Check Server Message Information (S! Mail)
- Forward a Server Messages (S! Mail)
- Delete Server Messages (S! Mail)
- Check Server Memory Status (▶ P. 5-24)

Customize

Display Settings

- Set Image or Video for Incoming Message
- Set Image for New Message/Received Result Window (▶ P. 14-4)
- Show New S! Mail/SMS Message Info While Viewing TV

Incoming Message Alerts

- Adjust Ringtone Volume
- Set a Ringtone
- Set Random Playback of Melodies as Ringtones
- Set Ringtone Duration for Incoming Message
- Set Vibration
- Set Illumination Color
- Set Illumination Pattern
- Set Illumination to Flash for New Messages
- Set an Incoming Message Image (▶ P. 14-8)

Incoming Message Settings

- Do Not Show Emotion Indicators
- Show Keyword Indicators
- Delete Keywords
- Set Priority When Receiving Messages during Operation (▶ P. 14-17)

Incoming S! Mail Messages

- Set Whether to Read Out Received Messages
- Set Voice to Read Out Messages
- Set Mail Retrieval Method
- Restrict Incoming S! Mail Size (▶ P. 14-17)

Incoming PC Mail Messages

- Set New Message Retrieval Method
- Retrieve Notification Only or Full Message
- Set Interval for New Message Retrieval
- Set New Message Retrieval Off During Set Hours
- New Message Retrieval While Abroad (▶ P. 14-18)

Reply Settings

- Quote Message Marks (▶ P. 14-18)

Key Illumination


- Set Illumination for Receiving Messages
- Set Illumination for Emotion-Expressing Mail
- Set Illumination for New Message (▶ P. 14-30)




Message Folders

Press to open Mail Menu.

Sent, received and draft messages are saved in the locations below. Press to toggle Mail menu and PC Mail menu. Set the default mail menu in **Priority Mail Menu** (P. 14-19).



Mail Menu



PC Mail Menu

Received messages

Sent messages

Draft messages

Received messages


Sent messages

Draft messages

Opening Sent & Received Messages

<Example> Open a Sent Message (S! Mail)

1 → **Outbox** →




Folder List

2 Select a folder →



Message List

3 Select a message →



Message Window

To check previous/next message, press .

Tip


- When Outbox/Inbox is full, the oldest message is deleted for each message sent/received. Unread and protected messages and Secret Folder messages are not deleted.




Windows & Indicators

Check message status, attachment type, etc. by indicators.


Folder Lists



Message Lists



Message Windows



①	Folder Type General Folder Secret Folder
②	Message Status Unread Read Protected (Unread) Protected (Read) Forwarded Replied Sent to a Single Recipient Sent to Multiple Recipients
③	Message Type SMS on Handset SMS on USIM Card S! Mail/PC Mail Notification Attachment Type Image Video Melody (Tones/Ringtones) Music Copy-protected File Phone Book Entry, Account Details, Schedule Event or Bookmark Widget Book PDF Document Forwarded Server Mail Others Multiple Files

The following marks appear on indicators to inform you:

- Folder Contains Unread Messages
- Locked Folder
- Folder with Auto Sort Set
- Protected Message
- Delivery failed to Some Recipients or Some Attachments Deleted
- Delivery Failed/All Attachments Deleted
- Attachment Deleted
- High Priority S! Mail

Tip

- To open/play copy-protected files, save files to Data Folder.
- appears in **Subject** field when Delivery Report is received.



Sorting Messages

Automatically sort incoming/outgoing messages into folders.

1 [Folder List] ⇨ Select a folder ⇨ ⇨ **Auto-sort** ⇨

▶ To Sort by Address

Address Sort ⇨ ⇨ *Look-up Address, Look-up Group, Look-up Member or Enter Address* ⇨

▶ To Sort by Subject

Subject Sort ⇨ ⇨ Enter subject ⇨

▶ To Sort by Reply Failed, Send Failed or Unregistered Address
Reply Impossible, Sent Impossible or Unregistered Add. ⇨

Tip

- Only one Inbox folder can be specified for sorting *Reply impossible* messages.
- Only one Outbox folder can be specified for sorting *Send impossible* messages.
- Only one Inbox/Outbox folder can be specified for sorting *Unregistered Add.* messages.
- Search addresses from Phone Book, Received/Sent Address List (S! Mail & SMS) in *Look-up address*.

Canceling Auto Sort

1 [Folder List] ⇨ Select a folder ⇨ ⇨ **Auto-sort** ⇨

2 Select a criterion ⇨ ⇨ **Release** ⇨

▶ To Cancel a Criteria

Release This ⇨ ⇨ YES ⇨

▶ To Cancel Multiple Criteria

Release Selected ⇨ ⇨ Select criteria ⇨ ⇨ YES ⇨

▶ To Cancel All Criteria


Release All ⇨ ⇨ YES ⇨

Using Tomomato-Mail

Store e-mail addresses in Tomomato-Mail and check messages (S! Mail/SMS) with stored addresses by selecting Tomomato-Mail BOX.

Checking Tomomato-Mail

1 ⇨ **Tomomato-Mail BOX** ⇨



Tomomato-Mail Folder List

2 Select a folder ⇨



Storing Tomomato-Mail

- [Tomomato-Mail Folder List]** ⇨
Select a folder ⇨ ⇨
 ▶ **To Enter an Address**
Enter Address ⇨ ● ⇨ Enter Address
 ⇨ ●
 ▶ **To Store E-Mail Address From Phone Book or Sent/Received Address List (S! Mail & SMS)**
Phonebook, Sent Address or Received Address ⇨ ● ⇨ Select an address ⇨ ●

Canceling Tomomato-Mail

- [Tomomato-Mail Folder List]** ⇨
Select a folder ⇨ ⇨
Unregister ⇨ ● ⇨ **YES** ⇨ ●

Prohibiting Access to Messages

Setting Mail Box Lock

- (⇨) ⇨ **Mail Setting or PC Mail Settings** ⇨ ●
- Mail Box Lock** ⇨ ● ⇨ Enter Security Code ⇨ ●
- Select a mail box** ⇨ ●
Repeat Step 3 to specify other boxes.
-

Setting Folder Lock

- [Folder List]** ⇨ **Select a folder** ⇨ ⇨ **Folder Lock** ⇨ ● ⇨ Enter Security Code ⇨ ● ⇨ **YES** ⇨ ●
Locked folders are indicated by .

Tip

- Repeat the same procedure to cancel mail box and folder lock.
- Security Code entry is required to view messages in locked mail boxes and folders.

Storing Messages in Secret Folders

- Set handset to Secret Mode or Secret Data Only Mode beforehand (P. 4-7).
- Unread Messages, S! Mail/PC Mail with Text Unreceived or delivery reports cannot be stored in Secret Folders.

- [Message List]** ⇨ **Select a message** ⇨ ⇨ **Keep in Secret** ⇨ ● ⇨
 ▶ **To Store a Message**
Keep This ⇨ ●
 ▶ **To Store Multiple Messages**
Keep Selected ⇨ ● ⇨ Select a message ⇨ ● (repeat to select another message) ⇨ ⇨ **YES** ⇨ ●
 ▶ **To Store All Messages in a Folder**
Keep All ⇨ ● ⇨ **YES** ⇨ ●

Returning Messages in Secret Folders to Ordinary Messages

- [Folder List]** ⇨ **Secret** ⇨ ●
- Select a message** ⇨ ⇨ **Put Out** ⇨ ● ⇨
 ▶ **To Return a Message**
Put Out This ⇨ ● ⇨ Select a folder ⇨ ●



Handling Messages

- ▶ **To Return Multiple Messages**
Put Out Selected → ● → Select a folder → ● → Select a message → ● (repeat to select another message) → ☑ → **YES** → ●
- ▶ **To Return All Messages**
Put Out All → ● → Select a folder → ● → **YES** → ●

Saving an Image Inserted in Text

- 1 [Message] window → → **Save Insert Image** → ●
- 2 Select an image → ● → **YES** → ● → Select a folder → ●
- 3 **YES** or **NO** → ● (→ Select an item → ● (→ Select a view → ● → Check an image → ●))

Saving a Bookmark

- 1 [Message] window → Select a link (URL, etc.) → ● (twice) → Select a destination → ● → Select a folder → ●

Note

- Mail-attached phone book entries, schedule events or bookmarks cannot be saved to *microSD*.

5

Mail

Saving Attachments

Saving Image, Video, Melody, Music, Flash®, Book and PDF Files

<Example> Save an image

- 1 [Message] window → Select a file → → **Save Data** → ● → **YES** → ●
- 2 Select a folder → ●
- 3 **YES** or **NO** → ● (→ Select an item → ● (→ Select a view → ● → Check an image → ●))

Saving a Phone Book Entry

- 1 [Message] window → Select contact information (a phone number, etc.) → ● (twice) → **Phone** or **USIM** → ● → **New** → ●
- 2 Edit each item → ☑

Saving a Schedule Event

- 1 [Message] window → Select Schedule events → ● (twice)



More Features

Advanced

Managing Messages

- Protect a Message
- Move Messages to a Different Folder
- Delete Messages
- Delete All Read Messages
- Delete All Delivery Reports
- Delete Attached Files
- Copy SMS Messages between Handset and USIM Card
- Delete SMS Messages on USIM Card
- Change Message Color
- Add a Folder
- Edit a Folder Name
- Change Order of Folders
- Delete a Folder
- Check Number of Saved Messages
- Check Sent/Received Addresses (S! Mail & SMS)
- Delete All Messages (S! Mail & SMS) in Tomomato-Mail Folder

▶ P. 5-25)

Using Messages

- Edit a Sent Message
- Edit & Send a Draft Message
- Forward a Message
- Save Sender, Recipient's E-mail Address or Phone Number to Phone Book
- Call a Phone Number in Text
- Send an S! Mail to an E-mail Address in Text
- Access the Internet from a URL in Text

- Save Number/Address in Text to Phone Book or Blog/Mail Member List
- Search Information by Keyword
- Switch Subject Field Views
- Change Message Font Size
- Search for Messages in a Folder
- Sort Messages
- Filter Messages
- Return Message List View to Default
- Switch All Unread Messages to Read Messages
- Open S! Mail Delivery Report
- Check Attachment Properties (Image File)

▶ P. 5-27)

Customize

Message Window/Messaging Settings

- Set Default Mail Menu
- Set Message List View
- Set Auto-Play for Melody Attachments
- Set Scroll Unit
- Set Font Size
- Check Mail Settings
- Restore to Default Settings

▶ P. 14-19)

SMS Server Settings

- Change SMS Center Address
- Reset to SoftBank SMS Center Address

▶ P. 14-19)



Sending Messages

Start Here

- [S! Mail Composition] window P. 5-6
- [S! Mail Text Entry] window P. 5-6
- [SMS Composition] window P. 5-7
- [PC Mail Composition] window P. 5-7
- [Blog/Mail Member List] P. 5-8
- [Blog/Mail Member] window P. 5-8

Composing Messages

Enter Address from Phone Book

[S! Mail Composition] window, [SMS Composition] window or [PC Mail Composition] window → **To** → ● → **Phonebook** → ● → Search Phone Book → Select Phone Book → ● → Select an e-mail address or phone number → ●

Enter Address from Sent/Received Address List (S! Mail & SMS)

[S! Mail Composition] window, [SMS Composition] window or [PC Mail Composition] window → **To** → ● → **Sent Address** or **Received Address** → ● → Select an e-mail address/phone number → ● (twice)
 Alternatively, select **To** and press to open Sent/Received Address List (S! Mail & SMS).

Enter Address from Blog/Mail Member List

[S! Mail Composition] window/[PC Mail Composition] window → **To** → ● → **Blog/Mail Member** → ● → Select a Blog/Mail Member list → ●
 All addresses in the selected Blog/Mail Member list are entered in the Address field.
 You must save addresses to a Blog/Mail Member list in advance.

Set To, Cc or Bcc

[S! Mail Composition] window/[PC Mail Composition] window → **To** → ● → Select an address → → **Change Rcv. Type** → ● → **To, Cc or Bcc** → ●

- Cc (Carbon copy): S! Mail/PC Mail copies are sent to other addresses. Addresses in the Cc field are revealed to the other recipients.
- Bcc (Blind carbon copy): S! Mail/PC Mail copies are sent to other addresses. Addresses in the Bcc field are hidden to the other recipients.
- When there is no address in the To field, the message cannot be sent.

Delete an Address

[S! Mail Composition] window/[PC Mail Composition] window → **To** → ● → Select an address → → **Delete Receiver** → ● → **YES** → ●

Insert Header/Signature

[S! Mail Composition] window/[PC Mail Composition] window → → **Add Header** or **Add Signature** → ●
 Save header/signature in advance.



Enter My Pictograms

[S! Mail Text Entry] window → Press and hold → Select a pictograph → →

- Toggle categories by pressing or .
- Available only in S! Mail.

Delete Text

[S! Mail Composition] window, [SMS Composition] window or [PC Mail Composition] window → → **Erase Message** → → **YES** →

Change SMS Message to S! Mail

[SMS Composition] window → → **S! Mail Conversion** →

Change S! Mail to PC Mail

[S! Mail Composition] window → → **PC Mail Conversion** → → **YES** →

- My Pictograms and any Graphic Mail items/settings are deleted.
- Phone numbers are deleted from the Recipient field.

Sending Messages

Change Size of S! Mail to Send

[S! Mail Composition] window → → **Compose Size** → → **300KB** or **2MB** →

Set Priority (S! Mail)

[S! Mail Composition] window → → **Priority** → → **High**, **Normal** or **Low** →

Server Storage Period (SMS)

[SMS Composition] window → → **SMS Valid. Per.** → → Select a period →

- Specify a period the SMS message is stored in the server in case it fails to reach the recipient because the recipient's handset is out of range, etc.

- When **None** is set, the SMS message is deleted from the server after it is resent once in a certain period of time.

Request Delivery Report (S! Mail/SMS)

[S! Mail Composition] window/[SMS Composition] window → → **Delivery Report** or **SMS Report Req.** → → **ON** or **OFF** →

- When **ON** is set, handset receives a delivery report.

Save Messages to Draft

[S! Mail Composition] window, [SMS Composition] window or [PC Mail Composition] window → → **Save** → → **YES** →

- The message is saved to **Draft** or **PC Mail Draft**. Messages saved in **Draft** or **PC Mail Draft** can be edited and sent at a later time.

Quit Composing and Delete Message

[S! Mail Composition] window, [SMS Composition] window or [PC Mail Composition] window → → **Delete** → → **YES** →

Attaching Files

Capture and Attach Still Image/Video

[S! Mail Composition] window/[PC Mail Composition] window → → **Activate Camera** → → **Photo Mode** or **Movie Mode** → → Shoot image/video → (→ **YES** →)



Advanced Features

Delete Files Attached to S! Mail/PC Mail

[S! Mail Composition] window/[PC Mail Composition] window → Select an attached file → → **Delete Att. File or Del All Att.Files** → ● → YES → ●

Blog/Mail Member

Edit an Address

[Blog/Mail Member] window → Select an address → → Edit address → ●

Delete Addresses from a Blog/Mail Member List

[Blog/Mail Member] window → Select an address →

- To Select *Delete this*
→ *Delete this* → ● → YES → ●
- To Select *Delete all*
→ *Delete all* → ● → Enter Security Code
→ ● → YES → ●

Edit a Blog/Mail Member List Name

[Blog/Mail Member List] → Select a Blog/Mail Member list → → **Edit Member Name** → ● → Edit name → ●

Reset a Blog/Mail Member List Name

[Blog/Mail Member List] → Select a Blog/Mail Member list → → **Reset Member Name** → ● → YES → ●

Graphic Mail

Add/Edit Text Decoration

[S! Mail Text Entry] window → → → ● → Select beginning of characters → ● → Select end of characters → ● → Select effects menu → ● →

Apply or Change effects

Available only in S! Mail.
 Select , press , select YES and then press ● to select the entire text.

Undo

[S! Mail Text Entry] window → → → ●
 Available only in S! Mail.

Preview Graphic Mail

[S! Mail Text Entry] window → → → ● → or to close preview
 Available only in S! Mail.

Cancel All Decoration

[S! Mail Text Entry] window → → → ● → YES → ● (→ ●)
 Available only in S! Mail.

Create Graphic Mail Automatically

[S! Mail Text Entry] window → Enter text → → → ● → to toggle effects → ●

Available only in S! Mail.
 Emotion of the message is detected from the entered text, and a set of effects that matches the emotion is automatically applied.
 Press to toggle insert and no insert for pictographs and emoticons.

Save Graphic Mail as a Template

[S! Mail Text Entry] window → Enter text → ● → → **Template** → ● → **Save Template** → ● → YES → ●

Available only in S! Mail.
 Attached files except images inserted in text are not included in a template.
Save up to 1,000 templates including downloads. Delete saved templates as needed.



Download Templates

→ **Templates** → ● → **Download Templates** → ● → **YES** → ● → Follow onscreen instructions

Create Graphic Mail from a Template

→ **Templates** → ● → Select a template → ● → → ● →

Edit a Template

→ **Templates** → ● → Select a template → ● → → **Edit** → ● → Edit text → ● (twice) → **YES** or **NO** → ●

Edit Title of a Template

→ **Templates** → ● → Select a template → → **Edit Title** → ● → Edit title → ●

Delete Templates

→ **Templates** → ● → Select a template → → **Delete** → ●

- To Select *Delete This*
 - **Delete This** → ● → **YES** → ●
- To Select *Delete Selected*
 - **Delete Selected** → ● → Select templates → ● → → **YES** → ●
- To Select *Delete All*
 - **Delete All** → ● → Enter Security Code → ● → **YES** → ●

Receiving/Opening Messages

Start Here

[Message List] P. 5-11
 [Message] window P. 5-11
 [Mail List] P. 5-11
 [PC Mail Message List] P. 5-12

Receiving Messages

Manually Retrieve Messages (S! Mail)

→ **Retrieve New** → ● → Received Result window opens → **Mail** → ● → Select a message → ●

- Press **Y** or press and hold **CLEAR** to cancel message retrieval.
- Retrieve messages that were stored on the server while handset was off or out of range.



Checking Messages

Retrieve Complete S! Mail/PC Mail Manually

[Message List] / [PC Mail Message List] →
 Select an S! Mail/PC Mail notification → ●
 → [☒]

- ☞ S! Mail/PC Mail notification is deleted when you retrieve the complete message.
- ☞ Manually retrieve complete messages when *Auto Receiving* is set to *Manual* (S! Mail Settings, P. 14-17).
- ☞ Manually retrieve complete messages when *Auto Receiving* or *Manual Receiving* is set to *Part* (PC Mail Settings, P. 14-18).

Delete S! Mail from Server

[Message List] → Select an S! Mail notification → ● → [☒] → **Delete** → ●
 (→ **Notification, Server Mail** or **Notifi./Server** → ●) → **YES** → ●

Read Out Messages

[Message] window → [☒] → **Read Out Message** → ●
 ☞ Available only in S! Mail/SMS.
 ☞ Press ● to stop reading.
 ☞ Press [☒] to end reading.

Check Message Information

[Message List] / [PC Mail Message List] →
 Select a message → [☒] → **Mail Info** → ●

Server Message Operations

Update Mail List

[Mail List] → [☒] → **Mail List** → ●

Switch Mail List Views

[Mail List] → [☒] → **List Setting** → ● →
Subject, Name or **Address** → ●

Check Server Message Information (S! Mail)

[Mail List] → Select a message → [☒] →
Mail Info → ●

Forward a Server Message (S! Mail)

[Mail List] → Select a message → [☒] →
Forward → ● → **To** → ● → Enter
 address → [☒]

Delete Server Messages (S! Mail)

[Mail List] → Select a message → [☒] →
Delete → ●

- To Select **Delete This**
 → **Delete This** → ● → **YES** → ●
- To Select **Delete Selected**
 → **Delete Selected** → ● → Select
 messages → ● → [☒] → **YES** → ●
- To Select **Delete All**
 → **Delete All** → ● → Enter Security Code
 → ● → **YES** → ●

Check Server Memory Status

[☒] → **Server Mail** → ● → **Server Mail
 Memory** → ●



Managing/Using Messages

Start Here

[Folder List]	P. 5-14
[Message List]	P. 5-14
[Message] window	P. 5-14
[Inbox Folder List]	P. 5-15
[Inbox Message List]	P. 5-15
[Received Message] window	P. 5-15
[Sent Message] window	P. 5-15
[Tomomato-Mail Folder List]	P. 5-16

Managing Messages

Protect a Message

[Message] window ⇨ ⇨ **Protect ON/OFF** ⇨

If a message is protected, this procedure cancels protection.

Move Messages to a Different Folder

[Message List] ⇨ Select a message ⇨ ⇨ **Move** ⇨

- To Select *Move This*
⇨ *Move This* ⇨ ⇨ Select a destination folder ⇨ ⇨ **YES** ⇨
- To Select *Move Selected*
⇨ *Move Selected* ⇨ ⇨ Select a destination folder ⇨ ⇨ Select messages ⇨ ⇨ ⇨ **YES** ⇨
- To Select *Move All*
⇨ *Move All* ⇨ ⇨ Select a destination folder ⇨ ⇨ **YES** ⇨

A message can also be moved to a different folder from Message window.

Delete Messages

[Folder List] ⇨ ⇨ **Delete All** ⇨ ⇨ Enter Security Code ⇨ ⇨ **YES** ⇨

- [Message List] ⇨ Select a message ⇨ ⇨ **Delete** ⇨
- To Select *Delete This*
⇨ *Delete This* ⇨ ⇨ **YES** ⇨
 - To Select *Delete Selected*
⇨ *Delete Selected* ⇨ ⇨ Select messages ⇨ ⇨ ⇨ **YES** ⇨
 - To Select *Delete All*
⇨ *Delete All* ⇨ ⇨ Enter Security Code ⇨ ⇨ **YES** ⇨

Protected messages cannot be deleted.

Delete All Read Messages

[Inbox Folder List] ⇨ ⇨ **Delete Read** ⇨ ⇨ **YES** ⇨

[Inbox Message List] ⇨ ⇨ **Delete** ⇨ ⇨ **Delete Read** ⇨ ⇨ **YES** ⇨

Protected messages cannot be deleted.

Delete All Delivery Reports

[Inbox Message List] ⇨ ⇨ **Delete** ⇨ ⇨ **Delete All Reports** ⇨ ⇨ Enter Security Code ⇨ ⇨ **YES** ⇨

Available only in S! Mail/SMS.

Protected delivery reports cannot be deleted.



Advanced Features

Delete Attached Files

[Message] window → Select attached files → → **Delete Att. File** or **Del All Att. Files** → → **YES** →

Copy SMS Messages between Handset and USIM Card

→ **Tools** → → **USIM Operation** → → Enter Security Code → → **Copy** → → **Phone** → **USIM** or **USIM** → **Phone** → → **SMS** → → **Inbox** or **Outbox** → → Select a folder → → Select an SMS message → → **YES** →

Delete SMS Messages on USIM Card

→ **Tools** → → **USIM Operation** → → Enter Security Code → → **Delete** → → **USIM** → → **SMS** → → **Inbox** or **Outbox** → → Select a folder → → Select an SMS message → → **YES** →

Change Message Color

[Message List] → Select a message → Press and hold → Each time you press and hold , the message color toggles as follows: Red → Blue → Default (Black)

Add a Folder

[Folder List] → → **Add Folder** → → Enter folder name → → **YES** or **NO** → (→ **Address Sort, Subject Sort, Reply Impossible, Send Impossible** or **Unregistered Add.** → → Make auto Sort settings → → **YES** or **NO** →

Edit a Folder Name

[Folder List] → Select a folder → → **Edit Folder Name** → → Edit folder name → → Preinstalled folders cannot be renamed.

Change Order of Folders

[Folder List] → Select a folder → → **Sort Folder** → → Select a position → → The order of preinstalled folders cannot be changed.

Delete a Folder

[Folder List] → Select a folder → → **Delete Folder** → → Enter Security Code → → **YES** → → Folders containing protected messages and preinstalled folders cannot be deleted. → This procedure also deletes messages stored in the folder. → Auto Sort settings are also canceled when you delete a folder with Auto Sort settings.

Check Number of Saved Messages

[Folder List]/[Message List] → → **No. of Messages** → → Check number of total, unread, protected and USIM Card SMS Messages. → Folder List: The total of all folders. → Message List: The total of the selected folder.

Check Sent/Received Addresses (S! Mail & SMS)

Press and hold or press and hold → Select an entry →

Delete All Messages (S! Mail & SMS) in Tomomato-Mail Folder

[Tomomato-Mail Folder List] → Select a folder → → **Del All in Folder** → → Enter Security Code → → **YES** →



Using Messages

Edit a Sent Message

[Sent Message] window → → Edit (account,) address, subject and text →

Edit & Send a Draft Message

(→) → **Draft or PC Mail Draft** → ●
→ Select a message → ● → Edit (account,) address, subject and text →

Forward a Message

[Received Message] window → → **Reply/Forward** → ● → **Forward** → ● (twice) → Enter address →

The subject and text can also be edited.

When forwarding an HTML message with PC Mail, decorations are deleted.

Save Sender, Recipient's E-mail Address or Phone Number to Phone Book

[Message] window → → **Address List** → ● → Select an e-mail address/phone number → → **Save Address** → ● → **YES** → ●

- To Save to Handset
→ **Phone** → ● → Select store method → ● (→ Search Phone Book → Select Phone Book → ● (twice)) → Edit items → (→ **YES** or **NO** → ●) (→ Enter entry number → ●)

- To Save to USIM Card
→ **USIM** → ● → Select store method → ● (→ Search Phone Book → Select Phone Book → ● (twice)) → Edit items → (→ **Overwrite** or **Add** → ●) (→ **YES** or **NO** → ●)

Call a Phone Number in Text

[Message] window → Select a phone number → ● → **Voice Phone** or **Video Call** → ● → **Dial** → ●

Send an S! Mail to an E-mail Address in Text

[Message] window → Select an e-mail address → ● → Compose S! Mail →

Access the Internet from a URL in Text

[Message] window → Select a URL → ● → **Yahoo! Keitai** or **PC Site Browser** → ● (→ **YES** or **NO** → ●)

Save Number/Address in Text to Phone Book or Blog/Mail Member List

[Message] window → Select an e-mail address/phone number → → **Save Address** → ● → **Phonebook** or **Blog/Mail Member** → ●

- To Save to Handset
→ **Phone** → ● → Select store method → ● (→ Search Phone Book → Select Phone Book → ● (twice)) → Edit items → (→ **YES** or **NO** → ●) (→ Enter entry number → ●)

- To Save to USIM Card
→ **USIM** → ● → Select store method → ● (→ Search Phone Book → Select Phone Book → ● (twice)) → Edit items → (→ **Overwrite** or **Add** → ●) (→ **YES** or **NO** → ●)

- To Save to Blog/Mail Member List
→ Select a Blog/Mail Member list → ● → Select an item → ● (→ **YES** → ●)



Search Information by Keyword

[Message] window → → **Quick Search** → → **Enter Keyword** → → Enter keyword → → or → → Select an item from search results →

Switch Subject Field Views

[Message List] → Press and hold → When *Mail List Disp.* is set to *2 Lines*, view toggles in the order Name → Address.
 When *Mail List Disp.* is set to *1 Line*, or to *1 Line+Body*, the view cycles as follows:
 Subject → Name → Address

Change Message Font Size

[Message] window → Press and hold

Search for Messages in a Folder

[Message List] → → **Search Mail** → → **Search Sender**, **Search Receiver** or **Search Subject** → (→ Select a search criterion →) → Select an address, enter address or subject →

Narrow down search results by repeating the search operation.
 This procedure can be combined with *Sort* or *Filter*.

Sort Messages

[Message List] → → **Sort** → → Select a criterion →

This procedure can be combined with the *Search Mail* or *Filter*.

Filter Messages

[Message List] → → **Filter** → → Select a criterion →

This procedure can be combined with *Search Mail* or *Sort*.

Return Message List View to Default

[Message List] → → **Display All** →

Switch All Unread Messages to Read Messages

[Inbox Message List] → → **Read All** → → **YES** →

Open S! Mail Delivery Report

[Sent Message] window → → **Disp. Report** →

Only available in Message window of a sent message with a requested delivery report.

Check Attachment Properties (Image File)

[Message] window → → **Property** → → Select image →